

Installation guide/Electronic part replacement (non-SIL devices only)


Liquid Level Switch

Type LLS 4000 / LLS 4000U

148R9652



Warning! This is a Class A device. This device may cause radio interference in residential areas. In case of interference, the operator may be required to take appropriate measures. This instrument has to be mounted on a metallic tank. The device is intended to be used in industrial areas.



148R9652

Fig. 1




Fig. 2

If any damage to the O-ring
replace it carefully by use of
appropriate O-ring tooling





Fig. 3



Hand-tighten
clockwise




Fig. 5

Hand-tighten clockwise until O-ring is
compressed and mechanical stop is reached
(max torque 5 Nm/3.7 lb ft)




Fig. 4




Fig. 6

	Level	LLS 4000/4000U NO mode*	LLS 4000/4000U NC mode*	Voltage connected	Level detection	LLS 4000/4000U Fault
				Green LED	Yellow LED	Red LED
High Level sensor						
High Level sensor						
Low Level sensor						
Low Level sensor						
Voltage supply outside spec.	-					
LLS 4000/4000U fault**	-					


	Green LED ON		Yellow LED ON		Red LED ON		Green LED Flashing. LLS 4000/4000U connected to Bluetooth device
--	--------------	--	---------------	--	------------	--	---

* Configuration dependent. Non-SIL2 fully configurable. SIL2 fixed configuration and only applicable for High Level sensor


** For failure types please connect the device to the Bluetooth App, enter fault state mode, and read the failure type

*** Fault can be detected at any detected level, ie. 2 or all 3 lights on


LLS Bluetooth app download



Configuration



Configuration continued




Password: 121314

In Service menu a unique password for Service menu can be entered.

- Go to menu upper right
- Go login
- Go to settings
- Go to Service Password
- Enter new Service Password

Calibration (To be performed after replacement of Electronic part and always with LLS sensor head in gas phase)





Read and apply safety instructions contained in product documentation.



Direct current.

General warnings/precautions

- Instructions in this document should only be used for electronic part replacement. For device installation refer to Installation guide/Quickstart document.
- LLS4000/U electronic part replacement is not allowed on SIL device version.
- LLS4000/U electronic part should only be used as spare part of LLS4000/U liquid level switch.
- Every use that is not described in this guide is considered incorrect and is not authorized by the manufacturer.
- If any changes regarding installation, media or operating conditions of the device have been done then refer to Installation guide/Quickstart document and verify respect of specified values.
- All service and maintenance operations must be performed by qualified personnel.
- Installation must comply with local standards and legislation.
- Before carrying out any maintenance operations on the device, disconnect the device from the main power supply.
- Before unscrewing the LLS device from the pipe or tank ensure that pipe or tank is empty and not under pressure.
- Liability for injury or damage caused by incorrect use of the device lies solely with the user.
- Depending on the application, the metallic part of the instrument may be hot or cold.
- If media detection or non-detection by the level switch could generate a hazard the SIL version and specific instructions described in the safety manual (periodic proof test) should be used. The SIL safety manual can be downloaded from Danfoss web site or by scanning the QR code below.

For further documents (Installation guide, Data sheet, etc.) scan this QR code:



Danfoss A/S, 6430 Nordborg, Denmark
www.danfoss.com

