

INSTALLATION MANUAL AIR **CONDITIONER**

Please read this installation manual completely before installing the product. Installation work must be performed in accordance with the national wiring standards by authorized personnel only.

Please retain this installation manual for future reference after reading it thoroughly.

Standard inverter Original instruction

[Representative] LG Electronics Inc. EU Representative : LG Electronics European Shared Service Center B.V. Krijgsman 1, 1186 DM Amstelveen, The Netherlands [Manufacturer] LG Electronics Inc. Changwon 2nd factory 84, Wanam-ro, Seongsangu, Changwon-si, Gyeongsangnam-do, KOREA

For more information, Refer to the CD or LG Web site (www.lg.com).



P/NO: MFL67855411

CONTENTS

3
7
11
14
18
20
22
23
24

Safety Precautions

To prevent the injury of the user or other people and property damage, the following instructions must be followed.

Be sure to read before installing the air conditioner.

dust, water, etc.

- Be sure to observe the cautions specified here as they include important items related to safety.
- Incorrect operation due to ignoring instruction will cause harm or damage. The seriousness is classified by the following indications.

WARNING
 This symbol indicates the possibility of death or serious injury.
 This symbol indicates the possibility of injury or damage to properties only.

The meanings of the symbols used in this manual are as shown below.

\bigcirc	Be sure not to do.
	Be sure to follow the instruction.

Installation ———		
Always perform grounding.	Don't use a power cord, a plug or a loose socket which is dam- aged.	For installation of the product, always con- tact the service center or a professional instal- lation agency.
Otherwise, it may cause electrical shock.	 Otherwise, it may cause a fire or electrical shock. 	• Otherwise, it may cause a fire, electrical shock, explosion or injury.
Securely attach the electrical part cover to the indoor unit and the service panel to the outdoor unit.	Always install an air leakage breaker and a dedicated switching board.	Do not keep or use flammable gases or combustibles near the air conditioner.
 If the electrical part cover of the indoor unit and the service panel of the outdoor unit are not attached securely, it could result in a fire or electric shock due to 	 No installation may cause a fire and electri- cal shock. 	Otherwise, it may cause a fire or the failure of product.

Ensure that an installa- tion frame of the out- door unit is not dam- aged due to use for a long time.	Do not disassemble or repair the product ran- domly.		Do not install the prod- uct at a place that there is concern of falling down.
 It may cause injury or an accident. 	 It will cause electrical sh 		 Otherwise, it may result in personal injury.
Use caution when unpacking and installing.		gen) gas w air purge. I Oxygen and	um pump or Inert (nitro- hen doing leakage test or Do not compress air or d do not use Flammable erwise, it may cause fire n.
 Sharp edges may cause injury. 		There is the explosion.	e risk of death, injury, fire or

Operation —

Do not share the out- let with other appli- ances.	Do not use the dam- aged power cord.	Do not modify or extend the power cord randomly.
• It will cause an electric shock or a fire due to heat generation.	 Otherwise, it may cause a fire or electri- cal shock. 	 Otherwise, it may cause a fire or electri- cal shock.
Take care so that the power cord may not be pulled during oper- ation.	Unplug the unit if strange sounds, smell, or smoke comes from it.	Keep the flames away.

ENGLISH

Take the power plug out if necessary, hold- ing the head of the plug and do not touch it with wet hands.	Do not use the power cord near the heating tools.	Do not open the suc- tion inlet of the indoor/outdoor unit during operation.
 Otherwise, it may cause a fire or electri- cal shock. 	• Otherwise, it may cause a fire and electrical shock.	 Otherwise, it may elec- trical shock and failure.
Do not allow water to run into electrical parts.	Hold the plug by the head when taking it out.	Never touch the metal parts of the unit when removing the filter.
Otherwise, it may cause the failure of machine or electrical shock.	 It may cause electric shock and damage. 	 They are sharp and may cause injury.
Do not step on the indoor/outdoor unit and do not put any- thing on it.	Do not place a heavy object on the power cord.	When the product is submerged into water, always contact the service center.
• It may cause an injury through dropping of the unit or falling down.	 Otherwise, it may cause a fire or electri- cal shock. 	 Otherwise, it may cause a fire or electri- cal shock.

Take care so that children may not step on the outdoor unit.

• Otherwise, children may be seriously injured due to falling down.

l In	stal	lati	on -
------	------	------	------

Install the drain hose to ensure that drain can be securely done.

Otherwise, it may cause water leakage.

Install the product so that the noise or hot wind from the outdoor unit may not cause any damage to the neighbors.

• Otherwise, it may cause dispute with the neighbors.

Always inspect gas leakage after the installation and repair of product.

• Otherwise, it may cause the failure of product.

Keep level parallel in installing the product.

- Otherwise, it may cause vibration or water leakage.
- the product.If the strength is not sufficient, the product may fall and cause injury.

Please install safely at a place that can sufficiently endure the weight of

Operation

Avoid excessive cool- ing and perform venti- lation sometimes.	Use a soft cloth to clean. Do not use wax, thinner, or a strong detergent.	Do not use an appli- ance for special pur- poses such as preserv- ing animals vegetables, precision machine, or art articles.
 Otherwise, it may do harm to your health. 	• The appearance of the air conditioner may deteriorate, change color, or develop surface flaws.	 Otherwise, it may dam- age your properties.

Do not place obstacles around the flow inlet or outlet.

· Otherwise, it may cause the failure of appliance or an accident.


Installation of Outdoor Unit

You need to select adequate installation location considering the following conditions, and make sure to acquire the consent of the user.

1. Installation Places

- If an awning is built over the unit to prevent direct sunlight or rain exposure, make sure that heat radiation from the condenser is not restricted.
- Ensure that the spaces indicated by arrows around front, back and side of the unit.
- Do not place animals and plants in the path of the warm air.
- Take the air conditioner weight into account and select a place where noise and vibration are minimum.
- Select a place so that the warm air and noise from the air conditioner do not disturb neighbors.
- Place that can sufficiently endure the weight and vibration of the outdoor unit and where even installation is possible

- · Place that has no direct influence of snow or rain
- Place with no danger of snowfall or icicle drop
- Place without weak floor or base such as decrepit
 part of the building or with a lot of snow accumulation




2. Piping length and the elevation

Single Operation

Model	Capacity Pipe mm(Size Length A		ח A(m)	Elevatio	on B(m)	Additional refrigerant
		Gas	Liquid	Standard	Max.	Standard	Max.	(g/m)
UU18W	5kW	Ø12.7(1/2)	Ø6.35(1/4)	7.5	40	5	30	20
UU24W	7kW	Ø15.88(5/8)	Ø9.52(3/8)	7.5	50	5	30	40
UU30W	8kW	Ø15.88(5/8)	Ø9.52(3/8)	7.5	50	5	30	40
UU36W/UU37W	10kW	Ø15.88(5/8)	Ø9.52(3/8)	7.5	50	5	30	40
UU42W/UU43W	12.5kW	Ø15.88(5/8)	Ø9.52(3/8)	7.5	75	5	30	40
UU48W/UU49W	14kW	Ø15.88(5/8)	Ø9.52(3/8)	7.5	75	5	30	40
UU60W/UU61W	15kW	Ø15.88(5/8)	Ø9.52(3/8)	7.5	75	5	30	40

If installed tube is shorter than 7.5 m, additional charging is not necessary. Additional Refrigerant = $(A - 7.5) \times Additional refrigerant (g)$



Synchro Operation

Install the branch pipe so that pipe length and difference between high and low will not exceed below Spec.

L2	Branch		[Unit : m]
L3		Pipe Length & Height	Spec(MAX.)
	A	Total(L1+L2+L3+L4+L5)	80
L		Main Pipe(L1)	45
H1	5	Branch Pipe (L2+L3+L4+L5)	40
		Each	15
		Indoor-Outdoor (H1)	30
	77 Controller	Indoor-Indoor (H2)	1
		(L1+L2),(L1+L3),(L1+L4),(L1+L5)	70
	— L1	A	10
VS BOR			

- When installing the branch pipe, direction and angle of installation is not limited.
- Take care so that burrs and foreign material may not enter into the cutting surface when connecting.
- · Connect remaining those by cutting or direct insertion to the diameter of pipe.

Refrigerant Additional Charging Method

For additional charging method, see below table.

Indoor Unit	Refrigerant Additional charging (g)	Pipe Size mm(inch)	C (g/m)
Duo	Refrigerant = (L1-b) x B + (L2 + L3) x C	<u> </u>	,
Trio	Refrigerant = (L1-b) x B + (L2 + L3 + L4) x C	Ø6.35(1/4)	35
Quartet	Refrigerant = (L1-b) x B + (L2 + L3 + L4 + L5) x C	Ø9.52(3/8)	40

Model	b (m)	B (g/m)
UU42W/UU43W UU48W/UU49W UU60W/UU61W	7.5	40

NOTICE

- b : Rated performance for refrigerant line length.
- C : Additional charging Refrigerant of Branch Liquid Pipe.
- B : Additional charging Refrigerant of Main Liquid Pipe.



CAUTION:

- Capacity is based on standard length and maximum allowance length is on the basis of reliability.
 - · Improper refrigerant charge may result in abnormal cycle.

3. Synchro Combination table

		Possible combination of indoor units								
			Synchro							
			Duo		Trio		Quartet			
ODU : O BD : BR/ DIS REMO : 1	DU : INDOOR UNIT DDU : OUTDOOR UNIT DD : BRANACH DISTRIBUTOR UNIT REMO : WIRED REMOTE CONTROLLER		IDU REMO							
MODEL		Cas- sette	Duct	Ceiling Suspended	Cas- sette	Duct	Ceiling Suspended	Cas- sette	Duct	Ceiling Suspended
UU42W/UU43W		CT24 NP2*2	CB24 NH2*2	CV24 NJ2*2	CT18 NQ2*3	CB18 NH2*3	CV18 NJ2*3	CT12 NR2*4		-
UU48W/UU49W		CT24 NP2*2	CB24 NH2*2	CV24 NJ2*2	CT18 NQ2*3	CB18 NH2*3	CV18 NJ2*3	CT12 NR2*4		•
UU60W/UU61W		UT30 NP2*2	UB30 NG2*2	UV30 NJ2*2	CT18 NQ2*3	CB18 NH2*3	CV18 NJ2*3	CT12 NR2*4		•
Applied	Bdunit	PMUB11A		PMUB111A		PMUB1111A				
Acces- siries	Simple central controller**	PQCSZ250S0								

NOTICE

** When using synchro operation,


- Do not use wireless remote controller.
- Use only one wired remote controller in the indoor units.
- Use Simple central controller "PQCSZ250S0" only.

4. Outdoor Unit PCB Setting Procedure For Simultaneous Operation System

- 1. SW01N (PIP SW2) Setting Set the SW01N (PIP SW2) as below Table (A)
- 2. Auto Addressing Method

Addressing work assigns address to each indoor unit. When firstly installing product or replacing the indoor unit PCB. Auto Addressing work should be done for simultaneous operation.

- Work procedure
- 1) Set SW01N (PIP SW2) correctly.
- 2) Turn on main power.
- 3) Press the SW02N (SW01B) for about 3 seconds within 3 minutes After main power on.(B)



Installation of Outdoor Unit

- 4) After step 3), the LED01M/G (red LED) and LED02M/G (green LED) rapidly flickers. When Addressing work is done, green LED is off, else LED (LED01M/G) stops flickering and lights continuously. Address of indoor unit is indicated on the wired remote control display window. (CH01, CH02, CH03, CH04)
- 5) Press (1) button to turn on the indoor.
- 6) If you fail to perform the Addressing work, repeat step 2)~5).


Table SW01N (PIP SW2) Setting			
SW01N (PIP SW2)	Indoor Unit No.		
	1(Single) : Default		
	2(Duo)		
	3(Trio)		
	4(Quartet)		

Night Silent Operation setting

- 1. Open the Side panel or Top Cover of outdoor unit.
- 2. Set the SW01N (PIP SW2).

ҬҬӏҬ	<u>׀</u> ֛֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֢֕֕֕֕	ĨĻĻĻŢ
UU18W	UU36W	UU37W
UU24W	UU42W	UU43W
UU30W	UU48W	UU49W
	UU60W	UU61W

3. Close the Side panel or Top Cover.




Wiring Connection

Electrical Wiring

Perform the electrical wiring work according to the electrical wiring connection.


- · All wiring must comply with local requirements.
- Select a power source that is capable of supplying the current required by the air conditioner.
- Use a recognized ELCB(Electric Leakage Circuit Breaker) between the power source and the unit. A disconnection device to adequately disconnect all supply lines must be fitted.
- Model of circuit breaker recommended by authorized personnel only


Model	Phase(Ø)	ELCB
UU18W	1	20A
UU24W	1	30A
UU30W	1	30A
UU36W	1	40A
UU42W/UU48W/UU60W	1	40A
UU37W	3	20A
UU43W/UU49W/UU61W	3	20A




Connecting Cables between Indoor Unit and Outdoor Unit

- · Connect the wires to the terminals on the control board individually according to the outdoor unit connection.
- Ensure that the color of the wires of outdoor unit and the terminal No. are the same as those of indoor unit respectively








Precautions when laying power wiring

Use round pressure terminals for connections to the power terminal block.



When none are available, follow the instructions below.

- Do not connect wiring of different thicknesses to the power terminal block. (Slack in the power wiring may cause abnormal heat.)
- When connecting wiring which is the same thickness, do as shown in the figure below.








- For wiring, use the designated power wire and connect firmly, then secure to prevent outside pressure being exerted on the terminal block.
- Use an appropriate screwdriver for tightening the terinal screws. A screwdriver with a small head will strip the head and make proper tighterning impossible.
- · Over-tightening the terminal screws may break them.

Connecting the cable to Outdoor Unit

- Remove the side panel for wiring connection.
- · Use the cord clamp to fix the cord.
- Earthing work
 - Connect the cable of diameter more to the earthing terminal provided in the control box and do earthing.





CAUTION:

- The circuit diagram is not subject to change without notice.
- $\boldsymbol{\cdot}$ Be sure to connect wires according to the wiring diagram.
- Connect the wires firmly, so that not to be pulled out easily.
- · Connect the wires according to color codes by referring the wiring diagram.



CAUTION:

• The Power cord connected to the unit should be selected according to the following specifications.

Connecting Pipes

Preparation of Piping

Main cause of gas leakage is defect in flaring work. Carry out correct flaring work in the following procedure.

Cut the pipes and the cable.

- Use the accessory piping kit or the pipes purchased locally.
- Measure the distance between the indoor and the outdoor unit.
- Cut the pipes a little longer than measured distance.
- Cut the cable 1.5m longer than the pipe length.

Burrs removal

- Completely remove all burrs from the cut cross section of pipe/tube.
- Put the end of the copper tube/pipe to downward direction as you remove burrs in order to avoid to let burrs drop in the tubing.

Putting nut on

 Remove flare nuts attached to indoor and outdoor units, than put them on pipe/tube having completed burr removal.
 (Not possible to put them on after flaring work)

Flaring work


 Carry out flaring work using dedicated flaring tool for R-410A as shown below.


Outside	"A"	
mm	inch	mm
Ø6.35	1/4	1.1~1.3
Ø9.52	3/8	1.5~1.7
Ø12.7	1/2	1.6~1.8
Ø15.88	5/8	1.6~1.8


Firmly hold copper tube in a bar(or die) as indicated dimension in the table above.


Check


- · Compare the flared work with figure below.
- If flare is noted to be defective, cut off the flared section and do flaring work again.













Connecting the pipes to the Outdoor unit

- Align the center of the piping and sufficiently tighten the flare nut by hand.
- Finally, tighten the flare nut with torque wrench until the wrench clicks.
 - When tightening the flare nut with torque wrench, ensure the direction for tightening follows the arrow on the wrench.

Outside	Torque	
mm	mm inch	
Ø6.35	1/4	16±2
Ø9.52	3/8	38±4
Ø12.7	1/2	55±6
Ø15.88	5/8	75±7




* When tighten the pipe, hold the haxagonal body.



Connecting Pipes

• When connecting in a downward direction, knock out the knock-out hole of the base pan. (refer to figure 2)



Preventing foreign objects from entering (Figure3)

• Plug the pipe through-holes with putty or insulation material(procured locally)to stop up all gaps,as shown in the figure 3.



CAUTION:

Insects or small animals entering the outdoor unit may cause a short circuit in the electrical box.

ENGLISH

Forming the piping

Form the piping by wrapping the connecting portion of the indoor unit with insulation material and secure it with two kinds of vinyl tape.


• If you want to connect an additional drain hose, the end of the drain outlet should be routed above the ground. Secure the drain hose appropriately.

In cases where the outdoor unit is installed below the indoor unit perform the following.

- 1. Tape the piping, drain hose and connecting cable from down to up.
- 2. Secure the tapped piping along the exterior wall using saddle or equivalent.

In cases where the outdoor unit is installed above the indoor unit perform the following.

- 1. Tape the piping and connecting cable from down to up.
- Secure the taped piping along the exterior wall. Form a trap to prevent water entering the room.
- 3. Fix the piping onto the wall by saddle or equivalent.



Seal a small opening around the pipings with gum type sealant.

Leakage test and Evacuation

Air and moisture remaining in the refrigerant system have undesirable effects as indicated below.

- 1. Pressure in the system rises.
- 2. Operating current rises.
- 3. Cooling(or heating) efficiency drops.
- 4. Moisture in the refrigerant circuit may freeze and block capillary tubing.
- 5. Water may lead to corrosion of parts in the refrigeration system.

Therefore, the indoor/outdoor unit and connecting tube must be checked for leak tight, and vacuumed to remove incondensible gas and moisture in the system.

Preparation

Check that each tube(both liquid and gas side tubes) between the indoor and outdoor units have been
properly connected and all wiring for the test run has been completed. Remove the service valve caps
from both the gas and the liquid side on the outdoor unit. Check that both the liquid and the gas side service valves on the outdoor unit are kept closed at this stage.

Leakage test


 Connect the manifold valve(with pressure gauges) and dry nitrogen gas cylinder to this service port with charge hoses.

CAUTION: Be sure to use a manifold valve for leakage test. If it is not available, use a stop valve for this purpose. The "Hi" knob of the manifold valve must always be kept close.

• Pressurize the system to no more than 3.8 Mpa with dry nitrogen gas and close the cylinder valve when the gauge reading reached 3.8 MPa Next, test for leaks with liquid soap.

CAUTION: To avoid nitrogen entering the refrigerant system in a liquid state, the top of the cylinder must be higher than its bottom when you pressurize the system. Usually, the cylinder is used in a vertical standing position.

 Do a leakage test of all joints of the tubing(both Indoor unit and outdoor unit) and both gas and liquid side service valves. Bubbles indicate a leak. Be sure to wipe off the soap with a clean cloth. 2. After the system is found to be free of leaks, relieve the nitrogen pressure by loosening the charge hose connector at the nitrogen cylinder. When the system pressure is reduced to normal, disconnect the hose from the cylinder.



Evacuation

1. Connect the charge hose end described in the preceding steps to the vacuum pump to evacuate the tubing and indoor unit.

Confirm the "Lo and Hi" knob of the manifold valve is open. Then, run the vacuum pump.

The operation time for evacuation varies with tubing length and capacity of the pump. The following table shows the time required for evacuation.


Required time for evacuation when 30 gal/h vacuum pump is used		
If tubing length is less than 10 m(33 ft)	If tubing length is longer than 10 m(33 ft)	
30 min. or more	60 min. or more	
0.07 kPa or less		

2. When the desired vacuum is reached, close the "Lo and Hi" knob of the manifold valve and stop the vacuum pump.

Finishing the job

- 1. With a service valve wrench, turn the valve stem of liquid side valve counter-clockwise to fully open the valve.
- 2. Turn the valve stem of gas side valve counterclockwise to fully open the valve.
- Loosen the charge hose connected to the gas side service port slightly to release the pressure, then remove the hose.
- 4. Replace the flare nut and its bonnet on the gas side service port and fasten the flare nut securely with an adjustable wrench. This process is very important to prevent leakage from the system.
- 5. Replace the valve caps at both gas and liquid side service valves and fasten them tight.

This completes air purging with a vacuum pump. The air conditioner is now ready to test run.



Test running

1. PRECAUTIONS IN TEST RUNNING

• The initial power supply must provide at least 90% of the rated voltage. Otherwise, the air conditioner should not be operated.



CAUTION ^① For test run, carry out the cooling operation firstly even during heating season. If heating operation is carried out firstly, it leads to the trouble of compressor. Then attention must be paid.

② Carry out the test run more than 5 minutes without fail. (Test run will be cancelled 18 minutes later automatically)

- The test run is started by pressing the room temperature checking button and down timer button for 3 seconds at the same time.
- To cancel the test run, press any button.

CHECK THE FOLLOWING ITEMS WHEN INSTALLATION IS COMPLETE

- · After completing work, be sure to measure and record trial run properties, and store measured data, etc.
- · Measuring items are room temperature, outside temperature, suction temperature, blow out temperature, wind velocity, wind volume, voltage, current, presence of abnormal vibration and noise, operating pressure, piping temperature, compressive pressure.
- As to the structure and appearance, check following items.

□ Is the circulation of air adequate?

- □ Is the draining smooth?
- □ Is the heat insulation complete (refrigerant and drain piping)?
- □ Is there any leakage of refrigerant?

□ Is the remote controller switch operated?

□ Is there any faulty wiring?

□ Are not terminal screws loosened?


M4.....118N·cm{12kqf·cm} M5.....196N·cm{20kgf·cm} M6......245N·cm{25kgf·cm} M8......588N·cm{60kgf·cm}

2. Connection of power supply

- 1. Connect the power supply cord to the independent power supply. · Circuit breaker is required.
- 2. Operate the unit for fifteen minutes or more.

3. Evaluation of the performance

- 1. Measure the temperature of the intake and discharge air.
- 2. Ensure the difference between the intake temperature and the discharge one is more than 8°C (Cooling) or reversely (Heating).




ENGLISH

CAUTION: After the confirmation of the above conditions, prepare the wiring as follows:

- 1) Never fail to have an individual power specialized for the air conditioner. As for the method of wiring, be guided by the circuit diagram pasted on the inside of control box cover.
- 2) Provide a circuit breaker switch between power source and the unit.
- 3) The screw which fasten the wiring in the casing of electrical fittings are liable to come loose from vibrations to which the unit is subjected during the course of transportation. Check them and make sure that they are all tightly fastened. (If they are loose, it could give rise to burn-out of the wires.)
- 4) Specification of power source
- 5) Confirm that electrical capacity is sufficient.
- 6) Be sure that the starting voltage is maintained at more than 90 percent of the rated voltage marked on the name plate.
- 7) Confirm that the cable thickness is as specified in the power sources specification.

(Particularly note the relation between cable length and thickness.)

- 8) Never fail to equip a leakage breaker where it is wet or moist.
- 9) The following troubles would be caused by voltage drop-down.
 Vibration of a magnetic switch, damage on the contact point there of fuse breaking, disturbance to the normal function of a overload protection device.
 - Proper starting power is not given to the compressor.
- 10) Use only 1 remote-controller contained in indoor unit, when using simultaneous operation system as shown below.After setting the ESP value in the Ceiling Concealed Duct Type Indoor Unit, the main power turns off and then remove the remote controller.
- 11) It is possible to connect (install) same type of indoor units only and also with in a single room.



HAND OVER

Teach the customer the operation and maintenance procedures, using the operation manual (air filter cleaning, temperature control, etc.).


Function

Forced Cooling Operation

· Adding the refrigerant in winter.

Setting Procedure


1) Set the Dip Switch as follow after shutting the power source down.



- 2) Reset the power.
- 3) Red LED and Green LED of PCB lights during work. (The indoor unit is operated by force.)
- 4) If operation is done, Red LED will be turned off. If operation is not done normally, Red LED will blink.
- 5) Close the Liquid valve only after green LED turned off (7 minutes from the start of the machine). Then close the gas valve after Green LED on.


WARNING:

- When the green LED of PCB is on, compressor is going to be off because of low pressure.
- You should return the Dip Switch to operate normally after finishing the operation.
- Improper Pump down will lead to product turn off along with LED (green &red) off with in 20 minutes from the initial start.



Self-diagnosis Function

Error Indicator (Outd<u>oor)</u>



Outdoor Error Ex) Error 21 (DC Peack)







UU18W/24W/30W

UU36W/42W/48W/60W

UU37W/43W/49W/61W

Error Code	Description	LED 1 (Red)	LED 2 (Green)	Indoor status
21	DC Peak(IPM Fault)	2times ()	1time ()	OFF
22	Max. CT(CT2)	2times ()	2times ()	OFF
23	DC Link Low Volt.	2times ()	3times ()	OFF
24	Pressure switch/Heater Sink.	2times ()	4times ()	OFF
26	DC Comp Position Error	2times ()	6times ()	OFF
27	PFC Fault Error	2times ()	7times ()	OFF
29	Comp Over Current	2times ()	9times ()	OFF
32	D-Pipe High(Inv.)	3times ()	2times ()	OFF
40	CT Sensor(Open/Short)	4times ()	0	OFF
41	Inv. D-Pipe Th Error(Open/Short)	4times ()	1time ()	OFF
43	High Pressure Sensor(Open/Short)	4times ()	3times ()	OFF
44	Outdoor air Th Error(Open/Short)	4times ()	4times ()	OFF
45	Cond. Middle Pipe Th Error(Open/Short)	4times ()	5times ()	OFF
46	Suction Pipe Th Error(Open/Short)	4times ()	6times ()	OFF
48	Cond. Out-Pipe Th Error(Open/Short)	4times ()	8time ()	OFF
51	Capacity over	5times ()	1times ()	OFF
53	Communication Error(Indoor ↔ Outdoor)	5times ()	3times ()	OFF
60	EEPROM Error(Outdoor)	6times ()	0	OFF
61	Cond. Middle Pipe High	6times ()	1times ()	OFF
62	Heatsink Error(High)	6times ()	2times ()	OFF
65	Heatsink Th Error(Open/Short)	6times ()	5times ()	OFF
67	BLDC motor fan lock(Outdoor)	6times ()	7times 🕕	OFF

If abnormal voltage is supplied, the protection circuits will turn off the product in order to prevent the component damage. The product will automatically restart after 3 minutes.

Installation Guide at the Seaside




CAUTION:


- 1. Air conditioners should not be installed in areas where corrosive gases, such as acid or alkaline gas, are produced.
- Do not install the product where it could be exposed to sea wind (salty wind) directly. It can result corrosion on the product. Corrosion, particularly on the condenser and evaporator fins, could cause product malfunction or inefficient performance.
- 3. If outdoor unit is installed close to the seaside, it should avoid direct exposure to the sea wind. Otherwise it needs additional anticorrosion treatment on the heat exchanger.

Selecting the location(Outdoor Unit)

1) If the outdoor unit is to be installed close to the seaside, direct exposure to the sea wind should be avoided. Install the outdoor unit on the opposite side of the sea wind direction.



2) In case, to install the outdoor unit on the seaside, set up a windbreak not to be exposed to the sea wind.



- It should be strong enough like concrete to prevent the sea wind from the sea.
- The height and width should be more than 150% of the outdoor unit.
- It should be keep more than 70 cm of space between outdoor unit and the windbreak for easy air flow.

3) Place with fluent water draining

• Install at a place with fluent water draining to prevent damage from localized heavy rain and avoid frequent flooded area.

Periodic (more than once/year) cleaning of the dust or salt particles stuck on the heat exchanger by using water

Installation Manual 25

ENGLISH

Model Designation

U U 24 W U 4 2	Serial Number Chassis name Indoor / Outdoor Detailed product type W : Inverter outdoor WH : High COP Inverter outdoor H : High COP Inverter outdoor H : Low static Nominal Capacity EX) 9,000 Btu/h Class \rightarrow '09' 24,000 Btu/h Class \rightarrow '24'
	Type U : Outdoor units V : Floor-ceiling T : Cassette Q : Console B : Duct P : Floor standing
L	Model Type U : Universal model C : Common Indoor unit for Universal and Multi

Airborne Noise Emission

The A-weighted sound pressure emitted by this product is below 70 dB.

** The noise level can vary depending on the site.

The figures quoted are emission level and are not necessarily safe working levels. Whilst there is a correlation between the emission and exposure levels, this cannot be used reliably to determine whether or not further precautions are required. Factor that influence the actual level of exposure of the workforce include the characteristics of the work room and the other sources of noise, i.e. the number of equipment and other adjacent processes and the length of time for which an operator exposed to the noise. Also, the permissible exposure level can vary from country to country. This information, however, will enable the user of the equipment to make a better evaluation of the hazard and risk.

Limiting concentration

Limiting concentration is the limit of Freon gas concentration where immediate measures can be taken without hurting human body when refrigerant leaks in the air. The limiting concentration shall be described in the unit of kg/m³ (Freon gas weight per unit air volume) for facilitating calculation

Limiting concentration: 0.44kg/m³(R410A)

Calculate refrigerant concentration

Refrigerant concentration =

Total amount of replenished refrigerant in refrigerant facility (kg) Capacity of smallest room where indoor unit is installed (m³)

