
Service Manual Air-to-Water Heatpump

Indoor Unit WH-CME8

Outdoor Unit WH-WXG09ME8 WH-WXG12ME8 WH-WXG16ME8

> Destination Europe



This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the products dealt with in this service information by anyone else could result in serious injury or death.

IMPORTANT SAFETY NOTICE =

There are special components used in this equipment which are important for safety. These parts are marked by Δ in the Schematic Diagrams, Circuit Board Diagrams, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.

PRECAUTION OF LOW TEMPERATURE

In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigerant circuit.

R290

REFRIGERANT

This AIR-TO-WATER HEATPUMP contains and operates with refrigerant R290. THIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED BY QUALIFIED PERSONNEL Refer to National, State, Territory and local legislation, regulations, codes, installation & operation manuals, before the installation, maintenance and/or service of this product.



© Panasonic Corporation 2024.

TABLE OF CONTENTS

1.	Saf	ety Precautions	4
2.	Pre	cautions for Use of R290 Refrigerant	7
3.	Spe	ecifications	12
3	.1 .2 .3	WH-CME8 WH-WXG09ME8 WH-CME8 WH-WXG12ME8 WH-CME8 WH-WXG16ME8	15
4.	Fea	atures	21
5.	Loc	cation of Controls and Components	22
•	.1 .2	Indoor Unit Outdoor Unit	
6.	Din	nensions	55
•	.1 .2	Indoor Unit Outdoor Unit	
7.	Ref	frigeration and Water Cycle Diagram	57
8.	Blo	ock Diagram	58
9.	Wir	ring Connection Diagram	59
•	.1 .2	Indoor Unit Outdoor Unit	
10.	Ele	ctronic Circuit Diagram	61
-	0.1 0.2	Indoor Unit Outdoor Unit	
11.	Pri	nted Circuit Board	63
	1.1 1.2	Indoor Unit Outdoor Unit	
12.	Inst	tallation Instruction	68
1 1 1 1		Appendix Service and Maintenance	82 106 107 124
13.		tallation and Servicing Air-to-Water usin 90	
1 1 1	3.2 3.3 3.4	About R290 Refrigerant Characteristics of R290 Refrigerant Refrigerant piping installation • Tools used services New installation, and Repairing of Refriger Cycle System Procedures	139 in 141 ant 145
1	3.5	Servicing	146
14.	Ор	eration and Control	148
1 1 1 1 1	4.3 4.4 4.5 4.6 4.7	Basic Function	159 162 164 164 164 165
	4.8 4.9	Indoor Back-Up Heater Control Base Pan Heater Control (Optional)	

14.11 14.12 14.13	PForce Heater Mode Powerful Operation Quiet Operation Sterilization Mode DHW Circulation Pipe Sterilization Operat	168 168 169
	Outdoor Ambient Thermo OFF Control Alternative Outdoor Ambient Sensor Cont	170 rol
14.18 14.19 14.20 14.21	Force DHW Mode SMART DHW Mode Anti Freeze Control Solar Operation (Optional) Boiler Bivalent Control External Room Thermostat Control (Optio	171 171 172 173 174 nal)
14.24 14.25 14.26	Three Ways Valve Control Two Ways Valve Control Anti-Stick Mode Operation External OFF/ON Control External Compressor Switch (Optional PC	178 178 179 180 (B)
14.29 14.30 14.31 14.32	B Heat/Cool Switch (Optional PCB) DSG Ready Control (Optional PCB) Demand Control (Optional PCB) Holiday Mode Dry Concrete Flow Sensor	181 182 184 185 185
15. Pro	tection Control	186
15.1 15.2	5 1	
15.3	Protection Control for Cooling Operation	
16. Ser	vicing Mode	190
16.2	Open the Front Cover Test Run Expansion Vessel Pre Pressure Checking	190
16.4 16.5	How to Unlock Cool Mode	191
16.6	Procedure Dry Concrete Setup	
17. Mai	intenance Guide	195
17.1 17.2	Service and Maintenance Specifications	
18. Tro	ubleshooting Guide	199
18.1 18.2	o , , ,	Air- Inits
18.4	Breakdown Self Diagnosis Function Error Codes Table Self-Diagnosis Method	201 203

19. Dis	assembly and Assembly Instructions.	262
	Indoor Unit Outdoor Unit	
20. Teo	chnical Data	267
20.2	Operation Characteristics Heating Capacity Table Cooling Capacity Table	279
21. Exj 	bloded View and Replacement Parts Li	
	Indoor Unit Outdoor Unit	

1. Safety Precautions

- Read the following "SAFETY PRECAUTIONS" carefully before installation of Air-To-Water Heat Pump Indoor Unit.
- This AIR-TO-WATER HEAT PUMP INDOOR UNIT operates in combination with an outdoor unit containing refrigerant R290. This product and the outdoor unit must only be installed or serviced by qualified personnel. Refer to National, State, Territory and local legislation, regulations, codes, installation & operation manuals, before the installation, maintenance and/or service of these products.
- Electrical works and water installation works must be done by licensed electrician and licensed water system installer respectively. Be sure to use the correct rating and main circuit for the model to be installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below. Incorrect installation due to ignorance or negligence of the instructions may cause harm or damage, and the seriousness is classified by the following indications.

This indication shows the possibility of causing death or serious injury.
This indication shows the possibility of causing injury or damage to properties only.

The items to be followed are classified by the symbols:

\bigcirc	Symbols with white background indicate prohibited items.
00	Symbols with dark background must be executed.

- Carry out test run to confirm that no abnormality occurs after the installation. Then explain to the user how to operate, care and maintain the product as described in the operating instructions.
- This installation manual should be handed over with the unit after installation.
- Please remind the customer to keep the installation manual for future reference.
- If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.

1.	Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. Any unfit method or using incompatible material may cause product damage, burst and serious injury.	\oslash
2.	Do not install outdoor unit near balcony railings. If the outdoor unit is installed on the balcony of a high-rise building, small children may climb onto the outdoor unit and climb over the railing, which may lead to an accident.	\bigcirc
3.	Do not use unspecified, modified, jointed or extension cable for power supply cable. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current may cause electrical shock or fire.	\oslash
4.	Do not use unspecified cable or joint cable for power supply cable. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire.	\bigotimes
5.	Do not tie up the power supply cable into a bundle by band. Abnormal temperature rise on power supply cable may happen.	\bigcirc
6.	Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury.	\oslash
7.	Do not sit on or step on the unit, you may fall down accidentally.	\oslash
8.	Do not purchase unauthorized electrical parts for installation, service, maintenance and etc They might cause electrical shock or fire.	\oslash
9.	Do not modify wires of Outdoor Unit for installation of other components (such as heaters). Overloading of wires or wire connection points may cause electrical shock or fire.	\oslash
10.	Do not pierce or burn as the appliance is pressurized. Do not expose the appliance to heat, flame, sparks, or other sources of ignition. Else, it may explode and cause injury or death.	\oslash
11.	Do not pierce or burn as the appliance is pressurized. Do not expose the appliance to heat above 360°C, flame, sparks, or other sources of ignition. Else, it may explode and cause injury or death.	\oslash
12.	Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury etc.	\oslash
13.	Do not place containers of liquid on top of the indoor unit. Leakage or spillage of liquid into the indoor unit may cause damage to the indoor unit or cause a fire.	\oslash
14.	Do not install the indoor unit where flammable gases may leak. If gas leaks and accumulates around the unit, it may cause a fire.	\oslash
15.	Keep plastic bag (packaging material) away from small children, it may cling to nose and mouth and prevent breathing. (Outdoor unit only)	\bigcirc
16.	Keep plastic bag (packaging material) away from small children, it may cling to nose and mouth and prevent breathing. (Indoor unit only)	0


17.	Do not use joint cable for outdoor connection cable. For outdoor connections, use the specified outdoor connection cable. Refer to instruction "12.4.6 Connect the Cable to the Outdoor Unit" and connect tightly. Clamp the cable so that no external force will be acted on the terminal. If connection or fixing is not perfect, it will cause heat up or fire at the connection.
18.	Use the specified connection cables for the indoor unit and outdoor unit, and connect the indoor unit and outdoor unit securely, referring to " 12.1.3 Connect the Cable to the Indoor Unit ". Tighten the cable so that no external force is applied to the terminal. Incomplete connection or fixing may cause heat generation or ignition of the connection.
19.	For electrical work, follow the national regulation, legislation and this installation manual. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in the electrical work, it may cause electrical shock or fire.
20.	For electrical work, follow local wiring standards and regulations and this installation instructions. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in the electrical work, it will cause electrical shock or fire.
21.	For water circuit installation work, follow to relevant European and national regulations (including EN61770) and local plumbing and building regulation codes.
22.	Engage authorized dealer or specialist for installation. If installation done by the user is incorrect, it will cause electrical shock or fire.
23.	Engage authorized dealer or specialist for installation. If installation done by the user is incorrect, it will cause water leakage, electrical shock or fire.
24.	The refrigerant cycle is completed inside the outdoor unit. No refrigerant pipework is required. Also, no pump-down operation is required.
25.	For installation of refrigeration system, strictly follow this installation procedures. Incorrect installation may cause water leakage, which may lead to electrical shock or fire.
26.	Install at a strong and firm location which is able to withstand weight of the set. If the strength is not enough or installation is not properly done, the set will drop and cause injury.
27.	Comply with national wiring rules or country-specific safety measures in terms of residual current (Installing Residual Current Device (RCD) is strongly recommended).
28.	This equipment is strongly recommended to be installed with Residual Current Device (RCD) on-site according to the respective national wiring rules or country–specific safety measures in terms of residual current.
29.	Wiring must be properly routed to ensure that the control board cover is correctly secured. If the control board cover is not fully secured, it will cause fire or electrical shock.
30.	After installation is complete, make sure that there is no refrigerant gas leak. There is a risk of fire or explosion if the refrigerant contacts fire.
31.	If refrigerant gas leaks during operation, ventilate the room. Extinguish all sources of fire, if any. If the refrigerant contacts fire, there is a possibility of fire / explosion.
32.	Only use supplied or specified parts for installation. Other parts may cause the equipment to drop, vibrate, leak, catch fire or cause an electrical shock.
33.	Only use the supplied or specified installation parts. Else, it may cause unit vibrate, fall, water leakage, electrical shock, or fire.
34.	If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.
35.	When installing electrical equipment at wooden building of metal lath or wire lath, in accordance with electrical facility standard, no electrical contact between equipment and building is allowed. Insulator must be installed in between.
36.	Any work carried out on the Indoor Unit after removing any panels which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.
37.	Any work carried out on the outdoor unit after removing any panels which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.
38.	All power circuits must be disconnected before accessing the unit terminals.
39.	This installation may be subjected to building regulation approval applicable to respective country that may require to notify the local authority before installation.
40.	Be aware that R290 Refrigerant is odourless and flammable.
41.	Ensure that all wiring polarity is correct. Otherwise, this may cause electrical shock or fire.
42.	This equipment must be properly earthed. Earth line must not be connected to gas pipe, water pipe, earth of lightning rod and telephone. Otherwise, it may cause electrical shock in case of equipment breakdown or insulation breakdown.
43.	This equipment must be properly earthed. Electrical earth must not be connected to gas pipe, water pipe, earth of lightning rod and telephone. Otherwise, it may cause electrical shock in case of insulation breakdown or earth fault of the outdoor unit.

1.	Do not install the outdoor unit at place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire.	\otimes
2.	Do not release refrigerant while repairing refrigeration components. Be careful of liquid refrigerants as it can cause frostbite.	\bigcirc
3.	Do not install in humid areas such as laundry rooms. This may cause rust and damage to the unit.	\Diamond
4.	Make sure the insulation of power supply cable does not contact hot part (i.e. refrigerant piping) to prevent from insulation failure (melt).	\otimes
5.	Do not touch the sharp aluminium fins. Sharp edges may cause injury.	\bigcirc
6.	Do not apply excessive force to the water pipes as this may damage them. Water leaks may cause flooding and damage to other property.	\otimes
7.	Prevent liquid or vapour from entering sumps or sewers since vapour is heavier than air and may form suffocating atmospheres.	0
8.	Ensure that the insulation of the power cable does not come into contact with hot areas (e.g. water pipes) to prevent insulation failure (melting) of the power cable.	0
9.	Select an installation location which is easy for maintenance. Incorrect installation, service or repair of this Indoor Unit may result in loss damage or injury and/or property.	0
10.	Select an installation location which is easy for maintenance. Incorrect installation, service or repair of this outdoor unit may increase the risk of rupture and this may result in loss, damage or injury and/or property.	0
11.	 Connection of power supply to the Indoor Unit Power supply point should be in easily accessible place for power disconnection in case of emergency. Comply with local national wiring standard, regulation, and this installation manual. It is strongly recommended to make permanent connection to a circuit breaker. Power supply: use an approved 20A 4-poles circuit breaker with a minimum contact gap of 3.0 mm. 	0
12.	 Power supply connection Power supply point should be in easily accessible place for power disconnection in case of emergency. Comply with local national wiring standard, regulation, and this installation instruction. Strongly recommended to make permanent connection to a circuit breaker. Power supply: Use approved 20A 4-poles circuit breaker with a minimum contact gap of 3.0mm. 	0
13.	Ensure the correct polarity is maintained throughout all wiring. Otherwise, it will cause electrical shock or fire.	0
14.	Installation work. It may need two or more people to carry out the installation work. The weight of outdoor unit might cause injury if carried by one person.	0
15.	Ensure that the required ventilation openings are free from obstacles.	0
16.	Water piping in the occupied space should be installed in such a way as to prevent accidental damage during operation and service.	0
17.	Be careful not to subject the water piping to excessive vibration or pulsation.	0
18.	Protect water piping from accidental burst that may be caused by moving furniture or rebuilding activities.	0
19.	 The water piping should be routed to the shortest possible length. Avoid using dented pipes and avoid sharp bending. It must be ensured that water piping is protected from physical damage. 	0

2. Precautions for Use of R290 Refrigerant

• Pay close attention to the following points:

	MARNING	
1.	Mixing different types of refrigerants in the system is prohibited.	\otimes
2.	Do not place any part of the refrigeration circuit (evaporator, air cooler, AHU, condenser, or liquid receiver) or pipework near heat source, naked flame, or gas appliance or electric heater in operation.	\otimes
3.	Operation, maintenance, repair and recovery of refrigerants must be carried out by personnel trained and certified in the use of flammable refrigerants and in accordance with the manufacturer's recommendations. Personnel who operate, service or maintain the relevant parts of the system or equipment must be trained and certified.	0
4.	The user, owner or their authorised representative shall, where required by national regulations, regularly check alarms, mechanical ventilation, and detectors at least once a year to ensure they are functioning correctly.	0
5.	A logbook shall be maintained. The results of these checks shall be recorded in the logbook.	0
6.	In case of occupied space ventilation, it must be ensured that there are no obstacles.	0
7.	Before operating a new refrigeration system, the person responsible for operating the system must ensure that trained and certified operators are instructed in the construction, supervision, operation and maintenance of the refrigeration system, as well as the safety measures to be observed and the properties and handling of the refrigerants used in accordance with the operating manual.	0
8.	 The general requirements for trained and certified personnel are as follows: a) Knowledge of legislation, regulations and standards relating to flammable refrigerants. b) Detailed knowledge and skills in handling flammable refrigerants, personal protective equipment, refrigerant leak prevention, cylinder handling, charging, leak detection, recovery, and disposal. c) Able to understand and apply in practice the requirements of national laws, regulations and standards. d) Continuously undergoing regular and further training to maintain the expertise. 	9
9.	Ensure that protective devices, refrigeration circuits and accessories are adequately protected against adverse environmental effects (e.g. risk of water freezing in the relief pipe or accumulation of dirt and debris).	0



2.	 2-8. Checking electrical equipment Repair and maintenance of electrical components must include initial safety checks and component inspection procedures. Initial safety checks must include, but are not limited to: Capacitor has been discharged: This check must be carried out in a safe manner to avoid the possibility of sparks. No live electrical components or wiring are exposed during charging, recovery or purging of the system. Earth connection is continuous. Always follow the manufacturer's maintenance and service guidelines. If there is any doubt, contact the manufacturer's technical department. If a fault exists that could compromise safety, power supply must not be connected to the circuit until the problem has been resolved. If the fault cannot be corrected immediately but the operation needs to continue, a suitable temporary solution should be used. Then, the owner of the equipment must be notified or reported so that all parties are subsequently informed.
3.	 Repairing sealed components During repair of sealed components, all power supply must be disconnected from the equipment being worked on before removing sealed covers, etc. If it is absolutely necessary to supply power to equipment during servicing, a permanently operating form of leak detection should be located at the most critical points to warn of potentially hazardous situations. Particular attention must be paid to the following points to ensure that work on electrical components does not alter the casing in such a way as to affect the level of protection: These include damaged cables, excessive numbers of connections, terminals that differ from the original specifications, damaged seals and improperly fitted glands. Ensure that the equipment is securely fitted. Ensure that seals and sealing materials have not deteriorated to such an extent that they no longer serve the purpose of preventing the ingress of flammable atmosphere.
	Replacement parts shall be in accordance with the manufacturer's specifications. Note: Use of silicone sealant may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe explosion-proof components do not need to be isolated before work.
4.	 Repairing intrinsically safe components Do not apply any permanent inductive or capacitive loads to the circuit without ensuring that this will not exceed the permissible voltage and current for the equipment in use. Intrinsically safe components are the only type that can work in the presence of a flammable atmosphere. The test equipment must be at the correct rating. Replace components only with parts specified by the manufacturer. Use of parts not specified by the manufacturer may result in refrigerant leakage and ignition of the refrigerant in the atmosphere.
5.	 Cabling Ensure that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or other adverse environmental effects. The checks should also take into account the effects of ageing and continuous vibration from sources such as compressors and fans.
6.	Detection of flammable refrigerants. Under no circumstances should potential ignition sources be used to search for or detect refrigerant leaks. Do not use halide torches (or other detectors that use naked flames).
7.	 The following leak detection methods are considered acceptable for all refrigerant systems No leakage shall be detected if a detection device with a sensitivity of 5 grams or more of refrigerant per year is used under a pressure of at least 0.25 times the maximum permissible pressure (>0.98 MPa, max 3.90 MPa). An example is universal sniffer. Electronic leak detectors can be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need recalibration. (Calibration of the detector should be carried out in an area free from refrigerant.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection device must be set to a percentage of the LFL of the refrigerant, calibrated to the refrigerant used, and the appropriate percentage of gas (up to 25%) is confirmed. Leak detection fluids are also suitable for use with most refrigerants, including bubble and fluorescent agents. Avoid using detergents containing chlorine, as chlorine may react with refrigerants and corrode copper tubes. If a leak is suspected, all ignition sources must be removed or extinguished. If a refrigerant leak which requires brazing is found, all refrigerant must be recovered from the system. To remove the refrigerant, precautions #8 must be followed.

Re •	moval and evacuation Conventional procedures shall be used when working into the refrigerant circuit for repair or for any other purpose. However, it is important to follow best practice since flammability is a consideration. The following procedures must be followed:	
	 Remove refrigerant → • Purge the circuit with inert gas → • Create vacuum → • Purge with inert gas → Open the circuit by cutting. Do not use brazing. 	
8. •	The charged refrigerant shall be recovered in the correct recovery cylinder. The system must be purged with OFN to secure the appliance safe. (Remarks: OFN = oxygen-free nitrogen, a type of inert gas) This process may need to be repeated several times.	0
•	Do not use compressed air or oxygen for this task. Purging must be achieved by breaking the vacuum in the system with OFN, continuing to fill until the working pressure is reached, then venting to atmosphere, and finally reducing the pressure to vacuum. This process must be repeated until there is no refrigerant in the system. (until the purge gas concentration detected by the	
•	leak detector is below 0.25 LFL) * 0.25 LFL = 0.525 Vol% When the final OFN charge is used, the system must be vented to atmospheric pressure to allow work to be carried out. This operation is absolutely essential when brazing pipes. Ensure that the outlet of the vacuum pump is not near an ignition source and that ventilation is available.	
	arging procedures	
•	 In addition to conventional charging procedures, the following requirements must be followed: When charging equipment is used, ensure that contamination of different refrigerants does not occur. Hoses and lines should be as short as possible to minimise the amount of refrigerant contained in them. Cylinders must be stored in the appropriate position according to instructions. Ensure that the refrigeration system is earthed before charging refrigerant into the system. 	
9.	 Label the system. once the charging is complete. (if not yet completed) Extreme care must be taken not to overfill the cooling system. Before refilling the system, a pressure test must be carried out with OFN. (See #8) The system must be leak tested after completion of charging and before commissioning. 	g
•	A follow-up leak test must be carried out before leaving the site. Static build-up may occur while charging and purging refrigerant and it can cause hazardous conditions. To avoid fire and/or explosion, earth the containers and equipment before charging/releasing to dissipate static electricity during transport.	
De • •	commissioning Before carrying out this procedure, it is important that the technician is familiar with the equipment and all its details. It is recommended to recover all refrigerants safely. Reuse of recovered refrigerants is prohibited.	
•	 It is important that electrical power is available before commencing the work. a) Become familiar with the equipment and its operation. b) Electrically isolate the system. c) Before carrying out the procedure, ensure that: 	
10.	 If required, mechanical handling equipment can be used for handling refrigerant cylinders. All personal protective equipment and leak detectors are available and used correctly. The recovery process is always supervised by a competent person. Recovery devices and cylinders comply with appropriate standards. 	9
	 d) Make sure that the cylinder is placed on the scale before commencing recovery. e) Start the recovery machine and operate it according to the instructions. f) Do not overfill the cylinder. (No more than 80 % volume liquid charge) g) Do not exceed the maximum working pressure of the cylinder, even temporarily. h) Once the cylinder has been correctly filled and the process completed, ensure that the cylinder and equipment are 	
•	promptly removed from the site and that all shut-off valves on the equipment are closed. Static build-up may occur while charging and purging refrigerant and it can cause hazardous conditions. To avoid fire and explosion, earth the containers and equipment before charging/releasing to dissipate static electricity during transport.	
La	explosion, early the containers and equipment before charging/releasing to dissipate static electricity during transport.	
	The equipment shall be labelled to indicate that it has been decommissioned and empty of refrigerant.	•

Recovery

12.

When removing refrigerant from a system for maintenance or decommissioning, it is recommended to remove all
refrigerant safely.

<u>/</u>]\

CAUTION

- When transferring refrigerant into cylinders, always use only suitable refrigerant recovery cylinders.
 - Ensure that the correct number of cylinders are available to accommodate the total charge of the system.
- All cylinders used are designated for recovered refrigerants and labelled for that refrigerant. (i.e. special cylinders for recovery of refrigerant)
- The cylinder must be equipped with a pressure relief valve and associated shut-off valve in good working order.
- Before recovery is commenced, the recovery cylinder is vented and, if possible, cooled.
- Recovery equipment must have a set of instructions on the equipment at hand, be in good working order and be suitable for the recovery of flammable refrigerants.
- Ensure that the recovery equipment is not a potential source of ignition and is suitable for the refrigerant being used.
- In addition, a set of calibrated scales must be available and in good working order.
- Hoses must be in good condition with leak-free disconnect couplings.
 - Before using the recovery machine, make sure that it is fully operational and properly maintained, and that relevant electrical components are sealed to prevent ignition in the event of a refrigerant release. If there is any doubt, contact the manufacturer.

A

- The recovered refrigerant should be returned to the refrigerant supplier in a suitable recovery cylinder and the relevant waste transfer note should be prepared.
- Do not mix refrigerants in the recovery unit, especially in the cylinder.
- When removing compressor or compressor oil, ensure that it is exhausted to an acceptable level so that no flammable refrigerant remains in the lubricant.
- The exhaust process must be carried out before the compressor is returned to the supplier.
- To facilitate this process, only electrical heating to the compressor body is used.
- Any draining of oil from the system must be carried out safely.

3. Specifications

3.1 WH-CME8 WH-WXG09ME8

	Item	Unit		Outdo	or Unit	
Performance T	est Condition		EN 14511 / EN 14825			5
Cooling Capacity		Condition (Ambient/Water)	A35W7			
		kW	9.00			
		BTU/h		30700		
Cooling EER		W/W		3.	61	
		Condition (Ambient/Water)	A7W35	A2W35		A2W35
Heating Capac	ity	kW	9.00		9.00	
		BTU/h	30700			30700
Heating COP		W/W	5.23			3.81
	Low Temperature Application (W35)	10/	A		Oshian
	Application	Climate	Warmer	Ave	rage	Colder
	Pdesign	kW	9.0	9	.0	9.0
	Tbivalent / TOL	°C	2/2	-10	/ -10	-22 / -22
	SCOP / ns	(W/W) / %	6.33 / 250	5.00	/ 197	4.45 / 175
	Annual Consumption	kWh	1901	37	21	4990
	Class		A+++	A+	++	A+++
Heating ErP	Medium Temperature Applicati	on (W55)				
	Application	Climate	Warmer	Ave	rage	Colder
	Pdesign	kW	9.0	9	.0	9.0
	Tbivalent / TOL	°C	2/2	-10	/ -10	-22 / -22
	SCOP / ns	(W/W) / %	4.40 / 173	3.50	/ 137	3.20 / 125
	Annual Consumption	kWh	2735	53	18	6939
	Class		A+++	A	++	A++
		dB (A) ***	Cooling: -	Heating: -		Heating: -
Noise Level		Power Level dB ****	Cooling: 60)		Heating: 58
		dB *****	-			Heating: 52
Air Flow		m³/min (ft³/min)	Cooling: 97.0 (3426) Heating: 83.0 (2931)			
Refrigeration C	ontrol Device		Expansion Valve			
Refrigeration O	il	cm ³	PZ68S (1100)			
Refrigerant (R2	90) Precharge / Maximum	kg (oz)		1.78 (62	2.8) / (-)	
	GWP		3			
F-GAS	CO ₂ eq (ton) (Precha	rged / Maximum)		0.00	6 / (-)	
	Height	mm (inch)		1520 (5	9-27/32)	
Dimension	Width	mm (inch)		1200 (47-1/4)		
	Depth	mm (inch)	430 (16-15/16)			
Net Weight		kg (lbs)	163 (359)			
Water Piping O/D Outdoor Water Pipe Connector		mm (inch)	31.75 (1-1/4)			
Туре			Hermetic M	lotor Comp	ressor (Inv	olute Scroll)
Compressor	Motor Type		Synchr	onous Elect	tric Motor (6-poles)
	Rated Output	kW	3.10			

	Item	Unit		Outdoor Unit	
	Туре			Propeller Fan	
	Material			PP	
	Motor Type		DC (8-poles)		
Fan	Input Power	W	-		
	Output Power	W	120 × 2		
	Fan Speed	rpm		Cooling: 510 Heating: 400	
	Fin material			Aluminium (Pre Coat)	
	Fin Type			Corrugated Fin	
Heat Exchanger	Row × Stage × FPI			2 × 58 × 19	
	Size (W × H × L)	mm	44	× 1473.2 × 868.2:902	7
	Туре			Braze Plate	
	No. of Plates			36	
Hot Water Coil	Size (W × H × L)	mm		76.2 × 524 × 117	
	Water Flow Rate	l/min (m³/h)		Cooling: 25.8 (1.5) Heating: 25.8 (1.5)	
	Motor Type		Brushless DC M	otor (Sensorless vecto	r control system)
Pump	No. of Speed			Variable speed	
	Input Power	W		175	
	Туре		Voi	tex (Piezoelectric sens	sor)
Flow Sensor	Measuring range	l/min	5~60		
		Ø	Three		
Power Source (Phase, Vo	oltage, Cycle)	V	400		
	0, , ,	Hz	50		
Input Power		Condition (Ambient/Water)	A35W7	A7W35	A2W35
input i onoi		kW	Cooling: 2.49	Heating: 1.72	Heating: 2.36
Maximum Input Power Fo	or Heatpump System	kW	8.51		
Outdoor Power Supply : I	Phase (Ø) / Max. Current (A) /	/ Max. Input Power (W)		3Ø / 12.8 / 8.51k	
Indoor Power Supply : Ph	nase (Ø) / Max. Current (A) / M	/lax. Input Power (W)	3Ø / 14.9 / 9.50k		
Power Supply 3 : Phase (Ø) / Max. Current (A) / Max. I	Input Power (W)	- / - / -		
Starting Current		A	3.8		
Running Current		Condition (Ambient/Water)	A35W7	A7W35	A2W35
0		А	Cooling: 3.8	Heating: 2.6	Heating: 3.6
Maximum Current For He	atpump System	A		12.8	
Power Factor Power factor means total outdoor fan motor.	figure of compressor and	%	Cooling: 95	Heating: 96	Heating: 95
Dower Cord	Number of core			-	
Power Cord Length		m (ft)		-	
Thermostat				Electronic Control	
Protection Device				Electronic Control	
Pressure Relief Valve Water Circuit		kPa	Oper	n: 400, Close: 280 or h	igher
	Outdoor Ambient	°C (min. / max.)	H	Cooling: 10 / 43 eating (Circuit): -28 / 3	5
Operation Range	Water Outlet	°C (min. / max.)	Cooling: 5 / 20 Heating (Circuit): 25 / 55 (Below Ambient -25°C) * ⁴ Heating (Circuit): 25 / 75 (Above Ambient -15°C) * ⁴		
Internal Pressure Differer	ntial	kPa	Cooling: 13.0 Heating: 13.0		

Item		Unit	Indoor Unit		
Performance Test Condition			EN 14511 / EN 14825		
Noise Level		dB (A)	Cooling: 22***	Heating: 22***	
		Power Level dB	Cooling: 35****	Heating: 35****	
	Height	mm (inch)	454 520		
Dimension	Width	mm (inch)			
	Depth	mm (inch)	116		
Net Weight		kg (lbs)	7 (15)		

Note:

- In case it is necessary to indicate the air flow volume in (I/s), the value in (m³/min.) shall be multiplied by 16.7 and rounded down the decimal point.
- If the EUROVENT Certified models can be operated under the "extra-low" temperature condition, -7°C DB and -8°C WB temperature with rated voltage 230V shall be used.
- Capacity is measured at outdoor temperature 7°C DB and 6°C WB with controlled water inlet 30°C and water outlet 35°C (EN 14511-2)
- Flowrate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and ΔT=5°C.
- *** The sound pressure level is measured with distance 1.0m from the unit and height at 1.5m. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- ***** The sound power level is measured with accordance to EN12102 under conditions of the EN14825. (Test carry out for heating at ambient 7°C DB / 6°C WB and water out 55°C)
- EER and COP classification is at 230V only in accordance with EU directive 2003/32/EC.
- **** The sound power level is measured with accordance to EN12102 under full load conditions. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- *⁴ Between outdoor ambient -15°C and -25°C, the water outlet temperature gradually decreases from 75°C to 55°C.

3.2 WH-CME8 WH-WXG12ME8

	Item		Unit	Outdoor Unit			
Performance Te	est Condition				EN 14511	/ EN 14825	j
			Condition (Ambient/Water)		A35	5W7	
Cooling Capacity		kW	9.00				
			BTU/h	30700			
Cooling EER			W/W		3.	61	
			Condition (Ambient/Water)	A7W35			A2W35
Heating Capaci	ity		kW	12.00			12.00
			BTU/h	40900			40900
Heating COP			W/W	5.06			3.54
	Low Tempe	erature Application (W35)	10/	A		Caldan
	Application		Climate	Warmer	Ave	rage	Colder
	Pdesign		kW	12.0	12	2.0	12.0
	Tbivalent /	TOL	°C	2/2	-10	/ -10	-22 / -22
	SCOP / ns		(W/W) / %	6.20 / 245	4.73	/ 186	4.38 / 172
	Annual Cor	nsumption	kWh	2586	52	44	6758
la atina E-D	Class			A+++	A+++		A++
-leating ErP	Medium Te	mperature Application (\	N55)		A		Ostitus
	Application		Climate	Warmer	Average		Colder
	Pdesign		kW	12.0	12.0		12.0
	Tbivalent /	TOL	°C	2/2	-10	/ -10	-22 / -22
	SCOP / ns		(W/W) / %	4.40 / 173	3.65 / 143 3.25 /		3.25 / 127
	Annual Consumption		kWh	3647	6792 911		9111
	Class			A+++	A	++	A++
			dB (A) ***	Cooling: - Heating:		Heating: -	
Noise Level			Power Level dB ****	Cooling: 60)		Heating: 59
			dB *****	- Heating:		Heating: 53	
Air Flow			m ³ /min (ft ³ /min)	Cooling: 97.0 (3426) Heating: 92.0 (3249)			
Refrigeration C	ontrol Device			Expansion Valve			
Refrigeration O	il		cm ³	PZ68S (1600)			
Refrigerant (R2	90) Precharge	e / Maximum	kg (oz)		1.78 (62	2.8) / (-)	
	G	SWP			:	3	
F-GAS	C	O ₂ eq (ton) (Precharged	/ Maximum)	0.006 / (-)			
	F	leight	mm (inch)		1520 (5	9-27/32)	
Dimension	V	Vidth	mm (inch)		1200 (47-1/4)	
Depth		mm (inch)	430 (16-15/16)				
Net Weight		kg (lbs)		163 ((359)		
Water Piping O	/ater Piping O/D Outdoor Water Pipe mm (inch)		31.75	(1-1/4)			
	Т	уре		Hermetic N	lotor Comp	ressor (Inv	olute Scroll)
Compressor	Ν	lotor Type		Synchro	onous Elect	tric Motor (6-poles)
	F	ated Output	kW		3.	10	

	Item	Unit		Outdoor Unit			
	Туре			Propeller Fan			
	Material			PP			
	Motor Type			DC (8-poles)			
Fan	Input Power	W	-				
	Output Power	W		120 × 2			
	Fan Speed	rpm		Cooling: 510			
	· ·	ipin		Heating: 420			
	Fin material			Aluminium (Pre Coat)			
Heat Exchanger	Fin Type			Corrugated Fin			
-	Row × Stage × FPI			2 × 58 × 19			
	Size (W × H × L)	mm	44	× 1473.2 × 868.2:902	.7		
	Туре			Braze Plate			
Lat Water Cail	No. of Plates			36			
Hot Water Coil	Size (W × H × L)	mm		76.2 × 524 × 117			
	Water Flow Rate	l/min (m³/h)		Cooling: 25.8 (1.5) Heating: 34.4 (2.1)			
	Motor Type		Brushless DC M	otor (Sensorless vecto	r control system)		
Pump	No. of Speed			Variable speed			
	Input Power	W		175			
Flow Sensor	Туре		Vortex (Piezoelectric sensor)				
	Measuring range	l/min		5 ~ 60			
		Ø	Three				
Power Source (Phase, Vo	oltage, Cycle)	V	400				
		Hz	50				
Input Power		Condition (Ambient/Water)	A35W7	A7W35	A2W35		
•		kW	Cooling: 2.49	Heating: 2.37	Heating: 3.39		
Maximum Input Power Fo	or Heatpump System	kW	9.84				
Outdoor Power Supply : F	Phase (Ø) / Max. Current (A) /	Max. Input Power (W)		3Ø / 14.8 / 9.84k			
Indoor Power Supply : Ph	ase (Ø) / Max. Current (A) / M	lax. Input Power (W)		3Ø / 14.9 / 9.50k			
Power Supply 3 : Phase (Ø) / Max. Current (A) / Max. I	nput Power (W)		- / - / -			
Starting Current		А	3.8				
Running Current		Condition (Ambient/Water)	A35W7	A7W35	A2W35		
Ũ		А	Cooling: 3.8	Heating: 3.6	Heating: 5.2		
Maximum Current For He	atpump System	А		14.8			
Power Factor Power factor means total figure of compressor and outdoor fan motor.		%	Cooling: 95	Heating: 96	Heating: 95		
Power Cord	Number of core			-			
Power Cord Length		m (ft)		-			
Thermostat				Electronic Control			
Protection Device				Electronic Control			
Pressure Relief Valve Water Circuit		kPa	Oper	n: 400, Close: 280 or h	igher		
	Outdoor Ambient	°C (min. / max.)	H	Cooling: 10 / 43 leating (Circuit): -28 / 3	5		
Operation Range	Water Outlet	°C (min. / max.)	Cooling: 5 / 20 Heating (Circuit): 25 / 55 (Below Ambient -25°C) * ⁴ Heating (Circuit): 25 / 75 (Above Ambient -15°C) * ⁴				
Internal Pressure Differer	tial	kPa	Cooling: 13.0 Heating: 24.0				

Item		Unit	Indoor Unit		
Performance Test Condition			EN 14511/	EN 14825	
Noise Level		dB (A)	Cooling: 22***	Heating: 22***	
		Power Level dB	Cooling: 35****	Heating: 35****	
	Height	mm (inch)	454 520		
Dimension	Width	mm (inch)			
	Depth mm (inch) 116		3		
Net Weight		kg (lbs)	7 (15)		

Note:

- In case it is necessary to indicate the air flow volume in (I/s), the value in (m³/min.) shall be multiplied by 16.7 and rounded down the decimal point.
- If the EUROVENT Certified models can be operated under the "extra-low" temperature condition, -7°C DB and -8°C WB temperature with rated voltage 230V shall be used.
- Capacity is measured at outdoor temperature 7°C DB and 6°C WB with controlled water inlet 30°C and water outlet 35°C (EN 14511-2)
- Flowrate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and ΔT=5°C.
- *** The sound pressure level is measured with distance 1.0m from the unit and height at 1.5m. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- ***** The sound power level is measured with accordance to EN12102 under conditions of the EN14825. (Test carry out for heating at ambient 7°C DB / 6°C WB and water out 55°C)
- EER and COP classification is at 230V only in accordance with EU directive 2003/32/EC.
- **** The sound power level is measured with accordance to EN12102 under full load conditions. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- *⁴ Between outdoor ambient -15°C and -25°C, the water outlet temperature gradually decreases from 75°C to 55°C.

3.3 WH-CME8 WH-WXG16ME8

Item			Unit	Outdoor Unit			
Performance Te	est Conditio	n		EN 14511 / EN 14825			i
			Condition (Ambient/Water)		A35	5W7	
Cooling Capacit	ty		kW	9.00			
		BTU/h	30700				
Cooling EER			W/W		3.	61	
			Condition (Ambient/Water)	A7W35			A2W35
Heating Capaci	ty		kW	16.00			16.00
			BTU/h	54600			54600
Heating COP			W/W	4.89			3.30
	Low Tem	perature Application (W35)			A		Colder
	Application	on	Climate	Warmer	Ave	rage	Colder
	Pdesign		kW	16.0	16	6.0	16.0
	Tbivalent	t / TOL	°C	2/2	-10	/ -10	-22 / -22
	SCOP / r	าร	(W/W) / %	6.08 / 240	4.75	/ 187	4.33 / 170
	Annual C	Consumption	kWh	3517	69	66	9101
l la stia a EsD	Class			A+++	A+++		A++
Heating ErP	Medium	Temperature Application (W	55)		A		
	Application		Climate	Warmer	Average Co		Colder
	Pdesign		kW	16.0	16.0		16.0
	Tbivalent	t / TOL	°C	2/2	-10 / -10		-22 / -22
	SCOP / r	าร	(W/W) / %	4.45 / 175	3.70 / 145		3.40 / 133
	Annual C	Consumption	kWh	4801	8935		11613
	Class			A+++	A	++	A++
	•		dB (A) ***	Cooling: -		Heating: -	
Noise Level			Power Level dB ****	Cooling: 60			Heating: 62
			dB *****	-	Heating: 57		Heating: 57
Air Flow			m³/min (ft³/min)	Cooling: 97.0 (3426) Heating: 108.0 (3814)			
Refrigeration Co	ontrol Devic	e			Expansi	on Valve	
Refrigeration Oi	il		cm ³		PZ68S (1600)		
Refrigerant (R2	90) Prechar	ge / Maximum	kg (oz)		1.77 (6	2.4) / (-)	
- 0.40		GWP			:	3	
F-GAS CO2eq (ton) (Precharged /		,			6 / (-)		
Dimension		Height	mm (inch)		15	20	
		Width	mm (inch)			00	
Depth		mm (inch)		430 (16	6-15/16)		
Net Weight		kg (lbs)		165	(364)		
Water Piping O/D Outdoor Water Pipe Connector		mm (inch)		31.75 (1-1/4)			
		Туре		Hermetic M	lotor Comp	ressor (Invo	olute Scroll)
Compressor		Motor Type		Synchro	onous Elec	tric Motor (6	6-poles)
		Rated Output	kW		3.	10	

	Item	Unit		Outdoor Unit		
	Туре			Propeller Fan		
	Material			PP		
	Motor Type			DC (8-poles)		
Fan	Input Power	W	-			
	Output Power	W	120 × 2			
	Fan Speed	rpm		Cooling: 510 Heating: 480		
	Fin material			Aluminium (Blue Coat)		
Hoot Exchanger	Fin Type			Corrugated Fin		
Heat Exchanger	Row × Stage × FPI			2 × 58 × 19		
	Size (W × H × L)	mm	44	× 1473.2 × 868.2:902	2.7	
	Туре			Braze Plate		
	No. of Plates			44		
Hot Water Coil	Size (W × H × L)	mm		72.0 × 535 × 120.5		
	Water Flow Rate	l/min (m³/h)		Cooling: 25.8 (1.5) Heating: 45.9 (2.8)		
	Motor Type		Brushless DC M	otor (Sensorless vecto	r control system)	
Pump	No. of Speed			Variable speed		
	Input Power	W		175		
Flow Sensor	Туре		Vortex (Piezoelectric sensor)			
Flow Selisor	Measuring range	l/min	5 ~ 60			
		Ø	Three			
Power Source (Phase, Vo	oltage, Cycle)	V	400			
		Hz	50			
Input Power		Condition (Ambient/Water)	A35W7	A7W35	A2W35	
		kW	Cooling: 2.49	Heating: 3.27	Heating: 4.85	
Maximum Input Power Fo	or Heatpump System	kW	12.80			
Outdoor Power Supply : I	Phase (Ø) / Max. Current (A)	/ Max. Input Power (W)	3Ø / 19.0 / 12.8k			
Indoor Power Supply : Ph	nase (Ø) / Max. Current (A) / N	Max. Input Power (W)	3Ø / 14.9 / 9.50k			
Power Supply 3 : Phase (Ø) / Max. Current (A) / Max.	Input Power (W)	- / - / -			
Starting Current		А		4.9		
Running Current		Condition (Ambient/Water)	A35W7	A7W35	A2W35	
		A	Cooling: 3.8	Heating: 4.9	Heating: 7.3	
Maximum Current For He	atpump System	A		19.0		
Power Factor Power factor means total outdoor fan motor.	figure of compressor and	%	Cooling: 95	Heating: 97	Heating: 96	
Dowor Cord	Number of core			-		
Power Cord Length		m (ft)		-		
Thermostat				Electronic Control		
Protection Device				Electronic Control		
Pressure Relief Valve Water Circuit		kPa	Oper	n: 400, Close: 280 or h	igher	
	Outdoor Ambient	°C (min. / max.)	H	Cooling: 10 / 43 eating (Circuit): -28 / 3	5	
Operation Range	Water Outlet	°C (min. / max.)	Cooling: 5 / 20 Heating (Circuit): 25 / 55 (Below Ambient -25°C) * ⁴ Heating (Circuit): 25 / 75 (Above Ambient -15°C) * ⁴			
Internal Pressure Differer	ntial	kPa	Cooling: 13.0 Heating: 38.0			

Item		Unit	Indoor Unit		
Performance Test Condition			EN 14511 /	'EN 14825	
Noise Level		dB (A)	Cooling: 22***	Heating: 22***	
		Power Level dB	Cooling: 35****	Heating: 35****	
	Height	mm (inch)	454 520		
Dimension	Width	mm (inch)			
	Depth	mm (inch)	116		
Net Weight		kg (lbs)	7 (15)		

Note:

- In case it is necessary to indicate the air flow volume in (I/s), the value in (m³/min.) shall be multiplied by 16.7 and rounded down the decimal point.
- If the EUROVENT Certified models can be operated under the "extra-low" temperature condition, -7°C DB and -8°C WB temperature with rated voltage 230V shall be used.
- Capacity is measured at outdoor temperature 7°C DB and 6°C WB with controlled water inlet 30°C and water outlet 35°C (EN 14511-2)
- Flowrate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and ΔT=5°C.
- *** The sound pressure level is measured with distance 1.0m from the unit and height at 1.5m. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- ***** The sound power level is measured with accordance to EN12102 under conditions of the EN14825. (Test carry out for heating at ambient 7°C DB / 6°C WB and water out 55°C)
- EER and COP classification is at 230V only in accordance with EU directive 2003/32/EC.
- **** The sound power level is measured with accordance to EN12102 under full load conditions. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- *⁴ Between outdoor ambient -15°C and -25°C, the water outlet temperature gradually decreases from 75°C to 55°C.

4. Features

- Inverter Technology
 - o Energy saving
- High Efficiency
- A-class energy efficiency pump
 - Water pump speed can be set by selection at control panel
- Improved deice cycle

• Protection Feature

- o Random auto restart after power failure for safety restart operation
- Gas leakage protection
- Prevent compressor reverse cycle
- Inner protector to protect compressor


• Serviceability Feature

- Breakdown Self Diagnosis function
- System Status Check Buttons for servicing purpose
- Front maintenance design for outdoor unit

5. Location of Controls and Components

5.1 Indoor Unit

5.1.1 Remote Controller buttons and display



Di	lay
(A)	fode selection
	 Depending on the preset outdoor *1.*2 COOL operation is either turned ON or OFF. The outdoor unit provides cooling to the system.
	 3 TANK * TANK **** TANK *** TANK
	 HEAT • HEAT operation is either turned ON or OFF. • The outdoor unit provides heat to the system. ** TANK ** TANK ** TANK ** TANK • TANK operation is either turned ON or OFF. • The outdoor unit provides heat to the system.
	 HEAT ** TANK * The outdoor unit provides heat to the water tank and the system. This mode can be selected only when the water tank is installed. * The direction icons point to the currently active mode. * Room operation / Tank operation.
	Deice operation.
B	Operation icons The status of operation is displayed. con will not display (under operation OFF screen) whenever operation is OFF except weekly timer. Image: Holiday operation status Image: Holiday operation status Image: Holiday operation status Image: Holiday operation status Image: Cone:Room Thermostat Image: Holiday operation status Image: Holiday operation status Image: Holiday operatio
	Room Heater status
	Bivalent status (Boiler)
\bigcirc	emperature of each zone
\bigcirc	ïme and day
E	Vater Tank temperature
F	Outdoor temperature
G	ensor type/Set temperature type icons
	Water Temperature ↓ Water Temperature Pool only → Compensation curve ↓ →Direct Pool only ■ Room Thermostat ↓ ntermal Image: Comparison of the comparison of th

*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.
 *2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).
 *3 Only displayed when Tank connection is Yes.

5.1.2 Initialization

Before starting to install the various menu settings, please initiate the Remote Controller by selecting the language of operation and installing the date and time correctly.

When power is turned on for the first time, it becomes the setting screen automatically. It can also be set from personal setting of the menu.

Initialization

⇒ Select

Selecting the language

Wait while the display is initializing. When initializing screen ends, it turns to normal screen. When any button is pressed, language setting screen appears.

- (1) Scroll with \checkmark and \land to select the language.

Setting the clock

- Select with ✓ or ∧ how to display the time, either 24h or am/pm format (for example, 15:00 or 3:00 pm).
- 2 Press to confirm the selection.
- ③ Use ✓ and ∧ to select year, month, day, hour and minutes. (Select and move with > and press to confirm.)
- (4) Once the time is set, time and day will appear on the display even if the Remote Controller is turned OFF.
- Final precaution step to check and confirm whether outdoor front grille is fixed before operating the unit for safety purpose.
 Select Yes if outdoor front grille is already fixed. Then it will proceed to main screen.
 Select No if outdoor front grille is not yet fixed.
 A caution message will pop up to remind on the installation.

Initializing
12:00am,Mon
[(b]]Start
ENGLISH FRANÇAIS
DEUTSCH
ITALIANO
Clock format 12:00am,Sat
24h
am/pm
[≜] Select [₊-]Confirm
Date & Time 12:00am,Sat
Year/Month/Day Hour : Min
2022 / 01 / 01 12 : 00 am

[₊-]Confirm


12:00am, Mon

LCD blinking

Front grille	12:00am,Sat			
ls O/D front gr	Is O/D front grille fixed?			
	No			
	Yes			
Select	[₊]Confirm			
Exect aville	12:00em Eat			
ls	Caution			
To pre	event injury, fix rille before ope.			
	[⊐]Close			
+ Delect	[+]countri			
	12:00am,Sat			
[①] Start				

5.1.3 Quick Menu

After the initial settings have been completed, you can select a quick menu from the following options and edit the setting.



Quick Menu	
Force DHW - Powerful	₩ Quiet Set Force Heater
Weekly Timer S Force Defro	st • Error Reset 🛉 R/C Lock
-+Select [+-]ON/OFF	Select each setting and confirm the setting according to the instructions displayed at the bottom of the screen. (The icons refer to each selection key.)

To return to the Main Screen,

Press or ⊃ .

*1 Only displayed when Tank connection is Yes.

5.1.4 How to use the Quick Menu

Force DHW



Note:

- Force DHW is disabled when Force Heater is turned on.
- When Force DHW is turned off, operation & mode should change back to the previous memorized status.


.....

- Powerful

Select this icon to operate the heating/cooling system powerfully.

Press 🚽 to confirm your selection.

(The powerful operation starts approximately 1 minute after 🚚 is pressed.)



Note:


• Powerful is disabled when operation is turned OFF.



Select this icon to operate quietly.

Press 🚽 to confirm your selection.

(The quiet operation starts approximately 1 minute after \checkmark is pressed.)



登 Force Heater

Select to force the Heater on.

Press 🚽 to confirm your selection.

(The Force Heater mode starts approximately 1 minute after 🛁 is pressed.)



• Force Heater is turned off.

Force Heater is turned on.

Note:


• Force Heater is disabled whenever operation is already on and "Disabled due to operation ON!" will be displayed.

Disabled due to operation ON!

[⊅]Close

🖄 Weekly Timer

Select this icon to delete (cancel) or change the pre-set Weekly Timer.



Note:

• Timer is disabled when Force Heater is turned on or Heat-Cool SW is enabled.

• If you have preset the Weekly Timer on 2 zones, you must repeat the same procedure with Zone 2.

S Force Defrost

Select to defrost the frozen pipes.

Press 🚽 to confirm your selection. (When the mode is accepted, below screen will be displayed.)

Request accepted!

[⇒]Close

Intervention of the set **

Select to restore the previous settings when error has occurred.

Press 🚽 to confirm your selection.

(When the mode has been accepted, below screen will be displayed.)

Request accepted! [⇒]Close

• Make sure all units are turned off before selecting this mode which restores the whole system to the previous settings.

R/C Lock

Select to lock the Remote Controller.

Press 🚽 to confirm your selection.

(When the mode has been accepted, below screen will be displayed.)



Select "Yes". (The Main Screen will be locked.)

. If "No" is selected, the screen will return to the Main Screen.

To unlock the Remote Controller

Press any key.

(When the mode has been accepted, below screen will be displayed.)




Enter any 4 digits of number (if the number is correct, the screen will be unlocked).

To reset forgotten password (under operation OFF screen)

Press \bigcirc , \checkmark and > continuously for 5 seconds.

(When the mode has been accepted, below screen will be displayed.)



1.Password is reset to 0000

2.Remote control is unlocked

(The screen will be off after 3 seconds.)

5.1.5 Menus (For user)


Select menus and determine settings according to the system available in the household. All initial settings must be done by an authorised dealer or a specialist. It is recommended that all alterations of the initial settings are also done by an authorised dealer or a specialist.

- After initial installation, you may manually adjust the settings.
- The initial setting remains active until the user changes it.
- The Remote Controller can be used for multiple installations.
- Ensure the operation indicator is OFF before setting.
- The system may not work properly if set wrongly. Please consult an authorised dealer.

To display <Main Menu>: ≡

To select menu: $\land \lor < >$

To confirm the selected content:



Menu		Default Setting	Setting Options / I	Display	
1	Function setup >Weekly timer				
	Once the weekly timer is set up, User can edit from Quick Menu. To set up to 6 patterns of operation on a daily basis. • Disabled if Heat-Cool SW is select "Yes" or if Force Heater is on.	set the patte (Time / Operation Timer copy	the week and erns needed ON/OFF / Mode) of the week	Weekly timer Sun Mon Tue We 1. 8:00am ON ∰ 2.12:00pm ON ∰ 3. 1:00pm ON ∯ ⊕Day ↓Patter	40℃ ∰ 24/28℃ 40℃ € 12/10℃
1.2	> Holiday timer				
	To save energy, a holiday period may be set to either turn	OFF		ON OFF	
	OFF the system or lower the	> ON			
	temperature during the period.	Holiday start and end. Date and time		Holiday: End Year/Month/Day	10:34am,Mon Hour : Min
		OFF or lowere	d temperature	2022 / 01 / 01	10:00 am
	Weekly timer setting may be tem but it will be restored once the H			 → Select	[⊷]Confirm
1.3	> Quiet timer	<u> </u>			[+]0011111
1.0	To operate quietly during the	Time to st	art Quiet :	Quiet	10:34am, Mon
	preset period.	Date a			me Level
	6 patterns may be set.			-	00am 0 10pm 1
	Level 0 means the mode is off.	Level of c 0 ~	quietness: - 3	3 11:0	00pm 1 00pm 3 Edit

Ме	enu	Default Setting	Setting Options / Display
1.4	> Quiet priority		
	 To select priority during Quiet mode between Sound and Capacity. If Sound priority is selected, unit will operate in quiet condition only. If Capacity priority is selected, unit will operate in quiet condition but it will prioritize on providing required capacity at the same time. 	Sound	Sound Capacity
1.5	> Room heater		
	To set the room heater ON or OFF.	OFF	ON OFF
1.6	> *1 Tank heater		
	To set the tank heater ON or OFF.	OFF	OFF
1.7	> *1 Sterilization		
	To set the auto sterilization ON or OFF.	ON	ON OFF

Do not use the system during sterilization in order to prevent scalding with hot water, or overheating of shower.
Ask an authorised dealer to determine the level of sterilization function field settings according to the local laws and regulations.

*1 Only displayed when Tank connection is Yes. -----

2	System check				
2.1	> Energy monitor				
	Present or historical chart of energy consumption, generation or COP.	Present Select and retrieve Historical chart Select and retrieve			
	 COP= Coefficient of Performance. For historical chart, the period is selected from 1 day/1 week/1year. Energy consumption (kWh) of heating, *1.*2 cooling, *3 tank and total may be retrieved. The total power consumption is an estimated value based on AC 230 V and may differ from value measured by precise equipment. 		^{twn} 1year 1 2 3 4 5 6 7 Jan, 2022: 0.0 ⊧ ₩Month \$Mode		
2.2	> System information	-			
	Shows all system information in each area.	Actual system information of 11 items: Inlet / Outlet / Zone 1 / Zone 2 / Tank / Buffer tank / Solar / Pool / COMP frequency / Pump flowrate / Water pressure	System information 1. Inlet 2. Outlet 3. Zone 1 4. Zone 2	10:34am,Mon : 0°C : 0°C : 0°C : 0°C	
		*5 Select and retrieve	4. Zone Z	: 00	
22	> Error history	- age			
2.0	 Refer to Troubleshooting for error codes. The most recent error code is displayed at the top. 	Select and retrieve	Error history 1 2 3 4 [+-]Clear history	10:34am, Mon	
2.4	> Compressor		·		
	Shows the compressor performance.	Select and retrieve	Compressor 1. Current frequency 2. (OFF-ON) counter 3. Total ON time		
	A Hastan		[⊅]Back		
2.5			Heater	10:24am Mon	
	Total hours of ON time for Room heater/* ³ Tank heater.	Select and retrieve	Heater Total ON time ऄॖ≣	10:34am, Mon : 0h	
			ଧି⊮ି [⊅]Back	: 0h	

*4 If [Approx.] is shown on Energy Monitor display, data displayed on the remote controller is obtained through heat pump's internal calculation.

If [Approx.] is NOT shown on Energy Monitor display, data displayed on the remote controller is obtained by External Meters. *5 Only displayed when each connection is Yes.

 ^{*1} The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.
 ^{*2} Only displayed when COOL mode is unlocked (This means when COOL mode is available).
 ^{*3} Only displayed when Tank connection is Yes.

Ме	nu	Default Setting	Setting Options	/ Display	
3	Personal setup				
3.1	> Remote control No.				
	 To display remote control number of a particular remote controller so that installer and end user are well informed. Main remote controller is displayed as RC-1. Second remote controller is displayed as RC-2. 	Select and retrieve		RC No.	10:34am,Mc -1]Confirm
3.2	> Touch sound				
	Turns the operation sound ON/ OFF.	ON		ON OFF	
3.3	> LCD contrast		1		
	Sets the screen contrast.			LCD contrast	10:34am, Mo
		3		Low	High
				♦ Select [+-]Confirm
3.4	> Backlight				
	Sets the duration of screen backlight.	1 min		Backlight OFF 15 secs 1 min *Select	10:34am, Mo 5 mins 10 mins]Confirm
3.5	> Backlight intensity				
	Sets screen backlight brightness.			Backlight intensity	/ 10:34am, M
		4		Dark	Bright
				 Select [+]Confirm
3.6	> Clock format				
	Sets the type of clock display.	am/pm		Clock format 24 am/	<u> </u>
					JConfirm
3.7	> Date & Time		·		
	Sets the present date and time.		Day / Haur / Min	Date & Time Year/Month/Day	10:34am,Mo Hour : Min
		rear / wonth / I	Day / Hour / Min	2022 / 01 / 01	10:00 am

Menu		Default Setting Setting Options /)isplay	
3.8	> Language				
	Sets the display language for the top screen.	ITALIANO / ESP/ SWEDISH / NORW CZECH / NEDERL SUOMI / MAGYAR HRVATSKI / LIETU\ БЪЛГАРСКИ / EE ROMÂNĂ / SHQIF	ÇAIS / DEUTSCH / ÁÑOL / DANISH / VEGIAN / POLISH / ANDS / TÜRKÇE / SLOVENŠČINA / /IŲ / PORTUGUÊS / ESTI / LATVIEŠU / P / SLOVENČINA / AÏHCЬKA / E/\/HNIKA	Language ENGLISH FRANÇAIS DEUTSCH ITALIANO Select [+-	10:34am, Mon -] Confirm
3.9	> Unlock password				
	4 digit password for all the settings.	0000		Unlock password	10:34am, Mon
				\$Select [+]Confirm
4	Service contact				
4.1	> Contact 1 / Contact 2				
	Preset contact number for installer.	Select and retrieve		Service setup Contact 1 Name : Bryan A C : 088123 Select	

Ме	enu	Default Setting	Setting Options / D	isplay	
5	Installer setup > System setu	ıp			
5.1	> Optional PCB connectivity				
	To connect to the external PCB required for servicing.	No		Yes No	
	• If the external PCB is connected	(optional), the system wi	ill have following addition	al functions:	
	 Control over 2 zones (includ Solar function (the solar there DHW is not applicable for External compressor switch External error signal. SG ready control. Demand control. Heat-Cool SW 	mal panels connected to WH-ADC models.			or the Buffer Tank.
5.2	> Zone & Sensor				
	To select the sensors and to	Zone		Zone & Sensor	10:34am, Mon
	select either 1 zone or 2 zone	 After selecting 1 or 2 zone system, proceed to the selection of room or swimming pool. If the swimming pool is selected, the temperature must be selected for ∆T temperature between 0°C ~ 10 °C. Sensor For room thermostat, there is a further selection of external or internal. If select internal, there is a further selection of RC-1 or RC-2 (only available when Zone selection is 1 zone system). Select RC-1 if main remote controller's thermistor is to be used for room temperature control and vice versa. 		Zone	
	system.			1 Zone system 2 Zones system	
					10 0
				↓Select [+]Confirm
				Zone & Sensor Sensor	10:34am, Mon
				Water tem	perature
				Room the	
				Room the	Confirm
				• -	
5.3	> Heater capacity				
	To reduce the heater power if			Heater capacity	10:34am,Mon
	unnecessary.*			3 k	w
	3 kW / 6 kW / 9 kW				
	* Options of kW vary depending on the model.			[+-]Confirm
5.4	> Anti freezing				
	To activate or deactivate the water freeze prevention when the system is OFF	Yes		Yes No	-
5.5	> Tank connection				
	To connect tank to the system.	No		Yes No	

Menu	Default Setting	Setting Options / I	Display
5.6 > DHW capacity			
To select tank heating capacity to variable or standard. Variable capacity heat up tank with fast mode and keep the tank temperature with efficient mode. While standard capacity heat up tank with rated heating capacity.	Variable		Variable Standard
5.7 > Buffer tank connection	1		
To connect tank to the system and if selected YES, to set	No		Yes No
riangle T temperature.	> Yes	,	
	5 °C	Set ∆T for Buffer Tank	Buffer tank 10:34am,Mon △T for Buffer tank Range: (0°C~10°C) Steps: ±1°C 50°C
			\$Select [₊-]Confirm
5.8 > Tank heater			Tank heater 10:34am.Mon
To select external or internal tank heater and if External is selected, set a timer for the heater to come on. * This option is available if Tank connection is selected (YES).	Internal		Tank heater 10:34am,Mon External Internal ^Select [+-]Confirm
	> External		
	1:30	Tank heater ON time set.	Tank heater 10:34am,Mon Tank heater: ON time Range: (0:20~3:00) Steps: ±0:05 130 \$Select [+-]Confirm
5.9 > Base pan heater	-		
To select whether or not optional base pan heater is	No		Yes No
connected.	> Yes		
 * Type A - The base pan heater activates only during deice operation. * Type B - The base pan heater activates when outdoor ambient temperature is 5 °C or lower. 	A	Set base pan heater type*.	Base pan heater type 10:34am, Mon
5.10 > Alternative outdoor sensor	-		
To select an alternative outdoor sensor.	No		Yes No

5.11 > Bivalent connection

> Bivalent connection				
To select to enable or disable bivalent connection.	No		Yes No	
> Yes				
To select either auto control pattern or SG ready input control pattern or smart control pattern. - This selection only display to select when optional pcb connection set to Yes.	Auto		Auto SG ready Smart	/
To select a bivalent connection	> Yes > Auto			
to allow an additional heat source such as a boiler to heat- up the buffer tank and domestic hot water tank when heatpump capacity is insufficient at low	-5 °C	Set outdoor temperature for turn ON Bivalent connection.	Bivalent connection Turn ON: Outdoor te Range: (-15°C~35°C) Steps: ±1°C	
outdoor temperature. The bivalent feature can be set-up	Yes > After selecting	the outdoor temperatu	•	
either in alternative mode	Control pattern		Bivalent connection	10:34am, Mon
heatpump and boiler operate		I / Advanced parallel	Control pattern	
alternately), or in parallel mode (both heatpump and boiler operate simultaneously), or in advance parallel mode	Select advanced para the tanks.		Alternat Paralle Advanced p Select [+-]0	el 👘
(heatpump operates and boiler	Control pattern > Alte	ernative		
turns on for buffer-tank and/or domestic hot water depending on the control pattern setting options).	OFF	Option to set external pump either ON or OFF during bivalent operation. Set to ON if system is simple bivalent connection.	Bivalent connection External pump ON OFF *Select [+-]C	10:34am,Mon
	Control pattern > Adv	vanced parallel		
	Heat	Selection of the tank	Bivalent connection	10:34am, Mon
	"Heat" implies Buffer implies Domestic Hot		Advanced parallel Heat DHW	Confirm
	Control pattern > Adv	vanced parallel > Heat >		
	Buffer Tank is activate "Yes".		Bivalent connection Advanced parallel: H Yes No	10:34am, Mon eat
			-Select [+-]	Confirm

Menu

Default Setting Setting Options / Display

	-8 °C	Set the temperature threshold to start the bivalent heat source.	Bivalent connection 10:34am, Mon Heat start: Target temp. Range: (-10°C~0°C) Steps: ±1°C \$Select [+-]Confirm
	0:30	Delay timer to start the bivalent heat source (in hour and minutes).	Bivalent connection 10:34am, Mon Heat start: Delay time Range: (0:00~1:30) Steps: ±0:05
	-2 °C	Set the temperature threshold to stop the bivalent heat source.	Bivalent connection 10:34am, Mon Heat stop: Target temp. Range: (-10°C~0°C) Steps: ±1°C
	0:30	Delay timer to stop the bivalent heat source (in hour and minutes).	Select [+-] Confirm Bivalent connection 10:34am, Mon Heat stop: Delay time Range: (0:00~1:30) Steps: ±0:05 Steps: ±0:05
	 Control pattern > Advanced parallel > DHW > DHW Tank is activated only after selecting "Yes". 		Bivalent connection 10:34am, Mon Advanced parallel: DHW Yes No
			-Select [+-]Confirm
	0:30	Delay timer to start the bivalent heat source	Bivalent connection 10:34am, Mon DHW: Delay time Range: (0:30~1:30) Steps: ±0:05 0:30
		(in hour and minutes).	Select [₊-]Confirm
SG ready input control for	> Yes > SG ready		
bivalent system follow below input condition. SG signal Operation pattern Vcc-bit1 Vcc-bit2 Open Open Heat Pump OFF, Boiler OFF Heat Pump ON	OFF	Option to set external pump either ON or OFF during bivalent operation. Set to ON	Bivalent connection 10:34am,Mon External pump ON
Short Open Heat Pump OFF, Boiler OFF Open Short Heat Pump OFF, Boiler ON Short Short Heat Pump ON, Boiler ON		if system is simple bivalent connection.	OFF ^Select [+-] Confirm

Default Setting Setting Options / Display

To do settings related to	> Yes > Smart			
electricity and boiler so that unit is able to determine whether to operate heat pump or boiler at a particular period depends on operating cost of both heat sources. These settings are	OFF	Option to set external pump either ON or OFF during bivalent operation. Set to ON if system is simple bivalent connection.	Bivalent connection 10:34am,Mon External pump ON OFF OFF ^Select [+-] Confirm	
electricity price, boiler price,	> Yes > Smart > After	selecting for the extern	al pump > Energy price	
season, schedule etc.	- Select Electricity to s - Select Boiler to set of efficiency.	set on electricity price.	Bivalent connection 10:34am,Mon Energy price Electricity Boiler	
			-Select []Confirm	
	> Yes > Smart > After Electricity	selecting for the extern	al pump > Energy price >	
	 0.0 * / kWh There are total 10 different prices can be set for Electricity: Electricity price 1 ~ Electricity price 10 Range is 0 ~ 999.9 * / kWh Press ∧ or ∨ to enter a setting screen as shown in Figure 1. Then start setting the value of electricity price. After finish setting a particular electricity price (eg. Electricity price 1), press < or > to go and set for other electricity price. * Set the price according to value provided by electrical supply company. 		Bivalent connection 10:34am,Mon Electricity price 1 Range: (0~999.9 */kWh) Steps: ±0.1*/kWh Steps: ±0.1*/kWh	
			Figure 1 Bindent connection 10.24cm Mar F 0 0 0.0 C +>Select [+]Confirm	
	> Yes > Smart > After	selecting for the extern	al pump > Energy price > Boiler	
	0.0 * / kWh - Refer to method of El- above for setting of b - After finish setting of t boiler efficiency (Ran	oiler price. poiler price, set the	Bivalent connection 10:34am,Mon Boiler price Range: (0~999.9 */kWh) Steps: ±0.1*/kWh \$Select	
	0% * Set the price accordir boiler or gas supply c		Bivalent connection 10:34am,Mor Boiler efficiency Range: (0~99%) Steps: ±1%	
			\$Select [₊-]Confirm	

Remark : * implies cents in most currency except Czech crown.

Default Setting Setting Options / Display

Season 1 : Dec (Refers to Winter season)	Bivalent connec Schedule	tion 10:34am,Mor
Season 2 : Mar (Refers to Spring season)	Seaso	on setting ule setting
Season 3 : Jun (Refers to Summer season)	⊸ Select	[]Confirm
Season 4 : Oct (Refers to Autumn season) - There are total 4 seasons to be set	Bivalent connec	tion 10:34am,Mor
- Set the starting month for each	Season 1: Start	month
season. (Eg. when Season 1 is set to Dec and	Range: (Jan~De Steps: ±1month	·
Season 2 is set to Mar, month of December to February will be treated as Season 1).	<pre>\$Select</pre>	[₊-]Confirm
> Yes > Smart > After selecting for the exter	nai pump > Sched	aule > Scheaule
setting Start time (Pattern 1) : 3:00am	Rivalant connoc	
Start time (Pattern 1) : 3:00am	Bivalent connec	tion 10:34am,Mor
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am	Schedule setting	tion 10:34am,Mor g
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am Start time (Pattern 3) : 4:00pm	Schedule setting Se	tion 10:34am,Mor
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am Start time (Pattern 3) : 4:00pm Start time (Pattern 4) : 9:00pm	Schedule setting Se Se	ction 10:34am,Mor g eason 1
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am	Schedule setting Se Se Se	ction 10:34am,Mor g ason 1 ason 2
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am Start time (Pattern 3) : 4:00pm Start time (Pattern 4) : 9:00pm - For each season, there are total 4 patterns	Schedule setting Se Se Se	ction 10:34am,Mor g ason 1 ason 2 ason 3
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am Start time (Pattern 3) : 4:00pm Start time (Pattern 4) : 9:00pm - For each season, there are total 4 patterns can be set.	Schedule setting Se Se Se Select	ction 10:34am,Mor g ason 1 ason 2 ason 3 [⊷]Confirm
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am Start time (Pattern 3) : 4:00pm Start time (Pattern 4) : 9:00pm - For each season, there are total 4 patterns can be set. Price (Pattern 1/2/3/4) : 1	Schedule setting Se Se Se Select Season 1 Start time 1. 3:00am	tion 10:34am,Mor g ason 1 ason 2 ason 3 [⊷]Confirm 10:34am,Mor
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am Start time (Pattern 3) : 4:00pm Start time (Pattern 4) : 9:00pm - For each season, there are total 4 patterns can be set. Price (Pattern 1/2/3/4) : 1 - Set the target start time and the appropriate	Schedule setting Se Se Se Select Season 1 Start time 1. 3:00am 2. 9:00am	tion 10:34am,Mor g ason 1 ason 2 ason 3 []Confirm 10:34am,Mor Price(*/kWh) 0.0 0.0
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am Start time (Pattern 3) : 4:00pm Start time (Pattern 4) : 9:00pm - For each season, there are total 4 patterns can be set. Price (Pattern 1/2/3/4) : 1	Schedule setting Se Se Se Seect Season 1 Start time 1. 3:00am 2. 9:00am 3. 4:00pm	ttion 10:34am,Mo g ason 1 ason 2 ason 3 [⊶]Confirm 10:34am,Mo Price(*/kWh) 0.0 0.0 0.0
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am Start time (Pattern 3) : 4:00pm Start time (Pattern 4) : 9:00pm - For each season, there are total 4 patterns can be set. Price (Pattern 1/2/3/4) : 1 - Set the target start time and the appropriate	Schedule setting Se Se Se Seect Season 1 Start time 1. 3:00am 2. 9:00am 3. 4:00pm	tion 10:34am,Mor g ason 1 ason 2 ason 3 [-J]Confirm 10:34am,Mor Price(*/kWh) 0.0 0.0
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am Start time (Pattern 3) : 4:00pm Start time (Pattern 4) : 9:00pm - For each season, there are total 4 patterns can be set. Price (Pattern 1/2/3/4) : 1 - Set the target start time and the appropriate	Schedule setting Se Se Se Se Select Season 1 Start time 1. 3:00am 2. 9:00am 3. 4:00pm Select [Bjundent composition]	ttion 10:34am,Mor g ason 1 ason 2 ason 3 []Confirm 10:34am,Mor Price(*/kWh) 0.0 0.0 0.0
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am Start time (Pattern 3) : 4:00pm Start time (Pattern 4) : 9:00pm - For each season, there are total 4 patterns can be set. Price (Pattern 1/2/3/4) : 1 - Set the target start time and the appropriate	Schedule setting Se Se Se Select Season 1 Start time 1. 3:00am 2. 9:00am 3. 4:00pm Select [Birslont servers] S S	tion 10:34am,Mor g ason 1 ason 2 ason 3 [₊-]Confirm 10:34am,Mor Price(*/kWh) 0.0 0.0 0.0 0.0 0.0 0.0 0.0
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am Start time (Pattern 3) : 4:00pm Start time (Pattern 4) : 9:00pm - For each season, there are total 4 patterns can be set. Price (Pattern 1/2/3/4) : 1 - Set the target start time and the appropriate electricity price for each pattern. - Select "1" to edit both start time and	Schedule setting Se Se Se Select Season 1 Start time 1. 3:00am 2. 9:00am 3. 4:00pm Select [Birclast Second S Select Second S Select Second S Select Second S Second	tion 10:34am,Mo g ason 1 ason 2 ason 3 [₊-]Confirm 10:34am,Mo Price(*/kWh) 0.0 0.0 0.0 (₊-]Edit Select a & price
Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am Start time (Pattern 3) : 4:00pm Start time (Pattern 4) : 9:00pm - For each season, there are total 4 patterns can be set. Price (Pattern 1/2/3/4) : 1 - Set the target start time and the appropriate electricity price for each pattern.	Schedule setting Se Se Se Select Season 1 Start time 1. 3:00am 2. 9:00am 3. 4:00pm Select [Birslont servers] S S	tion 10:34am,Mo g ason 1 ason 2 ason 2 ason 3 [₊-]Confirm 10:34am,Mo Price(*/kWh) 0.0 0.0 0.0 0.0 0.0 (₊-]Edit Select a & price

Menu	Default Setting	Setting Options / D	lisplay	
	- Range of start time di or "am/pm" format de "Clock format".	splayed can be in "24h" pend on setting of	Season 1 Pattern 1: Start tin Range: (0.00~23. Steps: ±1hour	
			\$Select]Confirm
	indicates the previous price 1 to Electricity p * When the price is set price will be treated a	different electricity ander "Energy price > ectricity price 10). In the upper right corner as set value of Electricity rice 10. to "0", the electricity s 0.0 * / kWh. It is for staller when 0.0 is the	Season 1 Pattern 1: Price Range: (0~10) Steps: ±1 \$Select [.	10:34am,Mon 0.0 */kWh
5.12 > External SW				
	No			es No
5.13 > Solar connection				
 The optional PCB connectivity must be selected YES to 	No			es ▲
enable the function.If the optional PCB	> Yes			
 on the optional PCB connectivity is not selected, the function will not appear on the display. DHW is not applicable for WH-ADC models. 	Buffer tank	Selection of the tank	DHW	10:34am,Mon er tank ' tank
WI-ADO INOUCIS.			-Select [-	⊢]Confirm
	> Yes > After selectin	g the tank	Solar connection	10:24am Mon
	10 °C	Set ∆T ON temperature	<u>ΔT Turn ON</u> Range: (6°C~15°C Steps: ±1°C	10:34am,Mon
			\$Select [-	L]Confirm

Menu	Default Setting	Setting Options / I	Display	
	> Yes > After selectin	ig the tank > \triangle T ON ten	nperature	
	5 °C	Set ∆T OFF temperature	Solar connection ΔT Turn OFF Range: (2°C~9°C) Steps: ±1°C	10:34am, Mon
			•	Confirm
	> Yes > After selectin	ig the tank > \triangle T ON ten	-	temperature
	5 °C	Set Antifreeze temperature	Solar connection Anti freeze Range: (-20°C~10°C Steps: ±1°C	10:34am, Mon
		⊔ ng the tank >		
	80 °C	Set Hi limit	Solar connection Hi limit Range: (70°C~90°C) Steps: ±5°C	10:34am, Mon
			\$Select [+-]	Confirm
5.14 > External error signal	1	I		
	No		Yes No	
5.15 > Demand control				
	No		Yes No	
5.16 > SG ready	1	1		
	No		Yes No	
	> Yes	1		
	120 %	Capacity (1) & (2) of DHW (in %), Heat (in %) and Cool (in °C)	SG ready Capacity [1-0]: DHW Range: (50%~150% Steps: ±5%	5) 120 %
			\$Select [₊.]	Confirm
5.17 > External compressor SW			Yes	
	No		No	
5.18 > Circulation liquid	l			
To select whether to circulate water or glycol in the system.	Water		Circulation liquid Wate Glyce	
			-Select [₊.]	Confirm

save energy.

Menu	Default Setting	Setting Options / Display
5.19 > Heat-Cool SW		
	No	Yes No
5.20 > Force heater		
To turn on Force heater either manually (by default) or automatically.	Manual	Force heater 10:34am,N Auto Manual *Select [+-]Confirm
5.21 > Force defrost		
If auto selection is set, outdoor unit will start defrost operation if long heating hour operate during low outdoor temperature	Manual	Auto Manual
5.22 > Defrost signal		
To turn on defrost signal to stop fan coil during defrost operation (If defrost signal set to yes, bivalent function will not available to use)		Yes No
5.23 > Pump flowrate		
To set variable flow pump control or fix pump duty control.	∆T	AT Max. Duty
5.24 > DHW Defrost		
Allow system to run defrost by using hot water instead of room unit for better room comfort.	Yes	Yes
5.25 > Heating control		
To select unit operation condition whether to achieve set temperature faster or to	Comfort	Comfort Efficiency

17	T

Default Setting Setting Options / Display

5.26	> External meter		
-	To set which external meter to be used depends on meter connection. There are generation meters and various types of electricity meters. For generation meters, there are two connection systems :- a) One generation meter system : Heat-cool meter only	Heat-cool meter : No * Tank meter : No Elec. meter HP : No Elec. meter 1 (PV) : No Elec. meter 2 (Building) : No Elec. meter 3 (Reserve) : No * Only available if both Heat-cool meter and Tank connection are set to Yes.	External meter 10:34am,Mon Heat-Cool meter Tank meter Elec. meter HP Elec. meter 1 (PV) √Select [-+]Confirm External meter 10:34am,Mon Elec. meter HP Elec. meter HP Elec. meter HP Elec. meter 1 (PV) Elec. meter 1 (PV) Elec. meter 3 (Reserve) ^Select []Confirm
	b) Two generation meter	> Heat-cool meter	
	system : Heat-cool meter and Tank meter	 Set Heat-cool meter to Yes when this generation meter is connected. It is to measure energy generation of heat pump unit during heating and cooling only operation (one generation meter system) or during heating, cooling and DHW operation (two generation meter system). > Tank meter 	Yes No
		 Set Tank meter to Yes when this generation meter is connected. It is to measure energy generation of heat pump unit during DHW operation*. * Only available if both Heat-cool meter and Tank connection are set to Yes. Only set Tank meter to Yes when the connection is two generation meter system. 	Yes ▲ No
		> Elec. meter HP	
		 Set Elec. meter HP to Yes when this electricity meter is connected. It is to measure energy consumption of heat pump unit. 	Yes No
		> Elec. meter 1 (PV)	
		 Set Elec. meter 1 (PV) to Yes when this electricity meter is connected. It is to measure energy generation of solar system. This data will be displayed only on Cloud system. 	Yes ▲ No
		> Elec. meter 2 (Building)	
		 Set Elec. meter 2 (Building) to Yes when this electricity meter is connected. It is to measure energy consumption of the building. This data will be displayed only on Cloud system. 	Yes No

Menu	Default Setting	Setting Options / Display	
	> Elec. meter 3 (Rese	rve)	
	 Set Elec. meter 3 (Reselectricity meter is correctly is to measure energed ata will be displayed 	nected. y consumption. This	Yes No
Remark : Elec. stands for "Electricity" HP stands for "Heat pump"			
5.27 > *1 Electrical anode			
To enable or disable operation of electrical anode.			Yes No

*1 It is used when supplying power to the electric anode of optional parts from inside the equipment.

Ме	enu	Default Setting	Setting Options / D)isplay	
6	Installer setup > Operation s	etup			
	To access to the four major functions or modes.	4 main	modes *1, *2 Auto / *3 Tank	Operation setup Heat Cool Auto Tank - Select [+	10:34am,Mon JConfirm
6.1	> Heat	1			
	To set various water & ambient temperatures for heating.	Water temp. for heating ON / Outdoor temp. for heating OFF / △T for heating ON / Heater ON/OFF		Operation setup Heat Water temp. for h Outdoor temp. for ∆T for heating Ol ↓Select [+	r heating OFF
		> Water temp. for hea	ating ON	1	
		Compensation curve	Heating ON temperatures in compensation curve or direct input.	Operation setup Heat ON: Water te Compensa Dire Select [+	tion curve
		> Water temp. for heating ON > Compensation curve			
		X axis: -5 °C, 15 °C Y axis: 55 °C, 35 °C	Input the 4 temperature points (2 on horizontal X axis, 2 on vertical Y axis).	Heat ON: Water ter 55°C ⁷⁵ 35°C ₂₀ -20 -5°C √⇒Select [+	np.:Zone1
		Temperature range fo WH-WDG model: 20 Regardless of the abo the operating conditio If 2 zone system is se 2.	°C ~ 75 °C ove setting, there is a limi	it to the water tempe e points must also b	e input for Zone
		> Water temp. for hea	ating ON > Direct		
		35 °C	Temperature for heating ON	Operation setup Heat ON: Water ter Range: (20°C~75°C Steps: ±1°C	c)
				\$Select [₊]Confirm
		the operating conditio • If 2 zone system is se	°C ~ 75 °C ove setting, there is a limi	point must input for 2	Zone 2.

*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners. *2 Only displayed when COOL mode is unlocked (This means when COOL mode is available). *3 Only displayed when Tank connection is Yes. Menu

Default Setting Setting Options / Display

laartamp for h	ooting OEE	
		Display

	> Outdoor temp. for heating OFF			
			Operation setup Heat OFF: Outdoor	10:34am, Mon temp.
	24 °C	Temperature for heating OFF	Range: (5°C~35°C) Steps: ±1°C	24 °C
			\$Select [₊-]	Confirm
	> △T for heating ON	ĺ		
	5 °C	Set △T for heating ON. * This setting will not available to set when pump flowrate set to Max. duty.	Operation setup Heat ON: ∆T Range: (1°C~15°C) Steps: ±1°C \$Select [+-]	10:34am, Mon 5 ℃ Confirm
	> Heater ON/OFF	Max. duty.		
		Outdoor temp. for heater	ON	
			Operation setup	10:34am,Mon
	0 °C	Temperature for heater ON	Heater ON: Outdoor Range: (-20°C~15°C Steps: ±1°C	temp.
			\$Select [₊-]	Confirm
	> Heater ON/OFF > D	elay time for heater ON		
	0:30 min	Delay time for heater to turn on	Operation setup Heater ON: Delay ti Range: (0:10~1:00) Steps: ±0:10	10:34am,Mon me 0:30
			\$Select [₊-]	Confirm
	> Heater ON/OFF > V	Vater temperature for he	·	comm
			Operation setup	10:34am,Mon
	-4 °C	Setting of water temperature to turn on from water set	Heater ON: ΔT of ta Range: (-10°C~-2°C) Steps: ±1°C	arget Temp.
		temperature.	\$Select [₊-]	Confirm
	> Heater ON/OFF > V	Vater temperature for he	• • •	
			Operation setup	10:34am,Mon
	-2 °C	Setting of water temperature to turn off from water set temperature.	Heater OFF: ∆T of t Range: (-8°C~0°C) Steps: ±1°C	arget Temp.
			\$Select [₊-]	Confirm
6.2 >* ^{1, *2} Cool	1			
To set various water & ambient temperatures for cooling.		res for cooling ON cooling ON.	Operation setup Cool Water temp. for coo AT for cooling ON	10:34am, Mon bling ON
			-Select [₊-]	Confirm

*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners. *2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

Menu	Default Setting	Setting Options / D	lisplav
			портау
	> Water temp. for con	Cooling ON temperatures in compensation curve or direct input.	Operation setup 10:34am, Mon Cool ON: Water temp. Compensation curve Direct
	> Water temp, for co	∣ oling ON ≻ Compensatio	· · · ·
	X axis: 20 °C, 30 °C Y axis: 15 °C, 10 °C	Input the 4 temperature points (2 on horizontal X axis, 2 on vertical Y axis)	Cool ON: Water temp: Zone1 15°C 20 10°C 5 15 20°C 30°C 30 ↓ Select [] Confirm
	2.	•	e points must also be input for Zone isplay if only 1 zone system.
	> Water temp. for co		
	10 °C	Set temperature for Cooling ON	Operation setup10:34am, MonCool ON: Water temp.: Zone2Range: (5°C~20°C)Steps: ±1°C
			\$Select [←]Confirm woint must input for Zone 2. isplay if only 1 zone system.
	> △T for cooling ON		
	5 °C	Set △T for cooling ON * This setting will not available to set when pump flowrate set to	Operation setup 10:34am, Mon Cool ON: ΔT Cool ON: ΔT Range: (1°C~15°C) 5 Steps: ±1°C 5
		Max. duty.	\$Select [₊-]Confirm
6.3 > *1, *2 Auto	1		
Automatic switch from Heat to Cool or Cool to Heat.		o for switching from Heat Cool to Heat.	Operation setup 10:34am, Mon Auto Outdoor temp. for (Heat to Cool)
	Outdoor temp. for (Heat to Cool) / Outdoor temp. for (Cool to Heat)		Outdoor temp. for (Cool to Heat) ↓Select [↓]Confirm
	> Outdoor temp. for	(Heat to Cool)	
	15 °C	Set outdoor temperature for switching from Heat to Cool.	Operation setup10:34am, MorAuto: Outdoor temp.(Heat to Cool)Range: (11°C~25°C)Steps: ±1°C
			\$Select [₊]Confirm

^{*1} The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners. *2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

Menu	Default Setting	Setting Options / D	isplay
	> Outdoor temp. for	(Cool to Heat)	
	10 °C	Set outdoor temperature for switching from Cool to Heat.	Operation setup 10:34am, Mon Auto: Outdoor temp.(Cool to Heat) Range: (5°C~14°C) Steps: ±1°C \$Select []Confirm
6.4 >*1 Tank		1	• • • •
Setting functions for the tank.	Floor operation time (max) / Tank heat up time (max) / Tank re-heat temp. / Sterilization		Operation setup 10:34am, Mon Tank Floor operation time (max) Tank heat up time (max) Tank re-heat temp. ↓Select [+-] Confirm
	The display will show		
	> Floor operation time	ne (max)	
	8:00	Maximum time for floor operation (in hours and minutes)	Operation setup 10:34am, Mon Tank: Floor ope. time (max) Range: (0:30~10:00) Steps: ±0:30
			\$Select [₊-]Confirm
	> Tank heat up time (max)		
	1:00	Maximum time for heating the tank (in hours and minutes)	Operation setup10:34am, MonTank: Heat up time (max)Range: (0:05~4:00)Steps: ±0:05
			\$Select [₊-]Confirm
	> Tank re-heat temp.	T	
	-8 °C	Set temperature to perform reboil of tank water.	Operation setup10:34am, MonTank: Re-heat temp.Range: (-12°C~-2°C)Steps: ±1°C
			\$Select [₊-]Confirm
	> Sterilization	1	
	Monday	Sterilization may be set for 1 or more days of the week.	Operation setup 10:34am, Mon Sterilization: Day Sun Mon Tue Wed Thu Fri Sat
		Sun / Mon / Tue / Wed / Thu / Fri / Sat	→ Day ↓
	> Sterilization: Time		
	12:00	Time of the selected day(s) of the week to sterilize the tank	Operation setup 10:34am,Mon Sterilization: Time
		0:00 ~ 23:59	Select [→] Confirm

r	
¹ *1 Only displayed when Tank connection is Yes.	!


Menu

Default Setting Setting Options / Display


> Sterilization: Boiling temp. Operation setup 10:34am,Mon Sterilization: Boiling temp. Set boiling temperatures for Range: (55°C~65°C) 65 °C 65 °C Steps: ±1°C sterilize the tank. - Select [₊-]Confirm > Sterilization: Ope. time (max) 10:34am, Mon Operation setup Sterilization: Ope. time (max) Set sterilizing time Range: (0:05~1:00) 0:10 (in hours and minutes) Steps: ±0:05 0:10 \$Select [₊-]Confirm

7 Installer setup > Service setu	qu			
7.1 > Pump maximum speed				
To set the maximum speed of the pump.		nax. duty and operation f the pump.	Service setup Flow rate Max. D	10:34am, Mon Outy Operation
	Flow rate: XX:X L/min Max. Duty: 0x40 ~ 0xFE,			E Air Purge
	Pump: ON/C)FF/Air Purge	✓ Select	
7.2 > Dry concrete				
To dry the concrete (floor, walls, etc.) during construction.	Edit to set the temperature of dry concrete.		Service setup Dry concrete	10:34am,Mon
Do not use this menu for any other purposes and in period	ON	/ Edit	ON Edit	t
other than during construction			-Select [₊-]	Confirm
	> Edit			
		Heating temperature	Service setup	10:34am, Mon
		for drying the	Dry concrete: 1/10	
	Stages: 1 Temperature: 25 °C	concrete. Select the desired stages: 1 ~ 10,	Range: (25°C~55°C) Steps: ±1°C	25 °C
		range: 1 ~ 99	^Select [₊-]	Confirm
	> ON			
	Confirm the setting	temperatures of dry	Service setup	10:34am, Mon
	concrete for each stage.		Dry concrete: Status	S
			Stage Water set temp. Actual water temp.	: 1/10 : 25℃ :25℃/25℃
			[O] OFF	

Menu	Default Setting	Setting Options / D	lisplay
7.3 > Service contact			
To set up to 2 contact names and numbers for the User.	Service engineer's nar	me and contact number.	Service setup 10:34am, Mon Service contact: Confact 1
	Contact 1	/ Contact 2	Contact 2 ↓Select [+-]Confirm
	> Contact 1 / Contact	t 2	
		ne or number.	Service contact 10:34am, Mon Contact 1 Name : Bryan Adams
	Name / p	ohone icon	€ : 08812345678 ↓Select [+-]Edit
	Input name and number		Contact-1 ABC/abc 0-9/Other ABCDEFGHIJKLMNOPQR Space STUVWXYZ abcdefghi BS jklmnopqrstuvwxyz Conf ₄→Select [₄-]Enter
		: alphabet a ~ z. ımber: 1 ~ 9	Number: 2 3 (4 5 6) 7 8 9 - 7 8 9 - BS * 0 # _ Conf 4 >Select []Enter
	4		
8 Installer setup > Remote con	itrol setup	1	
 To select whether to use one remote controller or two remote controllers. Select Single when one remote controller is 		Selection of one or two remote controllers.	Single Dual
connected. Select Dual when two remote controllers are connected. Second remote controller can be used for zone 2 room temperature control.	Single	When Dual is selected, Main remote controller (RC-1) will start to communicate with second remote controller (RC-2) and display "RC-1 & RC-2 sync. in progress".	RC-1 & RC-2 sync. in progress!
		They are ready to be used after this pop up screen disappears. When both remote	
		controllers have communication failure, it will display	Communication with RC-2 failed!
		"Communication with RC-2 failed".	[±]Close




5.2 Outdoor Unit




6. Dimensions

6.1 Indoor Unit




6.2 Outdoor Unit



7. Refrigeration and Water Cycle Diagram


OUTDOOR UNIT



·····► REFRIGERANT CYCLE [COOLING]


TH1	Outdoor discharge sensor
TH2	-
TH3	Outdoor heat exchanger sensor
TH4	Outdoor ambient sensor
TH5	Evaporator outlet sensor
TH6	Refrigerant sensor
TH7	Water inlet 2 sensor
TH8	Water outlet sensor 2
TH9	Outdoor heat exchanger middle sensor
TH10	Bypass outlet sensor
TH11	Bypass inlet sensor
TH12	Economizer outlet sensor

8. Block Diagram




9. Wiring Connection Diagram

9.1 Indoor Unit



9.2 Outdoor Unit




Resistance of Compressor Windings


MODEL	WH-WXG09ME8 / WH-WXG12ME8 / WH-WXG16ME8
CONNECTION	7CD081ZA02
U - V	0.261 Ω
V - W	0.261 Ω
U - W	0.261 Ω

Note: Resistance at 20°C of ambient temperature.

10. Electronic Circuit Diagram

10.1 Indoor Unit







11. Printed Circuit Board

11.1 Indoor Unit

11.1.1 Main Printed Circuit Board




11.1.2 Sub Printed Circuit Board (Optional)




11.2 Outdoor Unit


11.2.1 Main Printed Circuit Board



11.2.2 Noise Filter Printed Circuit Board



11.2.3 Sub Printed Circuit Board




12. Installation Instruction

Attached Accessories

No.	Accessories part	Qty.
1	Installation plate	1
2	Network adaptor (CZ-TAW1*)	1

Optional Accessories

No.	Accessories part	Qty.
3	Remote controller Case (PAW-A2W-COV-KL)	1
4	Extension Cable (CZ-TAW1-CBL)	1
5	Optional PCB (CZ-NS7P)	1
6	Remote controller (CZ-RTW2-1) ^{*1}	1



^{*1} If you need the 2nd remote controller, buy 6 and set it up.

Field Supply Accessories (Optional)

No.	Part		Model	Specification	Manufacturer
	2-way valve kit	Electromotoric Actuator	SFA21/18	AC230V, 12 VA	Siemens
*Cooling model		2-port Valve	VXI46/25	-	Siemens
ii 3-way valve kit	2 way yalva kit	Electromotoric Actuator	SFA21/18	AC230V, 12 VA	Siemens
	S-way valve kit	3-port Valve	VVI46/25	-	Siemens
iii	Room thermostat	Wired	PAW-A2W-RTWIRED	100001/	-
		Wireless	PAW-A2W-RTWIRELESS	AC230V	
iv	Mixing valve	-	13020800	AC 230V, 5 VA	ESBE
v	Pump	-	Yonos Pico 1.0 25/1-8	AC 230V, 0.6 A max	Wilo
vi	Buffer tank sensor	-	PAW-A2W-TSBU	-	-
vii	Outdoor sensor	-	PAW-A2W-TSOD	-	-
viii	Zone water sensor	-	PAW-A2W-TSHC	-	-
ix	Zone room sensor	-	PAW-A2W-TSRT	-	-
х	Solar sensor	-	PAW-A2W-TSSO	-	-
xi	Outlet water sensor	-	PAW-A2W-TSBH	-	-

■ It is recommended to purchase the field supply accessories listed in above table.


12.1 Indoor Unit

12.1.1 Select the Best Location

Obtain customer's approval before deciding the installation location.


- Ensure that there are no heat sources or vapours near the Indoor Unit.
- Good air circulation in the room.
- Ensure to keep distance of spaces as illustrated below from walls, ceilings, or other obstacles.
- A place where flammable gas leaking might not occur.
- The Indoor Unit must be installed on a vertical wall.
- When installing electrical equipment in a wooden building of metal lath or wire lath, according to electrical facility technical standards, no electrical contact between equipment and building is allowed. An insulator must be installed in between them.
- Do not install the Indoor Unit at outdoor. This is designed for indoor installation only.

12.1.1.1 Required Space for Installation



12.1.1.2 Installation Position

The mounting wall is strong and solid enough to prevent it from vibration.



The centre of the installation plate should be more than 360 mm from the right and left of the wall.

The distance from the installation plate edge to the ground should be more than 1200 mm.

 Always mount the installation plate horizontally by aligning the marking thread and using a level gauge. Mount the installation plate on the wall with 3 sets of plug, screw, and washer with size M6 (field supply). The combined thickness of the screw head and washer must be less than 6 mm.


12.1.2 Install the Indoor Unit and Open the Front Cover

🕂 WARNING

This section is for authorized and licensed electrician only.
 Work behind the front cover ① secured by screws must only be carried out under the supervision of a qualified contractor, installation engineer, or service person.

12.1.2.1 Hang the Indoor Unit on the Installation Plate

- 1. Engage the slots on the Indoor Unit to the hooks of installation plate 1.
- 2. Ensure the hooks are properly seated on the installation plate by moving it left and right.




12.1.2.2 Open the Front Cover

Before opening the front cover (1) of the Indoor Unit, always switch off all power supplies (e.g. the Indoor Unit power supply, the outdoor unit power supply, and the heater power supply).

- 1. Remove the 2 mounting screws located at the top of the enclosure (2).
- Gently pull the upper section of the front cover (1) towards you.
 (The front cover will stops once it has opened


about 2 degrees.)

3. Gently rotate the front cover ① to open 180 degrees.




12.1.2.3 Fix the Indoor Unit

Fasten two screws (M6) at the bottom holes of the Indoor Unit.



12.1.2.4 An Example of System Installation



12.1.3 Connect the Cable to the Indoor Unit

🔨 WARNING

This section is for authorized and licensed electrician only. Work behind the front cover (1) (secured by screws) must only be carried out under the supervision of a qualified contractor, installation engineer, or service person.

1. Remove the terminal cover.

Remove one screw from the terminal cover (9), and move it upward.

2. Connect the power supply cable.


The specification of the power supply cable must be as follows:

- Cable size: 5 x min 1.5 mm²
- Cable type: 60245 IEC 57 or heavier, with an approved polychloroprene sheath.

• The earth wire must be longer than other wires. The specification of the isolating device (disconnecting means) and RCD must be as follows:

- The isolating device: 20A
- Recommended RCD: 30mA, 4P, type A
- The isolating device must be connected to the power supply cable.
- The isolating device must have a contact gap of at least 3.0 mm.

The method of wiring a cable is shown below. Go through the cable from the left squared bushing hole.



Terminal screw Tightening torque cN•m {kgf•cm}

Terminal solew	rightening torque or in [tgi on]
M4	157~196 {16~20}
M5	196~245 {20~25)


*1 - Earth wire should be longer than other cables for safety reasons

Terminals of RCCB/ELCB tightening torque cN•m {kgf•cm}	160~200 {16.3~20.4}	
Holder tightening torque cN•m {kgf•cm}	70~130 {7.1~13.3}	

3. Connect the ID-OD communication cable. The specification of the ID-OD communication cable must be as follows:

- Cable size: 2 x min 0.75 mm²
- Cable type: 60245 IEC 57 or heavier, with a double-insulated approved polychloroprene sheath.

The method of wiring a cable is shown below. Go through the cable from the left squared bushing hole.



Terminal screw	Tightening torque cN•m {kgf•cm}
M4	157~196 {16~20}
M5	196~245 {20~25)

4. Assemble the terminal cover. Reverse step 1.

Tightening torque cN•m {kgf•cm}	98.1 {10.2}	
---------------------------------	-------------	--

12.1.3.1 Compliance with IEC/EN 61000-3-2 and IEC/EN 61000-3-3

- The power supply of this Indoor Unit complies with IEC/EN 61000-3-2.
- The power supply of this Indoor Unit complies with IEC/EN 61000-3-3, and it can be connected to the current supply network.

12.1.3.2 External Heater


External heater can be used as an In-line heater or a buffer tank heater.

- Connect a heater of 9kW (3kW x 3) or less.
- Each heater shall be equipped with an 85°C OLP that can directly turn OFF the power supply. The OLP shall be non-automatic return type.
- The external heater shall be equipped with an 85°C OLP for signal line. The OLP can be either automatic or non-automatic return type.
- Using it as an In-line heater, be sure to install Optional outlet water sensor (PAW-A2W-TSBH) at the heater outlet.
- Using it as a buffer tank heater, be sure to install Optional Buffer tank sensor (PAW-A2W-TSBU).
- Ground the In-line heater body or buffer tank body in case of electrical leakage. (See illustration below)


🔨 WARNING

Incorrect electrical work may result in electric shock or fire. Please follow this installation manual.

How to connect to the main circulation circuit as an In-line heater



How to connect to the buffer tank as a buffer tank heater



The connecting cable between the external heater (in-line heater or buffer tank heater) and the Indoor Unit should be a double-insulated approved polychloroprene sheathed cord with type designation 60245 IEC 57 or heavier.

Cable size is 1.5mm² or more.

Maximum cable length of OLP for signal and outlet water sensor: 30m

The tightening torque for the terminals are as shown in the table below.


Terminal screw	Tightening torque cN•m {kgf•cm}	
M4	157~196 {16~20}	
M5	196~245 {20~25)	

- The heater capacity is designed to be 3kW per element.
- For example, if the heater specification is 1kW or 2kW, the display will be worse than the actual COP. (1kW is 1/3 COP of 3kW)


Note: The data calculated by Energy Monitor or COP may be different from the actual value if the capacity is different from 3kW.

12.1.3.3 Wire Stripping and Connecting Requirement

Terminal size	Ø d [mm]	A [mm]
M4	4.2 or more	10.0 or less
M5	5.2 or more	12.5 or less



12.1.3.4 Cable Arrangement



Terminal 1 6


12.1.4 Connect to External Device (Optional)

This section is for authorized and licensed electrician only. Work behind the front cover (1) secured by screws must only be carried out under the supervision of a qualified contractor, installation engineer, or service person.

12.1.4.1 Cable Specification

- All connections shall be followed the local national wiring standard.
- It is strongly recommended to use manufacturerrecommended parts or accessories for installation.
- Connection to PCB ④.
- 2-way valve shall be spring and electronic type. Refer to "Field Supply Accessories" table for details. Valve cable shall be 3 x min 1.5 mm² of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
 - * Note: It shall be CE marking compliance component.
 - Maximum load for the valve is 12VA.
- 3-way valve shall be spring and electronic type. Valve cable shall be 3 x min 1.5 mm² of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
 - * Note: It shall be CE marking compliance component.
 - It shall be directed to heating mode when it is OFF.
 - Maximum load for the valve is 12VA.
- Room thermostat zone 1 cable must be 4 or 3 x min 0.5 mm² of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
- Maximum output power of booster heater shall be 3 kW. Booster heater cable must be 3 x min 1.5 mm² of type designation 60245 IEC 57 or heavier.
- 5. Extra pump cable shall be 2 x min 1.5 mm² of type designation 60245 IEC 57 or heavier.
- Boiler contact cable/ defrost signal cable shall be 2 x min 0.5 mm² of type designation 60245 IEC 57 or heavier.
- External control shall be connected to 1-pole switch with min 3.0 mm contact gap. Its cable must be 2 x min 0.5 mm² double insulation layer of PVC-sheathed or rubber-sheathed cable.
 - * Note: The switch shall be CE compliance component.
 - Maximum operating current shall be 3Arms.
- Tank sensor shall be resistance type. See the graph below for the characteristic and details of sensor. Its cable shall be 2 x min 0.3 mm² double insulation layer (with insulation strength of min 30V) of PVC-sheathed or rubber-sheathed cable.


Tank Sensor Resistance Vs Temperature



Tank sensor characteristic


- Room sensor zone 1 cable shall be 2 x min
 0.3 mm² double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 10. Outdoor air sensor cable shall be 2 x min 0.3 mm² double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 11. Tank OLP cable must be 2 x min 0.5 mm² double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 12. Buffer tank sensor cable shall be 2 x min 0.3 mm² double insulation layer of PVC-sheathed or rubber-sheathed cable.
- Connection to Optional PCB 5.
- 1. Before connecting the cables to Optional PCB, remove the network adaptor holder (12) (Refer to the installation manual of CZ-NS7P for details).
- Pump zone 1 and zone 2 cable shall be 2 x min 1.5 mm² of type designation 60245 IEC 57 or heavier.
- 3. Solar pump cable shall be 2 x min 1.5 mm² of type designation 60245 IEC 57 or heavier.
- 4. Pool pump cable shall be 2 x min 1.5 mm² of type designation 60245 IEC 57 or heavier.
- Room thermostat zone 2 cable shall be 4 x min 0.5 mm² of type designation 60245 IEC 57 or heavier.
- Mixing valve zone 1 and zone 2 cable shall be 3 x min 1.5 mm² of type designation 60245 IEC 57 or heavier.
- Room sensor zone 1 and zone 2 cable shall be 2 x min 0.3 mm² double insulation layer (with insulation strength of minimum 30V) of PVCsheathed or rubber-sheathed cable.
- Pool water sensor and solar sensor cable shall be 2 x min 0.3 mm² double insulation layer (with insulation strength of minimum 30V) of PVCsheathed or rubber-sheathed cable.
- Water sensor zone 1 and zone 2 cable shall be 2 x min 0.3 mm² double insulation layer of PVCsheathed or rubber-sheathed cable.
- Demand signal cable shall be 2 x min 0.3 mm² double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 11. SG signal cable shall be 3 x min 0.3 mm² double insulation layer of PVC-sheathed or rubber-sheathed cable.
- Heat/Cool switch cable shall be 2 x min 0.3 mm² double insulation layer of PVC-sheathed or rubber-sheathed cable.

- External compressor switch cable shall be 2 x min 0.3 mm² double insulation layer of PVC-sheathed or rubber-sheathed cable.
- How to access the Optional PCB 5.




12.1.4.2 Cable Arrangement

How to guide the optional cables and power supply cord connecting (view without internal wiring)



Terminal screw	Tightening torque cN•m {kgf•cm}
M4	157~196 {16~20}
M5	196~245 {20~25)




- Bushing hole A is used for power supply cable (including external heater power supply), outlet water sensor cable, OLP for signal line cable and ID-OD communication cable
- Bushing hole B and C are used for
- Pump zone 1 cable
- Pump zone 2 cable
- Solar pump cable
- Pool pump cable
- Room thermostat zone 1 cable
- Room thermostat zone 2 cable
- Booster heater cable
- Mixing valve zone 1 cable
- Mixing valve zone 2 cable
- 2-way valve cable
- 3-way valve cable
- Extra pump cable
- Boiler contact cable
- Defrost signal cable
- Bushing hole D and E are used for
- External control cable
- Outdoor air sensor cable
- Remote controller cable
- Room sensor zone 1 cable
- Room sensor zone 2 cable
- Buffer tank sensor cable
- Pool water sensor cable
- OLP for booster heater cable
- Water sensor zone 1 cable
- Water sensor zone 2 cable
- Demand signal cable
- Solar sensor cable
- SG signal cable
- Heat/Cool switch cable
- External compressor switch cable
- Ensure all sensor cables are not in touching the front panel.
- Once all wiring work is done, tie the cable with the banding strap (field supply).

12.1.4.3 Cable Length

When connecting cables between the Indoor Unit and external devices, the length of the cables must not exceed the maximum length as shown in the table below.

External device	Maximum cable length [m]
2-way valve, 3-way valve, Mixing valve, Room Thermostat, Booster heater, Extra pump, Solar pump, Pool pump, Zone pump, Boiler contact/Defrost signal, External control, Demand signal, SG signal, Heat/Cool switch, External compressor switch	50
Room sensor, Outdoor air sensor, Buffer tank sensor, Pool water sensor, Solar sensor, Zone water sensor	30

12.1.4.4 Connection of PCB



Signal inputs

Optional thermostat	L N=AC230V, Heat, Cool=Thermostat heat, Cool terminal
OLP for booster heater	Dry contact Vcc-Bit1, Vcc-Bit2 open/short (System setup necessary) It is connected to the safety device (OLP) of DHW tank.
External control	Dry contact Open=not operate, Short=operate (System setup necessary) Able to turn ON/OFF the operation by external switch
Remote controller	Connected (Use 2 cores wire for relocation and extension. Total cable length shall be 50m or less.)


Thermistor inputs

Zone 1 room sensor	PAW-A2W-TSRT
Outdoor air sensor	PAW-A2W-TSOD
Tank sensor	Use Panasonic specified part
Buffer tank sensor	PAW-A2W-TSBU

Outputs

3-way valve	AC230V N=Neutral Open, Close=direction (For circuit switching when connected to DHW tank)
2-way valve	AC230V N=Neutral Open, Close (Prevent water circuit pass through during cooling mode)
Extra pump	AC230V (Used when Indoor Unit pump capacity is insufficient)
Booster heater	AC230V (Used when using booster heater in DHW tank)
Boiler contact/ Defrost signal	Dry contact (System setup necessary)

12.1.4.5 Connection of Optional PCB (CZ-NS7P)



Signal inputs

Optional Thermostat	L N =AC230V, Heat, Cool=Thermostat heat, Cool terminal
SG signal	Dry contact Vcc-Bit1, Vcc-Bit2 open/short (System setup necessary) Switching SW (Connect to the 2 contacts controller)
Heat/Cool SW	Dry contact Open=Heat, Short=Cool (System setup necessary)
External comp. SW	Dry contact Open=Comp.OFF, Short=Comp.ON (System setup necessary)
Demand signal	DC 0~10V (System setup necessary) Connect to the DC 0~10V controller.

Thermistor inputs

Zone room sensor	PAW-A2W-TSRT
Pool water sensor	PAW-A2W-TSHC
Zone water sensor	PAW-A2W-TSHC
Solar sensor	PAW-A2W-TSSO


Outputs

Mixing valve	AC230V N=Neutral Open, Close=mixture direction Operating time: 30s~120s	AC230V, 6 VA
Pool pump	AC230V	AC230V, 0.6 A max.
Solar pump	AC230V	AC230V, 0.6 A max.
Zone pump	AC230V	AC230V, 0.6 A max.


12.1.4.6 Recommended External Device Specification

This section explains about the external devices (optional) recommended by Panasonic. Always ensure to use the correct external device during system installation.


- Optional sensor.
- Buffer tank sensor: PAW-A2W-TSBU Use it to measure the buffer tank temperature. Insert the sensor into the sensor pocket on the tank.




 Zone water sensor: PAW-A2W-TSHC Use it to measure the control zone temperature. Mount it on the water piping by using the stainless steel metal strap and contact paste (both are included).




 Outdoor air sensor: PAW-A2W-TSOD If the installation location of the outdoor unit is exposed to direct sunlight, the outdoor air temperature sensor will be unable to measure the actual outdoor ambient temperature correctly.



4. Room sensor: PAW-A2W-TSRT Install the room temperature sensor to the room where the temperature control is required.



5. Solar sensor: PAW-A2W-TSSO Use it to measure the solar panel temperature. Insert the sensor into the sensor pocket and paste it on the solar panel surface.




See the table below for the characteristic of the sensors (No. 1 to 5).

Temperature (°C)	Resistance value (kΩ)
30	5.326
25	6.523
20	8.044
15	9.980
10	12.443
5	15.604
0	19.70
-5	25.05
-10	32.10
-15	41.45
-20	53.92
-25	70.53
-30	93.05
-35	124.24
-40	167.82

Temperature (°C)	Resistance value (kΩ)
150	0.147
140	0.186
130	0.236
120	0.302
110	0.390
100	0.511
90	0.686
80	0.932
70	1.279
65	1.504
60	1.777
55	2.106
50	2.508
45	3.003
40	3.615
35	4.375

 Outlet water sensor: PAW-A2W-TSBH Use it to detect the water temperature of the In-line heater outlet water. Mount it on the water piping by using the stainless steel metal strap and contact paste (both items are included).



See the table below for the characteristic of the outlet water sensor (No. 6).


Temperature (°C)	Resistance value (kΩ)
30	16.07
25	20.00
20	25.07
15	31.67
10	40.35
5	51.85
0	67.24
-5	88.05
-10	116.49
-15	155.80
-20	210.77
-25	288.63
-30	400.41
-35	563.15
-40	803.72

Temperature (°C)	Resistance value (kΩ)
150	0.40
140	0.50
130	0.63
120	0.81
110	1.06
100	1.40
90	1.87
80	2.54
70	3.52
65	4.17
60	4.97
55	5.96
50	7.18
45	8.70
40	10.60
35	13.01

 Optional pump Each power supply: AC230V/50Hz, 0.6Amax Total power supply: Less than 500W Recommended part: Yonos Pico 1.0 25/1-8: Manufactured by Wilo




 Optional mixing valve Power supply: AC230V/50Hz, 5VA (Input open/Output close) Operating time: 120 seconds. Recommended part: 13020800: Manufactured by ESBE




12.1.4.7 Network Adaptor 2 Installation

- 1. Insert a flathead screwdriver into the slot on the network adaptor and remove the cover.
- 2. Connect cable coming out from the left side of the network adaptor holder to the connector inside the network adaptor.



3. Pull the CN-CNT cable through the hole in the bottom of the network adaptor and re-attach the front cover to the back cover.




4. Fix the network adaptor 2 to network adaptor holder.

Guide the cable as shown in the diagram so that external forces cannot act on the connector in the network adaptor.


12.1.4.8 Connection of M-Bus, Modbus or KNX

When connecting devices such as Panasonic A2W compatible M-Bus or Modbus, it is necessary to change the connection position of the network adaptor on the PCB.



- 1. Replace the lead wire connector of the network adaptor connected to CN-CNT2 with CN-CNT.
- 2. Insert the M-Bus or Modbus, etc. lead wire connector into CN-CNT2.

When connecting Optional PCB to devices such as M-Bus or Modbus, it is necessary to change the connection position of the network adaptor on the PCB.



- 1. Insert the Optional PCB lead wire connector into CN-CNT.
- Replace the lead wire connector of the network adaptor connected to CN-CNT2 with CN-CNT on Optional PCB.
- 3. Insert the M-Bus or Modbus, etc. lead wire connector into CN-CNT2.

12.1.5 Install Remote Controller as Room Thermostat

This section is for authorized and licensed electrician only. Work behind the front cover ① secured by screws must only be carried out under the supervision of a qualified contractor, installation engineer, or service person.


• Remote controller ③ mounted to the indoor unit can be moved to the room and serve as a Room Thermostat.

12.1.5.1 Installation Location

- Install at the height of 1 to 1.5 m from the floor where average room temperature can be detected properly.
- Install vertically against the wall.
- Avoid the following locations for installation.
 - 1. Location exposed to direct sunlight or direct air.
 - 2. In the shadow or backside of objects deviated from the room airflow.
 - Location where condensation occurs (The remote controller is not moisture proof or drip proof.)
 - 4. Location near heat source.
 - 5. Uneven surface.
- Keep distance of 1 m or more from the TV, radio and PC.

(Cause of fuzzy image or noise)


12.1.5.2 Remote Controller Wiring




- Remote controller cable shall be 2 x min 0.3 mm², of double insulation PVC-sheathed or rubber sheathed cable. Total cable length shall be 50 m or less.
- Do not connect cables to other terminals of Indoor Unit (e.g. power source wiring terminal); malfunction be caused.
- Do not bundle together with the power supply cable or store in the same metal tube; operation error may be caused.

12.1.5.3 Remove the Remote Controller from the Indoor Unit


 Remove both left and right decoration panel (10) and (11) from the front cover (1) while gently pushing them from the behind.




2. Remove the 4 screws and take out the holder with remote controller (3).



3. Remove the body from the base.




4. Remove the cable between remote controller ③ and Indoor Unit terminal.



12.1.5.4 Mounting the Remote Controller


For exposure type

Preparation: Drill 2 holes for screws with a screwdriver.




For embedded type

Preparation: Drill 2 holes for screws with a screwdriver.



12.1.5.5 Replace the Remote Controller Cover

- Replace the existing remote controller with remote controller Case 3 to close the hole left after removing it.
 - 1. Refer to Section "Remove The remote controller From Indoor Unit".
 - 2. Remove the top case from the bottom case of remote controller Case 3.




3. Reverse the steps 1 to 4 of section "Remove The remote controller From Indoor Unit" to fix remote controller Case 3 to Indoor Unit.

12.1.6 Check RCCB/ELCB

1. Ensure the RCCB/ELCB set to "ON" condition before check RCCB/ELCB.

2. Turn ON the power supply to the Indoor Unit. This check can only be done when power is supplied to the Indoor Unit.



- 4. Contact authorized dealer if the RCCB/ELCB malfunction.
- 5. Turn OFF the power supply to the Indoor Unit.
- If RCCB/ELCB functions normal, set the lever to "ON" again.

12.1.7 Close Front Cover


Gently close the front cover and fix with 2 screws.

Tightening torque cN•m {kgf•cm} 147.1~245.2 {15~25}

12.1.8.1 Check Water Pressure

* (0.50 bar = 0.05 MPa)


Water pressure must not be lower than 0.50 bar. (Check the water pressure by the remote controller.) If it is lower, fill Space Heating/Cooling pipes with water through the tube connector on the outdoor unit.



12.1.8.2 Check Pressure Relief Valve

* Pressure relief valve is located on outdoor unit.

- 1. Pull the lever in the horizontal direction and confirm that the pressure relief valve works properly.
- 2. Release the lever when water comes out of the drain pipe of the pressure relief valve. While the air continues to come out of the drain pipe, keep raising the lever to completely discharge the air.
- 3. Confirm that the water from the drain pipe stops.
- 4. If water is leaking, pull the lever several times and return it to make sure the water stops.
- 5. If water keeps coming out of the drain, turn OFF the system and contact your local authorized dealer.



12.1.8.3 Check Air Accumulation

• Open the air vent plugs on the heating panel, fan convector, etc., and remove the air accumulated in the equipment and piping.

12.1.8.4 Expansion Vessel Pre Pressure Checking

- The system where the Indoor Unit is installed is equipped with an expansion vessel with the capacity of 10 L and the initial pressure of 1 bar.
- The total volume of water in the system should not exceed 200 L.
- If the total water volume exceeds 200 L, add an expansion vessel. (Supplied on site)
- The installed height difference of the water circuit of the system should not exceed 30 m. (Extra pump may be required).
 - In case of 30 m, set the pressure in the circulation circuit to 0.5~1.0 bar.
 Higher than 1.0 bar may cause water leakage due to component breakage.

12.1.9 Test Run

- 1. Check the items below before the test run.
- a) Pipework are properly done.
 - b) Electric cable connecting work are properly done.
 - c) Water circuit unit is filled up with water and trapped air is released.
 - d) Turn ON the power supply after filling the indoor until full.
- Turn ON the power supply for the Indoor, and RCCB/ELCB in the Indoor Unit. Then, refer to the Operation Instruction for operation of remote controller (3).

Note:

During winter, turn ON the power supply and standby the unit for at least 15 minutes before test run. To allow sufficient time to warm up refrigerant and prevent wrong error code judgement.

- 3. For normal operation, the water pressure reading should be in between 0.50 bar and 4.00 bar (0.05 MPa and 0.4 MPa). If not, adjust the speed of the water pump to bring it into the aforementioned pressure operating range. If this procedure does not solve the problem, contact a local authorized dealer.
- 4. After test run, clean the magnetic water filter set with reference to "Maintenance for magnetic water filter" in the Installation Manual of the AIR-TO-WATER HEAT PUMP OUTDOOR UNIT and reinstall it. After the cleaning is finished.

12.1.9.1 Check Water Flow of the Water Circuit

Select Installer setup \rightarrow Service setup \rightarrow Pump maximum speed \rightarrow Air purge. Confirm that the maximum water flow rate is not less

than 25 l/min when the main pump is in operation.

 Water flow can be checked in Service setup (Pump maximum speed) [Heating operation at low water temperature with

lower flow rate may cause "H75" during defrost process.]

* If there is no water flow or H62 is displayed, stop pump operation and release the air (See "CHECK AIR ACCUMULATION").

12.1.10 Maintenance

- To ensure the safety and optimum performance of the indoor unit, seasonal inspections of the indoor unit and functional checks of RCCB/ELCB, field wiring and pipe should be carried out on a regular basis. This maintenance and scheduled inspection should be carried out by authorized dealer.
- Regular maintenance of the expansion vessel (at least once a year) is recommended and should be performed by authorized dealer. First, make sure that the expansion or pressure tank is completely drained of water, that the system is switched off, and that there are no live electrical components. If you need to reset the preload pressure, set 1bar.

12.2 Appendix


12.2.1 Variation of System

This section introduces some variation of systems using Air-To-Water Heat pump and actual setting method. For this model, the Zone 1 external room thermistor and Zone 1 external room thermostat must be always connected to the main room board, irrespective of whether they are connected to a board (CZ-NS7P) sold separately.


12.2.1.1 Introduce Applications Related to Temperature Setting

12.2.1.1.1 Temperature Setting Variation for Heating

1. Remote controller



- Connect floor heating and radiators directly to the outdoor unit.
- The remote controller is located on the indoor unit.
- This is the simplest system.
- 2. Room thermostat




Connect floor heating and radiators directly to the outdoor unit.

Remove the remote controller from the indoor unit and install it in the room where the floor heating is installed. This is an application that uses remote controller.

Refer to 12.1.5 Install Remote Controller as Room Thermostat (Optional).

3. External room thermostat




Connect floor heating and radiators directly to the outdoor unit.

The remote controller is located on the indoor unit.

Install separate External Room Thermostat (field supply) in the room where floor heating is installed. This is an application that uses External Room Thermostat.

4. Room thermistor



Connect floor heating or radiator directly to the outdoor unit.

The remote controller is located on the indoor unit.


An external room thermistor (specified by Panasonic) is installed in the room where the floor heating is installed. This is an application that uses an external room thermistor.

 There are two ways of setting the circulating water temperature. Direct: Sets the circulating water temperature directly (fixed value). Correction curve: sets the circulating water temperature according to the outside temperature.
 In case of Room thermistor, the compensation curve is shifted according to the thermo ON/OFF situation.
 (Example) If room temperature increasing speed is; Very slow → Shift the compensation curve upwards

Very fast \rightarrow Shift compensation curve downwards

12.2.1.1.2 Examples of Installations

Floor heating 1 + Floor heating 2



Connect Floor heating to the 2 circuits via buffer tank as shown in the figure.

Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits.

Remove the remote controller from the indoor unit and attach it to either circuit to use as a Room Thermostat.

Install an external Room Thermostat (field-supply) on a another circuit.


Both circuits can set the circulating water temperature independently.

Install the buffer tank thermistor on the buffer tank.

The buffer tank connection settings and the ΔT temperature settings for heating operation are required separately. This system requires an Optional PCB (CZ-NS7P).

Note: Buffer tank thermistor must be connected to PCB 4.

Floor heating + Radiator



Connect Floor heating and radiators to the 2 circuits via buffer tank, as shown in the figure above. Install pumps and thermistors (specified by Panasonic) on both circuits.


Install a mixing value in the circuit with lower temperature among the 2 circuits. (Generally, where floor heating and radiator circuits are installed in 2 zones, install mixing value in the floor heating circuit.) The remote controller is located on the indoor unit.

The temperature setting selects the circulating water temperature for both circuits. Both circuits can be set the circulating water temperature independently.

Install thermistor on the buffer tank. The buffer tank connection settings and the ΔT temperature settings for heating operation are required separately.

This system requires the Optional PCB (CZ-NS7P). Note: if there is no mixing valve on the secondary side, the circulating water temperature may be higher than the set temperature.

Note: Buffer tank thermistor must be connected to PCB (4).



Connect floor heating and swimming pool to the 2 circuits via buffer tank, as shown in the figure above. Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits.

Additional pool heat exchanger, pool pumps and pool sensor are installed in the pool circuit.

Remove the remote controller from the indoor unit and install it in the room where the floor heating is installed. The floor heating and the pool circulation water temperatures can be set separately.


Install thermistor on the buffer tank.

The buffer tank connection settings and the ΔT temperature settings for heating operation are required separately. This system requires the Optional PCB (CZ-NS7P).

* Be sure to connect the pool to "Zone 2".

When connected to a swimming pool, operating in 'Cool' will stop the pool operation. Note: Buffer tank thermistor must be connected to PCB (4).

Swimming pool only



This is an application that connect to the swimming pool only.


Connect the pool heat exchanger directly to the tank unit without buffer tank.

Install a pool pump and pool thermistor (specified by Panasonic) at the secondary side of the pool heat exchanger. The pool temperature can be set with a remote controller.

This system requires the Optional PCB (CZ-NS7P).

The cooling mode cannot be selected for this application. (Not displayed on the remote controller).

Simple 2 zone (Floor heating + Radiators)



This is an example of simple 2 zone control without buffer tank.

The built-in pump in the Outdoor unit acts as the pump for zone 1.

Install mixing valve, pump and thermistor (specified by Panasonic) at zone 2 circuit.

The temperature in Zone 1 is not adjustable, so always assign the hot side to Zone 1.

To display the temperature of zone 1 on the remote controller, zone 1 thermistor is required.

The circulating water temperature for both circuits can be set independently.

(However, the temperature of high temperature side and low temperature side cannot be reversed.)


This system requires the Optional PCB (CZ-NS7P).

Note:

- Thermistor 1 has no direct influence on the operation. However, if thermistor 1 is not installed, an error will occur.
- Adjust the flow rate so that zone 1 and zone 2 are balanced. If not correctly adjusted, performance may be affected.


(If the pump flow rate in zone 2 is too high, hot water may not flow to zone 1) The flow rate can be checked from "Actuator Check" under maintenance menu.

Buffer tank connection



This is an application that connects the buffer tank to the indoor unit.

The temperature of the buffer tank is detected by a buffer tank thermistor (specified by Panasonic). If Optional PCB is not connected, external pump can be used for circulation in the floor heating circuit. Note: Buffer tank thermistor must be connected to PCB (4).



This is an application that connect the buffer tank unit to the indoor unit and then to the solar water heater to heat the buffer tank.

The temperature of the buffer tank is detected by a buffer tank thermistor (specified by Panasonic).

The temperature of the solar panel is detected by a solar thermistor (specified by Panasonic).


Buffer tanks are stand-alone tanks with built-in solar heat exchange coils.

During winter season, solar pump for circuit protection will be activated continuously. If you wish not to activate the solar pump operation, use glycol and set the anti-freezing operation start temperature to -20°C.

Heat accumulation operates automatically by comparing the temperature of tank thermistor and solar thermistor. This system requires the Optional PCB (CZ-NS7P).

Note: Buffer tank thermistor must be connected to PCB (4).

Boiler connection



This is an application that connects the boiler to the buffer tank, to compensate for insufficient capacity by operate boiler when outdoor temperature drops & heat pump capacity is insufficient.


Boiler is connected parallel with heat pump and used as heating circuit.

The boiler output can be controlled either by SG-ready input from a board (sold separately) or by automatic control via three mode selection patterns.

(Operation setting of boiler shall be responsible by installer.)

This system requires the Optional PCB (CZ-NS7P) for SG-ready input control.

Depending on the settings of the boiler, it is recommended to install buffer tank as temperature of circulating water may get higher. (In particular, if the advanced parallel setting is selected, it must be connected to a buffer tank.) Note: Buffer tank thermistor must be connected to PCB ④.




Boiler is turned off by safety control when the water temperature of the heating circuit exceed 85°C.

12.2.2 System Installation

12.2.2.1 Remote Controller Outline

The LCD display as shown in this manual are for instructional purpose only, and may differ from the actual unit.





First time of power ON (Start of installation)


Initialization	12:00 pm, Mon	
	Initializing	When the power is ON, firstly the initialization screen appears (approx. 10 sec)
	Approx, 10 sec later.	
	12:00 pm, Mon	
	p,	
		When the initialization screen ends, it turns to normal screen.
[(b)] Start		
	Press any key	
	12:00 pm, Mon	When any button is pressed, language setting
Language ENGLISH	12.00 pm, Mon	screen appears.
FRANÇAIS		Note: If initial setting is not performed, it does not go into menu.
DEUTSCH		When there are two remote controllers installed
ITALIANO		from the beginning, the first remote controller
 Select 	[←] Confirm	used to set and confirm language will be recognised as the main remote controller.
	Set language and press cont	
	• <u> </u>	
Clock format	12:00 pm, Mon	
	24h ▼ am/pm	When language is set, setting screen of time display appears (24h/am/pm)
✓ Select	[←] Confirm	
	Set time display and press c	onfirm
Date & time	12:00 pm, Mon	
Year/Month/Day	Hour : Min	
2024 / 01 / 01	12 : 00	YYYY/MM/DD/Time setup screen appears
Select	[🖵] Confirm	
<u> </u>	Set YY/MM/DD/Time & conf	irm Select 'No' to confirm, before continuing with
Encirch anille	* <u> </u>	the operation, a caution message confirming
Front grille Is O/D front grille fixed	12:00 pm, Mon	the installation of the outdoor front grille will be displayed.
IS O/D Home grille liked	No	
	Yes	To prevent injury, fix front grille before ope.
✓ Select	[←] Confirm	[←] Close
	Set Yes & confirm if outdoor	front grille has been installed
	▼	
	12:00 pm, Mon	
		Back to initial screen
[()] Start		
	Press Menu and select Insta	Iller setup

Main menu	12:00 pm, Mon
System check	
Personal setup	
Service contact	
Installer setup	
Select	[-] Confirm
	Confirm to go into Installer setu

12.2.2.2 Installer Setup







12.2.2.3 System Setup

1. Optional PCB connectivity Initial setting: No	System setup 12:00 pm, Mor	
	Optional PCB connectivity	
If any functions below is necessary, purchase and install (CZ-NS7P).	Zone & Sensor	
Select Yes after installing it. 2-zone control 	Heater capacity	
Pool	Anti freezing	
• Solar	_ Select [⊶] Confirm	
External error signal output		
Demand control		
SG readyStop heat source unit by external SW		
Heat-Cool SW		

2. Zone & Sensor		Initial setting: Room and Water temp.		System setup	12:00 pm, Mon
If there is no Optional PCB Select sensor of room temperature control from the following 3 items (1) Water temperature (circulation water temperature)		1	Optional PCB connectivity		
			Zone & Sensor		
)	Heater capacity		
(2) Room thermostat (Internal or External)		Anti freezing			
③ Room thermistor			Select	[←] Confirm	
If there is Optional PC	В				
0		ntrol or 2 zone control.			
,		er room or pool, select sensor			
,		sensor in zone 1, then the either room or	pool for zone 2		
and select the sen	sor				
Note: In 2-zone system	n, po	ol function can be set to zone 2 only.			

3. Heater capacity Initial setting: Depend on model	System setup 12:00 pm, Mon
If there is external heater, set the heater capacity.	Optional PCB connectivity Zone & Sensor
Note: Some heaters cannot select the capacity.	Heater capacity
	Anti freezing
	Select [+] Confirm

4. Anti freezing Initial setting: Yes	System setup 12:00 pm, Mon	
Operate anti-freezing of water circulation circuit. If set to yes, the pump will start when the water temperature reaches its freezing temperature.	Optional PCB connectivity Zone & Sensor Heater capacity	
If the temperature does not reach the pump stop temperature, heat pump will be activated.	Anti freezing ♣ Select [↓] Confirm	
Note: If set to No, when the water temperature reaches its freezing temperature or		

below, the water circulation circuit may freeze and cause malfunction.

5. Tank connection Initial setting: No	System setup 12:00 pm, Mon	
Select whether it is connected to hot water tank or not.	Zone & Sensor	
If set to Yes, it enables the hot water function settings.	Heater capacity	
Hot water temperature of the tank can be set from main screen.	Anti freezing	
	Tank connection	
	Select [4] Confirm	

6. DHW capacity Initial setting: Variable

Variable DHW capacity setting normally run with efficient boiling which is energy saving heating. However while hot water usage high and tank water temperature low, variable DHW mode run with fast heat up which heat up the tank with high heating capacity.

If standard DHW capacity setting is selected, heat pump run with heating rated capacity at tank heat up operation.

System setup	12:00 pm, Mon
Heater capacity	
Anti freezing	
Tank connection	
DHW capacity	
Select	[⊷] Confirm

7. Buffer Tank connection	Initial setting: No	System set	up 12:00 pm, Mo
	·	Anti freezir	ng
Select whether it is connected to buffer tank for heating or not. If buffer tank is used, set to Yes.		Tank conn	ection
,	nd set ΔT (ΔT use to increase primary	/ side DHW capa	city
emperature against secondary s	ide target temperature).		connection
the buffer tank capacity is not s	o large, set larger value for ΔT .	Select	[┛] Confirm
8. Tank heater Initial se	etting: External	System set	up 12:00 pm, Mc
		Tank conn	ection
lote: Does not display if there is	no tank for hot water supply.	DHW capa	city
et "Tank heater" to "ON" in the "	Function setup" from remote controlle	er when Buffer tank	connection
sing heater to boil the tank.		Tank heate	ər
		Select	[🚽] Confirm
DHW tank to boil the ta The permissible heate The operation to boil tl	g booster heater installed on ank. r capacity is 3kW and below. he tank with heater is as below. ink heater: ON time" appropriately.	For 65°C setting	I time OD temp. > -10°C OD temp. ≦ -10 HP thermo OFF
		Booster heater	

9. Base pan heater Initial setting: No	System setup 12:00 pm, Mon	
	DHW capacity	
Select whether Base pan heater is installed or not. If set to Yes, select to use either heater A or B.	Buffer tank connection Tank heater	
A: Turn ON Heater when heating with defrost operation only	Base pan heater	
B: Turn ON Heater at heating	Select [+] Confirm	

10. Alternative outdoor sensor	Initial setting: No	:	System setup	12:00 pm, Mon
Set to Yes if outdoor sensor is installed. Controlled by optional outdoor sensor without reading the outdoor sensor of heat pump unit.		Buffer tank connection Tank heater Base pan heater		
			Alternative outdoor se	ensor [←] Confirm

11. Bivalent connection Initial setting: No	System setup 12:00 pm, Mon	
	Tank heater	
Set if heat pump linked with boiler operation. Connect the start signal of the boiler in boiler contact terminal (PCB).	Base pan heater	
Set Bivalent connection to YES.	Alternative outdoor sensor	
After that, begin setting according to remote controller instruction.	Bivalent connection	
Boiler icon will be displayed on remote controller top screen.	Select [+] Confirm	
After Bivalent connection set YES, there are three options of control pattern (Auto / SG Ready / Smart).		

1) Auto


There are 3 different modes in the boiler auto pattern operation. Movement of each modes are shown below.

- 2 Alternative (switch to boiler operation when drops below setting temperature)
- Parallel (allow boiler operation when drops below setting temperature) 3
- (4) Advanced Parallel (able to slightly delay boiler operation time of parallel operation)

When the boiler operation is "ON", "boiler contact" is "ON", " "(underscore) will be displayed below the boiler icon.

Set target temperature of boiler to be the same as heat pump temperature.

When boiler temperature is higher than heat pump temperature, zone temperature cannot be achieved if mixing valve is not installed. This product only allows one signal to control the boiler operation. Operation setting of boiler shall be responsible by installer.



each time the mode is switched, the boiler output will be reset to OFF. Please have a good understanding on the boiler control characteristic in order to select the optimal setting for the system.

- 2) SG ready (Only available to set when optional PCB set to YES)
 - SG Ready input from optional PCB terminal control ON/OFF of boiler and heat pump as below condition

SG signal		Operation pattern
Vcc-bit1	Vcc-bit2	
Open	Open	Heat pump OFF, Boiler OFF
Short	Open	Heat pump ON, Boiler OFF
Open	Short	Heat pump OFF, Boiler ON
Short	Short	Heat pump ON, Boiler ON

* This bivalent SG ready input is sharing same terminal as [16. SG ready] connection. Only one of these two setting can be set at the same time.

When one is set, another setting will reset to not set.

3) Smart


There are Energy price (both electricity and boiler) and Schedule to be set on remote controller.

Operation setting of Energy price and Schedule shall be responsible by installer.

Based on these settings, system will calculate the final price for both electricity and boiler.

When final price of Electricity is lower than Boiler's, heat pump will operate.

When final price of Electricity is higher than Boiler's, boiler will operate.





System setup	12:00 pm, Mon
Alternative outdoor sensor Bivalent connection	
External SW	
Solar connection	
Select [4] Con	firm
	Alternative outdoor sensor Bivalent connection External SW Solar connection

Solar pump stop operation when it exceeds high limit temperature (when tank temperature exceed designated temperature (70~90°C))

Note: Does not display if there is no Optional PCB.

System setup 12:00 pm, Mon	
Bivalent connection	
External SW	
Solar connection	
External error signal	
Select [+] Confirm	

15. Demand control

Initial setting: No

Set when there is demand control. Adjust terminal voltage within 1 \sim 10 V to change the operating current limit.

Note: Does not display if there is no Optional PCB.

System setup	12:00 pm, Mon
External SW	
Solar connection	
External error signal	
Demand control	
Select	[←] Confirm

Analog input [v]	Rate [%]		
0.0 0.1 ~ 0.6	▲ not activate		
0.7	10	not activate	
0.9 ~ 1.1		10	
1.2 1.3	15	10	
1.4 ~ 1.6		15	
1.7 1.8	20	15	
1.9 ~ 2.1		20	
2.2 2.3	25	20	
2.4 ~ 2.6		25	
2.7 2.8	30	25	
2.9 ~ 3.1		30	
<u>3.2</u> 3.3	35	30	
3.4 ~ 3.6		35	
3.7 3.8	40	35	

Analog input		Rate		
[v]		[%]		
3.9 ~ 4.1		40		
4.2			40	
4.3		45	40	
4.4 ~ 4.6		4	5	
4.7		50	45	
4.8		50		
4.9 ~ 5.1		50		
5.2		55	50	
5.3		55		
5.4 ~ 5.6		55		
5.7	60		55	
5.8		00	55	
5.9 ~ 6.1		60		
6.2		65	60	
6.3	05		00	
6.4 ~ 6.6		<u>6</u> 5		
6.7		70	65	
6.8				
6.9 ~ 7.1		70		
7.2		75	70	
7.3		13	10	

Analog input		Rate		
[v]		[9	6]	
7.4 ~ 7.6		7	5	
7.7		80	75	
7.8		00	15	
7.9 ~ 8.1		8	0	
8.2		85	80	
8.3		05	00	
8.4 ~ 8.6		8	5	
8.7		90	85	
8.8		90	00	
8.9 ~ 9.1		90		
9.2		95	90	
9.3		30	30	
9.4 ~ 9.6		95		
9.7		100	95	
9.8		100	90	
9.9 ~	100			

*A minimum operating current is applied on each model for protection purpose.

*0.2 voltage hysteresis is provided. *The value of voltage after 2nd decimal point are cut off.

16. SG R	eady	Initial setting: No		System setup	12:00 pm, Mon
The followi Capacity: I	ng setting: imit by cap	eat pump by open-short of 2 termin s are possible. pacity. limit by power consumption.	als.	Solar connection External error signal Demand control SG Ready	
SG s	signal	Operation pattern		Select	[⊷] Confirm
Vcc-bit1	Vcc-bit2				
Open	Open	Normal			
Short	Open	Heat pump/heater OFF			
Open	Short	Capacity 1			
Short	Short	Capacity 2			
	setting 1 W capacity	y <u>%.</u> city%.			
		city°C			
Capacity	-	SG ready - Y	es - Capacity setting		
	W capacity				
		city% city°C			
- 00	oning capa				
Select Pov	ver consun	nption			
HPU sto		nptionkW nption value never exceeded eeded, heating is provided by the he	eater only.		
Power of	consumptio	on setting 1			
		umption of DHWkW			
		ver consumptionkW	SG ready -	Yes - Power consumption	n setting
	• •	ver consumptionkW on setting 2			
		umption of DHWkW			
		ver consumptionkW			
		ver consumptionkW	J		
		'Yes', Bivalent control pattern is set ay if there is no Optional PCB.	to 'Auto').		

17. External compressor SW Initial setting: No	System setup 12:00 pm, Mon	
Set when external compressor SW is connected. SW is connected to external devices to control power consumption, Open Signal will stop compressor's operation. (Heating operation etc. are not cancelled).	External error signal Demand control SG Ready	
Note: Does not display if there is no Optional PCB.	External compressor SW Select [4] Confirm	

System setup 12:00 pm, Mon	
Demand control	
SG Ready	
External compressor SW	
Circulation liquid	
Select [4] Confirm	

	System setup	12:00 pm, Mc
	SG Ready	
Able to switch (fix) heating & cooling by external switch.	External compres	ssor SW
(Open) : Fix at Heating (Heating + DHW)	Circulation liquid	
(Short) : Fix at Cooling (Cooling + DHW) Note: This setting is disabled for model without Cooling.	Heat-Cool SW	
Note: Does not display if there is no Optional PCB.	Select	Confirm [
Timer function cannot be used. Cannot use Auto mode.		
20. Force Heater Initial setting: Manual	System setup	12:00 pm, Mc
Index manual mode, user can turn ON force bester through quick manual	External compres	ssor SW
Jnder manual mode, user can turn ON force heater through quick menu.	Circulation liquid	
f selection is 'auto', force heater mode will turn automatically if pop up error	Heat-Cool SW	
nappen during operation. Note: When external heater is No and tank heater is OFF, force heater does not	Force heater	
turn ON even if selection is 'auto'.	Select	[←] Confirm
Force heater operation follows the latest mode selection. Mode selection is disable under force heater operation.		
Heater source will ON during force heater mode.		
21. Force Defrost Initial setting: Manual	System setup	12:00 pm, Mo
21. Force Defrost Initial setting: Manual	,	12.00 pm, we
Inder manual mode, user can turn ON force defrost through quick menu.	Circulation liquid Heat-Cool SW	
	Heat-Cool SW	
f selection is 'auto' outdoor unit will run defrost operation once if heat pump have	Force heater	
ong hour of heating without any defrost operation before at low ambient condition.	Force heater	
If selection is 'auto', outdoor unit will run defrost operation once if heat pump have ong hour of heating without any defrost operation before at low ambient condition. (Even if auto is selected, user still can turn ON force defrost through quick menu)	Force defrost	
ong hour of heating without any defrost operation before at low ambient condition.	Force defrost	[🗗] Confirm
ong hour of heating without any defrost operation before at low ambient condition.	Force defrost	[4] Confirm
bong hour of heating without any defrost operation before at low ambient condition. Even if auto is selected, user still can turn ON force defrost through quick menu)	Force defrost	
22. Defrost signal Initial setting: No	Force defrost	
22. Defrost signal Initial setting: No	Force defrost Select System setup	
22. Defrost signal Initial setting: No Pefrost signal and bivalent connection have the same connection port in the main CB. When defrost signal set to YES, bivalent connection reset to NO. Only one	Force defrost System setup Heat-Cool SW	
22. Defrost signal Initial setting: No Defrost signal and bivalent connection have the same connection port in the main PCB. When defrost signal set to YES, bivalent connection reset to NO. Only one unction can be set between defrost signal and bivalent.	Force defrost Select System setup Heat-Cool SW Force heater	
22. Defrost signal Initial setting: No 22. Defrost signal Initial setting: No Defrost signal and bivalent connection have the same connection port in the main PCB. When defrost signal set to YES, bivalent connection reset to NO. Only one unction can be set between defrost signal and bivalent. Vhen defrost signal set to YES, during defrost operation is running at outdoor	Force defrost Select System setup Heat-Cool SW Force heater Force defrost	
22. Defrost signal Initial setting: No 22. Defrost signal Initial setting: No Defrost signal and bivalent connection have the same connection port in the main PCB. When defrost signal set to YES, bivalent connection reset to NO. Only one unction can be set between defrost signal and bivalent. When defrost signal set to YES, during defrost operation is running at outdoor unit defrost signal contact turn ON. Defrost signal contact turn OFF after defrost operation end. Purpose of this contact output is to stop indoor fan coil or water pump during	Force defrost ◆ Select System setup Heat-Cool SW Force heater Force defrost Defrost signal	12:00 pm, M
22. Defrost signal Initial setting: No 22. Defrost signal Initial setting: No Defrost signal and bivalent connection have the same connection port in the main PCB. When defrost signal set to YES, bivalent connection reset to NO. Only one unction can be set between defrost signal and bivalent. When defrost signal set to YES, during defrost operation is running at outdoor unit defrost signal contact turn ON. Defrost signal contact turn OFF after defrost operation end. Purpose of this contact output is to stop indoor fan coil or water pump during	Force defrost ◆ Select System setup Heat-Cool SW Force heater Force defrost Defrost signal	12:00 pm, Mo
22. Defrost signal Initial setting: No 22. Defrost signal Initial setting: No Defrost signal and bivalent connection have the same connection port in the main PCB. When defrost signal set to YES, bivalent connection reset to NO. Only one unction can be set between defrost signal and bivalent. Vhen defrost signal set to YES, during defrost operation is running at outdoor init defrost signal contact turn ON. Defrost signal contact turn OFF after defrost operation end. Purpose of this contact output is to stop indoor fan coil or water pump during	Force defrost ◆ Select System setup Heat-Cool SW Force heater Force defrost Defrost signal	 12:00 pm, Mo [↓] Confirm
22. Defrost signal Initial setting: No 22. Defrost signal Initial setting: No Defrost signal and bivalent connection have the same connection port in the main PCB. When defrost signal set to YES, bivalent connection reset to NO. Only one unction can be set between defrost signal and bivalent. When defrost signal set to YES, during defrost operation is running at outdoor unit defrost signal contact turn ON. Defrost signal contact turn OFF after defrost operation end. Purpose of this contact output is to stop indoor fan coil or water pump during lefrost operation). 23. Pump flowrate	Force defrost ↓ Select System setup Heat-Cool SW Force heater Force defrost Defrost signal ↓ Select	 12:00 pm, Mo [↓] Confirm
22. Defrost signal Initial setting: No 22. Defrost signal Initial setting: No Defrost signal and bivalent connection have the same connection port in the main PCB. When defrost signal set to YES, bivalent connection reset to NO. Only one unction can be set between defrost signal and bivalent. When defrost signal set to YES, during defrost operation is running at outdoor unit defrost signal contact turn ON. Defrost signal contact turn OFF after defrost operation end. Purpose of this contact output is to stop indoor fan coil or water pump during defrost operation).	Force defrost ↓ Select System setup Heat-Cool SW Force heater Force defrost Defrost signal ↓ Select System setup	12:00 pm, Mo

If pump flowrate setting is set to Max. duty, unit will set the pump duty to the set duty at *Pump maximum speed in service setup menu during room side operation.

[←] Confirm

Select

24. DHW defrost Initial setting: Yes	System setup	12:00 pm, Mon
When DHW defrost set to YES, hot water of domestic hot water tank will be used during defrost cycle. When DHW defrost set to NO, hot water of floor heating circuit will be used during defrost cycle.	Force defrost Defrost signal Pump flowrate DHW Defrost ↓ Select	←] Confirm
25. Heating control Initial setting: Comfort	System setup	12:00 pm, Mon
Compressor frequency control can be selected from two modes: Comfort and	Defrost signal	·

Efficiency.

Select "Comfort"

- The compressor operates at the maximum frequency at the upper zone limit and reaches the set temperature faster.

Select "Efficiency"

The compressor frequency is gradually increased to reduce power consumption. The system have 3 steps to achieve maximum compressor frequency. You can set period time of each stage on R/C. (compressor frequency for each stage)
1st stage: 50% of the maximum frequency
2nd stage: 66% of the maximum frequency
3rd stage: 83% of the maximum frequency

Defrost signal Pump flowrate DHW Defrost Heating control ◆ Select [←] Confirm Select Efficiency. Capacity

1st stage 2nd stage 3rd stage

26. External meter	Initial setting: [Heat-cool meter : No]	System setup	12:00 pm, Mon
	[Tank meter : No] *only available when Heat-cool meter select Yes [Elec. meter HP : No] [Elec. meter 1 (PV meter) : No] [Elec. meter 2 (Building) : No] [Elec. meter 3 (Reserve) : No]	Pump flowrate DHW Defrost Heating control External meter	
		Select	[←] Confirm

There are two systems for generation meter connection : one generation meter system

(Heat-cool meter) or two generation meter system (Heat-cool meter and Tank meter)

Both systems can provide all generation data of heating, cooling and DHW directly from external meter.

If Heat-cool meter is set to Yes, it will read from external meter for heat pump's energy generation data during heating, cooling and DHW operation '1.

If Heat-cool meter is set to No, it will base on unit's calculation for heat pump's energy generation data during heating, cooling and DHW operation.

If Tank meter is set to Yes, it will read from external meter for heat pump's energy generation data during DHW operation^{*1}.

If Elec. meter HP is set to Yes, it will read from external meter for heat pump's energy consumption data.

If Elec. meter HP is set to No, it will base on unit's calculation for heat pump's energy consumption data.

If Elec. meter 1 (PV meter) is set to Yes, it will read from external meter for energy generation data of solar system and display it on Cloud system.

If Elec. meter 2 (Building) is set to Yes, it will read from external meter for energy consumption data of the building and display it on Cloud system.

If Elec. meter 3 (Reserve) is set to Yes, it will read from external meter for energy consumption data obtained from reserved electricity meter and display it on Cloud system.

¹¹ Set Heat-cool meter to Yes and set Tank meter to No when 1 generation meter system is installed.

Set Heat-cool meter to Yes and set Tank meter to Yes when 2 generation meter system is installed.

Remark : Elec. meter HP refers to Electricity meter that measures Heat Pump unit's consumption.

Elec. meter 1 / 2 / 3 refers to Electricity meter no. 1 / no. 2 / no. 3

System setup 12:00 pm, Mon	
DHW Defrost	
Heating control	
External meter	
Electrical anode	
Select [+] Confirm	

28. Extra pump	Initial setting: Heat	System setup	12:00 pm, Mon
the circulation circuit	extra pump is used in the circulation circuit for heating or in for DHW, or it is not used. ake choices such as the pump ON/OFF time and whether	Heating control External meter Electrical anode	
Select DHW	y is a phoney.	Extra pump	↓] Confirm
- Pump ON time - Pump OFF time Select Comfort (E: Select Efficiency - ON time - OFF time	8:00 20:00 xit extra pump settings) 0:15 (0:05 ~ 1:00) 0:15 (0:05 ~ 1:00)	Select DHW Select Comfort OFF Pump ON time Select DHW Select Efficiency	Total time Pump OFF time
		ON OFF Pump ON time	Total time Pump OFF time

29. External heater	Initial setting: No	System setup	12:00 pm, Mon
		External meter	
Select the type of external heater. "In-line": Select this if you're using the external heater as an In-line heater. "Buffer tank": Select this if you're using the external heater as a buffer tank heater.		Electrical anode Extra pump	
external heater" for details.	nect the Cable to the Indoor Unit "how to install	Select [←] Confirm

30. Static pressure	Initial setting: No		System setup	12:00 pm, Mon
			Electrical anode	
If set to No, the outdoor fan motor operates at a normal speed. If set to YES, the outdoor fan motor operates at a higher speed than normal in response to high static pressure.		Extra pump	Extra pump External heater	
		External heater		
		Static pressure		
			Select	←] Confirm

31. Cooling capacity Initial setting: Efficiency	System setup 12:00 pt	m, Mon
Select the cooling capacity.	Extra pump External heater	
If set to "Efficiency", the unit performs cooling operation efficiently at rated capacity. If set to "Comfort", the cooling operation is performed at maximum capacity.	Static pressure	
	Cooling capacity	
	▲ Select [⊶] Confirm	

12.2.2.4 Operation Setup


Heat

32. Water temp. for heating ON	Initial setting: compensation curve	55°C compensation curve
Set target water temperature to operate he Compensation curve: Target water temper ambient temperature Direct: Set direct circulation water tempera In 2 zone system, zone 1 and zone 2 wate	rature change in conjunction with outdo e change. Iture.	W Decide temperature Hot water of 4 points as shown in diagram 35°C W -5°C 15°C Outdoor temperature
		• •
33. Outdoor temp. for heating OFF		ON
If the operation of the outdoor unit is frequ on the outdoor air temperature, the followin the frequency.		<pre></pre>
a. Outdoor temp. for heating OFF	Initial setting: 24°C	
Set outdoor temp. to stop heating Setting range is 6°C~35°C		
b. Outdoor temp. for heating ON	Initial setting: 23°C	
Set outdoor temp. to start heating. Setting range is 5°C~X°C (X is heating 0	DFF temp1)	OFF ◀0:30► → Time
c. Heating ON delay time	Initial setting: 0:30min	
Set delay time from heating OFF to heat	ting ON.	
34. ΔT for heating ONInitial setSet temp difference between out temp & re Heating operation.Heating operation.When temp gap is enlarged, it is energy sa gap gets smaller, energy saving effect gets Setting range is 1°C ~ 15°C	aving but less comfort. When the	$\begin{array}{c c} Out & \longrightarrow & \\ \hline \\ Return & \longleftarrow & \\ Outlet - return = 1^{\circ}C - 15^{\circ}C & \\ \end{array}$
35. Heater ON/OFF		ON
a. Outdoor temp. for heater ON	Initial setting: 0°C	
Set outdoor temp when back-up heater sta Setting range is -20°C ~ 15°C	arts to operate.	L
User shall set whether to use or not to use	heater.	▲ 0°C ►
b. Heater ON delay time Initial se	etting: 30 minutes	Heater ON.
Set delay time from compressor ON for he water set temperature. Setting range is 10 minutes ~ 60 minutes	ater to turn ON if not achieve	Compressor ON ◀ 0 : 30 ►
c. Heater ON: ΔT of target Temp	Initial setting: -4°C	
Set water temperature for heater to turn O Setting range is -10°C ~ -2°C	N at heat mode.	Set water ▲ temperature2°C Heater OFF ▼
d. Heater OFF: ΔT of target Temp	Initial setting: -2°C	-4°C
Set water temperature for heater to turn O Setting range is -3°C ~ 0°C	FF at heat mode.	

Set target water temperature to operate cooling operation. Compensation curve: Target water temperature change in conjunction with outdoor ambient temperature change. Direct: Set direct circulation water temperature.	36. Water temp. for cooling ON	Initial setting: compensation curve	15°C compensation curve
In 2 zone system, zone 1 and zone 2 water temperature can be set separately.	Compensation curve: Target water temperature change in conjunction with outdoor ambient temperature change. Direct: Set direct circulation water temperature.		↓ 10°C ↓ 20°C 30°C temperature
			$\overline{\mathbf{v}}$


37. ΔT for cooling ON	Initial setting: 5°C	$Out \longrightarrow$	
Cooling operation. When temp gap is enlarged	n out temp & return temp of circulating water of , it is energy saving but less comfort. When the ving effect gets worse but it is more comfortable.	Return ← Return - Out = 1°C ~ 15°C	

Auto




39. Outdoor temp. for (Cool to Heat)	Initial setting: 10°C	Heat Outdoor temp. dropping		
Set outdoor temp that switches from Coolin Setting range is 5°C ~ 14°C	Cool			
Timing of judgement is every 1 hour ◀ 10°C ►				

Tank



12.2.2.5 Service Setup

44. Pump maximum speed Initial setting: Varies according to model S		Service setup	Service setup	
Normally setting is not necessary		Flow rate	Max Duty	Operation
Normally setting is not necessary. Adjust when needed to reduce the pump sound, etc. Besides that, the unit has Air Purge function.		45.6 L/min.	0xCE	Air Purge
When the Pump flow setting is Max. Duty, this duty setting is the duty of fixed pump that runs during operation.		▲ Select		



46. Service contact	Service setup	12:00 pm, Mon	Contact - 1: Brian Ada	ams
	Service contact:		ABC/ abc	0-9/ Other
Able to set the name & telephone no. of contact person when there is	Contact 1		ABCDEFGHIJK	(LMNOPQR
breakdown etc. or client has trouble.	Contact 2		STUVWXYZ	abcdefghi
(2 items)			jklmnopqrstuv	w x y z
	Select [4] Co	nfirm	↓ Select	[-] Confirm

12.2.2.6 Remote Control Setup

47. RC selection Initial setting: Single	RC selection	12:00 pm, Mon
If there is only one remote controller, set to "Single". If two remote controllers are installed, set to "Dual". For details on the Dual setting, refer to the instruction manual of the optional	Single ▼ Dual	
remote controller.	Select [↓] Cor	nfirm

12.3 Service and Maintenance

If forget Password and cannot operate remote controller f + + + > Press for 5 seconds. Password unlock screen appears, press Confirm and it shall reset. Password will become 0000. Please reset it again. Note: This is displayed only when the remote controller is password-locked.

12.3.1 Maintenance Menu

Н	How to set up the Maintenance menu			
Ма	aintenance menu 12:00 pm, Mon			
Ac	tuator check			
Te	Test mode			
Se	ensor setup			
Re	eset password			
	, Select [+] Confirm			
	+ + > Press for 5 seconds.			
Iter	Items that can be set			
1	 Actuator check (Manual ON/OFF all functional parts) Note: As there is no protection action, be careful not to cause any error when operating each part (do not turn ON pump when there is no water etc.) 			
2	Test mode (Test run) Normally it is not used.			
3	 Sensor setup (offset gap of detected temp of each sensor can be set within -3~3°C range) Note: Use only when sensor is deviated. It affects temperature control. 			
4	Reset password (password reset)			

12.3.2 Custom Menu

Сι	ustom menu	12:00 pm, Mon
С	Cool mode	
В	Back-up heater	
F	Reset energy monitor	
F	Reset operation history	
Γ,	Select [.	┛] Confirm
_		
Сι	ustom menu	12:00 pm, Mon
В	Back-up heater	
F	Reset energy monitor	
F	Reset operation history	
A	nti-stick mode	
⁴	Select [-	┛] Confirm
	ms that can be set Cool mode (Select C is Disable. Note: As Enable/Disa application, be In Cool mode, I properly, dew n	ble Cool mode may affect electricity careful and do not simply change it. e careful if piping is not insulated ay form on pipe and water may drip or
1	ms that can be set Cool mode (Select C is Disable. Note: As Enable/Disa application, be In Cool mode, I properly, dew n the floor and da Back-up heater (Sele Note: This back-up h Differs from the set by the custo if requested by	boling function: Enable/Disable) Defaul ble Cool mode may affect electricity careful and do not simply change it. e careful if piping is not insulated ay form on pipe and water may drip or mage the floor. ct Back-up heater: Enable/Disable) eater refers to the Extra heater. use/non-use of back-up heater that is mer. (This setting should only be used the utility company.)
1	ms that can be set Cool mode (Select C is Disable. Note: As Enable/Disa application, be In Cool mode, I properly, dew n the floor and da Back-up heater (Sele Note: This back-up h Differs from the set by the custo if requested by Installation mus	boling function: Enable/Disable) Defaul ble Cool mode may affect electricity careful and do not simply change it. e careful if piping is not insulated ay form on pipe and water may drip or mage the floor. ct Back-up heater: Enable/Disable) eater refers to the Extra heater. use/non-use of back-up heater that is mer. (This setting should only be used
1	ms that can be set Cool mode (Select C is Disable. Note: As Enable/Disa application, be In Cool mode, I properly, dew n the floor and da Back-up heater (Sele Note: This back-up h Differs from the set by the custo if requested by Installation mus of the person ir Reset energy monito	boling function: Enable/Disable) Defaul ble Cool mode may affect electricity careful and do not simply change it. e careful if piping is not insulated ay form on pipe and water may drip or mage the floor. ct Back-up heater: Enable/Disable) eater refers to the Extra heater. use/non-use of back-up heater that is mer. (This setting should only be used the utility company.) t be carried out under the responsibility
(1) (2) (3)	ms that can be set Cool mode (Select C is Disable. Note: As Enable/Disa application, be In Cool mode, I properly, dew n the floor and da Back-up heater (Sele Note: This back-up h Differs from the set by the custo if requested by Installation mus of the person ir Reset energy monito Use this when movin Reset operation histo	boling function: Enable/Disable) Defaul ble Cool mode may affect electricity careful and do not simply change it. the careful if piping is not insulated tay form on pipe and water may drip or mage the floor. to Back-up heater: Enable/Disable) eater refers to the Extra heater. use/non-use of back-up heater that is mer. (This setting should only be used the utility company.) t be carried out under the responsibility charge of installation. (delete memory of Energy monitor). p house and handover the unit.
(1) (2) (3) (4)	ms that can be set Cool mode (Select C is Disable. Note: As Enable/Disa application, be In Cool mode, I properly, dew n the floor and da Back-up heater (Sele Note: This back-up h Differs from the set by the custo if requested by Installation mus of the person ir Reset energy monito Use this when movin Reset operation histo	boling function: Enable/Disable) Defaul ble Cool mode may affect electricity careful and do not simply change it. the careful if piping is not insulated tay form on pipe and water may drip or mage the floor. to Back-up heater: Enable/Disable) eater refers to the Extra heater. use/non-use of back-up heater that is mer. (This setting should only be used the utility company.) t be carried out under the responsibility charge of installation. (delete memory of Energy monitor). g house and handover the unit. ry (delete memory of operation history g house and handover the unit. ct Anti-stick mode: Enable/Disable)
(1) (2) (3) (4)	ms that can be set Cool mode (Select C is Disable. Note: As Enable/Disa application, be In Cool mode, I properly, dew n the floor and da Back-up heater (Sele Note: This back-up h Differs from the set by the custo if requested by Installation mus of the person ir Reset energy monito Use this when movin Reset operation histo Use this when movin Anti-stick mode (sele Default is Anti-stick n The actuator is regula to prevent the actuat	boling function: Enable/Disable) Defaul ble Cool mode may affect electricity careful and do not simply change it. e careful if piping is not insulated may form on pipe and water may drip or mage the floor. ct Back-up heater: Enable/Disable) eater refers to the Extra heater. use/non-use of back-up heater that is mer. (This setting should only be used the utility company.) t be carried out under the responsibility charge of installation. (delete memory of Energy monitor). g house and handover the unit. ry (delete memory of operation history g house and handover the unit. et Anti-stick mode: Enable/Disable) ode Enable. may activated every Monday at 3:00 am ng parts from sticking together.
1ter (1) (2) (3) (4) (5)	ms that can be set Cool mode (Select C is Disable. Note: As Enable/Disa application, be In Cool mode, I properly, dew n the floor and da Back-up heater (Sele Note: This back-up h Differs from the set by the custo if requested by Installation mus of the person ir Reset energy monito Use this when movin Reset operation histo Use this when movin Anti-stick mode (sele Default is Anti-stick n The actuator is regula to prevent the actuat	boling function: Enable/Disable) Defaul ble Cool mode may affect electricity careful and do not simply change it. the careful if piping is not insulated tay form on pipe and water may drip or mage the floor. to Back-up heater: Enable/Disable) eater refers to the Extra heater. use/non-use of back-up heater that is mer. (This setting should only be used the utility company.) t be carried out under the responsibility charge of installation. (delete memory of Energy monitor). g house and handover the unit. ry (delete memory of operation history) g house and handover the unit. et Anti-stick mode: Enable/Disable) ode Enable. rly activated every Monday at 3:00 am

12.4 Outdoor Unit

Attached accessories

No.	Accessories part	Qty.
1	Drain Elbow	1
2	Screw	8
3	Rubber Cap	3
4	Rubber Cap	15
5	Discharge Grille (Left Top)	1
6	Discharge Grille (Left Bottom)	1
7	Discharge Grille (Right Top)	1
8	Discharge Grille (Right Bottom)	1

Optional Accessories

No.	Accessories part	Qty.
9	Remote Controller set (CZ-RTW2TAW1C) *Include Remote Controller + Network adapter with 10m cable	1
10	Remote Controller (CZ-RTW2)	1
11	Base Pan Heater CZ-NE4P	1

- When the outdoor unit is used alone, either 9 or 10 is always required.
- If you need the 2nd remote controller, purchase
 10 and set it up as the 2nd remote controller.
- When installing the outdoor units in cold climates, it is strongly recommended to install a base pan heater (optional). For installation details, refer to the installation manual of the base pan heater (optional).

Field Supply Accessories (Optional)

Part	3-way valve kit	
	Electromtoric Actuator	3-port Valve
Model	SFA 21/18	VXI 46/25
Specification	AC230V, 12VA	-
Supplier	Siemens	

12.4.1 Select the Best Location

- If an awning is placed over the unit to avoid direct sunlight or rain, be careful not to disturb the heat dissipation from the capacitor.
- Avoid installation where the ambient temperature may fall below -28°C.
- A protective zone is defined in the area close to the perimeter of the product. Refer to 12.4.2 Protective Zone section.
- Do not place obstacles that could short-circuit the discharge air.
- The lifespan of Outdoor Unit may be shorter if it is installed near the sea, in areas with high sulphur content or high oil content (e.g. machine oil).
- For maximum length and elevation between outdoor unit and indoor unit, refer to "Cooling/Heating Pipework" in 12.4.5 Piping Installation.

12.4.2 Protective Zone

This outdoor unit is filled with R290(Extremely flammable gas, safety A3 group per ISO 817). Note that this refrigerant has a higher density than air. In case of a refrigerant leak, the leaked refrigerant may accumulate near the ground.

Prevent accumulation of refrigerant in any way that is potentially dangerous, explosive or risk suffocation. Prevent refrigerant from entering the building through building openings. Prevent accumulation of refrigerant in the drain grooves.


A protective zone is defined around this outdoor unit. There must be no building openings, windows, doors, light shafts, cellar entrances, escape hatches, flat-roof windows or ventilation openings in the protective zone.

There must be no ignition sources, such as heat above 360°C, sparks, open flame, plug sockets, light switches, lamps, electrical switches or other permanent ignitions sources, in the protective zone.


The protective zone must not extend to adjacent buildings or public traffic areas (boundaries of neighbors, the public road, neighbor's private roads, subsidence area, depressions, pump shafts, sewers intakes, waste water shafts and so on.).

In the protective zone, you are not permitted to make any subsequent structural alterations which infringe the stated rules for the protective zone.


1) Protective zone for ground installation (or flat-roof installation) at the open areas




2) Protective zone for ground installation in front of a building wall



3) Protective zone for ground installation in a building corner




4) Protective zone for wall installation in front of a building wall



The protective zone under the product extends to the floor.


5) Protective zone for wall installation in a building corner




The protective zone under the product extends to the floor.

12.4.3 Install Outdoor Unit


12.4.3.1 Dimension Diagram






12.4.3.3 Install the Outdoor Unit

- After selecting the best location, start installation according to the Installation Diagram.
 - 1. When installing at roof, please consider strong wind and earthquake. Please fasten the installation stand firmly with bolt or nails.
 - For mounting on concrete or solid surfaces, fix the unit using M10 or W 3/8 bolts and nuts. Make sure that the unit is installed vertically against the horizontal plane. (Install the unit using anchor bolt as shown right.)




12.4.3.4 Disposal of Outdoor Unit Drain Water

- When the Drain elbow 1 is used, please ensure to:
 - The unit must be mounted on a stand at least 50 mm high.
 - Seal the ø32 mm holes with Rubber caps 3. (Refer to the diagram below and install from the outside)
 - If drain water leaks, attach rubber caps 4 when necessary. (Refer to the diagram below and install from the outside)
 - When disposing drain water from the outdoor unit, use a tray (field supply) if necessary.
- If the unit is used in an area where temperature falls below 0°C for 2 or 3 consecutive days, it is recommended not to use the Drain elbow 1 Rubber caps 3 and Rubber caps 4 since drain water will freeze up and obstruct fan rotation.



12.4.4 Install a Sleeve of Piping (Drilll a Hole in the Wall)

- 1. Make a through hole. (Check pipe diameter and insulation thickness)
- 2. Insert the piping sleeve into the hole.
- 3. Fix the bushing to the sleeve.
- 4. Cut the sleeve until it extrudes about 15 mm from the wall.




5. Finish by sealing the sleeve with putty or caulking compound at the final stage.

12.4.5 Piping Installation

12.4.5.1 Typical Piping Installation

When outdoor unit is used alone




Outdoor

15mm


Wall

Indoor



12.4.5.2 Water Piping Installation

- Please engage a licensed water circuit installer to install this water circuit.
- This water circuit must comply with relevant European and national regulations (including EN61770), and local building regulation codes.
- Ensure the components installed in the water circuit could withstand water pressure during operation.
- Do not use worn out tube or detachable hose set.
- Do not apply excessive force to the pipe. There is a risk of damage.
- Choose proper sealer which can withstand the pressures and temperatures of the system.
- Make sure to use two spanners to tighten the connection. Further tighten the nuts with torque wrench to the specified torque as stated in the table.
- Cover the pipe end to prevent dirt and dust when inserting it through a wall.
- If non-brass metallic piping is used for installation, make sure to insulate the pipes to prevent galvanic corrosion.
- Do not connect galvanised pipes. This may cause galvanic corrosion.
- Use correct nut for all Outdoor Unit tube connections and clean all tubes with tap water before installation.



	Size	Torque	
Water Inlet Port a	P 11/"	117 6 Nam	
Water Outlet Port (b)	R 1¼"	117.6 N•m	

Do not overtighten, overtightening may cause water leakage.

- Make sure to insulate the water circuit pipes to prevent reduction of heating capacity.
- After installation, check the water leakage condition in connection area during test run.
- Failure to connect the tube appropriately might cause the Outdoor Unit malfunction.
- Protection from frost:
 When water is left inside the system, freezing up is very likely to happen, which could damage the system.
 Make sure the power supply is turned off before draining.

When outdoor unit is used alone

Install an expansion tank (set pressure: 1 bar) to the circulation circuit. For capacity, refer to 12.4.11 Reconfirmation.

12.4.5.3 Space Cooling/Heating Pipework

- Failure to connect the tube appropriately might cause the Outdoor Unit malfunction.
- Refer to the table below for the rated flow rate of each particular Outdoor Unit.

Model	Rated flow rate (L/min)	
	Cooling	Heat
WH-WXG09ME8	25.8	25.8
WH-WXG12ME8	25.8	34.4
WH-WXG16ME8	25.8	45.9

When outdoor unit is used alone

- Connect Outdoor unit Zone 1 Water inlet (a) to outlet connector of Zone 1 Panel/Floor heater.
- Connect Outdoor unit Zone 1 Water outlet (b) to inlet connector of Zone 1 Panel/Floor heater.

When connected to indoor unit

Refer to the Indoor Unit Installation Manual.

* In the case of Control Module model, it is the same as outdoor unit alone case.

Pipe diameter and length

Model	Water piping between outdoor unit and indoor unit			
Model	Inner diameter	Maximum length	Insulator thickness	Maximum Elevation
WH-WXG09ME8	Ø 25 mm	30m		
WH-WXG12ME8	Ø 22 mm		30 mm or more	30m
WH-WXG16ME8	Ø 32 mm			

* However, if the indoor unit is located more than 10 m below, the water pressure in the circulation circuit (outdoor unit section) shall be 0.5 to 1 bar.

If the outdoor unit is located below, install an extra pump on the outdoor side.

Refer to "12.4.5.4 Special Installation Patterns" in next page.


* WH-WXG16ME8 may require installation of an extra pump depending on piping length.

		Water piping (When outdoor unit is used alone)		
Model	Inner diameter	Insulation thickness	Maximum elevation between outdoor unit and Panel/Floor heater	
WH-WXG09ME8	Ø 25 mm	30 mm or more		
WH-WXG12ME8	Ø 22 mm		10m	
WH-WXG16ME8	Ø 32 mm			

12.4.5.4 Special Installation Patterns


Special construction patterns mentioned here refer to the case where there is a substantial difference in elevation (e.g. more than 10 m) between the outdoor unit installation and the Panel/Floor heater. In this case, attention must be paid since incorrect water filling during installation may prevent the system from operating correctly and may cause water leak.

① When outdoor unit is located below and Panel/Floor heater is 30 m above it




- Pressure checked by remote controller:
 3.5 ~ 4 bar. (at an elevation difference of 30 m)
- When installing an extra pump, connect it to the water outlet of the outdoor unit.
 (If installed to the water inlet, the safety valve is activated and the water is drained)
- Indoor unit is required to install an extra pump.

(2) When outdoor unit is located above and Panel/Floor heater is 30 m below it



- Pressure checked by remote controller:
 0.5 ~ 1 bar. (at an elevation difference of 30 m)
- When installing an extra pump, connect it to the water outlet of the outdoor unit.
- Indoor unit is required to install an extra pump.

12.4.6 Connect the Cable to the Outdoor Unit



12.4.6.1 Fixing of Power Supply Cable and Connecting Cable

- 1. An isolating device must be connected to the power supply cable.
 - Isolating device (disconnecting means) should have minimum 3.0 mm contact gap.
 - Use approved polychloroprene sheathed flexible cable of type designation 60245 IEC 57 or heavier. Connect the other end of the cable to isolating device (Disconnecting means). See table below for cable size requirements.

Model	WH-WXG09ME8 WH-WXG12ME8	WH-WXG16ME8
Cable specification	5 × min 1.5 mm ²	5 × min 2.5 mm ²
Cable Diameter	Ø 8.5 ~ 10.0 mm	Ø 12.0 ~ 14.0 mm
Cable gland to be used (see diagram in 2 next page)	ŀ	A
Isolating Devices	20A	25A
Recommended RCD	30mA, 4	P, typeA

Power Supply Cable

• Earth wire shall be longer than the other wires as shown in the figure 3 for the electrical safety in case of the slipping out of the cord from the Holder (Clamper).

 Connecting cable must be an approved polychloroprene sheathed flexible cable (see table below), type designation 60245 IEC 57 or heavier. The sheath diameter of some connecting cables must be within specifications compatible with the cable gland.

	connection between Indoor unit and outdoor unit	Tank temperature sensor	Remote controller
Cable	2 × min	2 × min	2 × min
Specifications	0.75 mm ²	0.3 mm ²	0.3 mm ²

	3-Way Valve	Boiler
Cable Specifications	3 × min 1.5 mm ²	$2 \times \text{min } 0.5 \text{ mm}^2$
Cable Diameter	Ø 8.5 ~ 10.0 mm	Ø 4.0 ~ 7.0 mm
Cable gland to be used (see diagram in 2 next page)	В	С

3. Route the cables as follows.


Do not damage the cables by sharp edges.


Remove the front plate ① and pull the power cable (cabtyre cable *1) and connection cable through into the rear bushing. Be sure to use the bushing and do not lose it.

2 Remove the terminal board cover (3) and cable gland cap and insert the cables into the cable gland on the bottom of the electrical control unit box.

3 Connect to 3-phase RCCB/ELCB ④ and optional terminal board ⑤.

- 4 Fix the cable gland by referring to [Figure 2]*2
- 5 Set the terminal board cover (3) by referring to [Figure 2] *2
- *1 Locally procure the specified cabtyre cable.
- *2 Screws of cable gland and terminal board cover ③ must be tightened to the specified tightening torque to prevent ingress of gas.







★

12.4.6.2 Connection Between Indoor Unit and Outdoor Unit


When outdoor unit is used alone, leave the short-circuit wires "C2" and "C3" attached as shown in the diagram below.



When connecting to an indoor unit, remove the short-circuit wires "C2" and "C3" and connect as shown in the diagram below.



12.4.6.3 Wire Stripping and Connecting Requirement



12.4.6.4 Connection Requirement

For model WH-WXG09ME8, WH-WXG12ME8

- The equipment's Power Supply complies with IEC/EN 61000-3-2.
- The equipment's Power Supply complies with IEC/EN 61000-3-3 and can be connected to current supply network.

For model WH-WXG16ME8

- The equipment's Power Supply complies with IEC/EN 61000-3-12.
- The equipment's Power Supply complies with IEC/EN 61000-3-3 and can be connected to current supply network.


12.4.7 Install Remote Controller

Remote controller is an optional item.
 Be sure to purchase it if the outdoor unit is used alone.
 If you have purchased an indoor unit, it is included.
 When relocating the remote controller, install in accordance with its Installation Manual.

12.4.7.1 Installation Location

- When using as Room Thermostat, install at the height of 1 to 1.5 m from the floor (Location where average room temperature can be detected).
- Install vertically against the wall.
- Avoid the following locations for installation.
 - 1. By the window, etc. where is exposed to direct sunlight or direct air
 - 2. In the shadow or backside of objects deviated from the room airflow
 - 3. Location where condensation occurs (Remote Controller is not moisture proof or drip proof)
 - 4. Location near heat source
 - 5. Uneven surface
 - 6. Outdoors
- Keep distance of 1 m or more from the TV, radio and PC. (Cause of fuzzy image or noise)


12.4.7.2 Remote Controller Wiring (If the Outdoor Unit is Used Alone)




- Remote Controller cable shall be (2 × min 0.3 mm²) of double insulation PVC-sheathed or rubber sheathed cable. Total cable length shall be 50 m or less.
- (UV protection should be provided for the portion exposed to the outdoors)
- Be careful not to connect cables to other terminals of Outdoor Unit (e.g. power source wiring terminal). Malfunction may occur.
- Do not bundle together with the power source wiring or store in the same metal tube. Operation error may occur.
- When using the 2nd Remote Controller (optional), connect it to the terminal by tightening it together.

12.4.8 Network Adaptor Installation


1. Insert a flat head screwdriver into the slot on the top of the adaptor and remove the cover. Connect the CN-CNT cable to the connector inside the adaptor.



2. Pull the CN-CNT cable through the hole at the bottom of the adapter and reattach the cover.



3. Connect the CN-CNT cable to the CN-CNT connector on the outdoor unit.




For details, refer to the instructions supplied with the network adapter. For installation location, refer to "Installation location" in 12.4.7 Install Remote Controller.

12.4.9 Piping Insulation

• Carry out insulation of pipe connections according to "Space Cooling/Heating Pipework" in 12.4.5 Piping Installation. Wrap the pipes end-to-end with insulation to prevent condensation.

12.4.10 Charging the Water

- Make sure all the piping installations are properly done before carrying out the steps below.
- Start filling water to the Space Heating /Cooling circuit via Zone 1 Water inlet (a) (with pressure more than 1 bar (0.1MPa))
- 2. Stop filling water if the free water flow through Drain pipe of Pressure Relief Valve 12. (Check the Outdoor Unit)
- 3. Turn ON the Outdoor Unit.
- Remote control menu → Installer setup → Service setup → Pump maximum speed → Turn on the pump.
- 5. Make sure Water Pump ⑦ is running.
- 6. Check and make sure no water leaking at the tube connecting points.



12.4.11 Reconfirmation

Be sure to switch off all power supply before performing each of the below checks.

12.4.11.1 Check Water Pressure

* (0.50 bar = 0.05 MPa)

Water pressure should not be lower than 0.5 bar. (Check the water pressure by the remote controller) If necessary, add water into Space Heating /Cooling pipes (through the Zone 1 water inlet (a)).

Icon flashes if dropped below "0.50 bar"



12.4.11.2 Check Pressure Relief Valve

- 1. Pull the lever in the horizontal direction and confirm that the pressure relief valve works properly.
- 2. Release the lever when water comes out of the drain pipe of the pressure relief valve. (While the air continues to come out of the drain pipe, keep raising the lever to completely discharge the air)
- 3. Confirm that the water from the drain pipe stops.
- 4. If water is leaking, pull the lever several times and return it to make sure the water stops.
- 5. If water keeps coming out of the drain, drain water. Turn off the system and contact your local authorized dealer.

12.4.11.3 Check Air Accumulation


- Open the air vent plugs on the heating panel, fan convector, etc., and remove the air accumulated in the equipment and piping.
- If the outdoor unit and the indoor unit are installed on different floors, open the air vent plug on the water plug of the outdoor unit and the air vent plug on the heater bottle inside the indoor unit to remove the air.

(Be careful, water will come out)

12.4.11.4 Expansion Vessel Volume and Set Pressure

- This outdoor unit does not have a built-in expansion tank.
- Capacity of expansion vessel should be calculated using the formula below:
- Install an expansion vessel (set pressure: 1 bar) to the circulation circuit.

See formula below for capacity:



- V : Required gas amount <expansion vessel volume: L>
- Vo : System total water volume <L>
- ε : Water expansion rate5 x 80°C = 0.0219P1 : Expansion tank
charging pressureP1 = 100 kPa
- P2 : Maximum system P2 = 400 kPa pressure
- It is recommended to calculate the required volume of vessel with a margin of approximately 10%.

Water expansion rate table

Water temperature (°C)	Water expansion rate ε
10	0.0003
20	0.0019
30	0.0044
40	0.0078
50	0.0121
60	0.0171
70	0.0228
80	0.0291
90	0.0360

When an indoor unit is introduced and it is installed more than 7m lower than the outdoor unit

Increase the initial pressure in the expansion tank as per the calculations below.

Pg= (H*10+30) kPa

Pg : Initial pressure of expansion

tank (kPa) H : Difference in elevation (m)

12.4.11.5 Check RCCB/ELCB

- Ensure the RCCB/ELCB is set to "ON" condition before checking RCCB/ELCB.
- Turn on the power supply to the outdoor unit. This testing can only be done when power is supplied to the outdoor unit.

Be careful not to touch parts other than the TEST button of RCCB/ELCB when the power is supplied to Outdoor Unit. Else, electrical shock may happen. Before obtaining access to terminals, all supply circuits must be disconnected.

- Press the "TEST" button on the RCCB/ELCB. The lever would turn down if it functions normal.
- Contact authorized dealer if the RCCB/ELCB malfunction.
- If the RCCB/ELCB operates correctly, set the lever to 'ON' again after the test.

12.4.12 Install Discharge Grille

1 Install the front plate ①

1

2

- 2 Remove the 4 screws securing the cabinet front plate ①.
- Insert the 4 claws of the discharge grille (right side) 7 and 8, and tighten the 4 screws.

12.4.13 Test Run

- 1. Before test run, make sure below items have been checked:
 - a) Pipework are properly done.
 - b) Electric cable connecting work are properly done.
 - c) The Space Heating/Cooling circuit is filled up with water and trapped air is released.
- Switch ON the power supply of the Outdoor Unit. Set the Outdoor Unit RCCB /ELCB to "ON" condition. Then, please refer to the Operation Instruction for operation of Remote Controller.

Note:

During winter, turn on the power supply and standby the unit for at least 15 minutes before test run. Allow sufficient time to warm up refrigerant and prevent wrong error code judgement.

- For normal operation, the water pressure reading should be in between 0.5 bar and 4 bar (0.05 MPa and 0.4 MPa). If necessary, adjust the speed of the water pump ⑦ accordingly to obtain normal water pressure operating range. If adjusting the speed of the water pump ⑦ does not solve the problem, contact a local authorized dealer.
- After test run, please clean the magnetic water filter (8). Reinstall it after the cleaning is finished. (Refer to 12.4.14 Maintenance)

12.4.13.1 Check Water Flow of Water Circuit


Select Installer setup \rightarrow Service setup \rightarrow Pump maximum speed \rightarrow Air purge.

Confirm the rated flow rate has been reached. If don't reach, change max duty or install the extra pump.


*Water flow can be check in Service setup (Pump maximum speed)

[Heating operation at low water temperature with lower water flow may trigger "H75" during defrost process.]

*If there is no flow or H62 is displayed, stop operating the pump and release the air. (See "CHECK AIR ACCUMULATION" in 12.4.11 Reconfirmation)



Front plate (1)





12.4.14 Maintenance

 In order to ensure safety and optimal performance of the Outdoor Unit, seasonal inspections, functional check of RCCB/ELCB, field wiring and piping have to be carried out at regular intervals. This maintenance and scheduled inspection should be carried out by authorized dealer.

12.4.14.1 Maintenance for Magnetic Water Filter (8)

- 1. Turn OFF the power supply.
- 2. Place a container below Magnetic Water Filter (8).
- 3. Turn to remove the Magnet Bar at bottom of Magnetic Water Filter (8).
- Remove the Cap of Discharge Port with Allen key (8mm).
- 5. Open the Service Valve with Allen key (4mm) to release the dirty water from the Discharge Port into a container. Close the service valve when the container is full to avoid spillage in the outdoor unit. Dispose the dirty water.
- 6. Reinstall the Cap of Discharge Port and Magnet Bar.
- 7. Re-charge the water to Space Heating / Cooling circuit if necessary.
- (For details, refer to 12.4.10 Charging the Water)
- 8. Turn ON the power supply.





12.5 Appendix


12.5.1 Variation of System

This section introduces variation of various systems using Air-To-Water Heatpump and actual setting method. (NOTE) : This model does not have a built-in expansion vessel to prevent the pressure in the water circuit from rising in the event of temperature rise. Be sure to purchase in the market and install it.

12.5.1.1 Introduce Applications Related to Temperature Setting


12.5.1.1.1 Temperature Setting Variation for Heating

1. Remote Controller



Connect floor heating or radiator directly to the Outdoor Unit. Install remote controller on the wall of the room. This is the basic form of the simplest system.


2. Room Thermostat



Connect floor heating or radiator directly to the Outdoor Unit. Install the remote controller in the room where floor heating is installed. This is an application that uses remote controller as Room Thermostat.

12.5.1.2 Examples of Installations

1. DHW (Domestic Hot Water) Tank connection



Setting of remote controller
Installer setup System setup
Zone & Sensor: Water temperature

Setting of remote controller	
Installer setup System setup	
Zone & Sensor: Room Thermostat	


Internal

Setting of remote controller

Installer setup System setup

> Tank connection: Yes

2. Boiler connection



This is an application that connects the boiler to the Outdoor Unit, to compensate for insufficient capacity by operate boiler when outdoor temperature drops & heat pump capacity is insufficient.

Boiler is connected parallel with heat pump and used as heating circuit.

Besides that, an application that connects to the DHW tank's circuit to heat up tank 's hot water is also possible. Boiler output can be control by either SG ready input from Control Module unit or Auto control by 3 modes selection pattern.

(Operation setting of boiler shall be responsible by installer.)

Depending on the settings of the boiler, it is recommended to install buffer tank as temperature of circulating water may get higher. (It must connect to buffer tank especially when select Advanced Parallel setting) However, buffer tank connection requires Control Module unit.

Note: Buffer tank thermistor must be connected to Control Module unit PCB.

🕂 WARNING

Panasonic is NOT responsible for incorrect or unsafe situation of the boiler system.

Make sure the boiler and its integration in the system complies with applicable legislation.

Make sure the return water temperature from the heating circuit to the Outdoor Unit does NOT exceed 70°C.

Boiler is turned off by safety control when the water temperature of the heating circuit exceed 85°C.

If you wish to use optional features other than connecting DHW tank or boiler, purchase an optional indoor unit or Control Module unit.

Functions that become available by purchasing an indoor unit, etc. include:

Buffer tank connection


- 2-zone control
- Solar connection
- SG Ready
- Demand control
- J

Optional PCB is required


12.5.2 System Installation

12.5.2.1 Remote Controller Outline

The LCD display as shown in this manual are for instructional purpose only, and may differ from the actual unit.




First time of power ON (Start of installation)




Main menu	12:00 pm, Mon	
System check		
Personal setup		
Service contact		
Installer setup		
Select	[←] Confirm	
	Confirm to go into Installer set	up

12.5.3 Setup







12.5.3.2 System Setup

1. Zone & Sensor Initial setting: Water temp.	System setup	12:00am,Mo
	Zone & Sensor	
Select sensor of room temperature control from the following 2 items:	Anti freezing	
 Water temperature (circulation water temperature) Room thermostat (Internal) 	Tank connection	
	DHW capacity	
	✓ Select	[⊷] Confirm
2. Anti freezing Initial setting: Yes	System setup	12:00am,Mo
	Zone & Sensor	
Operate anti-freezing of water circulation circuit. f select "Yes", when the water temperature is reaching its freezing temperature, the	Anti freezing	
irculation pump will start up. If the water temperature does not reach the pump stop	Tank connection	
emperature, heat pump will be activated.	DHW capacity	
NOTE) If set to "No", when the water temperature is reaching its freezing	Select	[←] Confirm
temperature or below 0°C, the water circulation circuit may freeze and		
cause malfunction.		
cause malfunction.		
	System setup	12:00am,Mo
3. Tank connection Initial setting: No	System setup Zone & Sensor	12:00am,Mo
3. Tank connection Initial setting: No elect whether a hot water storage tank is connected or not.	,	12:00am,Mo
3. Tank connection Initial setting: No elect whether a hot water storage tank is connected or not. If set to "Yes", the water heating function is set to be used.	Zone & Sensor	12:00am,Mo
	Zone & Sensor Anti freezing	12:00am,Mo

4. DHW capacity Initial setting: Variable	System setup	12:00am,Mon
Variable DHW capacity setting normally runs with efficient boiling which is energy saving heating. But while hot water usage is high and tank water temperature is low, variable DHW mode will run with fast heat up which heat up the tank with high heating capacity. If standard DHW capacity setting is selected, heat pump runs with heating rated	Zone & Sensor Anti freezing Tank connection DHW capacity	
capacity at tank heat up operation. * Only when "Yes" is selected for tank connection	Select	[🚽] Confirm

5. Base pan heater Initial setting: No	System setup 12:00am,Mon		
 Select whether Base pan heater is installed or not. If set to "Yes", select to use either heater A or B. A: Turn on Heater when heating with defrost operation only B: Turn on Heater during heating operation when outside temperature is below 5 °C . 	Anti freezing		
	Tank connection		
	DHW capacity		
	Base pan heater		
	Select [+] Confirm		

6. Bivalent connection	Initial setting: No		System setup	12:00am,Mon
			Tank connecti	· · ,
Set if heat pump is linked with			DHW capacity	
Connect the start signal of the Set Bivalent connection to "Ye		minal (main PCB).	Base pan hea	
Then, begin setting according		۱.	Bivalent conne	
Boiler icon will be displayed or	remote controller top screen.		▲ Select	[🚽] Confirm
Auto There are 3 different modes in Alternative (switch to boiler Parallel (allow boiler operati Advanced Parallel (able to When the boiler operation is "C Please set target temperature When boiler temperature is hig This product only allows one s	operation when drops below tion when drops below setting slightly delay boiler operation DN", "boiler contact" is "ON", "_ of boiler to be the same as he gher than heat pump temperation	setting temperature) temperature) time of parallel operatio _"(underscore) will be di at pump temperature. ure, zone temperature of ation. Operation setting	on) splayed below the b cannot be achieved of boiler shall be re	ooiler icon. if mixing valve is not installed.
Alternative mode	oporato hoat nump only	Parallel mo		
operate boiler only	operate heat pump only	pump	te boiler and heat simultaneously	operate heat pump only
	Oute	door temp. \rightarrow		Outdoor temp.
-10°C(setting from	remote controller)			``
Advanced Parallel mode			-10°C(setting from	n remote controller)
For heating		Ec	or DHW tank	
operate boiler and heat pump simultaneously	operate heat pump only		rate boiler and heat	operate heat pump only
		pun	np simultaneously	operate near pump only
4 ³	Outdoo	or temp.		Outdoor temp.
-10°C(setting fro	om remote controller)	*** <u>*</u> ***	40%0/#	→ ·
Heat pump operates but water	AND			ng from remote controller) AND
temperature does not reach this temperature for more than 30 minutes (setting from remote control)		Tank temperature	If a no ten ten (state)	ctual tank temp. does tachieve the setting np. within 30 minutes setting from remote
ON = Setting-8°C OFF = s (setting from (setti	Circulation wat emperature setting-2°C ng from e control)	er temp. Tank Boiliniti Heat pump Boiler	ng al	ontroller), the boiler turn ON Tank setting temp. temp. time
In Advanced Parallel mode, se be made simultaneously. Durir when each time the mode is so reset to OFF. Please have goo characteristic in order to select	ng operation of "Heat/Tank" mo witched, the boiler output will b od understanding on the boiler	ode, oe ⁻ control		
• Smart There are Energy price (both e Operation setting of Energy pr Based on these settings, syste When final price of Electricity is When final price of Electricity is	ice and Schedule shall be resp em will calculate the final price s lower than Boiler's, heat pur	ponsible by installer. for both electricity and p will operate.		
Electricity price	Boiler price Boiler price ate heat pump Outdoor temp.			

7. Circulation Liquid Initial setting: Wa	ater	System setup	12:00am,Mon
]	DHW capacity	
Set circulation of heating water.		Base pan heater	
There are 2 types of settings: water and glycol.		Bivalent connection	
(NOTE) Please set glycol when using anti-freez		Circulation Liquid	
It may cause error if setting is wrong.		Select	[←] Confirm
8. Force Defrost Initial setting: Manua		System setup	12:00am,Mon
		Base pan heater	
Under manual code, user can turn on force defro	st through quick menu.	Bivalent connection	
f 'Auto' is selected, the outdoor unit will run defro		Circulation Liquid	
nave long hour of heating without any defrost op Even when Auto is selected, user still can turn o		Force Defrost	
menu)	0	Select	[←] Confirm
9. Pump flowrate Initial setting: ∆T		System setup	12:00am,Mon
		Bivalent connection	
f pump flowrate setting is * ΔT , the unit adjusts p nlet and outlet based on the setting of * ΔT for he		Circulation Liquid	
n operation setup menu during indoor operation.		Force Defrost	
If pump flowrate setting is set to Max. duty, the u	nit will set the nump duty at *Pump	Pump flowrate	
maximum speed in the service setup menu durin		Select	[←] Confirm
*1			
10. DHW Defrost Initial setting: Yes		System setup	12:00am,Mon
		Circulation Liquid	
When DHW defrost set to "YES", hot water of do Juring defrost cycle.	mestic hot water tank will be used	Force Defrost	
When DHW defrost set to "NO", hot water of floor	r heating circuit will be used during	Pump flowrate	
defrost cycle.		DHW Defrost	
		Select	[←] Confirm
11. Heating control Initial setting: Con	nfort	System setup	12:00am,Mon
]	Force Defrost	
There are two modes to select for compressor fre	equency control: "Comfort" or	Pump flowrate	
Efficiency". When set to Comfort mode, the compressor will r	un at the zone limit maximum	DHW Defrost	
requency to reach the set temperature faster.		Heating control	
When set to Efficiency mode, the compressor wil stage for energy saving.	I run at part load frequency at initial	Select	[⊷] Confirm
When "Efficiency" is selected, the time setting wil	I transition to 1st, 2nd, and 3rd stage	· · ·	

Increasing the time will slowly increase the capacity.

*1 Only when the selection for Tank connection is Yes % The above description is for outdoor unit alone case.

12. External meter	Initial setting: [Heat-cool meter : No]	System setup 12:00am,Mon	
	[Tank meter : No] *only available when Heat-cool meter select Yes	Pump flowrate	
	[Elec. meter HP : No] [Elec. meter 1 (PV meter) : No]	DHW Defrost	
		Heating control	
[Elec. meter 2 (Total building) : No] [Elec. meter 3 (Reserve) : No]	External meter		
		Select Confirm	

There are two systems for generation meter connection: single generation meter system

(Heat-cool meter) or two generation meter system (Heat-cool meter and Tank meter)

Both systems can provide all generation data of heating, cooling and DHW directly from external meter.

If Heat-cool meter is set to "Yes", it will read from external meter for heat pump's energy generation data during heating, cooling and DHW operation '1.

If Heat-cool meter is set to "No", it will base on unit's calculation for heat pump's energy generation data during heating, cooling and DHW operation.

If Heat-cool meter is set to "Yes", it will read from external meter for heat pump's energy generation data during heating, cooling and DHW operation '1.

If Elec. meter HP is set to "Yes", it will read from external meter for heat pump's energy consumption data.

If Elec. meter HP is set to "No", it will base on unit's calculation for heat pump's energy consumption data.

If Elec. meter 1 (PV meter) is set to "Yes", it will read from external meter for energy generation data of solar system and display it on Cloud system.

If Elec. meter 2 (Building) is set to "Yes", it will read from external meter for energy consumption data of the building and display it on Cloud system.

If Elec. meter 3 (Reserve) is set to "Yes", it will read from external meter for energy consumption data obtained from reserved electricity meter and display it on Cloud system.

^{*1} Set Heat-cool meter to Yes and set Tank meter to No when 1 generation meter system is installed.

Set Heat-cool meter to Yes and set Tank meter to Yes when 2 generation meter system is installed.

Remarks: Elec. meter HP refers to the electricity meter that measures Heat Pump unit's consumption.

Elec. meter 1 / 2 / 3 refers to the Electricity meter No. 1 / No. 2 / No. 3.

System setup 12:00am,Mon	
DHW Defrost	
Heating control	
External meter	
Static pressure	
Select [4] Confirm	

14. Cooling Capacity Initial setting: Efficiency	System setup 12:00am,Mon	
Select the cooling capacity. If set to "Efficiency", the unit performs cooling operation efficiently at rated capacity. If set to "Comfort", the cooling operation is performed at maximum capacity.	Heating control	
	External meter	
	Static pressure	
	Cooling capacity	
	Select [4] Confirm	

X The above description is for outdoor unit alone case.

12.5.3.3 Operation Setup

Heat


15. Water temp. for heating ON Initial setting: compensation curve Set the target water temperature to perform heating operation. Compensation curve: Target water temperature change in conjunction with outdoor temperature change. Direct: Set the circulation water temperature directly.	Compensation curve Solution curve Hot water temperature 35°C ↓ Compensation curve Decide temperature of 4 points as shown in diagram ↓ Outdoor temperature ↓ Compensation curve
16. Outdoor temp. for heating OFF If the operation of the outdoor unit is frequently switched on and off depending on the outdoor air temperature, the following settings can be used to reduce the frequency. a. Outdoor temp. for heating OFF Initial setting: 24°C Set outdoor temp. to stop heating Setting range is 6°C~35°C	ON OFF $23 \triangleright 4 24 \triangleright \rightarrow Temp.$
b. Outdoor temp. for heating ONInitial setting: 23°CSet outdoor temp. to start heating. Setting range is 5°C~X°C (X is heating OFF temp1)c. Heating ON delay timeInitial setting: 0:30minSet delay time from heating OFF to heating ON.	$\begin{array}{c c} ON & ON \\ \hline \\ OFF \\ \hline \\$
17. ΔT for heating ON Initial setting: 5°C Set temp difference between out temperature and return temperature of circulating	Out

Set temp difference between out temperature and return temperature of circulating water during Heating operation. When the temperature gap is enlarged, it is energy saving but less comfort. When the gap gets smaller, energy saving effect gets worse but it is more comfortable. Setting range is $1^{\circ}C \sim 15^{\circ}C$


 $\begin{array}{c|c} Return \\ \hline \\ Out - Return = 1^{\circ}C \sim 15^{\circ}C \end{array}$

% The above description is for outdoor unit alone case.

Cool X Cooling model only



circulating water during Cooling operation. When the temperature gap is enlarged, it is energy saving but less comfort. When the gap gets smaller, energy saving effect gets worse but it is more comfortable. Setting range is 1°C ~ 15°C



∢10°C ►

Auto X Cooling model only

20. Outdoor temp. for (Heat to Cool) Initial setting: 15°C	Heat Outdoor temp. rising
Set outdoor temp that switches from Heating to Cooling by Auto setting. Setting range is 11°C ~ 25°C	Cool
Timing of judgement is every 1 hour	◀ 15°C ►
21. Outdoor temp. for (Cool to Heat) Initial setting: 10°C Set outdoor temp that switches from Cooling to Heating by Auto setting.	Heat Outdoor temp. dropping
Set outdoor temp that switches from Cooling to Heating by Auto setting. Setting range is 5° C ~ 14°C	Cool

Timing of judgement is every 1 hour


X The above description is for outdoor unit alone case.

Tank $\stackrel{\text{\tiny $\%$}}{\longrightarrow}$ Only when the selection for Tank connection is Yes

22. Floor operation time (max.) Initial setting: 8h	
Set the max. operating hours of heating. When max. operation time is shortened, it can boil the tank more frequently.	30min ~ 10h
It is a function for Heating + Tank operation.	Tank
23. Tank heat up time (max.) Initial setting: 1h	Heat
Set the max. boiling hours of tank. When the max. boiling hours are shortened, it immediately returns to Heating operation, but it may not fully boil the tank.	
	5min ~ 4h
24. Tank re-heat temp. Initial setting: -8°C	\downarrow
Set the temperature to re-boil the tank water.	
Setting range is -12°C ~ -2°C	-12°C ~ -2°C
25. Sterilization Initial setting: 65°C 10min.	2
Set timer to perform sterilization.① Set operating day & time. (Weekly timer format)② Sterilization temperature (* 55 ~65°C)	
 ③ Operation time (Time to run sterilization when it reached setting temperature. (5 ~ 60 minutes) 	
 * When the outdoor air temperature is below -15°C The Tank temperature may only rise to about 55°C. (Turn on the external heater to perform sterilization. Need Indoor unit). Sterilization temperature varies depending on the model. 	
The use/non-use of the sterilization mode must be set.	

12.5.3.4 Service Setup

26. Pump maximum speed	Initial setting: Depend on model	S	Service setup		12:00am,Mon
		Flow rate	Max. Duty	Operation	
Normally setting is not necessary. Please adjust when needed to reduce the pump sound, etc. Besides that, the unit has Air Purge function.		Γ	34.4 L/min	0xCE	Air Purge
When the Pump flow setting is Max. Duty, this duty setting is the duty of fixed pump that runs during room-side operation.		•	Select		




28. Service contact	Service setup	12:00am,Mon	Contact-1: Bryan	Adams
	Service contact:		ABC/ abc	0-9/ Other
Able to set the name & tel. no. of contact person when there is	Contact 1		ABCDEFGH	JKLMNOPQR
breakdown etc. or client has trouble.	Contact 2		STUVWXYZ	abcdefghi
(2 items)			jklmnopqrst	u v w x y z
	Select [4] Conf	irm	↓ Select	[⊷] Enter

12.5.3.5 Remote Control Setup


29. RC selection Initial setting : Single	RC selection	12:00am,Mon
Set to "Single" when only one remote controller is installed. Set to "Dual" when two remote controllers are installed.		ingle ▼ Dual
	✓ Select	←] Confirm

% The above description is for outdoor unit alone case.

12.6 Service and Maintenance



12.6.1 Maintenance Menu



12.6.2 Custom Menu

Se	etting me	ethod of Custom menu		
Cu	stom mer	nu 1	2:00am,Mon	
Co	ool mode			
Re	eset ener	gy monitor		
Re	eset oper	ation history		
Ar	nti-stick m	lode		
	Select	[┛] Confirm		
	ns that ca Cool moo without	de (Set With/Without Coo As with/without Cool mo application, please be c		
2		may drip on the floor an nergy monitor (delete me	may form on pipe and wat d damage the floor. mory of Energy monitor)	
3	Reset op	peration history (delete m	use and handover the unit. nemory of operation history use and handover the unit.	()

 Anti-stick mode (select Anti-stick mode Enable/Disable) Default is Anti-stick mode /Enable Every Monday at 3:00 AM the actuator is activated periodically to prevent sticking of the operating parts.
 Select Disable if you wish to stop the part being activated periodically.
 Parts and other components that may not operate if Disable is

selected may stick if not operated for a long period of time.

X The above description is for outdoor unit alone case.

13. Installation and Servicing Air-to-Water using R290



This symbol shows that this equipment uses a flammable refrigerant with safety A3 group per ISO 817. If the refrigerant is leaked, together with an external ignition source, there is a possibility of fire / explosion.

13.1 About R290 Refrigerant

Hydrocarbon is a class of organic chemical made up only with the element Carbon (C) and Hydrogen (H). R290 is the type of Hydrocarbon refrigerant which is environmentally good-natured and odorless refrigerant. Under Kigali Amendment to the Montreal Protocol, 80% reduction of greenhouse gas emission by next 30 years is required, and due to this requirement, further reduction in the emission of high greenhouse effect gas is required. Therefore, the conversion of air-conditioning refrigerant into one which has no greenhouse effect, even if it is dissipated into the atmosphere became our responsibility.

Nevertheless, in case of air-conditioning refrigerant, it would be the best if there is a refrigerant which has no impact on global warming but ensures good energy efficiency and performance, and is safe; however, there is no such refrigerant which satisfies all these conditions. As a result, we have been considering the practical usage, within the safety frame-work, of R290 refrigerant which has no effect of global warming but highly flammable.

13.2 Characteristics of R290 Refrigerant

1. Chemical Characteristics

R290 (Propane) is refrigerant grade propane, which is natural, non toxic, and chemically stable compound formed by hydrogen.

R290 is one of natural refrigerant, therefore it has almost zero greenhouse gas effect. R-290 is a single-component hydrocarbon substance and the most hydrocarbon properties as it is highly flammable.

	R290	R32
Chemical Formula	C3H8	CH2F2
Composition	Single Composition	Single Composition
Boiling point (°C)	-42.1	-51.7
50°C vapor pressure (MPa)	1.71	3.14
Ozone Depletion Potential	0	0
Global Warming Potential (GWP)	3	675
Inflammability	Highly Inflammable (A3)	Slightly Inflammable (A2L)
Toxicity	None	None

Chemical Characteristic Table of R290 and R32

2. Characteristic of Pressure

As shown in Table 2, R290 has half the vapor pressure of R32 at the same refrigerant temperature. As such, it can be installed and maintained with the same high-pressure tools and components as the R32.

Table 2. Saturated vapor pressure comparison table

(Unit: MPaG)

Tomporature (°C)	Refrigerant		
Temperature (°C)	R290	R32	
-20	0.14	0.30	
0	0.37	0.71	
20	0.74	1.37	
40	1.27	2.38	
60	2.03	3.84	
65	2.23	4.29	

Reference : Thermal properties table of Japan Society of Refrigerating and Air Conditioning Engineers (60, 65°C) NIST REFPROP V8.0 (-20 ~ 40°C)

3. Flammable characteristic

As shown in below table, R290 is highly flammable and explosive when heated. The installation must be equipped with ATEX (Atmospheres Explosible) certified equipment and must always turn on the combustible gas detector during servicing and when entering the service area. Service must also be performed in a well-ventilated area, especially if the refrigerant system is being accessed.

3.1 Safety class

		SAFETY	GROUP
	Higher Flammability	A3	B3
sing ability		A2	B2
Increasing Flammability	Lower Flammibility	A2L	B2L
ц На Га	No Flame Propagation	A1	B1
		Lower Toxicity	Higher Toxicity
		Increasin	g Toxicity


Refrigerant	Burning Speed cm/s
R32	6.7
R290	38.7

3.2 Concentration control for R290

Because R290 is highly flammable, it can burn or explode if there is enough product concentrated in one space and the refrigerant comes in contact with an ignition source.

Control measurement;

Descriptions	Specifications
Lower flammability limit (LFL) [kg/m³]	0.038
Lower flammability limit (LFL) [%]	2.1
Practical limit (PL) [kg/m ³]	0.008
Density of vapour [kg/m³]	1.83



The concentration of R290 between the lower flammable limit (2%) and upper flammable limits (10%) is enough to ignite fire.

Note:

LFL – Lower flammable limit whereby the concentration of flammable gas, vapour or mist in the air below which an explosive gas atmosphere will not be formed.

UFL – Upper flammable limit whereby the concentration of flammable gas, vapour or mist in the air below which an explosive gas atmosphere will not be formed.

PL – Defined as concentration used for simplified calculation to determine the maximum acceptable amount of refrigerant in an occupied space (20% of LFL)

3.3 Material classification and Hazard statement

H280	Contain gas under pressure; may explode if heated
CGA-HG01	May cause frostbite

13.3 Refrigerant piping installation • Tools used in services

13.3.1 Required Tools

R290 refrigerant air conditioners must use ATEX (Atmosphere Explosible) certified equipment. The common parts as R32 air conditioners for two-way valves and three-way valves (diameters of service ports); thus, they maintain commonality in the maintenance of the compressive strength, the size of pipe flaring, and the size of flare nuts as R32. However refrigerant pipe installation and services must use tools certified for highly flammable gas.

However, mixing of refrigerants is not allowed, so that you have to separate the cylinders for the recovery of refrigerants.

Tools used for installation • relocation • replacement of air conditioning units

Works	R290	R32
Connecting of refrigerant pipes	Not applicable for Monobloc	
Connecting of reingerant pipes	Not applicable for Monobloc	
Manifold gauge charging hose	HC Manifold gauge to avoid refrigerant contamination R32 & R410A Common	
Air purging	Vacuum pump complied with ATEX (Atmosphere Explosible) Vacuum pump + Reducer / expande	
Gas leakage test	Combustible gas detector	Detection liquid or soup water, HFC detector

For other installation, you can use general tools such as screw drivers (+, -), metal saws, long-nose pliers, hole core drills, linen tape, levels, temperature gauges, clamp meters, electric knives, nippers, pipe cutters, reamers or scrapers, spring benders, monkey wrenches, fixing wrenches, feeler gauges, hexagon wrenches (4 mm), testers, megohm testers, etc.

Tools used for services.

Works	R290	R32
Insertion of refrigerant	Digital scale for refrigerant charging, refrigerant cylinders, cylinder adopters and packing *a	
Recovery of refrigerant	Refrigerant recovery devices, refrigerant cylinders, manifold gauges, charging hoses *b	

*a. Use cylinder for each refrigerant, cylinder adopter and packing.

*b. Use refrigerant recovery cylinder separately for each refrigerant (no mixture of refrigerant allowed).

13.3.2 Tools for R290

1. Manifold gauges

R32 gauge can be used for R290 pressure.

Each port of manifold has different shapes in order to prevent inserting wrong refrigerant. *However, the port shape for R290 and R32 is the same; therefore, attention need to be paid not to insert wrong refrigerant.

Differences in high/low pressure gauges

	R290 (common R32)
High pressure gauges (red)	-0.1 ~ 5.3 MPa -76 cmHg ~ 53 kgf / cm²
Low pressure gauges (blue)	-0.1 ~ 3.8 MPa -76 cmHg ~ 38 kgf / cm²

Difference in manifold port sizes


R290 (common R32)		
Port sizes	1/2 UNF20	

2. Charging hoses

The material is changed to HC resistant, and the size of each manifold adopter is common, as the R32 port size of manifold gauge.

Further, some hoses are with anti-gas pressure backflow valves placed near the adopters. (hoses with the valves recommended)

Manifold gauges / Charging hoses



Differences in charging hoses

		R290 (common R32)	
Pressure Resistance	Normal operation pressure	5.1 MPa (52 kgf / cm²)	
	Burst pressure	27.4 MPa (280 kgf / cm²)	
Material		HNBR rubber Internal nylon coating	

3. Vacuum pump and isolator.

When using a vacuum pump, it is compulsory to use an ATEX certified vacuum pump.

When connecting service equipment (such as vacuum pumps) to a power source, the connection should be made in outside the Temporary Danger Zone. It is recommended to use an ATEX Isolator switch to facilitate a safe shutdown in the danger zone. It is necessary to set a solenoid valve in order to prevent backflow of vacuum pump oil into the charge hoses and use a vacuum pump with oil backflow prevention function.

If vacuum pump oil (mineral oil-based) mixes with R290, it may cause damage to the machine.

Vacuum pump



Isolator



4. Leak Detector

HC refrigerant Electric gas leakage tester is used for R290. The usage of existing HFC detectors cannot be use as they can produce spark. We recommend to use detectors specifically designed for combustible gas.

Combustible gas leak detector



5. Digital scale for refrigerant charging

R290 has lower pressure level and the evaporates speed is slow. Thus, the digital scale for refrigerant charging can be used in common with R32. The charging port for R32 is (1/2 UNF20), common with R290

Digital scale for refrigerant charging



6. Refrigerant cylinders

Refrigerant cylinders for R290 are painted in other colors that might subject to change according to the international standards. R290 is a single refrigerant, so that both liquid and gas insertion are possible. Additional charging is also possible.

Refrigerant cylinders



7. Connection ports of refrigerant cylinders and packing

Charging ports which fit to the charging hose connection port size (1/2 UNF20) is needed. At the same time, the packing has to be of HC resistant materials.

Connection ports and packing



8. Tools used for refrigerant piping installations and services

	Common tools	R290	R32		
1.	Pipe cutters, reamers or scrapers	Not applicable for Monobloc	Not applicable for Monobloc		
2.	Flare tools (clutch type)	Not applicable for Monobloc	Not applicable for Monobloc		
3.	Torque wrench (1/4, 3/8)	Not applicable for Monobloc	Not applicable for Monobloc		
4.	Torque wrench (1/2, 5/8)	Not applicable for Monobloc	Not applicable for Monobloc		
5.	Manifold gauges, charging hose	0	0		
6.	Vacuum pump, vacuum pump isolator *2	Connection 5/16 [ATEX certified] *1			
7.	Electric gas leakage detectors	Combustible gas detector	HFC detector		
8.	Digital scale for refrigerant charging	0	0		
9.	Recovery devices (connection port 5/16) *2	ATEX certified	HFC recovery devices		
10.	Refrigerant cylinder color	Other (colors that might subject to change according to the international standards)	Other (colors that might subject to change according to the international standards)		
11.	Refrigerant cylinder connection port and packing	x	0		
12.	Allen wrench (4mm) Electric knives	x	0		
*1	Those testers only for HC only cannot be for common use with HFC				
*2	Recovery devices which are certified by Atmosphere Explosible (ATEX)				
	 [Knowledge for the common usage of tools for R290 & R32] R290 and R32 machines use different compressor oils. If unregulated compressor oil gets mixed into, it may cause 	se damage to the machine function.			

At the same time, it is not subject to product warranty, if wrong refrigerant was inserted into system.


Reference:-

- ASHRAE Standard 34-2016
- ISO Standard ISO 5149
- ISO 817:2014

13.4 New installation, and Repairing of Refrigerant Cycle System Procedures

Personnels working on A3 systems may be subject to applicable occupational hazard or regulations required by local or national law.

For safe servicing and disposal, technicians must have detailed knowledge and skills in handling of flammable refrigerants, prevention of refrigerant leaks, leak detection, personal protective equipment, cylinder handling and loading. A dry powder or CO_2 fire extinguisher must be available at the place of service.




13.5 Servicing

13.5.1 Recover R290 refrigerant with refrigerant recovery machine


CAUTION!

- Always turn ON the combustible leak detector.
- Keep all ignition sources, hot surface, and open flames 3 meter away from the product.
- Ensure the servicing area is well ventilated.
- Ensure the product is service by certified serviceman.
- Ensure to always have the approved fire extinguisher.



CAUTION!

All equipment and material must be ATEX certified to be allowed to operate within Atmosphere Explosible zone.




CAUTION!

Do not refill R290 refrigerant more that 50% of recovery cylinder capacity to avoid overpressure. (Safety risk)

Refrigerant Type	Recovery Cylinder Capacity	
R32	80% of the weight	
R290	50% of the weight	

- 2. Connect the Low side charging hose of the manifold gauge to the service valve (2-way valve) in the outdoor unit.
- 3. Connect the center hose of the manifold gauge to the recovery machine.
- 4. Attached the manifold gauge correctly and tightly. Ensure both valve (Low side and High side) is in close position.
- 5. Connect the hose from recovery machine to the recovery cylinder.
- 6. Turn ON the recovery machine, turn the low side valve, service valve and recovery valve to open position.

13.5.2 Purging by using Nitrogen Gas Before Servicing and Disposal



- 1. Connect nitrogen cylinder to the high side at the manifold gauge. Ensure nitrogen cylinder is connected to pressure regulator.
- 2. Close air release valve and open service valve.
- 3. Open High side valve and nitrogen release valve. (Set the pressure regulator to 200psi).
- 4. Charge nitrogen gas up to 0.7MPa (101psi) or charge 400 grams of nitrogen into the unit.
- 5. Close high side valve and open air release valve (half open) to release remaining propane to the atmosphere. Air release valve must be directed 1 meter from the floor to enable the propane gas to spread properly in the atmosphere. [Beware not to fully open the air release valve to avoid high pressure and compressor oil discharge].
- 6. When gauge 1 pressure reach near atmospheric (15psi) point the combustible leak detector to air release valve to detect the presence of propane. If presence of propane can still be detected, repeat procedure 2 to 5 until presence of propane cannot be detected.

[Then refrigerant circuit repairment or unit decommissioning should be done].

7. Before charging new refrigerant, vacuum the system until it reaches to 500micron (67Pa) to remove foreign gas in the system and hold for 15 minutes.

14. Operation and Control

14.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operating mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operating mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at outdoor unit is operating following the frequency instructed by the microcomputer at indoor unit that judging the condition according to internal water setting temperature and water outlet temperature.

14.1.1 Internal Water Setting Temperature

Once the operation starts, control panel setting temperature will be taken as base value for temperature shifting processes. These shifting processes are depending on the Air-to-Water Heat pump settings and the operation environment. The final shifted value will be used as internal water setting temperature and it is updated continuously whenever the electrical power is supplied to the unit.

14.1.2 Heating Operation

14.1.2.1 Thermostat Control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > 3°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) <-3°C.

14.1.2.2 Thermostat Control (Outdoor Ambient Temperature)

Stops provide heating to room side during high outdoor ambient condition. Control content:

- Heating operation and water pump will turn OFF when outdoor ambient temperature > outdoor thermo off temperature + 3°C.
- (Outdoor thermo off set temperature is set by control panel. Thermo off set temperature is between 5°C ~ 35°C)
- Heating operation will resume when Outdoor ambient temperature < Outdoor thermo OFF set temperature + 1°C.

14.1.2.3 Heat Mode Operation

Operation of heat pump provide heating capacity to room side by hot water through heating panel, floor heating or fan coil unit.

1 3 ways valve control:

2

- 3 ways valve switch and fix to heating side.
- Heat pump operates follow normal heating operation.
- 3 Back up heater operate follow normal operation.
- 4 2 ways valve control:
- 2 ways valve opens.

14.1.3 Cooling Operation

14.1.3.1 Thermostat Control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > -1.5°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) >3°C.

14.1.3.2 Cool Mode Operation

- 1 3 ways valve control:
- \circ 3 ways valve switch and fix to cooling side.
- 2 Heat pump operates follow normal cooling operation.
- 3 Room heater DOES NOT operate during cool mode.
- 4 2 ways valve control:
 - \circ 2 ways valve is closed.

14.1.3.3 Cooling Capacity Control

The cooling capacity can be set to either Efficiency or Comfort priority. (However, this is only available for WH-WXG12ME8 and WH-WXG16ME8.)

Remocon setting : Cooling capacity = Efficiency (default)

Prioritize efficiency and operate the cooling with reduced capacity

Remocon setting : Cooling capacity = Comfort

Prioritize comfort and operate the cooling at maximum capacity.

14.1.4 Target Water Temperature Setting

14.1.4.1 Target Water Temperature Control of Standard System (Optional PCB not Connected)

There are 2 types of temperature control selection which are Compensation and Direct.

- Temperature control type selection by installer:
 - 1 Compensation : Wlo, WHi, ODLo, ODHi can be set at installer menu.
 - 2 Direct : Direct Water Temperature Set
- Remote control setting by user:
 - 1 Compensation : Shift value ±5°C from the compensation curve
 - 2 Direct : Direct water temperature set change

*This setting only able to set when room sensor select as Water Temperature.

*Instead of water temperature, user will set target room temperature when room sensor select as Room Thermistor OR Internal Room Thermostat.

- Target water temperature is calculated as below condition.
 - Target water temperature = A (Base temperature) + B (shift temperature)

A (Pass Tomporature)	Compensation	Direct
A (Base Temperature)	Value from the curve + User shift value set	Direct value from user setting

o B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below	
Sensor selection		
Water temperature	e B = 0	
External Room thermostat	B = 0	
Internal Room thermostat &	Cool Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = B = 1* (room set temp (R/C) – actual room temp) Max/Min Regulation of B: (Max = 5 ; Min = -5)	
Room Thermistor	Heat Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = follow Heating Room Temperature PI control logic	


• Maximum/minimum regulation of Target Water Temperature

	Heating	Cooling
МАХ	55°C (Below Ambient -25°C) * 75°C (Above Ambient -15°C) *	20°C
MIN	25°C	5°C

* Between outdoor ambient -15°C and -25°C, max target decreases gradually from 75°C to 55°C.

Compensation Type: (Operation under Heat Mode and Cool Mode)


• The set temperature defines the parameters for the ambient (Outdoor temperature) dependent operation of the unit. The water temperature is determined automatically depending on the outdoor temperature. Default setting is the colder outdoor temperature will result in warmer water and vice versa. The user has the possibility to shift up and shift down the target water by remote control setting.



- Outdoor ambient is updated every 30 minutes when operation ON.
- Setting water outlet temperature always follow W_(LO) or W_(HI) whenever is higher if outdoor ambient sensor or indoor communication error happen.

However, when powerful mode is requested by remote control during heating mode, the higher value of HLo or Whi will be used for A calculation.

- * There are 2 compensation curves (for heating and cooling). During heating mode, the heating curve is used and during cooling mode, the cooling curve is use.
- Compensation curve set shift value:



14.1.5 Target Water Temperature at Extension System (Optional PCB is Connected)

Target water temperature is calculated as below.

- Heat Mode:
- When buffer tank selection is "YES:" Target water temperature = Target buffer tank temperature + [2°C]
- When buffer tank selection is "NO"
 - If both zone 1 and zone 2 is active Target Water Temperature = Higher zone target water temperature of Zone 1 and Zone 2.
 If only one zone is active
 - Target Water Temperature = Zone target water temperature of active zone.

- Cool mode:
- When buffer tank selection is "YES"
 - o If both zone 1 and zone 2 active
 - Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2 $_{\odot}$ $\,$ If only one zone is active
 - Target Water Temperature = Zone Target Water Temperature of active zone
- When buffer tank selection is "NO"
 - If both zone 1 and zone 2 active
 - Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2
 If only one zone is active
 - Target Water Temperature = Zone Target Water Temperature of active zone

*Cool Mode does not have SG ready control

14.1.6 Target Zone Water Temperature Control

Purpose:- To control zone mixing and zone pump according to the zone sensor temperature

14.1.6.1 Target Zone 1 Water Temperature Setting Control

- Start condition
 - Heating zone 1 is ON by remote control or Timer or Auto Mode OR
 - Cooling zone 1 is ON by remote control or Timer or Auto Mode.
- Cancel condition
 - Heating zone 1 is OFF by remote control or Timer or Auto mode AND
 - Cooling zone 1 is OFF by remote control or Timer or Auto mode.
- Target Zone 1 water temperature is calculated as below condition.
 - Target Zone 1 water temperature = A (Base temperature) + B (shift temperature)

A (Pasa Tamparatura)	Compensation	Direct
A (Base Temperature)	Value from the curve + User shift value set	Direct value from user setting

- * During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.
 - o B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below	
Sensor selection		
Water temperature	r temperature B = 0	
External Room thermostat	B = 0	
Internal Room thermostat & Room Thermistor	Cool Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = B = 1* (room set temp (R/C) – actual room temp) Max/Min Regulation of B: (Max = 5 ; Min = -5)	
	Heat Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = follow Heating Room Temperature PI control logic	
Pool Function Selected	B = Delta value setting from remocon	

* B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool "B" value)

** Pool function also can be select at Zone 1 when optional PCB is connected and Zone 1 system is select.

• Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
МАХ	55°C (Below Ambient -25°C) * 75°C (Above Ambient -15°C) *	20°C
MIN	25°C	5°C

* Between outdoor ambient -15°C and -25°C, max target decreases gradually from 75°C to 55°C.

- Target Zone 1 Water Temperature (Heat mode only) during SG ready control
 - o If buffer tank selection is "NO" then following shift is carried out.
 - While digital input is "10" or "11" then,
 - Final Target Zone 1 water temperature
 - = Target Zone 1 water temperature* (SG ready % setting (remote control menu))%
 - If buffer tank selection is "YES"
 - No shift of Target Zone 1 Water Temperature. Target Buffer Tank Temperature will change accordingly.
 * Refer to "Buffer tank temperature control"

14.1.6.2 Target Zone 2 Water Temperature Setting Control

- Start condition
 - $_{\odot}$ Heating zone 2 is ON by remote control or Timer or Auto Mode OR
 - Cooling zone 2 is ON by remote control or Timer or Auto Mode.
- Cancel condition
 - \circ Heating zone 2 is OFF by remote control or Timer or Auto mode AND
 - Cooling zone 2 is OFF by remote control or Timer or Auto mode.
- Target Zone 2 water temperature is calculated as below condition.
 - Target Zone 2 water temperature = A (Base temperature) + B (shift temperature)

A (Base Temperature)	Compensation	Direct
A (base reinperature)	Value from the curve + User shift value set	Direct value from user setting

- * During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.
 - B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below	
Sensor selection		
Water temperature	B = 0	
External Room thermostat	B = 0	
Internal Room thermostat &	Cool Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = B = 1* (room set temp (R/C) – actual room temp) Max/Min Regulation of B: (Max = 5 ; Min = -5)	
Room Thermistor	Heat Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = follow Heating Room Temperature PI control logic	
Pool Function Selected	B = Delta value setting from remocon	

- * B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool "B" value)
- ** Pool function also can be select at Zone 2 when optional PCB is connected and Zone 2 system is select.

• Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
MAX	55°C (Below Ambient -25°C) * 75°C (Above Ambient -15°C) *	20°C
MIN	25°C	5°C

- * Between outdoor ambient -15°C and -25°C, max target decreases gradually from 75°C to 55°C.
- Target Zone 2 Water Temperature (Heat mode only) during SG ready control
 - If buffer tank selection is "NO" then following shift is carried out.
 - While digital input is "10" or "11" then,
 - Final Target Zone 2 water temperature
 - = Target Zone 1 water temperature* (SG ready % setting (remote control menu))%
 - If buffer tank selection is "YES"
 - No shift of Target Zone 2 Water Temperature. Target Buffer Tank Temperature will change accordingly.
 * Refer to "Buffer tank temperature control"

14.1.6.3 Zone Temperature Control Contents

- During Standard System (Optional PCB not connected)
 - Only 1 zone temperature control is available
 - This zone room temperature is control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temperature)
 - Target Zone Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor. Target Water Temperature will set same as Target Zone Water Temperature
 - Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).

* There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.

• During Extension System (Optional PCB connected)

* There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.

- During Extension System (Optional PCB connected)
- Buffer Tank connection select "NO" &
 - One zone system is select
 - This zone room temperature control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temp.)
 - Target Zone Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor.
 - Target Water Temperature will set same as Target Zone Water Temperature
 - Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).

* There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.


- 2 zone system select
 - Each zone room temperature is control by each sensor which select from either one of the 4 room sensor
 - Target Zone 1 & 2 Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor.
 * Zone Mixing Valve & Zone pump will operate to achieve Target Zone Water Temperature which refer to zone sensor.
 - * Zone Sensor will detect if zone sensor is open or short.
 - Target Water Temperature will set same as the active & higher zone water temperature setting. (When cooling mode, lower zone water temp setting)

- Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.
- Heat pump and water pump OFF when ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat).
- Buffer Tank Connection select "YES" &
 - 1 zone system or 2 zone system select
 - Each zone control by each sensor which select from either one of the 4 room sensor
 - Target Zone 1 & 2 Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor. Each zone have their own Target Zone Water Temperature.

* Zone Mixing Valve & Zone pump will operate to achieve each Target Zone Water Temperature which refer to zone sensor


- * Zone Sensor will detect if zone sensor is open or short.
- Target Buffer Tank Temperature will be set as active & higher zone water temperature setting + Buffer Delta T. (Heating) Target Buffer Tank Temperature will be set as active & lower zone water temperature setting (Cooling).
- Target Water Temperature will set as Target Buffer Tank Temperature + [2°C] (Heating) Target Water Temperature will set as Lower or Active Target Zone Water Temp. + [-3°C] (Cooling)
- Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
- Heat pump and water pump OFF when ROOM thermo OFF
 - Heat mode: ROOM thermo OFF (Buffer Tank Temperature > Target Buffer Tank + [0°C]
 - Cool mode: ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat)

14.1.7 Auto Mode Operation



- Control details:
 - To enable the unit to operate either heat or cool mode automatically, heat to cool set temperature and cool to heat set temperature can be set by control panel.
 - Automatic operation is judged based on control panel setting temperature and outdoor ambient temperature.
 - * Minimum setting of heat to cool set temperature is 1°C higher than cool to heat set temperature.
- Judgement control:
 - If outdoor ambient temperature < Heat to Cool Set Temperature, unit will operate in Heat Mode or else the unit will operate in Cool Mode.
 - If current operation is Cool mode, outdoor ambient temperature > Cool to Heat Temperature, unit will maintain Cool mode operation or else the unit will operate Heat mode.
 - If current operation is Heat mode, outdoor ambient temperature > Heat to Cool Temperature, unit will maintain Heat mode operation or else the unit will operate Cool mode.
 - Every 60 minutes the outdoor ambient temperature is judged.
 - When Auto + Tank mode is selected, operation mode switching is judged by both outdoor ambient temperature and indoor air temperature.

14.1.8 Auto Cooling Mode Operation Limit



- Auto Mode Cooling Only operation will start once the outdoor ambient temperature reaches 19°C and compressor will continue to run until the outdoor ambient temperature drops to 16°C.
- Due to this limitation, If Heat to Cool temperature is set lower than 19°C, the compressor will not operates until the outdoor ambient temperature reaches 19°C or higher.

14.1.9 Tank Mode Operation

- 3 ways valve direction
 - 3 ways valve switch to tank side during Tank Thermo ON condition. Switch 3 ways valve to room side when tank achieve Tank Thermo OFF temperature.
- Tank Thermo ON/OFF Characteristic
 - Tank Thermo OFF

Case 1: Internal Tank Heater is select and Tank Heater ON

- Tank temperature > Tank Set Temperature continuously for 15 seconds.
- Water outlet >75°C
- Case 2: Tank Heater OFF OR External Heater is select
 - When heat pump OFF due to water thermos & Tank temperature > Tank water set temperature for continuously 20 seconds. OR
 - Tank temperature > Tank set temperature + 1°C for continuously 20 seconds.
 - Tank Thermo ON

Case 1: <u>Tank Heater ON (Internal Tank Heater)</u>

Tank temperature < Tank set temperature + R/C (Tank re-heat temperature)

Case 2: Tank Heater OFF (Internal Tank Heater)

• Tank temperature < Tank water set temperature + R/C (Tank re-heat temperature)

* When tank thermo ON, water pump will ON for 3 minutes then only heat pump turn ON.

- * Tank water set temperature = tank set temperature or 65°C whichever lower.
- 2 ways valve close
- Heat pump Thermostat Characteristic
 - Heat pump Water Outlet set temperature is set to below table:

Outdoor ambient temperature	Heat pump water outlet temperature
< -20°C	55°C
> -20°C	65°C
> -10°C	75°C

Characteristic of heat pump thermos ON/OFF under tank mode condition:

Water Outlet Thermo Condition

- Heat pump thermos OFF temperature:
 - 1 Heat pump thermo OFF temperature = Target Water outlet temperature + (2°C)
 - 2 Water outlet temperature > heat pump thermo OFF temperature for continuously 3 minutes, heat pump OFF but water pump continue ON.

- Heat pump thermo ON temperature
 - 1 Heat pump thermo ON temperature = water inlet during thermo OFF time + [-3°C]
 - 2 When water outlet temperature < heat pump thermo ON temperature, heat pump ON.

Water inlet thermo protection condition

- Heat pump thermo OFF temperature:
- 1 Water inlet temperature > [75°C/55°C] for continuously 30 seconds, heat pump OFF, water pump continue ON.
- Heat pump thermo ON temperature:
 - Heat pump thermos ON temp = water inlet temperature < $[75^{\circ}C/55^{\circ}C]$.

Outdoor ambient temperature	Water inlet temperature
< -20°C	55°C
> -20°C	75°C

Thermo ON/OFF for Heat Pump in Tank Operation:

When tank temperature achieve heat pump OFF condition, refer below condition: Conditon 1 : Tank Heater ON (Internal Tank Heater)

• Heat pump will turn OFF, water pump continue ON and room heater will continue ON if tank temperature below tank heater thermo ON condition. 3 ways valve will only switch to room side after tank temperature reach tank heater thermo OFF condition.

Conditon 2 : Tank Heater OFF (Internal Tank Heater)

• If tank temperature achieve tank thermo OFF, heat pump turn OFF, water pump turn OFF, room heater OFF and 3 ways valve switch to room side.

When tank temperature achieve heat pump ON condition, water pump ON, heat pump ON and room heater turn OFF.

Heat pump OFF condition at Tank Mode

- Tank temperature > tank water set temperature continuously for 20 seconds after heat pump thermos OFF due to water thermo. (Heat pump turn OFF but water pump continue ON and room heater turn ON to achieve tank set temperature) OR
- Tank temperature > tank set temperature + [1°C] for continuously 20 seconds. (Heat pump OFF, water pump OFF, room heater OFF and 3 ways valve switch to room side)

Heat pump ON condition at Tank Mode

Tank temperature < tank water set temperature + R/C setting (Tank re-heat temp) (Water pump turn ON OR continue ON, heat pump ON and 3 ways valve switch to tank side or maintain at tank side)

Tank heater control

• Internal heater only operates to tank side if Tank heater ON and backup heater is enable.

Internal heater turn ON condition:

- Tank temperature < tank set temperature AND
- Heat pump thermos OFF AND
- 20 minutes from previous heater off AND
- Internal tank heater selects USE from control panel.

Internal heater turn OFF condition:

- Tank temperature > tank set temperature for continuously 15 seconds OR
- Heat pump thermo ON **OR**
- Mode change or operation is off by control panel.

14.1.10 Heat + Tank Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch to room side during room heat-up interval and switch to tank side during tank heatup interval. Both modes will switch alternately. Tank mode is the initial running mode of Heat + Tank mode.
- 2 Heat pump operation control:
 - During room heat-up interval
 - Follow normal heating operation.

Switching to tank side depends to below cases: Case 1:

[Previous switch from tank interval to room interval due to thermo OFF]

- Switch to tank heat-up interval when Tank temp < Tank thermos ON temp (Room heat-up interval ends)
 - Case 2:

[If heating operation at room side is less than 30 minutes and switch to tank side 3 times consecutively]

- Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank thermo ON temperature. Case 3:
 - [Previous switch from tank interval to room interval due to tank interval timer is complete]
- Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** tank temperature < Tank thermo ON temperature.
- During Tank heat-up interval
 - Tank interval is the first mode running when heat + tank mode is select.
 - Switch to room interval only when tank achieve tank thermo OFF **OR** tank heat-up interval timer is complete.
 - Heat pump operates according to normal tank mode operation.
- 3 Room heater control:
 - During heating heat-up interval
 - Follow normal room heater control operation.
- 4 Tank heater control:

0

0

- During heating heat-up interval
 - Internal tank heater will not function under heating heat-up interval.
 - During tank heat-up interval
 - Internal tank heater will turn ON after heat pump thermo off to boil tank temperature to tank set temperature.
 - 2 ways valve control is open
- Indoor water pump control:
 - Indoor water pump always turn ON if room heat pump thermo ON OR Tank thermo ON.

14.1.11 Cool + Tank Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch to room side during room cooling interval and switch to tank side during tank heatup interval. Both mode will switch alternately. Tank mode is the initial mode of cool + tank mode.
- 2 Heat pump operation control:
 - During room heat-up interval
 - Follow normal cooling operation.
 - Switching to tank side depends to below cases: Case 1:
 - [Previous switch from tank interval to room interval due to thermo OFF]
 - Switch to tank heat-up interval when Tank temperature < Tank Thermo ON temperature (Room interval will ends)
 - Case 2:

[If cooling operation at room side is less than 30 minutes and switch to tank side for 3 times consecutively]

- Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank thermo ON temperature. Case 3:
- [Previous switch from tank interval to room interval is due to tank interval timer is complete]
- Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** tank temperature < Tank thermo ON temperature.


*Tank Thermo ON temperature:

Internal Tank Heater select USE	<tank (tank="" +="" c="" r="" re-heat="" set="" setting="" temperature="" temperature)<="" th=""></tank>
Others	<tank (tank="" +="" c="" r="" re-heat="" set="" setting="" td="" temperature="" temperature)<="" water=""></tank>

- During Tank heat-up interval
 - Tank interval is the first mode running when the cool + tank mode is select.
 - Switch to room interval only when tank achieve tank thermo OFF **OR** tank heat-up interval timer is complete.
 - Heat pump operates according to normal tank mode operation.
- 3 Room heater control:
 - During room cooling interval
 - Room heater is OFF and not operates.
- 4 Tank heater control:
 - During room cooling interval
 - Internal tank heater will not function under room cooling interval.
 - During tank heat-up interval
 - Internal tank heater will turn ON after heat pump thermos off to boil tank temperature to tank set temperature.
- 5 2 ways valve is close.
- 6 Indoor water pump control:
 - o Indoor water pump always turn ON if room heat pump thermo ON **OR** Tank thermo ON.

14.1.12 Outdoor Fan Motor Operation

Outdoor fan motor is adjusted according to operation condition. It starts when compressor starts operation and it stops 30 seconds after compressor stops operation.



The reason the outdoor fan stops 60 seconds after the compressor stops is to exhaust heat.


The reason why the compressor starts operating 30 seconds before it starts is to accurately detect the outside temperature.

14.2 Water Pump

The system will start checking on the water flow level after operation start for 70 seconds. If water pressure level is detected low or high continuously 300 seconds, the water pump and the compressor will be OFF permanently and OFF/ON control panel LED will blink (H21 error occurs).

14.2.1 Water Pump Control

- Once the indoor unit is ON, the water pump will be ON immediately and no error judgment for 70 seconds. However, during this 70 seconds operation, if there is any abnormality cause at outdoor or malfunction, the compressor should be OFF immediately and restart delay after 3 minutes.
- The system will start checking on the water flow level after operation start for 70 seconds. If water flow level is
 detected low continuously 60 seconds, the water pump and the compressor will be OFF permanently and
 OFF/ON control panel LED will blink (H62 error occurs).
- When error happens, the power has to be reset to clear the error.
- If there is no error indication, the water pump shall be continuously running.
- The water pump will remain ON when compressor OFF due to thermostat OFF setting is reached.
- Water pump will OFF when room thermo OR tank thermo OR buffer tank thermo OFF.
- Water pump will delay 15 seconds to turn OFF when request to OFF except during anti-freeze deice activate or air purge mode.



Maximum pump speed setting on remote control


 Standard pump speed is automatically controlled to get the designed water temperature different between water inlet and outlet (ΔT). Instead of setting the standard pump speed, maximum pump speed is manually adjusted by the installer according to water circuit pressure drop.

However, the following sequences do not follow maximum pump duty setting by remote control.


- Pump down mode
- Air purge mode
- Normal deice

1) P-Q graph for different pump HEX duty

• Connection Control Module (WH-WXG09ME8, WH-WXG12ME8)



• Connection Control Module (WH-WXG16ME8)




P-Q curve (Standalone)

14.2.2 Zone Water Pump Control

Purpose:

• Water pump install at each zone to circulate the water inside each zone during buffer tank connection selected "YES" or 2 zone systems.



Content:

- AC type water pump install for this zone water pump control. When optional PCB connected, 230V output will drive this zone pump.
- There are three pump can be connected through Optional PCB. (Zone 1 Pump, Zone 2 Pump, & Pool Pump)

* Zone 1 pump [P1] use to circulate zone 1 water circuit & Zone 1 mixing valve [M1] adjust to control the Zone 1 target water temperature.

* Zone 2 pump [P2] use to circulate zone 2 water circuit & Zone 2 mixing valve [M2] adjust to control the Zone 2 target water temperature.

* When Pool Function select as Zone 2 circuit, [P2] use to circulate water to heat exchanger which use to transfer heat to pool water.

* Pool pump [P3] circulates the pool water through the heat exchanger to get warm water.

- Zone 1 and Zone 2 water pump start condition:
 Zone room request ON (eg. Zone 1 thermo ON, only zone 1 pump will turn ON)
- Zone 1 and Zone 2 water pump stop condition:
 Zone room request OFF
- Pool water pump start condition:
 - Pool Zone request ON AND
 - Pool function is selected
- Pool water pump stop condition
 - Pool zone: Zone room request OFF **OR**
 - Pool function is cancel

* Zone 1 & Zone 2 water pump need to turn OFF when antifreeze deice pump stop control activate and turn ON back after the antifreeze deice pump stop control end under setting of "NO" buffer tank connection.

Zone Pump Prohibit ON control:

- Start condition: Zone 1 water temperature ≥ 80°C continuously for 5 minutes *stop zone water pump operates if the zone water fulfilled.
- Cancel condition: After 30 minutes from start condition fulfilled.
 *zone water pump operates according to normal condition.

Zone Pump Control during Anti-Freeze


Zone pump control during Zone Anti-Freeze Control:

- When Zone Anti-Freeze Flag=1, Zone Pump Turn ON.
- When Zone Anti-Freeze Flag=0, Zone Pump Turn OFF.
- Zone pump control during Indoor Anti-Freeze Control:
- Zone pump only ON/OFF if the Extension PCB connected and Buffer Tank select "NO" condition
 - When Indoor Anti-Freeze flag=1, Zone Pump Turn ON
 - When Indoor Anti-Freeze flag=0, Zone Pump Turn OFF

* Pool Water Pump will not affected by both Indoor anti-freeze control or zone anti-freeze control.

14.2.3 Water Pump Speed Feedback Error

- Basically pump speed feedback is control by micon.
- When pump speed is below low limit or over high limit for a few seconds, micon detect pump error and system is stopped.
- Error detection conditions:
 - Detect abnormal water pump speed for continuous 10 secs.
- Current pump speed < 300 rpm or
 - Current pump speed > 6000 rpm for 10 seconds.
- Control contents:
 - When error occurs, water pump, heating and heater is stopped for 30 seconds then restart again (Retry control).
 - When micon detect error again, system is stopped and error code [H20] is displayed at control panel.



14.3 Extra Pump Function (Optional)

There are three different controls for the external pump, Heat (default), DHW or NO.

Remocon setting : Extra pump = Heat (default)

This is the conventional setting for adding an external water pump when the flow rate is insufficient due to water pressure loss, etc.

Start conditions:

- 1) Outdoor Water Pump Turn ON
- 2) 3 ways valve switch at room side
- 3) External Pump control for Bivalent ON. (Alternative or SG ready mode or Smart mode)
- 4) Heat Pump OFF AND Boiler turn ON under Bivalent control
- 5) When Optional PCB Connectivity select No AND Buffer Tank Connection select Yes
- 6) Not Tank only mode AND Zone room thermo ON
 When [(1) AND (2)] OR [(3) AND (4)] OR [(5) AND (6)] fulfill, turn ON extra pump.
 *Output 230V to the external pump when fulfil start condition.

Cancel conditions:

- 1) Outdoor water pump turn OFF
- 2) 3 ways valve switch to tank side
- 3) Heat pump OFF and Boiler OFF under Bivalent Control
- 4) When Optional PCB Connectivity select No AND Buffer Tank Connection select Yes
- 5) Tank Only mode
- 6) Zone room thermo OFF

When {[(1) OR (2)] AND (3) } OR { (4) AND [(5) AND (6)]} fulfill, turn OFF extra pump. *Stop output 230V to external pump when either one stop condition fulfil.

Remocon setting : Extra pump = DHW

This is the setting when using DHW circulation operation.

DHW circulation start conditions

- All of the following holds
- 1) Extra pump = "DHW"
- 2) DHW circulation is effective time.
- 3) Tank mode is "ON"

DHW circulation start conditions

- Which of the following holds
- 1) Extra pump = "No" or "Heat"
- 2) DHW circulation isn't effective time.
- 3) Tank mode is "OFF"

DHW circulation operation

Operation is 2 type, Confort or Efficiency

DHW circulation operation (Comfort)


Prioritize comfort over power consumption

- 1) When DHW circulation request is received, pump port is supply 230V
- 2) During this operation, 230V is always supply
- 3) When operation is "OFF", 230V is stopped

DHW circulation operation (Efficiency)

Pump operate intermittent (ON/OFF)

- 1) When DHW circulation request is received, pump port is supply 230V.
- 2) Pump operate intermittent (ON/OFF)
- ON time and OFF time is decided by Remocon.
- 3) When operation is "OFF", 230V is stopped



Remocon setting : Extra pump = No

The extra pump does not work.


14.4 Indoor Unit Safety

14.4.1 Indoor Unit Safety Control

- 1 When water pump is ON, the system will start checking flow switch status (ON/OFF).
- 2 If the flow switch ON for 10 seconds, the system will check on the water inlet temperature for 10 seconds. If the water inlet temperature not exceeds 80°C, the water pump shall be continuously running with normal mode.

If the water inlet temperature exceeds 80°C for continuously 10 seconds, the water pump will be OFF immediately.

3 After water pump OFF for more than 10 minutes, it will be ON back and the indoor unit safety control checking is restarted.



14.5 Auto Restart Control

1 When the power supply is cut off during the operation of Air-to-Water Heatpump, the compressor will reoperate after power supply resumes.

14.6 Indication Panel

LED	Operation	
Color	Green	
Light ON	Operation ON	
Light OFF	Operation OFF	

Note:

• If Operation LED is blinking, there is an abnormality operation occurs.

14.7 External Heater Control (Optional)

Control for attaching an external heater

When the external heater is In-line heater.

- Select "in-line" in the "External Heater" menu on the remote control.
- The heaters enabled by the above selection will operate in the same way as "Back-Up Heater" during Heating
 operation.

*However, a heater that has external heater control enabled cannot be used for protection control.

When the external heater is Buffer tank heater.

• Select "Buffer tank" in the "External Heater" menu on the remote control.

14.8 Indoor Back-Up Heater Control

14.8.1 Indoor Electric Heater Control

- 1 Normal Heating Mode
 - Heater On condition:
 - a. Heater switch is ON
 - b. After Heatpump thermo ON for **[30]** mins
 - c. After water pump operate [9] mins
 - d. Outdoor air temperature < Outdoor set temperature for heater
 - e. When water outlet temperature < Water set temperature + [-4°C]
 - f. [20] minutes since previous Backup heater Off
 - * When heatpump cannot operate due to error happens during normal operation, heater will go into force mode automatic
 - * Heater need to operate during deice operation
 - Heater Stop Condition:
 - a. When outdoor set temperature > outdoor set temperature + [+2°C] for continuous 15 secs OR
 - b. When water out temp> water set temperature + [-2°C] for continuous 15 secs OR
 - c. Heater switch is Off OR
 - d. Heatpump thermo-off or OFF condition
- 2 Force Heater Mode
 - Heater On condition:
 - a. After water pump operate [9] mins
 - b. When water outlet temperature < water set temperature + [-4°C]
 - c. [20] minutes since previous Backup heater Off
 - Heater Stop condition
 - a. Force mode off **OR**
 - b. When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs

* Do not operate heater at the following situation

- 1 Water outlet temperature sensor, and water inlet sensor abnormal
- 2 Flow switch abnormal
- 3 Circulation pump stop condition

14.9 Base Pan Heater Control (Optional)

- To enable the base pan heater function, control panel initial setting has to be manually adjusted by activating Base Pan Heater menu.
- There are 2 optional start condition can be selected, Type A or Type B.
- Control details:
 - 1 Type A: (Default Auto Mode)
 - Start conditions:
 - When outdoor air temperature \leq 3°C during heating and deice operation is ON.

Control contents:

• Base pan heater is ON during deice operation and continues ON for 10 minutes after deice operation ends.

Cancel condition:

- When outdoor temperature > 6°C after deice end or
- When operation is not at heating mode or
- Base pan heater ON timer count is completed.

2 Type B: (ON Mode)

Start conditions:

• When outdoor air temperature is $\leq 5^{\circ}$ C and operates in heating mode, base pan heater is ON.

Cancel conditions:

- \odot When outdoor air temperature is > 7°C or
- When operation is not at heating mode.

14.10 Force Heater Mode

Purpose of Force Heater Mode:

• As a backup heat source when heat pump error. Force heater Mode only control backup heater to heat up the room circuit, and turn ON back up heater or booster heater to boil up tank water base on the tank heater selection.

Force Heater Control start condition:

- Force heater request ON by user during error OR auto turn ON by remote controller during error AND (Force Heater mode can be operate regardless of mode selection, remocon will send the latest mode selection force bit by bit to indoor. Indoor will judge to turn ON heater to room side if it is heat mode selected, and turn ON heater to heat tank water base on tank heater selection)
- During Error Happen (exclude the error list below)

Error List which not allow Force Heater operation

H12	Capacity Mismatch	H90	Abnormal ID/OD communication	
H20	Abnormal Water Pump	H95	Abnormal Voltage Connection	
H21	Abnormal Water Pressure	F30	Abnormal water outlet 2 sensor	
H62	Abnormal Water Flow	F37	Abnormal Water Inlet sensor	
H70	Abnormal Back-up Heater OLP	F45	Abnormal Water Outlet sensor	
H74	PCB Communication Error	F50	Abnormal Water Inlet 2 sensor	
H76	Indoor-Remote Controller Communication Error			
[When tank mode operate with external heater selected & tank heater select ON]				
H22	Abnormal tank 2 sensor	H91	Abnormal tank heater OLP	
H72	Abnormal tank 1 sensor			

Force Heater Control Stop Condition:

- Force Heater request OFF OR
- Operation OFF request OR
- Power reset **OR**
- Error of above list happens during force heater operation.

Control contents:

After fulfill start condition, indoor will operate the force heater operation according to below mode condition Heat mode Only: Turn ON backup heater to achieve room heat pump target water temperature. Heat + Tank mode: Turn ON backup heater to heat up room **OR** Turn ON Heater to Boil up tank water. Cool mode Only: Water pump and backup heater will OFF in force heater mode.

- Cool + Tank mode: Operate pump and internal Heater OR External heater to Boil up tank water.
- Tank mode Only: Operate pump and internal Heater OR External heater to Boil up tank water.

* For heat mode condition, backup heater will only turn ON if the backup heater is enable regardless of Room Heater Selection.

* For tank mode condition, If internal heater selected backup heater will turn ON to boil up tank water.

If external heater selected, booster heater will turn ON to boil up tank water regardless of tank heater selection.

Room Side: (Heat Mode):

- When force heater mode start condition fulfilled, turn ON water pump and turn ON backup heater follow below control.
- Operate the 3 ways valve at room side only and turn ON 2 ways valve as heat mode operation.
- Turn ON the zone pump and mixing valve if system select 2 zone system or Buffer tank connect YES, control according to normal zone pump and mixing valve control.
- When Force heater mode stop condition fulfilled, turn OFF heater as below condition and turn OFF water pump after pump delay time.

Backup Heater On Condition:

- When Force Heater Control start condition fulfill AND
- After water pump operate 2 minutes AND
- When water outlet temperature < water set temperature + [-4°C] AND
- 20 minutes since previous Backup heater Off AND
- Backup Heater Enable

Backup Heater Stop condition:

- Force mode off **OR**
- Operation off **OR**
- When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs OR
 * ON/OFF follow normal heater sequence.

Tank side (Tank mode):

- When tank mode select and force heater bit received, turn ON backup heater (INTERNAL) or Booster Heater (External) depend on the tank heater selection.
- If tank heater selection is INTERNAL, follow normal thermo judgement to switch 3 ways valve to tank side and room side.
- If tank heater selection is EXTERNAL, only turn ON booster heater according to tank thermo.

Tank Heater selection is EXTERNAL:

Booster Heater ON condition:

- Force Heater mode ON AND
- Tank temperature < tank set temperature + [Remocon Set Tank Re-heat Temp] 1°C, AND
- 20 minutes since previous heater off.

Booster Heater OFF condition:

- Tank temperature > tank set temperature for continuous 15 secs.
- Force mode OFF
- Tank Mode Operation OFF (During tank interval or tank mode condition, water pump and 3 ways valve will OFF)

14.11 Powerful Operation

Powerful mode is use to increase the capacity of heat pump to achieve higher target temperature. Powerful mode is applicable when heat mode is operating.

Remote control setting:

On quick menu of remote control, there is 4 options of powerful mode can be select.

- OFF : Cancel powerful mode
- 30 minutes : Set powerful for 30 minutes
- 60 minutes : Set powerful for 60 minutes
- 90 minutes : Set powerful for 90 minutes

Control contents:

During the time set by remote control, powerful will activate according to 2 shift up controls. However, this function is applicable only for heating. Remote control will transmit the signal to indoor unit once this function is select then transmit OFF signal to indoor when the timer is complete. Indoor will transmit signal to outdoor for frequency control.

Indoor setting temperature shift

- If system is standard system (Optional PCB is not connected)
 - o Target water temperature will shift up to Wlo or Whi whichever higher.
- If system is extension system (Optional PCB is connected)
 - Target water Zone 1 and Zone 2 temperature will shift up to Wlo or Whi whichever higher.

* If "Direct Type" temperature control is select, this powerful shift up setting is not effective.

- Start condition
 - o Powerful function is select by remote control.
- End Condition
 - OFF/ON button is pressed.
 - o Powerful function is OFF by remote control.

14.12 Quiet Operation

Quiet mode is use to reduce the noise of outdoor unit by reducing the frequency or fan speed.

Quiet level

There are 3 level (Level 1, Level 2, Level 3) to set by quick menu function on remote control.

Control content

Once the quiet function is select, the remote control will transmit the signal to indoor and outdoor unit.

Quiet priority

Set whether to prioritize "Sound" or "Capacity"

In case of "Sound" is set for "Quiet priority" in the function setup of the remote control Start condition

Quiet mode is set on remote control. Quiet mode is request ON by weekly timer.

Stop condition

OFF/ON button is pressed. Quiet mode is OFF by remote control. Quiet mode is request OFF by weekly timer.

In case of "Capacity" is set for "Quiet priority" in the function setup of the remote control Start condition

- 1) Quiet mode is set on remote control.
- 2) Quiet mode is request ON by weekly timer.
- 3) During heating : Water outlet temperature > Target Water Temperature 3°C
- 4) During Cooling : Water outlet temperature < Target Water Temperature + 3°C
- 5) During operation mode when 3 way valve is at tank direction : Tank temperature > Tank set Temperature 3°C

When condition {(1) or (2)} and {(3) or (4) or (5)} is fulfilled, after the quiet mode start by user or timer.

Stop condition

- 1) Quiet mode is OFF by remote control.
- 2) OFF/ON button is pressed.
- 3) Quiet mode is request OFF by weekly timer.
- 4) During heating : Water outlet temperature ≤ Target Water Temperature 5°C for continues 30 minutes
- 5) During Cooling : Water outlet temperature ≥ Target Water Temperature + 5°C for continues 30 minutes
- 6) During operation mode when 3 way value is at tank direction : Tank temperature <= Tank set temperature - 5°C for continues 30 minutes

When any of above mentioned condition is achieved, this control is cancelled.

14.13 Sterilization Mode

- Purpose:
 - To sterilize water tank by setting the required boiling temperature.
- Remote control setting
 - Days for sterilization function to start can be select.
 - Time of selected day to start sterilization function.
 - Boiling temperature (Internal heater is $55^{\circ}C \sim 65^{\circ}C$)
 - Maximum operation time is 5 minutes to 1 hour.
- Start condition
 - Tank connection set to "YES" by remote control
 - Sterilization function selects "YES".
 - Sterilization signal received from remote controller by timer.
 - Tank mode request ON.
- Stop condition
 - When boiling timer is completed. Boiling timer (Remote control set maximum operation time) start counting once tank achieve boiling set temperature **OR**
 - After 8 hours of operation since sterilization start.
 - Tank mode request OFF.
- Control content:
 - During sterilization function activation time, target tank set temperature will internally change to boiling set temperature.
 - During sterilization activates, heat pump and heater (external or internal) will operate as normal tank mode to achieve the boiling set temperature.
 - o Sterilization operation will end when stop condition is fulfill.
 - After sterilization is complete, tank set temperature will resume to normal operation.

* Tank temperature may not achieve boiling set temperature if tank heater is select OFF **OR** external compressor switch.

14.14 DHW Circulation Pipe Sterilization Operation

Purpose:

This control is designed to prevent legionella for DHW circulation pipe.

DHW circulation pipe sterilization mode start conditions

- All of the following holds
- 1) Remocon setting : Extra pump = DHW
- 2) Tank sterilization operation is finished.
- 3) Tank sterilization is completed within 490 minutes since sterilization function start

DHW circulation pipe sterilization mode stop conditions

Which of the following holds

- 1) After 490 minutes of operation since DHW circulation pipe sterilization start
- 2) Circulation pump operated 30 minutes
- 3) Tank mode Request OFF
- 4) Remocon setting : Extra pump = Heat or NO


DHW circulation pipe sterilization mode control contents

- It works in the following order.
- 1) Tank sterilization mode is ON
- 2) Tank boiling start Target temp. is RC setting
- 3) Tank sterilization mode finish or stop.
- 4) DHW circulation pump operate during 30 minutes
- 5) Back to normal operation

14.15 Outdoor Ambient Thermo OFF Control

Purpose:

Stop provides heating to room side during high outdoor ambient condition.



Control content:

- Heating outdoor ambient thermo OFF control only applicable when heat pump operate in heat mode. (This control will not activate when running in tank side)
- Heat pump and water pump will turn OFF when outdoor ambient is higher than outdoor thermo OFF set temperature.
- Heat pump will thermo ON back when outdoor ambient < Outdoor thermo ON set temperature and RC delay time
 has passed after Heating thermo-ON temperature is reached.

14.16 Alternative Outdoor Ambient Sensor Control

Purpose of the Alternative Outdoor Ambient Sensor:

• It is some possibility that the air to water heat pump unit will install at a location where the original ambient sensor is expose to direct sunlight. Therefore, another optional ambient sensor can be connect to indoor PCB and locate at new and better reading location to improve the heat pump performance.

Control Detail:

- Remocon can select either the extra outdoor ambient sensor is connected or not. (YES/NO)
- The alternative outdoor ambient sensor will connect to indoor unit main PCB terminal.
 - o when alternative sensor select NO
 - Original Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
 - Data communication direction : OUTDOOR send outdoor temperature reading to INDOOR.
 - Error judge : OUTDOOR will judge the original outdoor sensor error (F36 display if error detect). No
 judge error on alternative outdoor sensor
 - when alternative sensor select YES
 - Alternative Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
 - Data communication direction : INDOOR send outdoor temperature reading to OUTDOOR.
 - Error judge : INDOOR will judge the Extra outdoor sensor error only after operation ON request received from remocon.

(F36 display if error detect). No judge error on original outdoor sensor.

14.17 Force DHW Mode

Purpose:

When user want to use hot water now, user can press this force DWH mode under the quick menu to operate tank only mode to boil up the tank temperature.

Remocon setting:

Force DHW function can be activate under quick menu.

Control Content:

- when press the Force DHW function during operation OFF condition:
 - When receive this Force DHW bit from remocon, indoor will run tank only mode regardless of the mode selection.
 - After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to operation OFF with previous mode selection.
- When press the Force DHW function during operation ON condition:
 - When receive this Force DHW bit from remocon, indoor will memories the running mode and run tank only mode regardless of the mode selection.
 - After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to previous memories running mode.

* When operation OFF or mode change request from remocon during force DHW mode operation, End force DHW mode and follow the new request operation.

* Once receive force DHW mode from remocon, indoor direct start tank mode and consider tank thermo ON. Thermo OFF only when achieve tank thermo OFF depend on the Tank System Setting.

14.18 SMART DHW Mode

Panasonic All In One model provide the option to choose STANDARD DHW Mode or SMART DHW Mode for Tank Heat Up according to requirement. SMART DHW mode comparatively consume lower tank heat up power but longer re-heat time than STANDARD DHW Mode.

SMART DHW control

- During SMART DHW start time 20:00 (Default Setting) to SMART DHW stop time 05:00 (Default setting) Heat pump re-heat the tank water only when tank temperature drop below 20°C (Default setting)
- Time between 05:00 to 20:00 Heat pump reheat the tank water when tank temperature as below condition

Condition 1: Tank Heater ON Reheat when tank temperature below tank set temperature + R/C (Tank re-heat Temperature) - 3°C

Condition 2: Tank Heater OFF

Reheat when tank temperature below Tank set temperature or 52°C (Whichever lower) + R/C (Tank re-heat Temperature) -3°C

* SMART DHW start time, stop time and SMART ON Temperature can change in CUSTOM menu.

14.19 Anti Freeze Control

- Anti freeze protection control menu can be set YES or NO by control panel.
 - 1. Models without Back up heater (Standalone and connection control module):
 - Water pump circulation anti freeze control
 - Water pump turns ON when <u>ALL</u> below conditions are fufilled:
 - Heat pump OFF (Stand by) OR error occurs.
 - Water flowing flag is ON.
 - Water flow sensor is not abnormal.
 - Outdoor ambient temp. < 3°C OR outdoor ambient temp. sensor is abnormal.
 - Water inlet 2 / outlet 2 temp. < 25°C
 - After 5 minutes from previous water pump OFF.
 - Water pump turns OFF when **ANY** below conditions is fufilled:
 - Outdoor ambient temp. $\ge 4^{\circ}$ C
 - During 0°C < Outdoor ambient temp. < 4°C
 - After water pump ON for 4 minutes, and water inlet temp. ≥ 26°C
 - Else, shift to back up heater anti freeze control.
 - During Outdoor ambient temp. < 0°C
 - After water pump ON for 4 minutes, and water inlet temp. ≥ 28°C
 - Else, shift to back up heater anti freeze control.
 - However, if flow sensor is abnormal (H62), then water pump circulation anti freeze control will not activate.
 - Heat pump unit operation anti freeze control
 - Heat pump unit operation turns ON when <u>ALL</u> below conditions are fufilled:
 - Water pump circulation anti freeze control activated and water pump ON for 4 minutes.
 - Heat pump unit operation turns OFF when <u>ANY</u> below conditions is fufilled:
 - Water inlet / Water inlet 2 temp. > $40^{\circ}C$ for 3 minutes.

14.19.1 Zone Anti-Freeze Control

• If buffer tank selection is "NO" and Anti- Freeze function select "NO" from remote control, this control cannot activate.

Start condition:

- After [5] min from previous Zone pump off. AND
- Outdoor air temp < [3] °C OR Outdoor sensor is abnormal. AND
- Zone water temperature < [6]°C OR Zone Sensor Short or Open

Cancel condition:

- After water Zone pump ON [4] min AND
- Outdoor air temp \geq [4]°C **OR**
- During -5 °C ≤ Outdoor air temp < [4] °C OR Zone water temperature sensor > [8] °C
- During Outdoor air temp < [-5] °C
 Zone water temperature sensor > [20] °C
 *However, Zone water temperature sensor is Open or Short, Condition C and D is ignored.


14.20 Solar Operation (Optional)

14.20.1 Solar Operation:

Solar function:

 This function allow user to control the solar pump to operate depend on the solar sensor reading compare to the tank installed. Solar pump will circulate the hot water energy store at solar panel to heat up the DHW Tank or Buffer Tank.

Solar Connection Diagram:



- Solar function can only enable when the Optional PCB is connected.
- Few part as below need to install to control the solar operation:
 - Solar Panel
 - o Solar Pump
 - Solar Panel Sensor
 - Tank Sensor (Buffer tank sensor OR DHW Tank sensor depend on the connection direction)
 * During Solar Connection to the system, installer need to alert on the high water temperature may flow to the zone circuit or DHW piping circuit. Therefore pipe which withstand higher water temperature need to be installed.
- Solar remote control setting
 - 1 Solar Setting can only be set when the optional PCB connection is select "YES"
 - 2 By remote controller, Setting as below list can be set for solar function operation (Installer Menu)
 - Solar Function ("YES" or "NO")
 - Tank Connection Direction ("DHW TANK" or "BUFFER TANK")
 - Delta T turns ON: Difference temperature setting between solar panel sensor and Tank to turn on solar pump. (Range :5 ~ 15°C)
 - Delta T turns OFF: Difference temperature setting between solar panel thermistor and Tank to turn off solar pump. (Range :2 ~ 10°C)
 - Outdoor temp for Anti-Freeze : Outdoor temp to start Anti-Freeze control for solar circuit. (Range : -20 ~ 10°C)
 - Tank Temperature HI Limit Set (Range : 70 ~ 90°C)

14.20.2 Solar Operation Control

• Solar function can only be activate if the solar function selection "YES" from remote control. To achieve hot water from solar panel, indoor need to control the solar pump and circulate hot water from solar panel.

Under normal case:

- Solar pump start condition:
 - Solar panel temperature > Delta T turn on setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) AND
 - Tank temperature (DHW or Buffer) < Solar HI Limit Temp (R/C) AND
 - Operation ON with heat mode (apply to solar connect to "Buffer Tank" case)

* Condition c) ignore if the solar system is connect to DHW tank (control active under operation OFF time for Tank connection case)

- Solar pump stop condition:
 - Solar panel temperature < Delta T turn OFF setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) OR
 - Tank hot water temp >= Solar HI Limit Temp (R/C) + [2]°C

Under solar Anti-freeze protection control:

- Solar pump start condition:
- Outdoor temp < Outdoor temp setting for Anti-Freeze (R/C)
- Solar pump stop condition:
 - Outdoor temp > Outdoor temp setting for Anti-Freeze + [2]°C

**However, During Cool mode this function cannot activate if Tank selection is "Buffer Tank".

**Solar pump can operate even if Heat pump is under error stop.

- Solar operation during error:
 - o During Tank sensor (DHW or Buffer depend on selection) abnormal, Solar operation will not able to function.
 - o During Solar Panel sensor detect OPEN (not include SHORT), Solar operation will not able to function too.

14.21 Boiler Bivalent Control

- Boiler is an additional or alternative heat source to heat up the room when necessary.
- Purpose of this control is to turn ON and turn OFF the Boiler output signal when boiler heating capacity needed in the system.
- Boiler is possible to connect to DHW Tank and Buffer Tank depends on the installer.
- Boiler operation parameter need to be set on Boiler itself, indoor do not control the boiler operation direction and operation.
- There are Alternative mode, Parallel mode, & Advance Parallel mode available to select by installer to fit to the total system.

Bivalent control selection by remote controller

Auto

0

Remote control setting value:

1 Outdoor Ambient Set = (Range: $-15^{\circ}C \sim 35^{\circ}C$)

Alternative Mode

o Only one heat source operates at one time, either heat pump or boiler depends on condition.

Control detail:

During Operation ON at Heat mode or Tank mode or Heat + Tank Mode

- Boiler signal turn ON and heat pump and water pump turn OFF when:
 - Outdoor ambient < Outdoor Ambient Set AND
 - Boiler prohibit flag = 0

** However indoor water pump can operate when Anti-freeze control condition fulfilled.

• Parallel Mode

 Parallel mode allows heat pump and boiler ON at the same time. Boiler operates as an additional heating capacity when low heat pump capacity at low ambient condition.

Control detail:

0

0

During operation ON at Heat mode or Tank mode or Heat + Tank mode

- Boiler signal turns ON when:
 - Outdoor ambient < Outdoor Ambient Set AND
- Boiler prohibit flag = 0
- Boiler signal turns OFF when:
- Outdoor ambient > Outdoor Ambient Set + [2°C] OR
- Boiler prohibit flag = 1

• Advance Parallel Mode

• Advance parallel mode allow heat pump to operate and turn ON boiler only when ambient and temperature condition is fulfilled.

Remote control setting value:

- 1 Outdoor Ambient Set = (Range : -15°C ~ 15°C)
- 2 Selection of boiler connection direction. (Heat only, DHW only, Heat & DHW)
- 3 Setting data under Heat Direction
 - Start Temperature | START_TEMP |
 - Start Delay Timer | START_TIMER |
 - Stop Temperature | STOP_TEMP |
 - Stop Delay Timer | STOP_TIMER |
- 4 Setting data under DHW Direction
 - Delay Timer | DELAY_TIMER |

Control detail:

During operation ON at Heat Mode

- Boiler signal turns ON when
 - Outdoor ambient < Outdoor Ambient Set AND
 - Buffer tank temperature < Target Buffer Tank Temperature + [START_TEMP] for [START_TIMER]
 AND
 - Heat pump operate at room side AND
 - Connection of Boiler to Heating Select "YES" From installer menu AND
 - Buffer Tank connection select "YES" AND
 - Boiler prohibit flag = 0
- Boiler signal turns OFF when
 - Outdoor ambient > Outdoor Ambient Set + [-2°C] OR
 - Buffer Tank temperature > Target Buffer Tank temperature + [STOP_TEMP] for [STOP_TIMER] OR
 - Heat pump not at room side. OR
 - Boiler prohibit flag = 1

During operation ON at Tank Mode

- Boiler signal turns ON when
 - Outdoor ambient < Outdoor Ambient Set AND
 - Heat pump operate at tank side for continuous | DELAY_TIMER | AND
 - Connection of Boiler to DWH Tank select "YES" from installer menu. AND
 - Boiler prohibit flag = 0
- Boiler signal turns OFF when
 - Outdoor ambient > Outdoor Ambient Set + [2°C] OR
 - Heat pump not operates at tank side. **OR**
 - Boiler prohibit flag = 1

SG ready

SG ready (Only available to set when optional PCB set to YES)

SG Ready input from optional PCB terminal control ON/OFF of boiler and heat pump as below condition


SG signal		Operation pattern
Vcc-bit1	Vcc-bit2	
Open	Open	Heat pump OFF, Boiler OFF
Short	Open	Heat pump ON, Boiler OFF
Open	Short	Heat pump OFF, Boiler ON
Short	Short	Heat pump ON, Boiler ON

* This bivalent SG ready input is sharing same terminal as [16. SG ready] connection. Only one of these two setting can be set at the same time.

When one is set, another setting will reset to not set.

Smart

There are Energy price (both electricity and boiler) and Schedule to be set on remote controller. Operation setting of Energy price and Schedule shall be responsible by installer. Based on these settings, system will calculate the final price for both electricity and boiler. When final price of Electricity is lower than Boiler's, heat pump will operate. When final price of Electricity is higher than Boiler's, boiler will operate.



Outdoor temp.

Boiler prohibit flag control

Purpose:

o For product safety. Boiler signal is OFF when water temperature is too high.

Start condition:

- Water outlet \geq 85°C continues for 5 minutes.
- Water inlet \ge 85°C continues for 5 minutes.
- Zone1 water temp ≥ 75° C continues for 5 minutes.
- Zone2 water temp \ge 75°C continues for 5 minutes.

Contents:

After start condition fulfilled, set boiler prohibit flag = 1

Cancel condition:

• After 30 minutes from start condition fulfilled.

Contents:

Set boiler prohibit flag = 0

14.22 External Room Thermostat Control (Optional)

Purpose:


1 Better room temperature control to fulfill different temperature request by external room thermostat. Recommended external room thermostat:

Maker	Characteristic
Siemen (REV200)	Touch panel
Siemen (RAA20)	Analog

Connection of external room thermostat:

Wire Connection and thermo characteristic of Siemen REV200:


Setting	L/L1 (H)	Heat Thermo	L/L2 (C)	Cool Thermo
Set Temp < Actual Temp	Open Circuit	OFF	Short Circuit	ON
Set Temp > Actual Temp	Short Circuit	ON	Open Circuit	OFF



heating and cooling line for heat + cool model.

Wire Connection and thermo characteristic of Siemen RAA20:

Setting	L/Y1 (H)	Heat Thermo	L/Y2 (C)	Cool Thermo
Set Temp < Actual Temp	Open Circuit	OFF	Short Circuit	ON
Set Temp > Actual Temp	Short Circuit	ON	Open Circuit	OFF



Connect only heating line for heating only model. And connect both heating and cooling line for heat + cool model.

Control Content:

- External room thermostat control activate only when remote thermostat connection select YES by Indoor control panel.
- When indoor running heat mode, refer thermo On/Off from heating line feedback. And when indoor running cool mode, refer thermo On/Off from cooling line feedback.
- Heat pump Off immediately when receive thermo off feedback.


14.23 Three Ways Valve Control

Purpose:

- 3 ways valve is used to change flow direction of hot water from heat pump between heating side and tank side.

Control contents:

- 1 3 ways valve switch Off:
- o During 3 ways valve switch Off time, the hot water will provide heat capacity to heating side.
- 2 3 ways valve switch On:
- During 3 ways valve switch On time, the hot water will provide heat capacity to tank side.
- 3 Stop condition:
 - During stop mode, 3 ways valve will be in switch off position.



* During pump down and force mode, fix 3 ways valve in close condition.

* Recommended Parts : SFA 21/18 (Siemens)


14.24 Two Ways Valve Control

Functionality of 2 ways valve:

• Use to allow hot water to floor heating panel or block cold water to floor heating panel.

Control contents:

- 1 When indoor running in heat mode, OPEN the 2 ways valve.
- 2 When indoor running in cool mode, CLOSE the 2 ways valve.
- 3 Stop condition:
 - a. During stop mode, fix 2 ways valve in close condition.



* During pump down mode, fix 2 ways valve in close condition.

* During force mode, open 2 ways valve.

* Recommended Parts : SFA 21/18 (Siemens)

14.25 Anti-Stick Mode Operation

This mode is a control to prevent the water circuit actuator from locking up if not used for an extended period of time.

Start conditions

- 1) A.M 3:00 o'clock every Monday.
- 2) Anti-stick mode = Enable. (Anti-stick mode is selected in custom menu)

Control Contents:

It works in the following order.


- 1) If any mode operated, all operation is stopped.
- 2) Anti-stick mode operates
- 3) If Anti-stick mode finished, back to the last operation.

Cancel conditions:

- Which of the following holds
- 1) Anti-stick mode is finished.
- 2) When the customer manually starts any mode operation. (include weekly timer, sterilization mode)


Anti-stick mode

If zone 2 or pool or solar are not connected, they are skipped



14.26 External OFF/ON Control


• Communication circuit between indoor unit and external controller is as per below.



- Maximum length of communication cable is 50 meter.
- Control content:

External Control Switch	Control Panel OFF/ON	Control Panel Power LED	System Status
ON	ON	ON	ON
ON	OFF	OFF	OFF
OFF	ON	ON	OFF
OFF	OFF	OFF	OFF

Remocon Screen Display and Control Detail:



When External SW connection select "YES" from remocon installer menu:

- Heating or Cooling system will operate normally if the External Switch signal is ON.
- Once the External Switch turn OFF, System Turn OFF (Heat pump, water pump, heater etc...)
- Remocon LED remain ON or OFF according to the current operation request.
- Pop up menu at remocon main screen as above screen to inform customer system stop by External Switch.
- It is possible to press cancel and return to main screen to do change of operation setting while waiting the External Switch turn ON back.
- Remocon LED will always follow the latest changes from remocon.
- If no action on remocon for continuous 5 minutes, the pop up screen will show again on the screen.
- But once the External Switch Turn ON back, pop up screen will disappear and system can operate normally according to the latest operation setting and request.

14.27 External Compressor Switch (Optional PCB)

External compressor switch port can have two purpose of control as below:

- Heat source ON/OFF function (Dip switch Pin 3 on PCB "OFF")
- Heater ON/OFF function (Dip switch Pin 3 on PCB "ON")
- Heat source ON/OFF function

Purpose:

• Heat pump ON/OFF function is use to turn OFF the high power consumption device (Heat pump, & Heater) when there is energy or electric current limitation. Other optional function still can be operate under heat pump and heater OFF condition.

Control Detail:

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & Dip Switch on PCB "OFF"
 This heat pump ON/OFF function will activate
- The ON/OFF signal of this External Compressor Switch is same as External Switch.
- When the External Compressor Switch is ON:
- Heat pump system operate normally
- When the External Compressor Switch is OFF:
 - o Heat pump, Indoor water pump & Heater (Booster heater & Backup Heater) need to turn OFF
 - Solar, Boiler and zone control can be operate follow normal control condition.
 - * pump delay OFF also included in this control

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

• Heater ON/OFF function

Purpose:

• Heater ON/OFF function is use to turn OFF the heater (backup heater & booster heater) when there is energy or electric current limitation. Heat pump and other optional function still can operate.

Control detail:

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & Dip Switch on PCB "ON" This heater ON/OFF function will activate
- When the External Compressor Switch is ON:
- Heat pump and heater operate normally
- When the External Compressor Switch is OFF:
 - Backup heater and booster heater cannot operate even heater request is ON.
 - Heat pump and option function (Solar, Boiler and zone control) can be operate follow normal control condition.

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

14.28 Heat/Cool Switch (Optional PCB)

Purpose:

• User can switch the running mode from heat to cool or cool to heat through external installed Heat/Cool switch. This kind of heat / cool switch may built in inside the field supply room remocon as well.

Control contents:

- Heat/Cool Switch can only be set when Cool Function is "enable" at custom menu setting, & Extension PCB select "YES" & Zone 1 not set "Pool" condition.
- This heat/cool switch control will be activate only when installer set the Heat/Cool Switch "USE" through remocon.
- Once the Heat/Cool Switch Set "USE", remocon will check indoor send Signal to judge the option of mode select.
 - When Heat/Cool Switch Contact Open : Remocon only can select Heat Mode, or Heat + Tank Mode, or Tank Mode
 - When Heat/Cool Switch Contact Close : Remocon only can select Cool Mode, or Cool + Tank Mode, or Tank Mode


- Operation ON/OFF will depend on remocon request.
- When Heat Mode is running with Contact Open, user change this setting to contact close, indoor will this signal to remocon judge and change mode to cool and send back to indoor. And it is same as from cool mode change to heat mode.
 - * This switch have higher priority, remocon follow indoor send signal when control activated.
 - * There is no effect to the operation when the mode running is only Tank Mode.

(Weekly Timer are ignored and cannot be set during Heat / Cool Switch is "Enable" Condition.)

14.29 SG Ready Control (Optional PCB)

Purpose:

• To set ON/OFF of heat pump and target temperature by digital input of third party device if necessary in field.



Remote control setting

For this function, following items need to be set on R/C (installer menu) -

- SG control = YES or NO
- Capacity up setting 1
 - Heating capacity [50 ~ 150 %]
 - DHW capacity [50 ~ 150 %]
 - Cooling capacity [-15 ~ 0 °C]
- Capacity up setting 2
 - Heating capacity [50 ~ 150 %]
 - DHW capacity [50 ~ 150 %]
 - Cooling capacity [-15 ~ 0 °C]
- HPU stop consumption [0.5 ~ 10.0 kW]
- Power consumption setting 1
 - Heating Power consumption [0.5 ~ 10.0 kW]
 - DHW Power consumption [0.5 ~ 10.0 kW]
 - Cooling Power consumption [0.5 ~ 10.0 kW]
- Power consumption setting 2
 - Heating Power consumption [0.5 ~ 10.0 kW]
 - DHW Power consumption [0.5 ~ 10.0 kW]
 - \circ Cooling Power consumption [0.5 ~ 10.0 kW]

Control contents:

If SG control on remote control = "Yes", then following control only activate by digital input.

- While Digital input is " 00 " (Normal operation)
 - Normal operation. Once detect '00' system will operate back to normal condition.
 (All the target set temperature for heating side and DHW side will return back to previous set temperature when digital signal change from "10" or "11" back to "00".)
- While digital input is detected " 01 " (HP stop)
 - Heat pump & room heater & tank heater cannot operate.
 (Solar control and Boiler back up and 2 Zone control can activate.)

• While digital input is detected " 10 " (Capacity 1)

- Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting. However, which setting temperature is change depend on system setting.
- Target temperature of cooling is change according to the adjustment value set by remocon setting.

• While digital input is detected " 11 " (Capacity 2)

- Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting. However, which setting temperature is change depend on system setting.
- \circ $\;$ Target temperature of cooling is change according to the adjustment value set by remocon setting.

• While digital input is detected " 10 " (Capacity 1)

Setting temperature for heating and Tank is changed. However, which setting temperature is change depend on system setting.

If Buffer selection is "YES"

Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature * Remote Control setting (" capacity 1) %

* Max Min regulation is follow Target Buffer tank temperature control specification

** No change of Target zone water temperature, only set higher buffer tank temperature.

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 1) % * (Max regulation depend on the tank max setting limit)

If Buffer selection is "NO"

Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature * Remote Control Setting (*Capacity 1) %

(Zone 1 and Zone 2 will change according to its own target zone water temperature.)

(Max regulation depend on the temperature control type select)

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 1) % * (Max regulation depends on the tank max setting limit)

Setting temperature for cooling is changed

New Target water temperature = target water temperature + R/C setting for cool (*Capacity 1) * (Min/max regulation of cooling water set apply)

• While digital input is detected "11" (Capacity 2)

- Setting temperature for heating and Tank is changed.
 - However, which setting temperature is change depend on system setting.

If Buffer selection is "YES"

Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature * Remote Control setting (" capacity 2) %

* Max Min regulation is follow Target Buffer tank temperature control specification

** No change of Target zone water temperature, only set higher buffer tank temperature.

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 2) % * (Max regulation depends on the tank max setting limit)

If Buffer selection is "NO"

Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature * Remote Control Setting (*Capacity 2) %

(Zone 1 and Zone 2 will change according to it's own target zone water temperature.)

(Max regulation depend on the temperature control type select)

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 2) %

* (Max regulation depends on the tank max setting limit)

** This function is not applicable for Cooling mode.

Setting temperature for cooling is changed

New Target water temperature = target water temperature + R/C setting for cool (*Capacity 2)

* (Min/max regulation of cooling water set apply)

HPU stop consumption

Operation will stop when the power consumption of the entire system exceeds (HPU stop consumption kW).

• While digital input is detected "10" (Power consumption 1)

Room side

Operate with the target of reducing power consumption to (Heating Power consumption 1) or less.

DHW Tank side

Operate with the target of reducing power consumption to (DHW Power consumption 1) or less.

Cool mode

Operate with the target of reducing power consumption to (Cooling Power consumption 1) or less.

• While digital input is detected "11" (Power consumption 2)

Room side

Operate with the target of reducing power consumption to (Heating Power consumption 2) or less.

DHW Tank side

Operate with the target of reducing power consumption to (DHW Power consumption 2) or less.

Cool mode

Operate with the target of reducing power consumption to (Cooling Power consumption 2) or less.

14.30 Demand Control (Optional PCB)

Remote control setting:

• When Optional PCB connection select "YES", Demand Control function can select "YES" or "NO".

Purpose:

- After the demand control select YES, below control will activated.
 - 0-10V Demand control

0-10V Demand control

• Demand control is use to reduce the current usage of heat pump unit by third party device.

Control start condition:

- Select "YES" at Demand control at installer menu.
- 0-10V input for this electrical current control is detected.

Control content:

- If start condition is fulfilled, indoor will receive the voltage signal from optional PCB. Indoor will send the rate value to outdoor unit.
- Outdoor will change the current limit according to the percentage receive from indoor unit.

14.31 Holiday Mode

Purpose:

Promotes energy saving by allowing the user to stop the system during holiday and enables the system to resume at the preset temperature after holiday.

- Control details:
 - Indoor operate the unit according running mode request. Target temperature will follow holiday setting temperature.
 - If heat mode request is receive, Target Water Out Temperature will change according to holiday shift temperature set.
 - [If heat is set OFF at holiday, unit, water pump and zone control will OFF]
 - If tank mode request is receive, Target Tank Set Temperature will change according to the holiday tank shift temperature set.
 - [If tank is set OFF at holiday, heat pump and tank heater will OFF]
 - After days of holiday have been set, heat pump will stop and only resume operation at the end of holiday countdown.
- Start condition:
 - Holiday timer set and the holiday timer start
 - * The day holiday mode was set is counted as day 1.
- Stop condition:
 - o OFF/ON button is pressed.
 - Holiday timer is reached.

14.32 Dry Concrete

- Purpose Provide heat to floor heating panel and dry the wet concrete during installation.
- Setting condition:
 - o Dry concrete parameter can be set through remote control under system setup.
 - Parameters are possible to set up to 99 days with different target set temperature
- Control details:
 - \circ Dry concrete mode will be activates when select ON from service setup.
 - Once start dry concrete function, remote control will send step 1 setting temperature to indoor unit.
 * This temperature is set at zone temperature. If system is 2 zones, both zone target temperature is set as same temperature.
 - Heat pump will start heat mode operation to room side with received target water outlet temperature. * Heat pump will operate according to Heat pump Target Water Temperature.
 - After complete day 1 setup operation, day 2 data will be send to indoor at 12.00am on the second day.
 - Each preset data will be send every day until dry concrete mode is complete, unit will turns OFF and exit dry concrete function.
 - o 3 ways valve and booster heater will turn OFF and 2 ways valve will turns ON.
- Cancel condition:
 - Dry concrete mode is complete and OFF signal is received.
 - OFF signal is received by pressing OFF/ON button.

14.33 Flow Sensor

- The water flow sensor serves as an overload protector that shuts down the unit when the water level is detected to be low.
- Abnormal flow detection:

Sequence	Abnormal flow	Normal flow
Normal case	Flow rate < 8 I/min or ≧ 69 I/min	≧ 8 l/min
During status 2~6 on Anti-freeze deice	≧8 l/min	< 8 l/min

15. Protection Control

15.1 Protection Control for All Operations

15.1.1 Time Delay Safety Control

1 The compressor will not start for three minutes after stop of operation.

15.1.2 30 Seconds Forced Operation

- 1 Once the compressor starts operation, it will not stop its operation for 30 seconds.
- 2 However, it can be stopped using control panel at indoor unit.

15.1.3 Total Running Current Control

- 1 When the outdoor running current exceeds X value, the compressor frequency will decrease.
- 2 If the outdoor running current does not exceed X value, the compressor frequency will return to normal operating frequency.
- 3 If the outdoor running current continue to increase till exceed Y value, compressor will stop, and if this occurs 3 times within 20 minutes, system will stop operation and OFF/ON control panel LED will blink (F16 error occurs).


	WH-WXG09ME8		WH-WXG12ME8		WH-WXG16ME8	
Operation Mode	X (A)	Y (A)	X (A)	Y (A)	X (A)	Y (A)
Heating	11.8	14.8	13.8	16.8	18.0	21.0
Cooling	9.0	14.8	9.0	16.8	9.0	21.0

A. DC Peak Current Control

- 1 When the current to IPM exceeds set value of 60.5 A, compressor will stop. Compressor will restart after three minutes.
- 2 If the set value exceeds again for more than 30 seconds after the compressor restarts, operation will restart after two minutes.
- 3 If the set value exceeds again for within 30 seconds after the compressor restarts, operation will restart after one minute. If this condition repeats continuously for seven times, system will stop operation and OFF/ON control panel LED will blink (F23 error occurs).

15.1.4 Compressor Overheating Prevention Control

 The compressor operating frequency is regulated in accordance to discharge temperature as shown in below figures. When the discharge temperature exceeds 107°C, compressor will stop, and if this occurs 4 times within 30 minutes, system will stop operation and OFF/ON control panel LED will blink (F20 error occurs).




15.1.5 High Pressure Sensor Control

- Purpose:
- To protect the system operation.
- Detection period:
- After compressor on for 1 minute.
- Detection conditions:
- When abnormal high voltage detection, 5 V or when open circuit detection 0V for 5 seconds continuously.
- After detection:
 - When abnormality is detected 4 times within 120 minutes, unit stop operation.
 - OFF/ON control panel LED will blink (H64 error occurs).

15.1.6 Outside Temperature Current Control

Heating



Cooling

15.1.7 Pre-Heat Control

• Purpose:

- For compressor protection during low outdoor ambient operation (during heating low temperature operation). Control content:

- a. Trigger Pre-Heat Control condition
 - When the outdoor air temperature is below than -10°C, and discharge temperature is -10°C or below.
- b. Resetting Pre-Heat Control condition
 - 1. When the outdoor air temperature exceeds entry condition (3°C)

2. When the discharge temperature exceeds entry condition (3°C)

15.2 Protection Control for Heating Operation

15.2.1 Outdoor Air Temperature Control


The maximum current value is regulated when the outdoor air temperature rises above 14°C in order to avoid compressor overloading.

15.2.2 Deice Operation


When outdoor pipe temperature and outdoor air temperature is low, deice operation start where outdoor fan motor stop.

• Deice judging condition

Outdoor Unit Deice Control



• Deice operation time diagram




a. Deice mode 1 control:

15.3 Protection Control for Cooling Operation

15.3.1 Outdoor Air Temperature Control

- The Compressor operating frequency is regulated in accordance to the outdoor air temperature as shown in the diagram below.
- This control will begin 1 minute after the compressor starts.
- Compressor frequency will adjust base on outdoor air temperature.



15.3.2 Freeze Prevention Control 1


- 1 When refrigerant temperature is lower than 0°C continuously for 10 seconds, compressor will stop operating.
- 2 Compressor will resume its operation three minutes after the refrigerant heat exchanger is higher than 2°C.
- 3 Heat exchanger freeze prevention (H99) will memory in error history.

16. Servicing Mode

16.1 Open the Front Cover

Before opening the front cover (1) of the Indoor Unit, always switch off all power supplies (e.g. the Indoor Unit power supply, the outdoor unit power supply, and the heater power supply).

- 1. Remove the 2 mounting screws located at the top of the enclosure 2.
- 2. Gently pull the upper section of the front cover (1) towards you. (The front cover will stops once it has opened about 2 degrees.)
- 3. Gently rotate the front cover (1) to open 180 degrees.



16.2 Test Run

- 1. Check the items below before the test run.
 - a) Pipework are properly done.
 - b) Electric cable connecting work are properly done.
 - c) Water circuit unit is filled up with water and trapped air is released.
 - d) Turn ON the power supply after filling the indoor until full.
- 2. Turn ON the power supply for the Indoor, and RCCB/ELCB in the Indoor Unit. Then, refer to the Operation Instruction for operation of remote controller ③.

Note:

During winter, turn ON the power supply and standby the unit for at least 15 minutes before test run. To allow sufficient time to warm up refrigerant and prevent wrong error code judgement.

- 3. For normal operation, the water pressure reading should be in between 0.50 bar and 4.00 bar (0.05 MPa and 0.4 MPa). If not, adjust the speed of the water pump to bring it into the aforementioned pressure operating range. If this procedure does not solve the problem, contact a local authorized dealer.
- 4. After test run, clean the magnetic water filter set with reference to "Maintenance for magnetic water filter" in the Installation Manual of the AIR-TO-WATER HEAT PUMP OUTDOOR UNIT and reinstall it. After the cleaning is finished.

16.2.1 Check Water Flow of the Water Circuit

Select Installer setup \rightarrow Service setup \rightarrow Pump maximum speed \rightarrow Air purge.


- Confirm that the maximum water flow rate is not less than 25 l/min when the main pump is in operation.
- * Water flow can be checked in Service setup (Pump maximum speed)
- [Heating operation at low water temperature with lower flow rate may cause "H75" during defrost process.]
 * If there is no water flow or H62 is displayed, stop pump operation and release the air (See "Check Air Accumulation").

16.3 Expansion Vessel Pre Pressure Checking

- The system where the Indoor Unit is installed is equipped with an expansion vessel with the capacity of 10 L and the initial pressure of 1 bar.
- The total volume of water in the system should not exceed 200 L.
- If the total water volume exceeds 200 L, add an expansion vessel. (Supplied on site)
- The installed height difference of the water circuit of the system should not exceed 30 m. (Extra pump may be required).

* In case of 30 m, set the pressure in the circulation circuit to 0.5~1.0 bar. Higher than 1.0 bar may cause water leakage due to component breakage.

16.4 How to Unlock Cool Mode




16.5 EEPROM Factory Default Data Setup Procedure

Initializatio	n 12:	00am,Mon	
	Initializing		
_	\wedge	\equiv	
<	لہ	>	
	\vee	Ċ	_
		4.4	-


- EEPROM default data setup is only possible during initialization process.

- Press (▲, ▼, ◀, ►) simultaneously for 5secs continuously, initialization process will stop & EEPROM default data setup process will start.


During EEPROM default data setup process, display should be as shown below.




- Once EEPROM default data setup process is complete, initialization process will re-start from beginning.



16.6 Dry Concrete Setup






Return to [Screen 6]

17. Maintenance Guide

To ensure the safety and optimum performance of the indoor unit, seasonal inspections of the indoor unit and functional checks of RCCB/ELCB, field wiring and pipe should be carried out on a regular basis. This maintenance and scheduled inspection should be carried out by authorized dealer.

Regular maintenance of the expansion vessel (at least once a year) is recommended and should be performed by authorized dealer. First, make sure that the expansion or pressure tank is completely drained of water, that the system is switched off, and that there are no live electrical components. If you need to reset the preload pressure, set 1bar.


- 1. Check Water Pressure * (0.50 bar = 0.05 MPa)
 - Water pressure must not be lower than 0.50 bar. (Check the water pressure by the remote controller.) If it is lower, fill Space Heating/Cooling pipes with water through the tube connector on the outdoor unit.



2. Check Pressure Relief Valve

* Pressure relief valve is located on outdoor unit.

- a. Pull the lever in the horizontal direction and confirm that the pressure relief valve works properly.
- b. Release the lever when water comes out of the drain pipe of the pressure relief valve. While the air continues to come out of the drain pipe, keep raising the lever to completely discharge the air.
- c. Confirm that the water from the drain pipe stops.
- d. If water is leaking, pull the lever several times and return it to make sure the water stops.
- e. If water keeps coming out of the drain, turn OFF the system and contact your local authorized dealer.



3. Check Air Accumulation

• Open the air vent plugs on the heating panel, fan convector, etc., and remove the air accumulated in the equipment and piping.

4. Check RCCB/ELCB

a. Ensure the RCCB/ELCB set to "ON" condition before check RCCB/ELCB.


b. Turn ON the power supply to the Indoor Unit.

This check can only be done when power is supplied to the Indoor Unit.


Be careful not to touch parts other than RCCB/ELCB test button when the power is supplied to Indoor Unit. Otherwise, electrical shock may be caused. Before obtaining access to terminals, all supply circuits must be disconnected.

- c. Push the "TEST" button on the RCCB/ELCB. The lever would turn down, if it works properly.
- d. Contact authorized dealer if the RCCB/ELCB malfunction.
- e. Turn OFF the power supply to the Indoor Unit.
- f. If RCCB/ELCB functions normal, set the lever to "ON" again.


- 5. Maintenance for Magnetic Water Filter Set OR [Check Magnetic Water Filter Set]
 - a. Turn OFF the power supply.
 - b. Place a container below Magnetic Water Filter.
 - c. Turn to remove the Magnet Bar at bottom of Magnetic Water Filter.
 - d. Remove the Cap of Discharge Port with Allen key (8mm).
 - e. Open the Service Valve with Allen key (4mm) to release the dirty water from the Discharge Port into a container. Close the service valve when the container is full to avoid spillage in the outdoor unit. Dispose the dirty water.
 - f. Reinstall the Cap of Discharge Port and Magnet Bar.
 - g. Re-charge the water to Space Heating / Cooling circuit if necessary.
 - h. Turn ON the power supply.



17.1 Service and Maintenance



17.1.1 Maintenance Menu



17.1.2 Custom Menu

Н	ow to set up a Custom menu						
Сι	istom menu	12:00 pm, Mon					
С	ool mode						
В	ack-up heater						
R	eset energy monitor						
R	eset operation history						
	, Select [⊶] Confi	rm					
С	istom menu	12:00 pm, Mon					
-	ack-up heater						
	eset energy monitor						
	eset operation history						
А	nti-stick mode						
Γ	Select [⊶] Confi	irm					
=	$+ \lor + <$ Press for 5 seco	onds.					
	ms that can be set						
1	Cool mode (Select Cooling fur is Disable.	nction: Enable/Disable) Default					
2	Note: As Enable/Disable Cool application, be careful a In Cool mode, be careful properly, dew may form the floor and damage th Back-up heater (Select Back-u Note: This back-up heater refe Differs from the use/non set by the customer. (Th if requested by the utility	nd do not simply change it. I if piping is not insulated on pipe and water may drip on e floor. up heater: Enable/Disable) ers to the Extra heater. -use of back-up heater that is his setting should only be used (company.) ied out under the responsibility					
3	Reset energy monitor (delete Use this when moving house a	• • • •					
4							
5	· · · · · · · · · · · · · · · · · · ·						
	The actuator is regularly activa to prevent the actuating parts	ated every Monday at 3:00 am from sticking together.					
	Select Disable if wish to stop t periodically.	he mode being activated					
	Parts and other components t	hat may not operate if Disable erated for a long period of time.					

17.2 Specifications

Parameter	Quality Limits for Tap Water on the Secondary Side
Temperature	Below 75°C
рН	7 to 9
Alkalinity	60mg/I <hco₃ <300mg="" i<="" td=""></hco₃>
Conductivity	<750 or 1250
Hardness	[Ca ⁺ , Mg ⁺] / [HCO ₃ ⁻] > 0.5
Chloride	< 200mg/l at 60°C
Sulphate	[SO ₄ ²⁻] < 100mg/l and [HCO ₃ ⁻] / [SO ₄ ²⁻] > 1
Nitrate	NO ₃ < 100mg/l
Chlorine	< 0.5mg/l

17.2.1 Specifications of Fresh Water was Heat Transfer Medium in Brazed Heat Exchanger

17.2.2 External Filter

Solids in the water must be filtered.


Minimum filter mesh size required for the field supply external filter in the water inlet is 20 mesh.

18. Troubleshooting Guide

18.1 Refrigeration Cycle System

In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle.

Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a fan.



18.2 Relationship between the Condition of the Air-to-Water Heatpump Indoor and Outdoor Units and Pressure and Electric Current

		Heating Mode			Cooling Mode	
Condition of the Air-to- Water Heatpump indoor and outdoor units	Low Pressure	High Pressure	Electric current during operation	Low Pressure	High Pressure	Electric current during operation
Water leakage or insufficient water flow rate in the system				1	1	1
Excessive amount of refrigerant				1	*	
Inefficient compression		1	1	1	1	1
Insufficient refrigerant (gas leakage)	*	1	*	1	1	*
Outdoor heat exchange deficiency	-	-	-			
Clogged expansion valve or Strainer				1	*	

• Carry out the measurements of pressure, electric current, and temperature fifteen minutes after an operation is started.

18.3 Breakdown Self Diagnosis Function


18.3.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- When abnormality occur during operation, the system will stop operation, and OFF/ON control panel LED will blink and error code will display on the control panel.
- Even error code is reset by turning OFF power supply or by selecting ERROR RESET, if the system abnormality
 is still unrepaired, system will again stop operation, and OFF/ON control panel LED will again blinks and error
 code will be display.
- The error code will store in IC memory.

• To check the error code

- 1 When an abnormality occurs, system will stop operation and OFF/ON control panel LED will blink.
- 2 Error code of the abnormality will be display on the control panel.
- 3 To determine the abnormality description, the error code table needs to be referred.

eg:




Press < > to select Close / Reset then press \prec

- To display past/last error code
 - 1 Turn ON power supply.
 - 2 Refer below procedure to retrieve the error code history.
- To permanently delete error code from IC memory
 - 1 Turn ON power supply.
 - 2 Refer below procedure to clear error history.

	12	:00am,Mon		
[①] Start				
_	\wedge	≡		
<		>		Press :≡ button and select
	\vee	Ċ		"System Check"
			•	

Main menu	9:	17am,Mon
Function set	up	
System chec	k	
Personal set	up	
Service cont	act	
Select	[₊-]Confi	rm



18.4 Error Codes Table

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify
H00	No abnormality detected	—	—
H12	Indoor/Outdoor capacity unmatched	10s after power supply	 Indoor/outdoor connection wire Indoor/outdoor PCB Specification and combination table in catalogue
*H15	Outdoor compressor temperature sensor abnormality	Continue for 5 sec.	Compressor temperature sensor (defective or disconnected)
*H17	Zone 2 water pump abnormality	Continue for 10 sec.	Indoor PCB (main)Water pump (malfunction)
H20	Water pump abnormality	Continue for 10 sec.	 Outdoor PCB (main), Outdoor PCB (sub) Water pump (malfunction)
H21	Abnormal water pressure	Continue for 300 sec.	Water pressure sensor
*H22	Abnormal tank 2 sensor	Continue for 5 sec.	Tank 2 sensor
H23	Refrigerant liquid temperature sensor abnormality	Continue for 5 sec.	Refrigerant liquid temperature sensor (defective or disconnected)
*H27	Service valve error	Continue for 5 minutes	 High pressure sensor (defective or disconnected)
H28	Abnormal solar sensor	Continue for 5 sec.	 Solar temperature sensor (defective o disconnected)
H31	Abnormal swimming pool sensor	Continue for 5 sec.	 Pool temperature sensor (defective or disconnected)
H36	Abnormal buffer tank sensor	Continue for 5 sec.	 Buffer tank sensor (defective or disconnected)
H38	Brand code not match	When indoor and outdoor brand code not same	—
H42	Compressor low pressure abnormality	_	 Outdoor pipe temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB Compressor
H43	Abnormal Zone 1 sensor	Continue for 5 sec.	Water temperature Zone 1 sensor
H44	Abnormal Zone 2 sensor	Continue for 5 sec.	Water temperature Zone 2 sensor
H62	Water flow switch abnormality	Continue for 140 sec.	Water flow switch
H63	Abnormal low pressure sensor	4 times in 20 minutes	 Low pressure sensor (defective or disconnect)
H64	Refrigerant high pressure abnormality	4 times in 120 minutes	 Outdoor high pressure sensor (defective or disconnected)
H65	Abnormal deice water circulation	Water flow > 8 l/min continuously for 10 seconds during anti freeze deice	• Water pump
H67	Abnormal External Thermistor 1	Continue for 5 sec.	Room temperature Zone 1 sensor
H68	Abnormal External Thermistor 2	Continue for 5 sec.	Room temperature Zone 2 sensor
H70	External heater OLP abnormality	Continue for 60 sec.	 External heater OLP (Disconnection or activated)
H72	Abnormal tank 1 sensor	Continue for 5 sec.	Tank 1 sensor
H74	PCB communication error	Communication or transfer error	Indoor main PCB and Sub PCB
H75	Low water temperature control	Room heater disable and deice request to operate under low water temperature	Heater operation must enable to increase water temperature
H76	Communication error (RC-1 & Indoor or RC-1 & RC-2)	_	 Indoor - control panel (defective or disconnected) control panel 1 - control panel 2 (defective or disconnected)
H90	Indoor/outdoor abnormal communication	> 15 sec after starting operation	Internal/external cable connectionsIndoor/Outdoor PCB

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify
H91	Tank heater OLP abnormality	Continue for 60 sec.	 Tank heater OLP (Disconnection or activated)
H95	Indoor/Outdoor wrong connection	_	Indoor/Outdoor supply voltage
H98 / F95	Outdoor high pressure overload protection Cooling high pressure overload protection	_	 Outdoor high pressure sensor Water pump or water leakage Clogged expansion valve or strainer Excess refrigerant Outdoor PCB
H99	Indoor heat exchanger freeze prevention	_	Indoor heat exchangerRefrigerant shortage
F12	Pressure switch activate	4 times occurrence within 30 minutes	Pressure switch
F14	Outdoor compressor abnormal revolution	4 times occurrence within 20 minutes	Outdoor compressor
F15	Outdoor fan motor lock abnormality	2 times occurrence within 20 minutes	Outdoor PCBOutdoor fan motor
F16	Total running current protection	3 times occurrence within 20 minutes	Excess refrigerantOutdoor PCB
F20	Outdoor compressor overheating protection	4 times occurrence within 30 minutes	 Compressor tank temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB Compressor
F22	IPM (power transistor) overheating protection	3 times occurrence within 30 minutes	Improper heat exchangeIPM (Power transistor)
F23	Outdoor Direct Current (DC) peak detection	7 times occurrence continuously	Outdoor PCB Compressor
F24	Refrigeration cycle abnormality	2 times occurrence within 30 minutes	 Insufficient refrigerant Outdoor PCB Compressor low compression
F25	Cooling/Heating cycle changeover abnormality	4 times occurrence within 30 minutes	 4-way valve V-coil
F27	Pressure switch abnormality	Continue for 1 min.	Pressure switch
F30	Water outlet sensor 2 abnormality	Continue for 5 sec.	Water outlet sensor 2 (defective or disconnected)
F32	Internal thermostat error (RC-1 or RC-2)	Continue for 5 sec.	Control panel PCB thermostat
F35 (No Self-diagnosis Method)	External meter communication error	Continue for 180 sec.	• External meter
F36	Outdoor air temperature sensor abnormality	Continue for 5 sec.	Outdoor air temperature sensor (defective or disconnected)
*F37	Indoor water inlet temperature sensor abnormality	Continue for 5 sec.	Water inlet temperature sensor (defective or disconnected)
F40	Outdoor discharge pipe temperature sensor abnormality	Continue for 5 sec.	Outdoor discharge pipe temperature sensor (defective or disconnected)
F41	PFC control	4 times occurrence within 10 minutes	Voltage at PFC
F42	Outdoor heat exchanger temperature sensor abnormality	Continue for 5 sec.	Outdoor heat exchanger temperature sensor (defective or disconnected)
*F43	Outdoor defrost sensor abnormality	Continue for 5 sec.	Outdoor defrost sensor (defective or disconnected)
F45	Indoor water outlet temperature sensor abnormality	Continue for 5 sec.	Water outlet temperature sensor (defective or disconnected)
*F46	Outdoor Current Transformer open circuit	_	Insufficient refrigerantOutdoor PCBCompressor low
F48	Outdoor EVA outlet temperature sensor abnormality	Continue for 5 sec.	Outdoor EVA outlet temperature sense (defective or disconnected)
F49	Outdoor bypass outlet temperature sensor abnormality	Continue for 5 sec.	Outdoor bypass outlet temperature sensor (defective or disconnected)
F50	Water inlet 2 sensor error	Continue for 5 sec.	Water inlet 2 sensor

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify
F51	Economizer outlet sensor abnormality	Continue for 5 sec.	Economizer outlet sensor (defective or disconnected)
F52	Bypass inlet sensor abnormality	Continue for 5 sec.	 Bypass inlet sensor (defective or disconnected)
F53	Main expansion valve overcurrent protection	4 times occurrence within 40 minutes	Main expansion valve
F54	Bypass expansion valve overcurrent protection	4 times occurrence within 40 minutes	Bypass expansion valve
F55	Electrical anode error	Continue for 60 sec.	Electric anodeElectric anode PCB
F56	Outdoor heat exchanger middle sensor abnormality	Continue for 5 sec.	Outdoor heat exchanger middle sensor (defective or disconnected)

Note: * This error code is not applicable for this system.

18.5 Self-Diagnosis Method

18.5.1 Connection Capability Rank Abnormality (H12)

Malfunction Decision Conditions:

During startup operation of cooling and heating, the capability rank of indoor checked by the outdoor is used to determine connection capability rank abnormality.


Malfunction Caused:

- 1 Wrong model interconnected.
- 2 Wrong indoor unit or outdoor unit PCB (main) used.
- 3 Faulty indoor unit or outdoor unit PCB (main).

Abnormality Judgment:

Continue for 10 seconds.

Troubleshooting:



18.5.2 Compressor Tank Temperature Sensor Abnormality (H15)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the compressor tank temperature sensor are used to determine sensor error.


Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:



18.5.3 Zone 2 Water Pump Abnormality (H17)

Malfunction Decision Conditions:


During startup and operation of cooling and heating, the rotation speed detected by the IPM of water pump motor during water pump operation is used to determine abnormal water pump (feedback of rotation > 6,000rpm or < 300rpm).

Malfunction Caused:

- 1 Operation stop due to short circuit inside the water pump motor winding.
- 2 Operation stop due to breaking of wire inside the water pump motor.
- 3 Operation stop due to breaking of water pump lead wires.
- 4 Operation stop due to water pump motor IPM malfunction.
- 5 Operation error due to faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 10 seconds.



18.5.4 Water Pump Abnormality (H20)

Malfunction Decision Conditions:


During startup and operation of cooling and heating, the rotation speed detected by the IPM of water pump motor during water pump operation is used to determine abnormal water pump (feedback of rotation > 6,000rpm or < 300rpm).

Malfunction Caused:

- 1 Operation stop due to short circuit inside the water pump motor winding.
- 2 Operation stop due to breaking of wire inside the water pump motor.
- 3 Operation stop due to breaking of water pump lead wires.
- 4 Operation stop due to water pump motor IPM malfunction.
- 5 Operation error due to faulty outdoor unit PCB (main).
- 6 Operation error due to faulty outdoor unit PCB (sub).

Abnormality Judgment:

Continue for 10 seconds.



18.5.5 Refrigerant Liquid Temperature Sensor Abnormality (H23)

Malfunction Decision Conditions:


During startup and operation of cooling and heating, the temperatures detected by the refrigerant liquid temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.



18.5.6 Service Valve Error (H27)

Malfunction Decision Conditions:

During cooling operation, when:-


- [a] Indoor refrigerant pipe temperature at compressor startup present indoor refrigerant pipe temperature < 2°C [b] Present high pressure high pressure at compressor startup < 5kg/cm²
- **Judgment only for first time cooling operation and not during pump down operation.

Malfunction Caused:

- 1 3 way valves closed.
- 2 Faulty high pressure sensor.
- 3 Faulty indoor refrigerant pipe temperature sensor
- 4 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 minutes.



18.5.7 Abnormal Solar Sensor (H28)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty solar sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment: Continue for 5 seconds.

Abnormal solar sensor			Caution	For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.
	7	_		
H28 happens check connectior	at CN207 normal?	NO	▶ •	Correct sensor connection
	YES	1		
Measure resistance of sensor r	natch characteristic?	NO	•	Change solar sensor
	YES	-		
Change Indoor sub PCB				


18.5.8 Abnormal Swimming Pool Sensor (H31)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty swimming pool sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

Continue for 5 seconds.



18.5.9 Abnormal Buffer Tank Sensor (H36)

Malfunction Caused:

- 1 Faulty connector connection.
- Faulty buffer tank sensor. 2
- 3 Faulty indoor sub PCB.


Abnormality Judgment: Continue for 5 seconds.

Abnormal buffer tank sensor	Cautior	For safety reason and to prevent component breakdown, always switch off the power before remove and
		connect the component.
H36 check buffer tank sensor connection at CN5 normal?	NO •	Correct connection
YES		
Disconnect sensor from sub PCB measure resistance of se and compare against characteristic same?	ensor NO	Change buffer tank sensor
YES		
Change sub PCB		

18.5.10 Brand Code Not Matching (H38)

Malfunction Caused:

1 Indoor and outdoor brand code not match.



18.5.11 Compressor Low Pressure Protection (H42)


Malfunction Decision Conditions:

During operation of heating and after 5 minutes compressor ON, when outdoor pipe temperature below -40°C or above 37°C is detected by the outdoor pipe temperature sensor.

For safety reason and to prevent component breakdown,

Malfunction Caused:

- Dust accumulation on the outdoor unit heat exchanger. 1
- 2 Air short circuit at outdoor unit.
- 3 Faulty outdoor unit fan motor.
- 4 Refrigerant shortage (refrigerant leakage).
- 5 Clodded expansion valve or strainer.
- 6 Faulty outdoor pipe temperature sensor.
- 7 Faulty outdoor unit main PCB (main).




18.5.12 Abnormal Zone 1 Sensor (H43)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:




18.5.13 Abnormal Zone 2 Sensor (H44)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:



18.5.14 Water Flow Switch Abnormality (H62)

Malfunction Decision Conditions:


During operation of cooling and heating, the water flow detected by the outdoor water flow switch is used to determine water flow error.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Water leak in system.
- 3 Faulty connector connection.
- 4 Faulty water flow switch.
- 5 Faulty outdoor unit PCB (sub).

Abnormality Judgment:

Continue for 140 seconds (but no judgment for 30 seconds after water pump startup/restart).



18.5.15 Outdoor High Pressure Abnormality (H64)

Malfunction Decision Conditions:


During operation of cooling and heating, when the outdoor high pressure sensor output signal is 0 Vdc or 5 Vdc.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 120 minutes.



18.5.16 Deice Circulation Error (H65)


Malfunction Decision Conditions:

During startup and operation of deice (mode 2), the water flow (> 8 l/min) detected by the water flow switch is used to determine deice circulation error.

Malfunction Caused:

- 1 Water flow in air-to-water heatpump unit circuitry.
- 2 Faulty outdoor unit water flow switch.
- 3 Faulty outdoor unit water pump.
- 4 Faulty outdoor unit PCB (sub).
- 5 Faulty outdoor unit PCB (main).

Abnormality Judgment:



18.5.17 Abnormal External Thermistor 1 (H67)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty room temperature zone 1 sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment: Continue for 5 seconds.


Abnormal external thermistor 1		Caution		For safety reason and to prevent component breakdown, always switch off the power before remove and	
				connect the component.	
Check CN205 connector on sub PCB normal?		NO	•	Correct connection	
	YES	,			
Disconnect sensor from sub PCB measure resistance of sensor and compare against sensor characteristic same?		NO	•	Change external thermistor 1	
	YES	_			
Change sub PCB					

18.5.18 Abnormal External Thermistor 2 (H68)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty room temperature zone 2 sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:



18.5.19 External Heater OLP Abnormality (H70)


Malfunction Decision Conditions:

During operation of external heater, when no power supplies to external heater or OLP open circuit.

Malfunction Caused:

- 1 Faulty power supply connector connection.
- 2 Faulty connector connection.
- 3 Faulty external heater overload protector (OLP).
- 4 Faulty indoor unit PCB (main).

Abnormality Judgment:



18.5.20 Tank Temperature Sensor Abnormality (H72)


Malfunction Decision Conditions:

When tank connection is set to ON, the temperatures detected by the tank temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).
- 4 Faulty outdoor unit PCB (sub).

Abnormality Judgment:



18.5.21 PCB Communication Error (H74)

Malfunction Decision Conditions:


When External PCB connection is select "YES" and no communication with External PCB micon for 10 seconds and above.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty indoor PCB.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

After 1 minute operation started.




18.5.22 Indoor-Control Panel Communication Abnormality (H76)

Malfunction Decision Conditions:

During standby and operation of cooling and heating, indoor-control panel error occur.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty control panel.
- 3 Faulty indoor unit PCB (main).
- 4 Faulty outdoor unit PCB (sub).



_ _ + _ _ → No polarity Terminal for Remote Controller wiring Figure 2 Case : Standalone

ι.

18.5.23 Indoor/Outdoor Abnormal Communication (H90)

Malfunction Decision Conditions:


During operation of cooling and heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

Malfunction Caused:

- 1 Faulty outdoor unit PCB (main).
- 2 Faulty outdoor unit PCB (sub).
- 3 Faulty indoor unit PCB (main).
- 4 Indoor-outdoor signal transmission error due to wrong wiring.
- 5 Indoor-outdoor signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.
- 6 Indoor-outdoor signal transmission error due to disturbed power supply waveform.

Abnormality Judgment:

Continue for 15 seconds after operation.



18.5.24 Tank Booster Heater OLP Abnormality (H91)


Malfunction Decision Conditions:

During operation of tank booster heater, and tank booster heater OLP open circuit.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty tank booster heater overload protector (OLP).
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:



18.5.25 Unspecified Voltage between Indoor and Outdoor (H95)

Malfunction Decision Conditions:

The supply power is detected for its requirement by the indoor/outdoor transmission.


Malfunction Caused:

- 1 Insufficient power supply.
- 2 Faulty outdoor unit PCB (noise filter/main).

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.




18.5.26 Outdoor High Pressure Protection (H98 / F95)

Malfunction Decision Conditions:

During operation of cooling / heating, when pressure 3.2 MPa and above is detected by outdoor high pressure sensor.

Malfunction Caused:


- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 Dust accumulation in the outdoor unit heat exchanger.
- 5 Air short circuit at outdoor.
- 6 Faulty outdoor unit fan motor.
- 7 2/3 way closed.
- 8 Clogged expansion valve or strainer.
- 9 Excessive refrigerant.
- 10 Faulty outdoor high pressure sensor.
- 11 Faulty outdoor unit PCB (main).



Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.




18.5.27 Indoor Freeze-up Protection (H99)

Malfunction Decision Conditions:

During anti-freezing control in cooling operation, when the refrigerant liquid temperature < 0°C.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 Clogged expansion valve or strainer.
- 5 Refrigerant shortage (refrigerant leakage).
- 6 Faulty indoor refrigerant liquid temperature sensor.
- 7 Faulty outdoor unit PCB (main).



18.5.28 Outdoor High Pressure Switch Activate (F12)

Malfunction Decision Conditions:


During operation of cooling and heating, when pressure 3.9 MPa and above is detected by outdoor high pressure switch.

Malfunction Caused:

- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 Faulty water pump.
- 4 Insufficient water flow rate in system.
- 5 Water leak in system.
- 6 Clogged expansion valve or strainer.
- 7 Excessive refrigerant.
- 8 Faulty outdoor high pressure sensor and switch.
- 9 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 30 minutes.



18.5.29 Compressor Rotation Failure (F14)

Malfunction Decision Conditions:


A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction Caused:

- 1 Compressor terminal disconnect.
- 2 Faulty outdoor unit PCB (main).
- 3 Faulty compressor.

Abnormality Judgment:

Continue 4 times in 20 minutes.



18.5.30 Outdoor Fan Motor (DC Motor) Mechanism Locked (F15)

Malfunction Decision Conditions:


The rotation speed detected by the Hall IC of the fan motor during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550 rpm or < 20 rpm).

Malfunction Caused:

- 1 Operation stop due to short circuit inside the fan motor winding.
- 2 Operation stop due to breaking of wire inside the fan motor.
- 3 Operation stop due to breaking of fan motor lead wires.
- 4 Operation stop due to fan motor Hall IC malfunction.
- 5 Operation error due to faulty outdoor unit PCB.

Abnormality Judgment:

Continue 2 times in 20 minutes.



18.5.31 Input Over Current Detection (F16)

Malfunction Decision Conditions:


During operation of cooling and heating, when outdoor current above WXG09ME8 13.8A, WXG12ME8 16.8A & WXG16ME8 21.0A is detected by the current transformer (CT) in the outdoor unit PCB.

Malfunction Caused:

- 1 Excessive refrigerant.
- 2 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 3 times in 20 minutes.



18.5.32 Compressor Overheating (F20)

Malfunction Decision Conditions:


During operation of cooling and heating, when temperature above 112°C is detected by the compressor tank temperature sensor.

Malfunction Caused:

- 1 Faulty compressor tank temperature sensor.
- 2 2/3 way valve closed.
- 3 Refrigerant shortage (refrigerant leakage).
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).
- 6 Faulty compressor.

Abnormality Judgment:

Continue 4 times in 30 minutes.



18.5.33 IPM Overheating (F22)

Malfunction Decision Conditions:


During operation of cooling and heating, when temperature 95°C is detected by the outdoor IPM temperature sensor.

Malfunction Caused:

- 1 Faulty outdoor unit fan motor.
- 2 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 30 minutes.



18.5.34 Output Over Current Detection (F23)

Malfunction Decision Conditions:

During operation of cooling and heating, when outdoor DC current is above set value is detected by the IPM DC Peak sensing circuitry in the outdoor unit PCB (main).

Malfunction Caused:

- 1 Faulty outdoor unit PCB (main).
- 2 Faulty compressor.


Abnormality Judgment:

Continue for 7 times.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



Tester's negative terminal	Power transistor (+)	UVW	Power transistor (-)	UVW		
Tester's positive terminal	UVW	Power transistor (+)	UVW	Power transistor (-)		
Normal resistance	Several kohms to several Mohms					
Abnormal resistance	0 or ∞					

18.5.35 Refrigeration Cycle Abnormality (F24)

Malfunction Decision Conditions:


- 1 During compressor running (heating / cooling) for more than 10 minutes except deice and test mode.
- 2 During heating, water outlet and water inlet difference is less than 3°C.
- 3 During cooling, water outlet and water inlet difference is less than 2°C.
- 4 During heating, high pressure < 0.16 MPa (23 Psi) for more than 10 minutes or during cooling, high pressure < 0.04 MPa (6 Psi) for more than 10 minutes or high pressure < 0.01 MPa (1 Psi) for more than 5 minutes.
- 5 During heating, discharge temperature saturation temperature of high pressure \geq 65°C.
- 6 During cooling, discharge temperature saturation temperature of high pressure \geq 70°C.

Malfunction Caused:

- 1 Refrigerant shortage (refrigerant leakage).
- 2 Faulty indoor water inlet, indoor water outlet, compressor discharge temp sensor or high pressure sensor.
- 3 Clogged expansion valve or strainer.
- 4 Faulty indoor or outdoor PCB (main).

Abnormality Judgment:

Continue 2 times in 30 minutes.



18.5.36 Four Way Valve Abnormality (F25)

Malfunction Decision Conditions:


- 1 During heating operation, when the indoor pipe temperature of thermostat ON indoor unit < 0°C.
- 2 During cooling operation, when the indoor pipe temperature of thermostat ON indoor unit > 45°C.

Malfunction Caused:

- 1 Faulty sensor.
- 2 Faulty connector connection.
- 3 Faulty outdoor unit PCB (noise filter/main).
- 4 Faulty four way valve.

Abnormality Judgment:

Continue 3 times in 40 minutes.



18.5.37 Outdoor High Pressure Switch Abnormal (F27)

Malfunction Decision Conditions:


During compressor stop, and outdoor high pressure switch is remain opened.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty switch.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 1 minute.



18.5.38 Outdoor Water Outlet Temperature Sensor 2 Abnormality (F30)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the water outlet temperature sensor 2 are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



18.5.39 Outdoor Air Temperature Sensor Abnormality (F36)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



18.5.40 Indoor Water Inlet Temperature Sensor Abnormality (F37)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water inlet temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:



18.5.41 Outdoor Discharge Pipe Temperature Sensor Abnormality (F40)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



18.5.42 Power Factor Correction (PFC) Abnormality (F41)

Malfunction Decision Conditions:


During operation of cooling and heating, when the PFC protection circuitry in the outdoor unit PCB (main) senses abnormal high DC voltage level.

Malfunction Caused:

- 1 Power supply surge.
- 2 Compressor windings not uniform.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 20 minutes.



18.5.43 Outdoor Pipe Temperature Sensor Abnormality (F42)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



18.5.44 Outdoor Defrost Temperature Sensor Abnormality (F43)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor defrost temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



18.5.45 Indoor Water Outlet Temperature Sensor Abnormality (F45)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water outlet temperature sensor are used to determine sensor errors.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:



18.5.46 Outdoor Current Transformer Open Circuit (F46)

Malfunction Decision Conditions:


A current transformer (CT) open circuit is detected by checking the compressor running frequency (≥ rated frequency) and CT detected input current (< 0.65 A) for continuously 20 seconds.

Malfunction Caused:

- 1 CT defective.
- 2 Faulty outdoor unit PCB (main).
- 3 Compressor defective (low compression).

Abnormality Judgment:

Continue 3 times in 20 minutes.



18.5.47 Outdoor Evaporator Outlet Temperature Sensor Abnormality (F48)

Malfunction Decision Conditions:


During start up and operation of cooling and heating, the temperature detected by outdoor evaporator outlet sensor is used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection
- 2 Faulty sensor
- 3 Faulty outdoor unit PCB (main)

Abnormality Judgment:

Continuous for 5 seconds



18.5.48 Outdoor Bypass Outlet Temperature Sensor Abnormality (F49)

Malfunction Decision Conditions:


During start up and operation of cooling and heating, the temperature detected by outdoor bypass outlet sensor is used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection
- 2 Faulty sensor
- 3 Faulty outdoor unit PCB (main)

Abnormality Judgment:

Continuous for 5 seconds



18.5.49 Outdoor Water Inlet 2 Temperature Sensor Abnormality (F50)

Malfunction Decision Conditions:


During startup and operation of cooling and heating, the temperatures detected by the indoor water inlet 2 temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 10 seconds.



18.5.50 Outdoor Economizer Outlet Temperature Sensor Abnormality (F51)

Malfunction Decision Conditions:


During start up and operation of cooling and heating, the temperature detected by outdoor economizer outlet sensor is used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continuous for 5 seconds.



18.5.51 Outdoor Bypass Inlet Temperature Sensor Abnormality (F52)

Malfunction Decision Conditions:


During start up and operation of cooling and heating, the temperature detected by outdoor bypass inlet sensor is used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continuous for 5 seconds.



18.5.52 Main Expansion Valve Overcurrent Protection (F53)

Malfunction Decision Conditions:


During start up and operation of cooling and heating, the determination is made based on whether or not an overcurrent flows through the main expansion valve coil.

Malfunction Caused:

- 1 Faulty connector connection
- 2 Faulty main expansion valve coil
- 3 Faulty outdoor unit PCB (main)

Abnormality Judgment:

4 times occurrence in 40 minutes



18.5.53 Bypass Expansion Valve Overcurrent Protection (F54)

Malfunction Decision Conditions:


During start up and operation of cooling and heating, the determination is made based on whether or not an overcurrent flows through the bypass expansion valve coil.

Malfunction Caused:

- 1 Faulty connector connection
- 2 Faulty bypass expansion valve coil
- 3 Faulty outdoor unit PCB (main)

Abnormality Judgment:

4 times occurrence in 40 minutes



18.5.54 Electrical Anode Error (F55)

Malfunction Decision Conditions:

If the indoor unit type is Control module, an error will occur due to a mismatch in settings.

Malfunction Caused:

1 The settings are incorrect.

Abnormality Judgment:

Continuous for 60 seconds

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.

Check the [Electrical anode] menu.

- Turn on the power
- Check [Installer setup System setup Electrical anode] menu.
- Change setting to [No] from [Yes]

18.5.55 Outdoor Heat Exchanger Middle Temperature Sensor Abnormality (F56)

Malfunction Decision Conditions:


During start up and operation of cooling and heating, the temperature detected by outdoor heat exchanger middle sensor is used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continuous for 5 seconds.




19. Disassembly and Assembly Instructions


High Voltage are generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.


19.1 Indoor Unit

19.1.1 To Remove Front Cover

- 1. Remove 2 mounting screws located at the top of the enclosure
- Gently pull the upper section of the front cover towards you. (The front cover will stops once it han opened
- 3. Gently open the front cover.









19.1.2 To Remove Remote Controller


1. Remove both left and right decoration panel from the front cover while gently pushing them from the behind.




2. Remove the 4 screws and take out the holder with remote controller.




3. Remove the body from the base.



4. Remove the cable between remote controller and Indoor Unit terminal.




19.1.3 To Remove RCCB



1. Remove the terminal cover screw. Then remove the terminal cover.

19.1.4 To Remove Electronic Controller Board



- 2. Disconnect all the lead wire. RCCB
 - 3. Remove the RCCB screw. Then remove the RCCB.

- Disconnect all connectors and lead wires from the electronic controller board. (Refer indoor unit wiring diagram).
- 2. Remove 2 screws from electronic control board.





This symbol shows that this equipment uses a flammable refrigerant with safety A3 group per ISO 817. If the refrigerant is leaked, together with an external ignition source, there is a possibility of fire / explosion.


- If you are working on the R290 product, before starting work and when entering the service area, always turn ON the combustible gas leak detector to ensure there is no leakage.
- Keep all ignition sources away from the product. In particular, open flames, hot surfaces, electrical devices that are not free from electrical sources, static discharges.
- Ensure the servicing area is well ventilated.
- Ensure all the serving tools and equipment complied with ATEX (Atmosphere Explosible) standard.
- Ensure the product is service by certified and authorized serviceman.
- Ensure to always have the approved fire extinguisher during servicing.
- Use a warning placard to ensure that unauthorized personnel cannot enter the protective zone.

19.2 Outdoor Unit

19.2.1 Electronic Controller Removal Procedures







Note: During re-assemble the Main PCB, ensure to attach the O-ring properly to avoid gas leakage into the control board complete.

20. Technical Data


20.1 Operation Characteristics

20.1.1 WH-WXG09ME8


Heating Characteristics at Different Outdoor Air Temperature

Condition


Outdoor air temperature : 7°C (DBT), 6°C (WBT) Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C




Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C



Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 19°C Indoor water outlet temperature : 14°C



Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 23°C Indoor water outlet temperature : 18°C




20.1.2 WH-WXG12ME8


Heating Characteristics at Different Outdoor Air Temperature

Condition


Outdoor air temperature : 7°C (DBT), 6°C (WBT) Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C




Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C



Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 19°C Indoor water outlet temperature : 14°C



Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 23°C Indoor water outlet temperature : 18°C




20.1.3 WH-WXG16ME8


Heating Characteristics at Different Outdoor Air Temperature

Condition


Outdoor air temperature : 7°C (DBT), 6°C (WBT) Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C




Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C



Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 19°C Indoor water outlet temperature : 14°C



Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 23°C Indoor water outlet temperature : 18°C



20.2 Heating Capacity Table

20.2.1 WH-WXG09ME8

Water Out (°C)		25			35			45	
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	7900	3500	5.3	8200	4200	6.3	7900	4800	7.0
-20	7900	2940	4.4	8200	3340	5.0	7900	3990	5.9
-15	9000	2740	4.1	9000	3300	5.0	9000	3970	5.9
-7	9000	2260	3.4	9000	2610	4.0	9000	3350	5.0
2	8800	1950	3.0	9000	2360	3.6	9000	2910	4.4
7	9000	1240	2.0	9000	1720	2.6	9000	2300	3.5
25	9000	610	1.2	9000	1080	1.8	9000	1550	2.4
Water Out (°C)		55			65			75	
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	7600	5700	8.3	-	-	-	-	-	-
-20	7600	4760	7.0	7100	5300	7.8	-	-	-
45				0000	5070	7.8	8200	6500	9.5
-15	9000	4480	6.8	9000	5270	1.0	0200	0500	9.5
-15 -7	9000	4480 3830	5.8	9000	4680	6.8	9000	5900	8.6
-7	9000	3830	5.8	9000	4680	6.8	9000	5900	8.6

20.2.2 WH-WXG12ME8

Water Out (°C)	25			35			45		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	10200	4900	7.2	10500	5550	8.1	9800	6700	9.9
-20	11000	4250	6.3	11200	4750	6.9	11000	5500	8.1
-15	12000	4270	6.3	12000	4560	6.7	12000	5670	8.3
-7	11500	3680	5.6	12000	4000	6.1	12000	5020	7.4
2	11500	2920	4.5	12000	3390	5.2	12000	4200	6.3
7	12000	1930	3.1	12000	2370	3.6	12000	3130	4.7
25	12000	1000	1.8	12000	1400	2.3	12000	2000	3.1

Water Out (°C)	55				65			75		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	
-25	9700	7400	10.8	-	-	-	-	-	-	
-20	10800	6450	9.5	10300	7550	11.0	-	-	-	
-15	12000	6000	8.8	12000	7060	10.4	11000	8450	12.4	
-7	12000	5530	8.2	12000	6570	9.6	11600	7300	10.6	
2	12000	4950	7.3	12000	5940	8.6	12000	7300	10.6	
7	12000	3710	5.6	12000	4620	7.1	12000	6100	9.0	
25	12000	2600	3.9	12000	3260	4.9	12000	3920	5.9	

20.2.3 WH-WXG16ME8

Water Out (°C)	25			35			45		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	14200	6800	9.9	14200	7800	11.4	14200	8600	12.5
-20	14200	5400	7.9	14200	6100	8.9	14200	6900	10.1
-15	16000	5900	8.6	16000	6700	9.8	16000	7700	11.2
-7	16000	5400	7.9	16000	6320	9.3	16000	7100	10.4
2	16000	3630	5.5	16000	4850	7.3	16000	5880	8.6
7	16000	2700	4.1	16000	3270	4.9	16000	4190	6.3
25	16000	1450	2.4	16000	1990	3.1	16000	2850	4.3

Water Out (°C)		55			65			75		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	
-25	14000	10530	15.4	-	-	-	-	-	-	
-20	14200	8100	11.8	14200	10160	14.8	-	-	-	
-15	16000	8700	12.7	16000	10150	14.8	14200	10900	15.9	
-7	16000	8120	11.9	16000	9400	13.7	16000	10300	15.0	
2	16000	6750	9.9	16000	8150	11.9	16000	9990	14.6	
7	16000	5000	7.4	16000	6300	9.3	16000	7600	11.1	
25	16000	3650	5.5	16000	4750	7.1	16000	6300	9.3	

20.3 Cooling Capacity Table

20.3.1 WH-WXG09ME8

Water Out (°C)	7			14			18		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
16	9800	2000	3.1	11000	2040	3.1	10800	1380	2.2
25	9300	2280	3.5	10500	2350	3.6	10200	1490	2.4
35	9000	2490	3.8	9800	2630	4.0	9000	1710	2.7
43	8400	2800	4.3	9000	2880	4.4	8600	2000	3.1

20.3.2 WH-WXG12ME8


Water Out (°C)	7			14			18		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
16	12000	2000	3.1	13700	2050	3.2	12000	1030	1.7
25	12000	3050	4.6	13500	3120	4.7	12000	1880	3.0
35	12000	4210	6.2	13200	3250	4.8	12000	2800	4.2
43	10800	4890	7.1	11200	4870	7.1	12000	3600	5.3

20.3.3 WH-WXG16ME8

Water Out (°C)	7			14			18		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
16	15500	3000	4.5	15800	2750	4.2	16000	2500	3.8
25	15000	3750	5.7	15500	3400	5.1	16000	3100	4.7
35	14500	5050	7.4	14500	4500	6.7	15500	3950	5.9
43	12000	5150	7.6	12000	5200	7.6	15000	5350	7.9


21. Exploded View and Replacement Parts List

21.1 Indoor Unit




Note:

The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.





The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.






The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.


SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-CME8	REMARK
	1	CHASSIS	1	ACXD50-03100A	
	2	PACKING	4	ACXB81-00030	
	3	PACKING	1	ACXB81-00040	
	4	WASHER	1	H57094	
	5	MACHINE SCREW & WASHER ASSY	1	XYN4DC8FJ	
	6	BOX SHAPED PLATE	1	ACXD66-04380	
Λ	7	ELECTRONIC CONTROLLER (MAIN)	1	ACXA74C12690	0
	8	MACHINE SCREW & WASHER ASSY	2	XTB3+8CFJ	
	9	LEAD WIRE - COMPLETE	1	ACXA61C03470	0
	10	SELF TAPPING SCREW	1	XTT4+8FFJ	
	11	BOX SHAPED PLATE	1	ACXD66-04390	
	12	BOX SHAPED PLATE	1	ACXD66-04400	
Ŵ	13	CIRCUIT BREAKER	1	ACXA18-00021	0
	14	U-SHAPED PLATE	1	ACXD62-03010	
	15	SELF TAPPING SCREW	1	XTT4+12CFJ	
\wedge	16	TERMINAL BOARD ASSY	1	A28K1064J	0
	17	SELF TAPPING SCREW	1	XTN4+20CFJ	
	18	U-SHAPED PLATE	1	ACXD62-02970	
	19	WASHER	1	H57094	
	20	MACHINE SCREW & WASHER ASSY	1	XYN4DC8FJ	
	21	HOLDER - P.S. CORD	1	H31103	
	22	SELF TAPPING SCREW	2	XTT4+16GFJ	
	23	HOLDER - P.S. CORD	1	H31042	
	24	SELF TAPPING SCREW	1	XTT4+12CFJ	
	25	LEAD WIRE - COMPLETE (AC-L1)	1	ACXA61C03350	0
	26	LEAD WIRE - COMPLETE (AC-L2)	1	ACXA61C03360	0
	27	LEAD WIRE - COMPLETE (AC-L3)	1	ACXA61C03370	0
	28	LEAD WIRE - COMPLETE (AC-N)	1	ACXA61C03380	0
	29	LEAD WIRE - COMPLETE (CN-AC)	1	ACXA61C03390	0
	30	LEAD WIRE - COMPLETE (AC-L3_2)	1	ACXA61C03400	0
	31	LEAD WIRE - COMPLETE (CN-DATA)	1	ACXA61C03460	0
	32	SCREW	2	H551217	
	33	BOX SHAPED PLATE	1	ACXD66-04410	
\wedge	34	TERMINAL BOARD ASSY	1	A28K1240	0
	35	SELF TAPPING SCREW	3	XTT4+12CFJ	
\wedge	36	TERMINAL BOARD ASSY	1	ACXA28K02540	0
	37	SELF TAPPING SCREW	1	XTN4+20CFJ	
	38	HOLDER - P.S. CORD	2	H31042	
	39	LEAD WIRE - COMPLETE (WIRE1)	1	ACXA61C06960	0
	40	LEAD WIRE - COMPLETE (WIRE2)	1	ACXA61C03440	0

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-CME8	REMARK
	41	LEAD WIRE - COMPLETE (CN-TH1)	1	ACXA61C03490	0
	42	LEAD WIRE - COMPLETE (CN-OLP1)	1	ACXA61C03500	0
	43	TERMINAL COVER	1	ACXH17-02080	
	44	SELF TAPPING SCREW	1	XTT4+12CFJ	
	45	BOX SHAPED PLATE	1	ACXD66-04420	
	46	A-PIECE	1	D77001	
	47	SELF TAPPING SCREW	1	XTT4+12CFJ	
\wedge	48	REMOTE CONTROL SWITCH - COMPLETE	1	ACXA75C26381	0
	49	LEAD WIRE - COMPLETE (RC)	1	ACXA61C03510	0
	50	LEAD WIRE - COMPLETE (CN-CNT2)	1	ACXA61C03520	0
	51	BOX SHAPED PLATE (DECO)	1	ACXD66-03970	
	52	SELF TAPPING SCREW	2	XTB4+8CFJ	
	53	SELF TAPPING SCREW	4	XTB4+8FFJ	
	54	CABINET FRONT PLATE	1	ACXE06-05530A	0
\wedge	55	WIRING DIAGRAM	1	ACXF29-01080	
	56	PARTICULAR PIECE	1	ACXD93-28250	0
	57	RUBBER (DECO)	1	ACXB81-07400	
	58	DECORATION BASE ASSY (L)	1	ACXE35K03630	
	59	DECORATION BASE ASSY (R)	1	ACXE35K03640	
	60	SELF TAPPING SCREW	13	XTT4+8CFJ	
	61	SCREW	2	ACXH55-00120	
\wedge	62	INSTALLATION INSTRUCTION COMPLETE	1	ACXF60C20950	
	63	MODEL LABEL	1	ACXF87-39540	
\wedge	64	NAME PLATE	1	ACXF09-10250	
$\overline{\mathbb{A}}$	65	CAUTION LABEL	1	ACXF75-14410	
$\overline{\mathbb{A}}$	66	WARNING LABEL	1	ACXF75-16770	
$\overline{\mathbb{A}}$	67	NETWORK ADAPTOR	1	CZ-TAW1C	
	68	CORRUGATED CARDBOARD	1	ACXG57-13730	
	69	SHOCK ABSORBER	2	ACXG70-16800	
	70	INSTALLING HOLDER	1	ACXH36-01290	
	71	DUMMY COVER FOR REMOTE C	1	ACXE15-01170	


- All parts are supplied from PHVACCZ, Czech (Vendor Code: 00029407). "O" marked parts are recommended to be kept in stock. ٠
- •




The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.



The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.








The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.


O/I


(224)

























DTL M

122


١Ħ




Note:



Note: The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.





SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	1	BASE PAN - COMPLETE	1	ACXD52C01870	~	÷	
	2	BASE PAN ASSY	1	ACXD52K05580	←	\leftarrow	
	3	CONVEX PIECE	2	ACXD75-00710	~	÷	
	4	SCREW	6	H551040J	←	Ļ	
	5	PACKING	4	B811017	←	\leftarrow	
	6	ANTI - VIBRATION BUSHING	4	ACXH50-00480	←	\leftarrow	
	7	FLAT PLATE	1	ACXD64-01770	←	\leftarrow	
	8	SCREW	4	ACXH55-08360	←	Ļ	
	9	NUT	4	H561049	←	Ļ	
	10	PACKING	4	ACXB81-07660	~	÷	
	11	ANTI - VIBRATION BUSHING	4	H501113	←	Ļ	
\wedge	12	COMPRESSOR	1	ACXB09-09930	←	\leftarrow	0
	13	CONNECTING BAR ASSY	1	ACXE26K00011A	~	÷	
	14	SCREW	4	H551040J	~	\leftarrow	
	15	NUT	4	H561049	~	÷	
	16	FIN & TUBE CONDENSER COMPLETE (U & L)	1	ACXB32C29731	←	ACXB32C28551	0
	17	MANIFOLD TUBE ASSY	1	ACXT07K11430	<i>←</i>	ACXT07K11420	
	18	SCREW	2	ACXH55-07140	<i>←</i>	\leftarrow	
	19	SOUND - PROOF BOARD	1	ACXH15-04300	←	\leftarrow	
	20	SOUND PROOF MATERIAL	1	ACXG30-14870	<i>←</i>	\leftarrow	
	21	PACKING	1	ACXB81-00030	<i>←</i>	\leftarrow	
	22	CAP	1	H521180	<i>←</i>	~	
	23	EPT SEAL	1	ACXD3A15-440	<i>←</i>	~	
	24	POLY - E. FOAM	1	ACXE5A45-80	<i>←</i>	←	
	25	SCREW	3	ACXH55-07140	~	÷	
	26	FIXED INDUCTORS	3	G0C392J00060	<i>←</i>	~	
	27	SCREW	12	ACXH55-07140	<i>←</i>	~	
\wedge	28	4-WAYS VALVE COMPLETE	1	ACXB00C03631	<i>←</i>	~	0
	29	4-WAYS VALVE	1	ACXB00-01530	<i>←</i>	←	0
	30	STRAIGHT TUBE	1	T102044	<i>←</i>	←	
Ŵ	31	PRESSURE SWITCH	1	ACXA10-00710	<i>←</i>	←	0
	32	2-WAYS VALVE	1	ACXB02-04110	<i>←</i>	←	0
	33	STRAINER	1	B111032	<i>←</i>	Ļ	
	34	HIGH PRESSURE SENSOR	1	ACXA50-06870	←	~	0
	35	TUBE ASSY	1	ACXT00-87530	<i>←</i>	Ļ	
	36	2-WAYS VALVE	1	ACXB02-03960	<i>←</i>	←	0
	37	TUBE ASSY	1	ACXT00-87710	←	ACXT00-87540	
	38	EXPANSION VALVE (SUB EXP. VALVE)	1	ACXB05-01580	←	←	0
	39	2-WAYS VALVE	1	ACXB02-04110	<i>←</i>	←	0
	40	STRAINER	1	B111032	←	↓	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	41	EXPANSION VALVE (MAIN EXP. VALVE)	1	ACXB05-01570	←	←	0
	42	STRAINER	2	B111032	←	←	
	43	SOUND PROOF MATERIAL - COMP. BODY	1	ACXG30-14830	←	<i>←</i>	
	44	SOUND PROOF MATERIAL - COMP. TOP	1	ACXG30-14840	←	←	
	45	SOUND - PROOF BOARD	1	ACXH15-04310	←	←	
	46	L-PIECE	1	ACXD70-02530	←	\leftarrow	
	47	PARTICULAR PLATE	1	ACXD90-30940	←	←	
	48	FOAMED POLYSTYRENE	1	ACXG07-08650	←	ACXG07-08660	
Λ	49	HOT WATER COIL - COMPLETE	1	ACXB90C02140	←	ACXB90C02130	
	50	PARTICULAR PLATE	2	ACXD90-30950	←	←	
	51	ADH. POLY - E. FOAM	1	ACXG12-42390	←	ACXE2A40-140	
	52	BUSHING	2	ACXH51-01760	←	←	
	53	SCREW	4	ACXH55-07140	←	←	
	54	BAND	4	4605008	←	←	
	55	POLY - E. FOAM	1	ACXE15A25-60	←	\leftarrow	
	56	HOLDER - COUPLING	1	ACXH35-02360	←	←	
	57	TUBE CONNECTER	2	ACXT29-01030	←	←	
	58	CAP	1	ACXH52-03610	←	←	
	59	TOOTHED LOCK WASHER	4	XWC5BV	←	←	
	60	SCREW	4	H551049J	←	←	
	61	PLUG	2	B821027	←	\leftarrow	
Λ	62	PACKING	2	ACXB81-06770	←	←	
	63	PACKING	2	ACXB81-06910	←	←	
	64	SCREW	2	ACXH55-07140	←	\leftarrow	
	65	FILTER COMPLETE	1	ACXB51C00110	←	←	0
	66	PLUG	1	ACXB82-00840	<i>←</i>	<i>←</i>	
Ŵ	67	PACKING	1	ACXB81-06810	←	\leftarrow	
	68	RETAINING RING (14-23)	1	H581038	←	←	
	69	PACKING	1	ACXB81-06910	←	←	
	70	RETAINING RING (25.4)	1	ACXH58-00370	←	←	
Λ	71	PUMP	1	ACXB53-01000	←	\leftarrow	0
	72	PARTICULAR PLATE	1	ACXD90-30970	←	←	
	73	SELF TAPPING SCREW	2	XTT4+16CFJ	←	←	
	74	SCREW	2	ACXH55-07140	←	←	
	75	U-SHAPED TUBE - COMPLETE	1	ACXT23C00180	←	ACXT00C49270	
	76	L-SHAPED TUBE	1	ACXT20-13860	←	-	
	77	L-SHAPED TUBE	1	ACXT20-14150	←	-	
	78	PACKING	1	ACXB81-06910	←	-	
	79	RETAINING RING (25.4)	1	ACXH58-00370	←	-	
	80	PACKING	2	ACXB81-06910	<i>←</i>	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	81	RETAINING RING (25.4)	2	ACXH58-00370	\leftarrow	\leftarrow	
	82	L-SHAPED TUBE	1	ACXT20-15030	←	ACXT20-15330	
	83	PACKING	2	ACXB81-06910	<i>←</i>	←	
	84	RETAINING RING (25.4)	2	ACXH58-00370	<i>←</i>	←	
	85	FILTER COMPLETE	1	ACXB51C00160	<i>←</i>	←	0
	86	TUBE ASSY COMPLETE INHOUSE	1	ACXT00C49260	<i>←</i>	ACXT00C49250	
	87	PACKING	2	ACXB81-06910	<i>←</i>	ACXB81-06900	
\wedge	88	PACKING	1	ACXB81-06820	<i>←</i>	←	
	89	RETAINING RING (25.4)	2	ACXH58-00370	←	←	
$\overline{\mathbb{V}}$	90	FLOW SENSOR (VALVE BODY)	1	ACXB62-00912	←	←	0
\triangle	91	LEAD WIRE - COMPLETE (FLOW SENSOR)	1	ACXA61C04000	<i>←</i>	<i>←</i>	0
	92	U-SHAPED TUBE - COMPLETE	1	ACXT23C00170	<i>←</i>	←	
	93	PACKING	1	ACXB81-06910	\leftarrow	\leftarrow	
	94	RETAINING RING (25.4)	1	ACXH58-00370	←	\leftarrow	
	95	PACKING	1	ACXB81-06910	←	\leftarrow	
	96	RETAINING RING (25.4)	3	ACXH58-00370	←	\rightarrow	
	97	PARTICULAR PLATE	1	ACXD90-31030	←	\rightarrow	
	98	SCREW	1	ACXH55-07140	<i>←</i>	←	
\wedge	99	VALVE BODY (PRESSURE RELIEF VALVE)	1	ACXB62-01320	←	←	0
	100	RETAINING RING (14-23)	1	H581038	←	\leftarrow	
	101	TUBE ASSY	1	ACXT00-85820	←	\rightarrow	
	102	STRAIGHT TUBE	1	ACXT10-21230	←	\rightarrow	
\mathbf{N}	103	PACKING	1	ACXB81-06820	←	\rightarrow	
	104	RETAINING RING (14-23)	1	H581038	←	\rightarrow	
\triangle	105	SENSOR - COMPLETE (WATER PRESSURE SENSOR CN-DPS)	1	ACXA50C20090	←	←	0
\wedge	106	PACKING	1	ACXB81-06790	<i>←</i>	←	
	107	SCREW	2	H55406J	<i>←</i>	←	
\wedge	108	SENSOR - COMPLETE (WATER OUTLET SENSOR 2 & WATER INLET TEMP. SENSOR CN-TH3)	1	ACXA50C20630	←	←	0
Λ	109	PACKING	2	ACXB81-06780	<i>←</i>	←	
	110	SELF TAPPING SCREW	2	XTT4+8CFJ	<i>←</i>	←	
	111	SCREW	2	ACXH55-07140	<i>←</i>	←	
	112	PARTICULAR PLATE	1	ACXD90-30930	←	←	
\wedge	113	TERMINAL BOARD ASSY	2	ACXA28K02540	←	←	0
	114	SELF TAPPING SCREW	2	XTN4+16CFJ	<i>←</i>	←	
	115	INDICATION LABEL (TERMINAL)	1	ACXF71-34380	<i>←</i>	~	
	116	LEAD WIRE - COMPLETE (OUTDOOR UNIT STAND ALONE CONNECTION)	1	ACXA61C00650	←	←	0
	117	SCREW	2	ACXH55-07140	<i>←</i>	←	
	118	PARTICULAR PLATE	1	ACXD90-30960	<i>←</i>	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	119	SCREW	1	ACXH55-07140	\leftarrow	\leftarrow	
	120	SCREW	2	ACXH55-07140	←	\leftarrow	
	121	SCREW	2	H55440J	<i>←</i>	<i>←</i>	
	122	SCREW	4	H55406J	<i>←</i>	<i>←</i>	
	123	RUBBER	1	G251015	←	←	
\wedge	124	V-COIL COMPLETE (4-WAY VALVE)	1	ACXA43C08090	←	←	0
	125	SCREW	1	H55082J	←	←	
\wedge	126	V-COIL COMPLETE (MAIN EXP. VALVE CN-EV)	1	ACXA43C08100	←	<i>←</i>	0
\wedge	127	V-COIL COMPLETE (BYPASS EXP. VALVE CN-INJ)	1	ACXA43C08110	←	←	0
\triangle	128	V-COIL COMPLETE (DIS/INLET BYPASS 2-WAY VALVE)	1	ACXA43C08120	<i>←</i>	←	0
\triangle	129	V-COIL COMPLETE (INJECTION 2-WAY VALVE)	1	ACXA43C08130	<i>←</i>	<i>~</i>	0
	130	SCREW	2	H55082J	<i>←</i>	<i>←</i>	
	131	RUBBER	3	ACXG25-02300	←	←	
	132	RUBBER	2	G251015	←	\leftarrow	
	133	RUBBER	1	G251021	←	\rightarrow	
	134	HOSE BAND	1	4090023	<i>←</i>	←	
\triangle	135	SENSOR - COMPLETE (OUTDOOR DISCHARGE TEMP SENSOR CN-TH1)	1	ACXA50C20620	←	←	0
\triangle	136	SENSOR - COMPLETE (OUTDOOR AMBIENT TEMP. SENSOR CN-TH1)	1	ACXA50C19550	←	<i>←</i>	0
\square	137	SENSOR - COMPLETE (OUTDOOR HEAT EXCHANGER MIDDLE TEMP. SENSOR CN-TH1)	1	ACXA50C19710	←	Ļ	0
\triangle	138	SENSOR - COMPLETE (BYPASS OUTLET TEMP. SENSOR & EVAP. OUTLET TEMP. SENSOR CN-TH2)	1	ACXA50C19570	←	←	0
Ŵ	139	SENSOR - COMPLETE (ECONOMIZER OUTLET TEMP. SENSOR CN-TH2)	1	ACXA50C19560	←	←	0
\triangle	140	SENSOR - COMPLETE (REFRIGERANT TEMP. SENSOR (CN-TH3)	1	ACXA50C19720	←	←	0
	141	PLATE SPRING	8	H711010	←	<i>←</i>	
	142	FAN MOTOR BRACKET	2	ACXD54-05180	←	<i>←</i>	0
	143	SCREW	18	H551040J	<i>←</i>	←	
	144	SCREW	2	H551040J	<i>←</i>	<i>←</i>	
\wedge	145	DC MOTORS (UPPER)	1	L6CBYYYL0475	<i>←</i>	<i>←</i>	0
$\overline{\mathbb{A}}$	146	DC MOTORS (LOWER)	1	L6CBYYYL0476	<i>←</i>	<i>←</i>	0
	147	SCREW	8	H551455	<i>←</i>	<i>←</i>	
	148	FAN ASSY	2	ACXH03K01200	<i>←</i>	<i>←</i>	
	149	WASHER	2	H571075A	<i>←</i>	<i>←</i>	
	150	NUT	2	H561112A	←	←	
	151	CONTROL BOARD ASSY	1	ACXH10K03210A	←	←	
\triangle	152	ELECTRONIC CONTROLLER - COMPLETE	1	ACXA74C07610	ACXA74C07620	ACXA74C07630	0
-	153	PACKING	1	ACXB81-07211	<i>←</i>	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	154	SCREW	31	H551198	←	\leftarrow	
\wedge	155	LEAD WIRE - COMPLETE (COMPRESSOR)	1	ACXA61C00660	←	←	0
	156	MACHINE SCREW & WASHER ASSY	3	XYN4+F10FJ	~	←	
	157	FIXED INDUCTORS	1	G0C103Z00006	~	←	
\wedge	160	CIRCUIT BREAKER	1	ACXA18-00021	~	←	0
	161	SELF TAPPING SCREW	2	XTT4+10CFJ	~	←	
	162	MACHINE SCREW & WASHER ASSY	2	XYN5DC10FJ	~	←	
\wedge	163	TERMINAL BOARD ASSY	1	A28K1294	<i>~</i>	←	0
	164	SELF TAPPING SCREW	1	XTN4+20CFJ	~	←	
	165	HOLDER - P.S. CORD	1	ACXH31-01640	~	ACXH31-01480	
	166	HOLDER - P.S. CORD	1	ACXH31-01620	~	←	
	167	HOLDER - P.S. CORD	1	ACXH31-01630	←	\leftarrow	
	169	PACKING BOX SHAPE PLATE	1	ACXB81-07670	←	←	
	170	SELF TAPPING SCREW	6	XTT4+12CFJ	←	\leftarrow	
\wedge	171	ELECTRONIC CONTROLLER (SUB)	1	ACXA74C07640	←	←	0
	172	CONTROL BOARD/SUB	1	ACXH10-10570	←	←	
	173	SCREW	4	XTB3+8CFJ	←	←	
	174	SELF TAPPING SCREW	2	XTT4+10CFJ	←	←	
	176	CONTROL BOARD/NF	1	ACXH10-10560	←	←	
	177	SCREW	6	XTB3+8CFJ	←	←	
	178	SELF TAPPING SCREW	2	XTT4+10CFJ	←	\leftarrow	
	179	PACKING	1	ACXB81-07680	←	\leftarrow	
	181	SCREW	1	H551040J	←	←	
\wedge	183	LEAD WIRE - COMPLETE (L1-IN, L2-IN, L3-IN, N-IN)	1	ACXA61C00670	←	←	0
	184	HOSE BAND	1	4090023	<i>~</i>	←	
	185	CONTROL BOARD COVER - COMPLETE	1	ACXH13C06720	←	←	
	186	PACKING	1	ACXB81-07690	<i>~</i>	←	
	188	HOLDER - P.S. CORD	1	ACXH31-01650	←	←	
	189	SCREW	3	ACXH55-00120	←	←	
	190	CONTROL BOARD COVER - COMPLETE	1	ACXH13C06650	←	←	
	191	PACKING	1	ACXB81-07650	←	←	
	192	MACHINE SCREW & WASHER ASSY	4	XYN4+F10FJ	←	←	
	193	HOLDER - SENSOR	1	ACXH32-01480	<i>←</i>	←	
	194	SOUND PROOF MATERIAL	1	ACXG30-14880	←	←	
	195	CABINET SIDE PLATE - COMPLETE (R)	1	ACXE04C09050	←	←	
	196	HANDLE	1	ACXE16-00230G	←	←	
	197	EPT SEAL	1	ACXD3A10-92	<i>←</i>	←	
	198	SCREW	1	ACXH55-07980	←	←	
	199	CAP (CABINET SIDE PLATE)	6	ACXH52-04230G	←	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	200	SCREW	15	ACXH55-07980	\leftarrow	\leftarrow	l
	201	SCREW	2	ACXH55-07140	←	\leftarrow	
	202	CABINET FRONT PLATE (L)	1	ACXE06-05620	\leftarrow	\rightarrow	
	203	HANDLE	1	ACXE16-00230G	←	\leftarrow	
	204	EPT SEAL	1	ACXD3A10-92	<i>←</i>	~	
	205	SCREW	1	ACXH55-07980	~	~	
	206	SCREW	7	ACXH55-07980	<i>←</i>	←	
	207	SCREW	5	ACXH55-07140	<i>←</i>	~	
	208	CABINET SIDE PLATE (L)	1	ACXE04-13910	←	÷	
	209	PARTICULAR PLATE	1	ACXD90-29140	<i>←</i>	~	
	210	SCREW	3	ACXH55-07740	←	\leftarrow	
	211	CABINET TOP PLATE - COMPLETE	1	ACXE03C02510	←	\leftarrow	
	212	SCREW	9	ACXH55-07980	←	\leftarrow	
	213	CABINET FRONT PLATE (R)	1	ACXE06-05630	←	\leftarrow	
	214	PARTICULAR PIECE	4	ACXD93-25230	←	\leftarrow	
	215	NUT	4	ACXH56-00120	←	Ļ	
	216	HANDLE	1	ACXE16-00230G	←	\leftarrow	
	217	EPT SEAL	1	ACXD3A10-92	←	\leftarrow	
	218	SCREW	1	ACXH55-07980	←	Ļ	
	219	SCREW	8	ACXH55-07740	←	Ļ	
	220	SOUND PROOF MATERIAL	1	ACXG30-14860	←	Ļ	
	221	SCREW	9	ACXH55-07980	←	\leftarrow	
	222	ACCESSORY - COMPLETE	1	ACXH82C29860	←	\leftarrow	
	223	CAP (OR PART ACXH52-01980)	3	ACXH52-04310	←	\leftarrow	
	224	DRAIN NOZZLE	1	ACXH41-00700	←	\leftarrow	
	225	SCREW	8	H551198	←	Ļ	
	226	CAP (ACCESSORY - COMPLETE CAP)	15	ACXH52-04470	←	←	
	227	INDICATION LABEL (OUT)	1	ACXF71-25700	←	÷	
	228	INDICATION LABEL (IN)	1	ACXF71-25710	~	\leftarrow	
	229	CAUTION LABEL (CONTROL BOARD COVER)	1	ACXF71-34831	←	←	
	230	OPERATING INSTRUCTION - COMPLETE	1	ACXF55C30530	←	\leftarrow	0
	231	INSTALLATION INSTRUCTION COMPLETE	1	ACXF60C20620	←	←	0
	232	MODEL LABEL	1	ACXF87-30900	ACXF87-30910	ACXF87-30920	
	233	DISCHARGE GRILLE - COMPLETE (R TOP)	1	ACXE20C09371	←	~	
	234	DISCHARGE GRILLE - COMPLETE (L BOTTOM)	1	ACXE20C09380	←	~	
	235	DISCHARGE GRILLE - COMPLETE (L TOP)	1	ACXE20C09390	<i>←</i>	<i>~</i>	
	236	DISCHARGE GRILLE - COMPLETE (R BOTTOM)	1	ACXE20C09400	<i>←</i>	<i>←</i>	
	237	BAG	1	ACXG86-06800	←	\leftarrow	1

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	238	BASE - BOARD COMPLETE	1	ACXG62C03020	←	←	
	239	SHOCK ABSORBER (MIDDLE LEFT)	1	ACXG70-16300	←	←	
	240	SHOCK ABSORBER (MIDDLE)	1	ACXG70-16310	\leftarrow	\rightarrow	
	241	SHOCK ABSORBER (MIDDLE RIGHT)	1	ACXG70-16320	\leftarrow	\rightarrow	
	242	SHOCK ABSORBER (UPPER LEFT)	1	ACXG70-15320	\leftarrow	\rightarrow	
	243	SHOCK ABSORBER (UPPER RIGHT)	1	ACXG70-15330	\leftarrow	\downarrow	
	244	CORRUGATED CARDBOARD	2	ACXG57-13710	\leftarrow	\rightarrow	
	245	C.C. CASE	1	ACXG50-64400	\leftarrow	\rightarrow	0
	246	CONTROL BOARD ASSY	1	ACXH10K03540	~	←	
\wedge	247	ELECTRONIC CONTROLLER - COMPLETE	1	ACXA74C10550	\leftarrow	←	0
	248	BOX SHAPED PLATE - COMPLETE	1	ACXD66C00840	\leftarrow	\leftarrow	
	249	CONTROL BOARD ASSY	1	ACXH10K03560	\leftarrow	\leftarrow	

- All parts are supplied from PHVACCZ, Czech (Vendor Code: 00029407).
- "O" marked parts are recommended to be kept in stock.