
Service Manual

Air-to-Water Heatpump



Mono Bloc Unit WH-MXC09J3E8 WH-MXC12J9E8

Destination Europe Turkey

MARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the products dealt with in this service information by anyone else could result in serious injury or death.

! CAUTION

R32 REFRIGERANT – This Air Conditioner contains and operates with refrigerant R32. THIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED BY QUALIFIED PERSONNEL.

Refer to National, State, Territory and local legislation, regulations, codes, installation & operation manuals, before the installation, maintenance and/or service of this product.

PRECAUTION OF LOW TEMPERATURE

In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigerant circuit.

Panasonic

TABLE OF CONTENTS

PAGE	P	'AGE
1. Safety Precautions4	13.15 Alternative Outdoor Ambient Sensor Cont	
2. Precaution for Using R32 Refrigerant6	13.16 Force DHW mode	
3. Specifications11	13.17 SMART DHW mode	
•	13.18DHW Capacity Setting	
3.1 WH-MXC09J3E811	13.19 Anti Freeze Control	
3.2 WH-MXC12J9E814	13.20 Solar Operation (Optional)	
4. Features17	13.21 Boiler Bivalent Control	
5. Location of Controls and Components18	13.22 External Room Thermostat Control (Optio	
5.1 Indoor Unit18	13.23 Three Ways Valve Control	
6. Dimensions37	13.24Two Ways Valve Control 13.25External OFF/ON Control	
6.1 Mono Bloc Unit37	13.26 External Compressor Switch (Optional PC	
		122
7. Refrigeration and Water Cycle Diagram38	13.27 Heat/Cool Switch (Optional PCB)	
7.1 Standard System (Optional PCB not	13.28 SG Ready Control (Optional PCB)	
connected)39	13.29 Demand Control (Optional PCB)	
7.2 Advance System (Optional PCB connected)	13.30 Holiday Mode	
39	13.31 Dry Concrete	
3. Block Diagram40	13.32 Flow Sensor	127
	14. Protection Control	128
8.1 WH-MXC09J3E840		
8.2 WH-MXC12J9E841	14.1 Protection Control for All Operations	
9. Wiring Connection Diagram42	14.2 Protection Control for Heating Operation	
	44.2 Protection Control for Cooling Operation	130
9.1 Water System42	14.3 Protection Control for Cooling Operation	
9.2 Refrigerant System44		132
10. Electronic Circuit Diagram45	15. Servicing Mode	133
10.1 Water System	15.1 Expansion Vessel ⑦ Pre Pressure Check	kina
10.1 Water System45 10.2 Refrigerant System47		
10.2 Reingerant System47	15.2 Maintenance	
11. Printed Circuit Board48	15.3 Pump Down Procedures	
11.1 Water System48	15.4 How To Adjust Pump Speed	
11.2 Refrigerant System50	15.5 How To Unlock Cool Mode	
	15.6 EEPROM Factory Default Data Setup	
12. Installation Instruction52	Procedure	137
12.1 Mono Bloc Unit52	15.7 Dry Concrete Setup	
12.2 Variation of System65	4C. Maintananaa Cuida	4 4 (
12.3 How to Fix External Device	16. Maintenance Guide	140
12.4 System Installation75	16.1 Maintenance Menu	142
12.5 Service and Maintenance87	17. Troubleshooting Guide	144
13. Operation and Control88	17.1 Refrigeration Cycle System	
·	17.2 Relationship between the Condition of the	
13.1 Basic Function	to-Water Heatpump Indoor and Outdoor L	
13.2 Water Pump	and Pressure and Electric Current	
13.3 Indoor Unit Safety	17.3 Breakdown Self Diagnosis Function	
13.4 Auto Restart Control	17.4 Error Codes Table	
	17.5 Self-diagnosis Method	
13.6 Indoor Back-Up Heater Control105 13.7 Tank Heater Control106	•	
13.8 Base Pan Heater Control (Optional)108	18. Disassembly and Assembly Instructions	196
13.9 Heater Turn ON/OFF priority Control109	18.1 To Remove The Cabinet Front Plate	196
13.10 Force Heater Mode109	18.2 To Remove The Cabinet Top Plate	
13.11 Powerful Operation111	18.3 To Remove The Cabinet Rear Plate	
13.12 Quiet Operation111	18.4 To Remove Pressure Gauge	
13.13 Sterilization Mode112	18.5 To Remove Water System Electronic	
13.14 Outdoor Ambient Thermo OFF Control112	Controller Board	198
TIZ	18.6 To Remove Air Purge Valve	

18.7	To Remove Flow Sensor	199
18.8	To Remove Water Pump	200
18.9	To Remove Heater	201
18.10	To Remove Filter	202
19. Ted	chnical Data	203
19.1	Operation Characteristics	203
	Heating Capacity Table	
	Cooling Capacity Table	
20. Ex	oloded View and Replacement Parts	
••••		214
20.1	Water System	214
20.2	Refrigerant System	215

1. Safety Precautions

- Read the following "SAFETY PRECAUTIONS" carefully before installation of (Mono bloc) Air-to-Water Heatpump system (hereafter referred to as "Mono bloc unit").
- Electrical works and water installation works must be done by licensed electrician and licensed water system installer respectively. Be sure to use the correct rating and main circuit for the model to be installed.
- The caution items stated here must be followed because these important contents are related to safety. The
 meaning of each indication used is as below.
 Incorrect installation due to ignorance or negligence of the instructions will cause harm or damage, and the
 seriousness is classified by the following indications.

WARNING This indication shows the possibility of causing death or serious injury.	
CAUTION This indication shows the possibility of causing injury or damage to properties only.	

The items to be followed are classified by the symbols:

\Diamond	Symbol with white background denotes item that is PROHIBITED.	
0 0	Symbol with dark background denotes item that must be carried out.	

- Carry out test run to confirm that no abnormality occurs after the installation. Then, explain to user the operation, care and maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.
- If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.
- This appliance is not intended for accessibility by the general public.
- Please leave this installation manual to the user after installation.

	<u></u> WARNING	
1.	Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. Any unfit method or using incompatible material may cause product damage, burst and serious injury.	\Diamond
2.	Do not install Mono bloc unit near handrail of veranda. When installing Mono bloc unit at veranda of high rise building, child may climb up to Mono bloc unit and cross over the handrail and causing accident.	0
3.	Do not use unspecified cord, modified cord, join cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire.	\Diamond
4.	Do not tie up the power supply cord into a bundle by band. Abnormal temperature rise on power supply cord may happen.	\Diamond
5.	Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury.	\Diamond
6.	Do not sit or step on the unit, you may fall down accidentally.	\Diamond
7.	Keep plastic bag (packaging material) away from small children, it may cling to nose and mouth and prevent breathing.	\Diamond
8.	Do not purchase unauthorized electrical parts for installation, service, maintenance and etc They might cause electrical shock or fire.	\Diamond
9.	Do not pierce or burn as the appliance is pressurized. Do not expose the appliance to heat, flame, sparks, or other sources of ignition. Else, it may explode and cause injury or death.	\Diamond
10.	Do not modify the wiring of Mono bloc unit for installation of other components (i.e. heater, etc). Overloaded wiring or wire connection points may cause electrical shock or fire.	\Diamond
11.	Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury etc.	\Diamond
12.	This Mono bloc unit is a multi supply appliance. All circuits must be disconnected before accessing the unit terminals.	0
13.	For electrical work, follow the national regulation, legislation and this installation instructions. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in the electrical work, it will cause electrical shock or fire.	0
14.	For water circuit installation work, follow to relevant European and national regulations (including EN61770) and local plumbing and building regulation codes.	0
15.	Engage authorized dealer or specialist for installation. If installation done by the user is incorrect, it will cause water leakage, electrical shock or fire.	0
16.	Install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock or fire.	0

	<u></u> WARNING	
17.	Only use the supplied or specified installation parts. Else, it may causes Mono bloc unit vibrate, fall, water leakage, electrical shock or fire.	0
18.	Install at a flat, strong and firm location which is able to withstand the Mono bloc unit's weight. If the location is slanting, or strength is not enough the set will fall and cause injury.	0
19.	Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed perfectly, it will cause fire or electrical shock.	0
20.	This equipment is strongly recommended to be installed with Residual Current Device (RCD) on-site according to the respective national wiring rules or country-specific safety measures in terms of residual current.	0
21.	The unit is only for use in a closed water system. Utilization in an open water system may lead to excessive corrosion of the water piping and risk of incubating bacteria colonies, particularly Legionella, in water.	0
22.	If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.	0
23.	Select a location where in case of water leakage, the leakage will not cause damage to other properties.	0
24.	When installing electrical equipment at wooden building of metal lath or wire lath, in accordance with electrical facility standard, no electrical contact between equipment and building is allowed. Insulator must be installed in between.	0
25.	This installation may be subjected to building regulation approval applicable to respective country that may require to notify the local authority before installation.	0
26.	Any work carried out on the Mono bloc unit after removing any panel which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.	0
27.	Be aware that refrigerants may not contain an odour.	0
28.	This equipment must be properly earthed. Earth line must not be connected to gas pipe, water pipe, earth of lightning rod and telephone. Otherwise, it may cause electrical shock in case of equipment breakdown or insulation breakdown.	•

23.	Select a location where in case of water leakage, the leakage will not cause damage to other properties.	V
24.	When installing electrical equipment at wooden building of metal lath or wire lath, in accordance with electrical facility standard, no electrical contact between equipment and building is allowed. Insulator must be installed in between.	0
25.	This installation may be subjected to building regulation approval applicable to respective country that may require to notify the local authority before installation.	0
26.	Any work carried out on the Mono bloc unit after removing any panel which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.	0
27.	Be aware that refrigerants may not contain an odour.	0
28.	This equipment must be properly earthed. Earth line must not be connected to gas pipe, water pipe, earth of lightning rod and telephone. Otherwise, it may cause electrical shock in case of equipment breakdown or insulation breakdown.	•
	<u></u> CAUTION	
1.	Do not install the Mono bloc unit at place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the Mono bloc unit, it may cause fire.	0
2.	Do not release refrigerant during piping work for installation, re-installation and during repairing a refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite.	0
3.	Make sure the insulation of power supply cord does not contact hot part (i.e. refrigerant piping, water piping) to prevent from insulation failure (melt).	0
4.	Do not touch the sharp aluminium fin, sharp parts may cause injury.	0
5.	Do not apply excessive force to water pipes that may damage the pipes. If water leakage occurs, it will cause flooding and damage to other properties.	0
6.	Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water leakage may happen and may cause damage to properties of the user.	0
7.	The piping installation work must be flushed before the Mono bloc unit is connected to remove contaminants. Contaminants may damage the Mono bloc unit components.	0
8.	Select an installation location which is easy for maintenance. Incorrect installation, service or repair of this Mono bloc unit may increase the risk of rupture and this may result in loss damage or injury and/or property.	0
9.	Ensure the correct polarity is maintained throughout all wiring. Otherwise, it will cause electrical shock or fire.	0
10.	Power supply connection to Mono bloc unit. Power supply point should be in easily accessible place for power disconnection in case of emergency. Must follow local national wiring standard, regulation and this installation instruction. Strongly recommended to make permanent connection to a circuit breaker. It must be a double pole switch with a minimum 3.0 mm gap. Power Supply 1: Use approved 20A 4-poles circuit breaker with a minimum contact gap of 3.0mm. Power Supply 2: Use approved 15/16A 2-poles circuit breaker with a minimum contact gap of 3.0mm. (Only applicable for WH-MXC09J3E8) or Use approved 20A 4-poles circuit breaker with a minimum contact gap of 3.0mm. (Only applicable for WH-MXC12J9E8, WH-MXC16J9E8)	9
11.	Ensure the correct polarity is maintained throughout all wiring. Otherwise, it will cause electrical shock or fire.	0
12.	After installation, the installer is obliged to verify correct operation of the Mono bloc unit. Check the connection point for water leakage during test run. If leakage occurs, it will cause damage to other properties.	0
13.	Keep any required ventilation openings clear of obstruction.	0
14.	Installation work. Four or more people are required to carry out the installation work. The weight of Mono bloc unit might cause injury if carried by less than four people.	0

2. Precaution for Using R32 Refrigerant

The basic installation work procedures are the same as conventional refrigerant (R410A, R22) models.
 However, pay careful attention to the following points:

	<u></u> WARNING	
1.	Since the working pressure is higher than that of refrigerant R22 models, some of the piping and installation and service tools are special. Especially, when replacing a refrigerant R22 model with a new refrigerant R32 model, always replace the conventional piping with the R32 and R410A piping on the outdoor unit side. For R32 and R410A, the same pipe can be used.	0
2.	The mixing of different refrigerants within a system is prohibited. Models that use refrigerant R32 and R410A have a different charging port thread diameter to prevent erroneous charging with refrigerant R22 and for safety. Therefore, check beforehand. [The charging port thread diameter for R32 and R410A is 12.7 mm (1/2 inch).]	0
3.	Ensure that foreign matter (oil, water, etc.) does not enter the piping.	0
4.	Operation, maintenance, repairing and refrigerant recovery should be carried out by trained and certified personnel in the use of flammable refrigerants and as recommended by the manufacturer. Any personnel conducting an operation, servicing or maintenance on a system or associated parts of the equipment should be trained and certified.	0
5.	Any part of refrigerating circuit (evaporators, air coolers, AHU, condensers or liquid receivers) or piping should not be located in the proximity of heat sources, open flames, operating gas appliance or an operating electric heater.	0
6.	The user/owner or their authorized representative shall regularly check the alarms, mechanical ventilation and detectors, at least once a year, where as required by national regulations, to ensure their correct functioning.	0
7.	A logbook shall be maintained. The results of these checks shall be recorded in the logbook.	0
8.	In case of ventilations in occupied spaces shall be checked to confirm no obstruction.	0
9.	Before a new refrigerating system is put into service, the person responsible for placing the system in operation should ensure that trained and certified operating personnel are instructed on the basis of the instruction manual about the construction, supervision, operation and maintenance of the refrigerating system, as well as the safety measures to be observed, and the properties and handling of the refrigerant used.	0
10.	The general requirement of trained and certified personnel are indicated as below: a) Knowledge of legislation, regulations and standards relating to flammable refrigerants; and, b) Detailed knowledge of and skills in handling flammable refrigerants, personal protective equipment, refrigerant leakage prevention, handling of cylinders, charging, leak detection, recovery and disposal; and, c) Able to understand and to apply in practice the requirements in the national legislation, regulations and Standards; and, d) Continuously undergo regular and further training to maintain this expertise.	•
11.	Protect the refrigerating system from accidental rupture due to moving furniture or reconstruction activities.	0
12.	To ensure no leaking, refrigerant joints shall be tightness tested. The test method shall have a sensitivity of 5 grams per year of refrigerant or better under a pressure of at least 0,25 times the maximum allowable pressure (>1.04MPa, max 4.3MPa). No leak shall be detected.	0

! CAUTION

Installation (Space)

- Must comply with national gas regulations, state municipal rules and legislation. Notify relevant authorities in accordance with all applicable regulations.
- 1. Must ensure mechanical connections be accessible for maintenance purposes.
 - In cases that require mechanical ventilation, ventilation openings shall be kept clear of obstruction.
 - When disposal of the product, do follow to the precautions in #12 and comply with national regulations.
 - Always contact to local municipal offices for proper handling.

Servicina

2-1. Service personnel

- Any qualified person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate
 from an industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance
 with an industry recognized assessment specification.
- Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the
 assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable
 refrigerants.
- Servicing shall be performed only as recommended by the manufacturer.
- The system is inspected, regularly supervised and maintained by a trained and certified service personnel who is employed by the person user or party responsible.
- Ensure refrigerant charge not to leak.

2-2. Work

Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of
ignition is minimised.

For repair to the refrigerating system, the precautions in #2-2 to #2-8 must be followed before conducting work on the system.

- Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapour being present while the work is being performed.
- All maintenance staff and others working in the local area shall be instructed and supervised on the nature of work being carried out
- Avoid working in confined spaces. Always ensure away from source, at least 2 meter of safety distance, or zoning of free space area of at least 2 meter in radius.
- Wear appropriate protective equipment, including respiratory protection, as conditions warrant.
- Keep all sources of ignition and hot metal surfaces away.
- 2-3. Checking for presence of refrigerant
- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of
 potentially flammable atmospheres.
- Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants, i.e. non sparking, adequately sealed or intrinsically safe.
 - In case of leakage/spillage happened, immediately ventilate area and stay upwind and away from spill/release.
 - In case of leakage/spillage happened, do notify persons down wind of the leaking/spill, isolate immediate hazard area and keep unauthorized personnel out.
 - 2-4. Presence of fire extinguisher
 - If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available at hand.
 - Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.
 - 2-5. No ignition sources
 - No person carrying out work in relation to a refrigerating system which involves exposing any pipe work that contains or has contained flammable refrigerant shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. He/She must not be smoking when carrying out such work.
 - All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which flammable refrigerant can possibly be released to the surrounding space.
 - Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or
 ignition risks.
 - "No Smoking" signs shall be displayed.

2-6. Ventilated area

- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work.
- A degree of ventilation shall continue during the period that the work is carried out.
- The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- 2-7. Checks to the refrigerating equipment
- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification.
- At all times the manufacturer's maintenance and service guidelines shall be followed.
- If in doubt consult the manufacturer's technical department for assistance.
- The following checks shall be applied to installations using flammable refrigerants.
 - The ventilation machinery and outlets are operating adequately and are not obstructed.
 - Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected.



CAUTION

2-8. Checks to electrical devices

- · Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures.
- Initial safety checks shall include but not limit to:-
 - That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking.
 - That there is no live electrical components and wiring are exposed while charging, recovering or purging the system.
 - That there is continuity of earth bonding.
- 2. At all times the manufacturer's maintenance and service guidelines shall be followed.
 - If in doubt consult the manufacturer's technical department for assistance.
 - If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily
 dealt with
 - If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used.
 - The owner of the equipment must be informed or reported so all parties are advised thereinafter.

Repairs to sealed components

- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc.
- If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
- Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections,
- terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
 - Ensure that apparatus is mounted securely.
 - Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres.
 - Replacement parts shall be in accordance with the manufacturer's specifications.

NOTE: The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment.
Intrinsically safe components do not have to be isolated prior to working on them.

Repair to intrinsically safe components

- Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.
- 4. Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere.
 - The test apparatus shall be at the correct rating.
 - Replace components only with parts specified by the manufacturer. Unspecified parts by manufacturer may result ignition of refrigerant in the atmosphere from a leak.

Cabling

- 5. Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects.
 - The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

Detection of flammable refrigerants

- 6. Under no circumstances shall potential sources of ignition be used in the searching or detection of refrigerant leaks.
 - A halide torch (or any other detector using a naked flame) shall not be used.

The following leak detection methods are deemed acceptable for all refrigerant systems.

- No leaks shall be detected when using detection equipment with a sensitivity of 5 grams per year of refrigerant or better under a pressure of at least 0,25 times the maximum allowable pressure (>1.04MPa, max 4.3MPa). For example, a universal sniffer.
- Electronic leak detectors may be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need re-calibration.
 - (Detection equipment shall be calibrated in a refrigerant-free area.)
- Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
- 7. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25 % maximum) is confirmed.
 - Leak detection fluids are also suitable for use with most refrigerants, for example, bubble method and fluorescent method agents.
 The use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.
 - If a leak is suspected, all naked flames shall be removed/extinguished.
 - If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.

The precautions in #8 must be followed to remove the refrigerant.

0

0

0



CAUTION

Removal and evacuation

- When breaking into the refrigerant circuit to make repairs or for any other purpose conventional procedures shall be used. However, it is important that best practice is followed since flammability is a consideration. The following procedure shall be adhered to:
 - remove refrigerant -> purge the circuit with inert gas -> evacuate -> purge with inert gas ->
 - open the circuit by cutting or brazing
- The refrigerant charge shall be recovered into the correct recovery cylinders. 8
 - The system shall be purged with OFN to render the appliance safe. (remark: OFN = oxygen free nitrogen, type of inert gas)
 - This process may need to be repeated several times.
 - Compressed air or oxygen shall not be used for this task.
 - Purging shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum.
 - This process shall be repeated until no refrigerant is within the system.
 - When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.
 - This operation is absolutely vital if brazing operations on the pipe work are to take place.
 - Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and there is ventilation available.

Charging procedures

- In addition to conventional charging procedures, the following requirements shall be followed.
 - Ensure that contamination of different refrigerants does not occur when using charging equipment.
 - Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
 - Cylinders shall be kept in an appropriate position according to the instructions.
 - Ensure that the refrigerating system is earthed prior to charging the system with refrigerant.
- Label the system when charging is complete (if not already).
 - Extreme care shall be taken not to over fill the refrigerating system.
- Prior to recharging the system it shall be pressure tested with OFN (refer to #7).
- The system shall be leak tested on completion of charging but prior to commissioning.
- A follow up leak test shall be carried out prior to leaving the site.
- Electrostatic charge may accumulate and create a hazardous condition when charging and discharging the refrigerant. To avoid fire or explosion, dissipate static electricity during transfer by grounding and bonding containers and equipment before charging/discharging.

Decommissioning

9.

10.

- Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its details.
- It is recommended good practice that all refrigerants are recovered safely.
- Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant.
- It is essential that electrical power is available before the task is commenced.
 - Become familiar with the equipment and its operation.
 - Isolate system electrically.
 - Before attempting the procedure ensure that:
 - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - all personal protective equipment is available and being used correctly;
 - the recovery process is supervised at all times by a competent person;
 - recovery equipment and cylinders conform to the appropriate standards.
 - d) Pump down refrigerant system, if possible.
 - If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system. e)
 - Make sure that cylinder is situated on the scales before recovery takes place.
 - Start the recovery machine and operate in accordance with instructions. g) h)
 - Do not over fill cylinders. (No more than 80 % volume liquid charge).
 - Do not exceed the maximum working pressure of the cylinder, even temporarily.
 - When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
 - Recovered refrigerant shall not be charged into another refrigerating system unless it has been cleaned and checked.
- Electrostatic charge may accumulate and create a hazardous condition when charging or discharging the refrigerant. To avoid fire or explosion, dissipate static electricity during transfer by grounding and bonding containers and equipment before charging/discharging.

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant.

The label shall be dated and signed.

Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

A

0

CAUTION

Recovery

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.
- Ensure that the correct number of cylinders for holding the total system charge are available.
- All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).
- Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.
- Recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of flammable refrigerants.
- In addition, a set of calibrated weighing scales shall be available and in good working order. 12.
 - Hoses shall be complete with leak-free disconnect couplings and in good condition.
 - Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.
 - The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged.
 - Do not mix refrigerants in recovery units and especially not in cylinders.
 - If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.
 - The evacuation process shall be carried out prior to returning the compressor to the suppliers.
 - Only electric heating to the compressor body shall be employed to accelerate this process.
 - When oil is drained from a system, it shall be carried out safely.



3. Specifications

3.1 WH-MXC09J3E8

Item		Unit	Refrigerant System				
Performance Test Condition			EN 14511 / EN 14825			i	
POS (EAN)			5025232910748				
		Condition (Ambient/Water)	A35W7				
Cooling Capacity		kW	9.00				
		BTU/h	30700				
		kcal/h	7740				
Cooling EED		W/W		3.0	09		
Cooling EER		kcal/hW		2.0	66		
		Condition (Ambient/Water)	A7W35			A2W35	
Heating Capacity		kW	9.00			9.00	
		BTU/h	30700			30700	
		kcal/h	7740			7740	
Heating COP		W/W	5.08			3.81	
Treating 001	T	kcal/hW	4.37			3.28	
	Low temperature Ap	plication (W35)	Warmer	Ave	rage	Colder	
	Application	Climate		,	, c. ugo		
	Pdesign	kW	9.0	9.	.0	11.0	
	Tbivalent / TOL	°C	2/2	-10	/ -10	-15 / -22	
	SCOP / ns	(W/W) / %	6.47 / 256	4.96	/ 195	4.31 / 169	
	Annual Consumption	kWh	1859	37	47	6289	
Heating ErP	Class		A+++	A+	++	A++	
	Medium temperature A	application (W55)	Warmer Average		rage	Colder	
	Application	Climate					
	Pdesign	kW	9.0	9.	.0	11.0	
	Tbivalent / TOL	°C	2/2	-10	/ -10	-15 / -22	
	SCOP / ns	(W/W) / %	4.34 / 171	3.57	/ 140	3.26 / 127	
	Annual Consumption	kWh	2772	52	.08	8327	
	Class		A+++	A-	++	A++	
Air Flow		m³/min (ft³/min)	Cooling: 95.1 (3360) Heating: 69.2 (2440)				
Refrigerant Control Device			Expansion Valve				
Refrigerant Oil		cm³	FW50S (1200)				
Refrigerant (R32)		kg (oz)	1.60 (56.4)				
F-GAS	GWP		675				
1-000	CO2eq (ton) (Prechar	ged / Maximum)	1.080 / -				
	Туре			Hermet	ic Motor		
Compressor	Motor Type		Brushless (4-poles)				
	Rated Output	kW	3.0				

Item		Unit	Refrigerant System
	Туре		Propeller Fan
	Material		PP
Fan	Motor Type		DC (8-poles)
raii	Output Power	W	60
	Fan Speed	rpm	Cooling: 630 (Top), 670 (Bottom) Heating: 440 (Top), 480 (Bottom)
	Fin Material		Aluminium (Pre Coat)
Heat Evebonger	Fin Type		Corrugated Fin
Heat Exchanger	Row x Stage x FPI		2 x 51 x 19
	Size (W x H X L)	mm	38.1 x 1259.4 x 903.7:873.8

I	tem	Unit		Mono bloc Unit			
	Height	mm (inch)		1410 (55-17/32)			
Dimension	Width	mm (inch)	1283 (50-17/32)				
	Depth	mm (inch)	320 (12-5/8)				
Net Weight		kg (lbs)		140 (309)			
		Condition (Ambient/Water)	A35W7	A7W35	A2W35		
Noise Level		dB(A)	Cooling: 50	Heating: 51	-		
		Power level dB	Cooling: 68	Heating: 68 Heating: 65	-		
		Ø		Three			
Power Source (Phase, Volt	age, Cycle)	V		400			
		Hz		50			
Input Power		Condition (Ambient/Water)	A35W7	A7W35	A2W35		
		kW	Cooling: 2.91	Heating: 1.77	Heating: 2.36		
Maximum Input Power for I	Heatpump System	kW	6.99k				
Power Supply 1 : Phase (Ø	i) / Max. Current (A) / Max. In	out Power (W)	3Ø / 14.7 / 9.99k				
Power Supply 2 : Phase (Ø	í) / Max. Current (A) / Max. In	out Power (W)	1Ø / 13.0 / 3.00k				
Power Supply 3 : Phase (2	i) / Max. Current (A) / Max. In	out Power (W)	-/-/-				
Starting current		А	4.3				
Running Current		Condition (Ambient/Water)	A35W7	A7W35	A2W35		
		А	Cooling: 4.3	Heating: 2.6	Heating: 3.5		
Maximum Current for Heat	pump System	A		10.4			
Power Factor Power factor means total figure of compressor and outdoor fan motor.		Condition (Ambient/Water)	A35W7	A7W35	A2W35		
		%	Cooling: 97	Heating: 97	Heating: 97		
Davis Oaml	Number of core		-				
Power Cord	Length	m (ft)	-				
Thermostat	•		Electronic Control				
Protection Device		1	Electronic Control				

Item		Unit	Water System
Performance Test Condition			EN 14511 / EN 14825
POS (EAN)			5025232910748
	Outdoor Ambient	°C (min. / max.)	Cooling: 10 / 43 Heating: -20 / 35
Operation Range	Water Outlet	°C (min. / max.)	Cooling: 5 / 20 Heating (Circuit): 20 / 55 (Below Ambient -20°C) *3 20 / 60 (Ambient -15 ~ 0°C or Above Ambient 25°C) *3 20 / 65 (Ambient 5 ~ 20°C) *3 *4
Internal Pressure Differe	ntial	kPa	Cooling: 35.0 Heating: 35.0
Matan Biran Biranatan	Inlet	inch	1-1/4
Water Pipe Diameter	Outlet	inch	1-1/4
Water Drain Hose Inner Diameter		mm (inch)	15.00 (19/32)
D	Motor Type		DC Motor
Pump	Input Power	W	173
	Туре		Brazed Plate
	No. of Plates		38
Hot Water Coil	Size (H x W x L)	mm	71.4 x 121 x 333
	Water Flow Rate	l/min (m³/h)	Cooling: 25.8 (1.5) Heating: 25.8 (1.5)
Pressure Relief Valve Water Circuit		kPa	Open: 300, Close: 266 and below
Flow Switch Type			Electronic Sensor
Protection Device		A	Residual Current Circuit Breaker (25) Residual Current Circuit Breaker (40)
Expansion Vessel	Volume	I	10
LAPATISIUTI VESSET	MWP	bar	3
Capacity of Integrated E	lectric Heater	kW / °C	3.00

Note:

- Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled indoor water inlet temperature of 12°C and water outlet temperature of 7°C.
- Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled indoor water inlet temperature of 30°C and water outlet temperature of 35°C.
- Specification are subjected to change without prior notice for further improvement.
- Flow rate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and ΔT 5°C
- The unit will restart automatically after the outdoor temperature returns to the specified range.
- *3 Between outdoor ambient -15°C and -20°C, the water outlet temperature gradually decreases from 60°C to 55°C.
- *3 Between outdoor ambient 5°C and 0°C, the water outlet temperature gradually decreases from 65°C to 60°C.
- *3 Between outdoor ambient 20°C and 25°C, the water outlet temperature gradually decreases from 65°C to 60°C.
- *4 Only when ΔT is set to 15°C, the set temperature above 60°C will take effect.

3.2 WH-MXC12J9E8

ľ	tem	Unit	Refrigerant System			
Performance Test Condition	n		EN 14511 / EN 14825			5
POS (EAN)				5025232	2910700	
		Condition (Ambient/Water)	A35W7			
Cooling Capacity		kW		12	.00	
		BTU/h		410	000	
				103	320	
0 " ===		W/W		2.	84	
Cooling EER		kcal/hW		2.	44	
		Condition (Ambient/Water)	A7W35			A2W35
Heating Capacity		kW	12.00			12.00
		BTU/h	41000			41000
		kcal/h	10320			10320
		W/W	4.80			3.53
Heating COP		kcal/hW	4.13		3.04	
	Low temperature Ap	plication (W35)	Marmor	rmer Average		Colder
	Application	Climate	vvaimei			Coldei
	Pdesign	kW	9.0	9	.0	11.0
	Tbivalent / TOL	°C	2/2	-10	/ -10	-15 / -22
	SCOP / ns	(W/W) / %	6.47 / 256	4.96 / 195		4.31 / 169
	Annual Consumption	kWh	1859	37	47	6289
Heating ErP	Class		A+++	A+	++	A++
Treating Lit	Medium temperature A	Application (W55)	Warmer	Average		Colder
	Application	Climate	vvaimei	Ave	raye	Coldei
	Pdesign	kW	9.0	9	.0	11.0
	Tbivalent / TOL	°C	2/2	-10	/ -10	-15 / -22
	SCOP / ns	(W/W) / %	4.34 / 171	3.57	/ 140	3.26 / 127
	Annual Consumption	kWh	2772	52	08	8327
	Class		A+++	A-	++	A++
Air Flow		m³/min (ft³/min)	Cooling: 102.4 (3620) Heating: 76.8 (2710))
Refrigerant Control Device				Expansi	on Valve	
Refrigerant Oil		cm³		FW50S	(1200)	
Refrigerant (R32)		kg (oz)		1.60	(56.4)	
E CAS	GWP		675			
F-GAS	CO2eq (ton) (Prechar	ged / Maximum)		1.08	80 / -	
	Туре			Hermet	ic Motor	
Compressor	Motor Type			Brushless	(4-poles)	
	Rated Output	kW		3	.0	

Item		Unit	Refrigerant System
	Туре		Propeller Fan
	Material		PP
Fan	Motor Type		DC (8-poles)
raii	Output Power	W	60
	Fan Speed	rpm	Cooling: 680 (Top), 720 (Bottom) Heating: 490 (Top), 530 (Bottom)
	Fin Material		Aluminium (Pre Coat)
Heat Evelopeer	Fin Type		Corrugated Fin
Heat Exchanger	Row x Stage x FPI		2 x 51 x 19
	Size (W x H X L)	mm	38.1 x 1259.4 x 903.7:873.8

	Item	Unit	Mono bloc Unit			
	Height	mm (inch)		1410 (55-17/32)		
Dimension	Width	mm (inch)		1283 (50-17/32)		
	Depth	mm (inch)	320 (12-5/8)			
Net Weight		kg (lbs)		140 (309)		
		Condition (Ambient/Water)	A35W7	A7W35	A2W35	
Noise Level		dB(A)	Cooling: 52	Heating: 52	Heating: 52	
		Power level dB	Cooling: 69	Heating: 69 Heating: 65	Heating: 69 Heating: 65	
		Ø		Three		
Power Source (Phase, Vol	tage, Cycle)	V		400		
		Hz	50			
Input Power		Condition (Ambient/Water)	A35W7	A7W35	A2W35	
		kW	Cooling: 4.23	Heating: 2.50	Heating: 3.40	
Maximum Input Power for	Heatpump System	kW	7.93k			
Power Supply 1 : Phase (&	Ø) / Max. Current (A) / Max. In	put Power (W)	3Ø / 11.8 / 7.93k			
Power Supply 2 : Phase (&	ಶ) / Max. Current (A) / Max. In	put Power (W)	3Ø / 13.0 / 9.00k			
Power Supply 3 : Phase (&	ð) / Max. Current (A) / Max. In	put Power (W)	-1-1-			
Starting current		A		6.3		
Running Current		Condition (Ambient/Water)	A35W7	A7W35	A2W35	
		А	Cooling: 6.3	Heating: 3.7	Heating: 5.1	
Maximum Current for Heat	pump System	A		11.8		
Power Factor Power factor means total f	igure of compressor and	Condition (Ambient/Water)	A35W7	A7W35	A2W35	
outdoor fan motor.		%	Cooling: 97	Heating: 97	Heating: 97	
Power Cord	Number of core					
rowei Cord	Length	m (ft)		-		
Thermostat			Electronic Control			
Protection Device				Electronic Control		

	ltem		Water System
Performance Test Cond	ition		EN 14511 / EN 14825
POS (EAN)			5025232910700
	Outdoor Ambient	°C (min. / max.)	Cooling: 10 / 43 Heating: -20 / 35
Operation Range	Water Outlet	°C (min. / max.)	Cooling: 5 / 20 Heating (Circuit): 20 / 55 (Below Ambient -20°C) *3 20 / 60 (Ambient -15 ~ 0°C or Above Ambient 25°C) *3 20 / 65 (Ambient 5 ~ 20°C) *3*4
Internal Pressure Differential		kPa	Cooling: 55 Heating: 55
Water Diver Diameter	Inlet	inch	1-1/4
Water Pipe Diameter	Outlet	inch	1-1/4
Water Drain Hose Inner	Water Drain Hose Inner Diameter		15.00 (19/32)
	Motor Type		DC Motor
Pump	Input Power	W	173
	Туре		Brazed Plate
	No. of Plates		38
Hot Water Coil	Size (H x W x L)	mm	71.4 x 121 x 333
	Water Flow Rate	l/min (m³/h)	Cooling: 34.4 (2.1) Heating: 34.4 (2.1)
Pressure Relief Valve W	/ater Circuit	kPa	Open: 300, Close: 266 and below
Flow Switch	Туре		Electronic Sensor
Protection Device	•	A	Residual Current Circuit Breaker (25) Residual Current Circuit Breaker (25)
Evnancian Vaccal	Volume	1	10
Expansion Vessel	MWP	bar	3
Capacity of Integrated E	lectric Heater	kW / °C	9.00

Note:

- Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled indoor water inlet temperature of 12°C and water outlet temperature of 7°C.
- Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled indoor water inlet temperature of 30°C and water outlet temperature of 35°C.
- Specification are subjected to change without prior notice for further improvement.
- Flow rate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and ΔT 5°C
- The unit will restart automatically after the outdoor temperature returns to the specified range.
- *3 Between outdoor ambient -15°C and -20°C, the water outlet temperature gradually decreases from 60°C to 55°C.
- *3 Between outdoor ambient 5°C and 0°C, the water outlet temperature gradually decreases from 65°C to 60°C.
- *3 Between outdoor ambient 20°C and 25°C, the water outlet temperature gradually decreases from 65°C to 60°C.
- *4 Only when ΔT is set to 15°C, the set temperature above 60°C will take effect.

4. Features

- Inverter Technology
 - Energy saving
- High Efficiency
- Compact Design
- Environment Protection
 - Non-ozone depletion substances refrigerant (R32)
- · Easy to use control panel
- Weekly Timer setting
- Quality Improvement
 - Random auto restart after power failure for safety restart operation
 - Gas leakage protection
 - Prevent compressor reverse cycle
 - Inner protector to protect compressor

Serviceability Improvement

- Breakdown Self Diagnosis function
- System Status Check Buttons for servicing purpose
- System Pumpdown Button for servicing purpose
- Front maintenance design for outdoor unit

Operation Condition

	HEATING (CIRCUIT)	*1, *2 COOLING (CIRCUIT)
Water outlet temperature (°C) (Min. / Max.)	20 / 55 (Below Ambient -20°C) *3 20 / 60 (Ambient -15 ~ 0°C or Above Ambient 25°C) *3 20 / 65 (Ambient 5 ~ 20°C) *3*4	5 / 20
Outdoor ambient temperature (°C) (Min. / Max.)	-20 / 35	10 / 43

When the outdoor temperature is out of the range in the table, the heating capacity will drop significantly and the mono bloc unit may stop operating for its protection.

The unit will restart automatically after the outdoor temperature returns to the specified range.

^{*3} Between outdoor ambient -15°C and -20°C, the water outlet temperature gradually decreases from 60°C to 55°C.

^{*3} Between outdoor ambient 5°C and 0°C, the water outlet temperature gradually decreases from 65°C to 60°C.


^{*3} Between outdoor ambient 20°C and 25°C, the water outlet temperature gradually decreases from 65°C to 60°C.


^{*4} Only when ΔT is set to 15°C, the set temperature above 60°C will take effect.

5. Location of Controls and Components

5.1 Indoor Unit


5.1.1 Remote Controller buttons and display





Display





Operation icons

The status of operation is displayed.

Icon will not display (under operation OFF screen) whenever operation is OFF except weekly timer.



Holiday operation status




Weekly Timer operation status



Quiet operation status



Zone: Room Thermostat





Powerful operation status



Demand Control or SG ready or SHP status



Room Heater status



Tank Heater status



Solar status

Bivalent status O (Boiler)

- *1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners. *2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).
- (3) Temperature of each zone
- (4) Time and day
- Water Tank temperature
- (6) **Outdoor temperature**
- Sensor type/Set temperature type icons



Water Temperature →Compensation curve



Water Temperature →Direct



Pool only





Room Thermostat →Internal



Room Thermistor

5.1.2 Initialization

Before starting to install the various menu settings, please initiate the Remote Controller by selecting the language of operation and installing the date and time correctly.

When power is turned on for the first time, it becomes the setting screen automatically. It can also be set from personal setting of the menu.

Selecting the language


Wait while the display is initializing. When initializing screen ends, it turns to normal screen.


When any button is pressed, language setting screen appears.

- Scroll with ▼ and ▲ to select the language.
- 2 Press 🚽 to confirm the selection.

Setting the clock

- 2 Press 🚽 to confirm the selection.
- 3 Use ▼ and ▲ to select year, month, day, hour and minutes. (Select and move with ► and press ← to confirm.)
- Once the time is set, time and day will appear on the display even if the Remote Controller is turned OFF.






5.1.3 Quick Menu

After the initial settings have been completed, you can select a quick menu from the following options and edit the setting.

1 Press to display the quick menu.







Powerful













- ② Use ▲ ▼ ◀ ► to select menu.
- 3 Press to turn on/off the select menu.

5.1.4 **Menus For user**

Select menus and determine settings according to the system available in the household. All initial settings must be done by an authorised dealer or a specialist. It is recommended that all alterations of the initial settings are also done by an authorised dealer or a

- After initial installation, you may manually adjust the settings.
- The initial setting remains active until the user changes it.
- The Remote Controller can be used for multiple installations.
- Ensure the operation indicator is OFF before setting.
- The system may not work properly if set wrongly. Please consult an authorised dealer.


To display <Main Menu>: ⋮≡

To select menu: A V



To confirm the selected content:





Menu	Default Setting	Setting Options	Display Display	
1 Function setup 1.1 > Weekly timer				
Once the weekly timer is set up, User can edit from Quick Menu. To set up to 6 patterns of operation on a daily basis.	set the patte	the week and erns needed o ON/OFF / Mode)	Weekly timer 10:34am, Mon Sun Mon Tue Wed Thu Fri Sat 1. 8:00am ON 40°C	
Disabled if Heat-Cool SW is select "Yes" or if Force Heater is on.	Timer copy Select day of the week		2.12:00pm ON ☀ 24/28°C 40 3. 1:00pm ON ☀ 12/10°C ◆Day →Pattern [←]Edit	

Me	enu	Default Setting	Setting Options / [Display			
1.2	> Holiday timer						
	To save energy, a holiday period may be set to either turn	OFF		ON OFF			
	OFF the system or lower the	> ON					
	temperature during the period.		art and end.	Holiday: End	10:34am, Mon		
			nd time	Year/Month/Day	Hour : Min		
			ed temperature	2020 / 01 / 07	10:00 am		
	Weekly timer setting may be ten but it will be restored once the H						
4.0	but it will be restored once the H	oliday timer is completed	J.	\$→ Select	[+-] Confirm		
1.3			Quiet	10:34am,Mon			
	To operate quietly during the	Time to start Quiet : Date and time		Pattern Tir			
	preset period. 6 patterns may be set.			1 8:0	0 am 0		
	Level 0 means the mode is off.	Level of guietness:			0 pm 1		
			3		0 pm 3 Edit		
1.4	> Room heater			A201055 [4-]	Luit		
	To set the room heater ON or OFF.	OFF		ON OFF	•		
1.5	> Tank heater						
	To set the tank heater ON or OFF.	OFF		ON OFF			
	Available only if connected to the tank.						
1.6	> Sterilization						
	To set the auto sterilization ON or OFF.	OFF		ON OFF			

- Available only if connected to the tank.
 Do not use the system during sterilization in order to prevent scalding with hot water, or overheating of shower.
 Ask an authorised dealer to determine the level of sterilization function field settings according to the local laws and regulations.

Me	enu	Default Setting	Setting Options / I	Display	
3.3	> Backlight				
3.3	Sets the duration of screen backlight.	1 min		Backlight OFF 15 secs 1 min ↑ Select [+]	10:34am,Mor 5 mins 10 mins Confirm
3.4	> Backlight intensity		l		
	Sets screen backlight brightness.	4		Dark ◆ Select [+]	10:34am,Mor Bright Confirm
3.5	> Clock format		1		
	Sets the type of clock display.	24h		Clock format 24h am/p	
	> Date & Time			-Select [←]	Confirm
	Sets the present date and time.	Year / Month /	Day / Hour / Min	Date & Time Year/Month/Day 2020 / 01 / 07 >> Select	10:34am, Moi Hour: Min 10:00 am
3.7	> Language			V	
	Sets the display language for the top screen. • For Greek, please refer to the English version.	ENGLISH / FRANÇAIS / DEUTSCH / ITALIANO / ESPAÑOL / DANISH / SWEDISH / NORWEGIAN / POLISH / CZECH / NEDERLANDS / TÜRKÇE / SUOMI / MAGYAR / SLOVENŠČINA / HRVATSKI / LIETUVIŲ		ENGLISH FRANÇAIS DEUTSCH ITALIANO Select Language	10:34am, Mor
3.8	> Unlock password		ı		
	4 digit password for all the settings.	0000		Unlock password	10:34am,Mor
				A2010CT [4-]	
4	Service contact				
4.1	> Contact 1 / Contact 2 Preset contact number for installer.	Select and retrieve		Service setup Contact 1 Name : Bryan A : 0881234	

5.1.5 **Menus For installer**

Menu	Default Setting	Setting Options / Display	
5 Installer setup > System setup > Optional PCB connectivity	nb		
To connect to the external PCB required for servicing.	No		Yes No

- If the external PCB is connected (optional), the system will have following additional functions:
- Buffer tank connection and control over its function and temperature.
 Control over 2 zones (including the swimming pool and the function to heat water in it).
 Solar function (the solar thermal panels connected to either the DHW (Domestic Hot Water) Tank or the Buffer Tank.
 DHW is not applicable for WH-ADC *models.
- 4 External compressor switch.
 5 External error signal.
 6 SG ready control.

	§ SG ready control.① Demand control.§ Heat-Cool SW				
5.2	> Zone & Sensor				
.	To select the sensors and to	Zone		Zone & Sensor	10:34am, Mon
	select either 1 zone or 2 zone	After selecting 1 or 2		Zone	
	system.	to the selection of roc	• .	1 Zone	
		If the swimming pool	is selected, the	2 Zones	system
		temperature must be \(\triangle T \) temperature betw		_Select [-	⊣]Confirm
		Sensor	reello Grafo G.	Zone & Sensor	10:34am,Mon
		Jenson		Sensor	10.34411,141011
		* For room thermostat, selection of external of		Water ten Room the Room th	ermostat
5.3	> Heater capacity				
	To reduce the heater power if			Heater capacity	10:34am,Mon
	unnecessary.*			3 k	(W
	3 kW / 6 kW / 9kW				
	* Options of kW vary depending				
	on the model.			[4] Confirm	
5.4	> Anti freezing				
•	To activate or deactivate the			Yes	_
	water freeze prevention when	Yes		No.	
	the system is OFF				
5.5	> Tank connection				
	To connect tank to the system.			Yes	
		No		No	
	. BUILL 14				
5.6	1 /				
	To select tank heating capacity				
	to variable or standard. Variable capacity heat up tank with				
	fast mode and keep the tank			Varia	olo
	temperature with efficient mode.	Variable		Valia	oie
	While standard capacity heat up	7 4114510		Stand	ard
	tank with rated heating capacity.				
	* This option is available if Tank				
	connection is selected (YES).				

Ме	nu	Default Setting	Setting Options / D	Display	
5.7	> Buffer tank connection				
•	To connect tank to the system and if selected YES, to set	No	Yes No		
	△T temperature.	> Yes		_	NO
	The optional PCB connectivity must be selected YES to enable the function.	100		Buffer Tank	10:34am, Mon
	If the optional PCB connectivity is not selected, the function will not appear on the display.	5°C	Set △T for Buffer Tank	Range: (0°C~10° Steps: ±1°C	
5.8	> Tank heater				
0.0	To select external or internal			Tank heater	10:34am, Mon
	tank heater and if External is selected, set a timer for the heater to come on.	Internal			eternal A ternal
	* This option is available if Tank connection is selected (YES).			^Select	[4-] Confirm
	connection is selected (1 LS).	> External			
		0:20	Tank heater ON time set.	Tank heater Tank heater: ON Range: (0:20~3: Steps: ±0:05	
				\$Select	[4] Confirm
5.9	> Base pan heater				
	To select whether or not optional base pan heater is connected.	No			∕es No
	* Type A - The base pan heater activates only during deice operation. *Type B -The base pan heater activates when outdoor ambient temperature is 5°C or lower.	> Yes	Set base pan heater type*.		type 10:34am,Mon
5.10	> Alternative outdoor sensor				
	To select an alternative outdoor sensor.	No			∕es ▲ No
5.11	> Bivalent connection				
	To select to enable or disable bivalent connection.	No			∕es ▲ No
	> Yes				
	To select either auto control pattern or SG ready input control pattern. * This selection only display to select when optional pcb connection set to Yes.	Auto		•	uto eady

Menu	Default Setting	Setting Options / Display		
To select a bivalent connection	> Yes> Auto			
to allow an additional heat source such as a boiler to heat-up the buffer tank and domestic hot water tank when heatpump capacity is insufficient at low outdoor temperature. The	-5°C	Set outdoor temperature for turn ON Bivalent connection.	Bivalent connection 10:34am,Mon Turn ON: Outdoor temp. Range: (-15°C~35°C) Steps: ±1°C	
outdoor temperature. The			\$Select [←] Confirm	
bivalent feature can be set-up either in alternative mode		the outdoor temperatur		
(heatpump and boiler operate	Control pattern	L / A d d H - l	Bivalent connection 10:34am,Mon	
alternately), or in parallel mode (both heatpump and boiler operate simultaneously),	Alternative / Parallel / Advanced parallel Select advanced parallel for bivalent use of the tanks.		Control pattern Alternative Parallel Advanced parallel Select [+-] Confirm	
or in advance parallel mode (heatpump operates and boiler turns on for buffer-tank and/or domestic hot water depending on the control pattern setting options).	Control pattern > Alte	avantii ra	2elect [⊷]Courium	
	OFF	Option to set external pump either ON or OFF during bivalent operation. Set to ON if system is simple bivalent connection.	Bivalent connection 10:34am,Mon External pump ON OFF Select [+] Confirm	
	Control pattern > Adv			
	Heat	Selection of the tank	Bivalent connection 10:34am,Mon	
	"Heat" implies Buffer implies Domestic Hot	Tank and "DHW"	Advanced parallel Heat DHW Select [4] Confirm	
	Control pattern > Adv	vanced parallel > Heat >	Yes	
	Buffer Tank is activated only after selecting "Yes".		Bivalent connection 10:34am,Mon Advanced parallel: Heat Yes No Select [4] Confirm	
			Bivalent connection 10:34am, Mon	
	-8°C	Set the temperature threshold to start the bivalent heat source.	Heat start: Target temp. Range: (-10°C~0°C) Steps: ±1°C	
			\$Select [+-] Confirm	
		Delay timer to start the bivalent heat	Bivalent connection 10:34am,Mon Heat start: Delay time	
	0:30	source (in hour and minutes).	Range: (0:00~1:30) Steps: ±0:05 Select [] Confirm	
			\$Select [←] Confirm Bivalent connection 10:34am, Mon	
	-2°C	Set the temperature threshold to stop the bivalent heat source.	Heat stop: Target temp. Range: (-10°C~0°C) Steps: ±1°C	
			\$Select [←] Confirm	

lenu	Default Setting	Setting Options / D	isplay
	0:30	Delay timer to stop the bivalent heat source (in hour and minutes).	Bivalent connection 10:34am,Mo Heat stop: Delay time Range: (0:00~1:30) Steps: ±0:05 \$\sqrt{\$}\$Select [] Confirm
	Control pattern > Ad	vanced parallel > DHW >	Yes
	• DHW Tank is activate "Yes".	·	Bivalent connection 10:34am,M Advanced parallel: DHW Yes No Select [] Confirm
	0:30	Delay timer to start the bivalent heat source (in hour and minutes).	Bivalent connection 10:34am, Moderate DHW: Delay time Range: (0:30~1:30) Steps: ±0:05 \$\\$\\$\\$\$Select [=-] Confirm
SG ready input control for	> Yes > SG ready		
bivalent system follow below input condition. SG signal Vcc-bit1 Vcc-bit2 Open Open Open Boiler OFF Short Open Heat Pump OFF, Boiler OFF Open Short Heat Pump OFF, Boiler OFF Open Short Heat Pump OFF, Boiler ON Short Short Short Heat Pump ON, Boiler ON Boiler ON Boiler ON	OFF	Option to set external pump either ON or OFF during bivalent operation. Set to ON if system is simple bivalent connection.	Bivalent connection 10:34am,M External pump ON OFF Select [] Confirm
2 > External SW			
	No		Yes No
3 > Solar connection			
 The optional PCB connectivity must be selected YES to enable the function. 	No		Yes No
 If the optional PCB 	> Yes		0.1
connectivity is not selected, the function will not appear on the display. • DHW is not applicable for WH-ADC *models.	Buffer tank	Selection of the tank	Buffer tank DHW tank
THI ADO MOUGIS.	. V A.	(b ()	-Select [] Confirm
	> Yes > After selecting	ng the tank	Solar connection 10:34am, M
		Set △T ON	ΔT Turn ON Range: (6°C~15°C)
	10°C	temperature	Steps: ±1°C

Menu	Default Setting	Setting Options / D	Display	
	> Yes > After selecting	ng the tank> △T ON tem	perature	
	5°C	Set △T OFF temperature	Solar connection AT Turn OFF Range: (2°C~9°C) Steps: ±1°C	10:34am, Mon
				Confirm
	> Yes > After selecting	ng the tank> △T ON tem	-	-
	5°C	Set Antifreeze temperature	Anti freeze Range: (-20°C~10°C) Steps: ±1°C	5 ℃
	Voc After coloctiv	and the tentes AT ON ten		Confirm
		ig the tank> $ riangle$ T ON tem itifreeze temperature	perature / 🖂 i OFF i	emperature
	80°C	Set Hi limit	Solar connection Hi limit Range: (70°C~90°C) Steps: ±5°C	10:34am,Mon
			\$Select [+-]	Confirm
5.14 > External error signal				
	No		Yes No	
5.15 > Demand control				
	No		Yes No	
5.16 > SG ready				
	No		Yes No	
	> Yes			
	120 %	Capacity (1) & (2) of DHW (in %), Heat (in %) and Cool (in°C)	SG ready Capacity [1-0]: DHW Range: (50%~150% Steps: ±5%	10:34am,Mon
		333. (3)	\$Select [←]	Confirm
5.17 > External compressor SW				
	No		Yes No	
5.18 > Circulation liquid				
To select whether to circulate water or glycol in the system.	Water		Circulation liquid Wate Glyco	
			-Select [←]	Confirm

Me	enu	Default Setting	Setting Options / D	isplay	
5.19	> Heat-Cool SW				
		No		Yes No	
5.20	> Force heater				
	To turn on Force heater either manually (by default) or automatically.	Manual		Aut Manu Select [+-]	
5.21	> Force defrost				
V	If auto selection is set, the unit will start defrost operation if long heating hour operate during low outdoor temperature.	Manual		Auto Manua	
5.22	> Defrost signal				
	To turn on defrost signal to stop fan coil during defrost operation. (If defrost signal set to yes, bivalent function will not available to use)	No		Yes No	•
5.23	> Pump flowrate				
	To set variable flow pump control or fix pump duty control.	ΔT		ΔT Max. Du	uty
6	Installer setup > Operation se	etun			
	To access to the four major functions or modes.	4 main		Operation setup Heat Cool Auto	10:34am,Mon
		Heat / *1, *2 Cool	/ *1, *2 Auto / Tank	Tank	Confirm
6.1	> Heat			V ocioce [1-1	
	To set various water & ambient temperatures for heating.	Outdoor temp. f △T for he	Vater temp. for heating ON / Itdoor temp. for heating OFF / △T for heating ON / Heater ON/OFF Operation Heat Water tem Outdoor ΔT for heating ON / Select		heating OFF
		> Water temp. for hea	iting ON		
		Compensation curve	Heating ON temperatures in compensation curve or direct input.	Operation setup Heat ON: Water ter Compensati Dire	ion curve ct
				→Select [←]	Confirm

^{*1} The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.
*2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

Menu	Default Setting	Setting Options /	Display		
	> Water temp. for he	eating ON > Compensat	N > Compensation curve		
	X axis: -5°C, 15°C Y axis: 55°C, 35°C	Input the 4 temperature points (2 on horizontal X axis, 2 on vertical Y axis).	Heat ON: Water 55°C 60 35°C 20 -20 -5°		
	Temperature range	 Temperature range: X axis: -20°C ~ 15°C, Y axis: See below Temperature range for the Y axis input: WH-MXC model: 20°C ~ 65°C Regardless of the above setting, there is a limit to the water set temperature to the operating conditions on page 3. If 2 zone system is selected, the 4 temperature points must also be input for "Zone 1" and "Zone 2" will not appear on the display if only 1 zone system. 			
	Regardless of the Refer to the operation of the second sec	e above setting, there is ating conditions on page elected, the 4 temperatu	e 3. ire points must also	be input for Zone 2	
	Regardless of the Refer to the operation of the second sec	e above setting, there is ating conditions on page elected, the 4 temperatu 2" will not appear on the	e 3. ire points must also	be input for Zone 2	
	Regardless of the Refer to the oper • If 2 zone system is s • "Zone 1" and "Zone	e above setting, there is ating conditions on page elected, the 4 temperatu 2" will not appear on the	e 3. ire points must also	be input for Zone 2 ne system. 10:34am,Mon temp.:Zone2	
	Regardless of the Refer to the operation of the Refer to the Operation of the Refer to the Refe	e above setting, there is ating conditions on page elected, the 4 temperatu2" will not appear on the eating ON > Direct Temperature for	Operation setup Heat ON: Water Range: (20°C~6! Steps: ±1°C	be input for Zone 2 ine system. 10:34am,Mon temp.:Zone2	

If 2 zone system is selected, temperature set point must input for Zone 2.
"Zone 1" and "Zone 2" will not appear on the display if only 1 zone system.

> Outdoor temp. for h	neating OFF		
24°C	Temperature for heating OFF	Operation setup Heat OFF: Outdoo Range: (5°C~35°C Steps: ±1°C \$Select [
> △T for heating ON			
5°C	Set △T for heating ON. * This setting will not available to set when pump flowrate set to Max. duty.	Operation setup Heat ON: ΔT Range: (1°C~15°C Steps: ±1°C	10:34am, Mon
> Heater ON/OFF			
> Heater ON/OFF > 0	Outdoor temp. for heater	· ON	
0°C	Temperature for heater ON	Operation setup Heater ON: Outdo Range: (-20°C~15 Steps: ±1°C	
		\$Select [-	⊷]Confirm

Menu	Default Setting	Setting Options / D	Display
	> Heater ON/OFF > D	Delay time for heater ON	V
	0:30 min	Delay time for heater to turn on	Operation setup 10:34am,Mon Heater ON: Delay time Range: (0:10~1:00) Steps: ±0:10 0:30
			\$Select [←] Confirm
	> Heater ON/OFF > V	Vater temperature for h	
	-4°C	Setting of water temperature to turn on from water set temperature.	Operation setup 10:34am,Mon Heater ON: ΔT of target Temp. Range: (-10°C~-2°C) Steps: ± 1 °C \$\int \text{Select} [] Confirm
	NIL STATE ON OFF NA	N-44	<u> </u>
	> Heater UN/UFF > V	Vater temperature for h	
	-2°C	Setting of water temperature to turn off from water set	Operation setup 10:34am,Mon Heater OFF: ΔT of target Temp. Range: (-8°C~0°C) Steps: ±1°C
		temperature.	\$Select [←]Confirm
6.2 > *1, *2 Cool			
To set various water & ambient temperatures for cooling.		res for cooling ON cooling ON.	Operation setup 10:34am,Mon Cool Water temp. for cooling ON ΔT for cooling ON Select
	> Water temp. for cod	olina ON	V
	Compensation curve	Cooling ON temperatures in compensation curve or direct input.	Operation setup 10:34am,Mon Cool ON: Water temp. Compensation curve Direct Select [] Confirm
	> Water temp. for cod	oling ON > Compensation	on curve
	X axis: 20°C, 30°C Y axis: 15°C, 10°C	Input the 4 temperature points (2 on horizontal X axis, 2 on vertical Y axis)	Cool ON: Water temp.:Zone1 15°C 10°C 15
	2.	·	e points must also be input for Zone display if only 1 zone system.

^{*1} The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.
*2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

Menu	Default Setting	Setting Options / D	isplay
		<u> </u>	
	> Water temp. for co	oling ON > Direct	
			Operation setup 10:34am, Mon
		Set temperature for	Cool ON: Water temp.: Zone2 Range: (5°C~20°C)
	10°C	Cooling ON	Steps: ±1°C
			\$Select [←]Confirm
			oint must input for Zone 2. isplay if only 1 zone system.
	→ △T for cooling ON		
		Set △T for cooling ON	Operation setup 10:34am, Mon
		* This setting will not	Cool ON: AT
	5°C	available to set when	Range: (1°C~15°C)
		pump flowrate set to	Steps: ±1°C 5 °C ▼
		Max. duty.	\$Select [₄-] Confirm
6.3 > *1, *2 Auto			
Automatic switch from Heat to		s for switching from Heat	Operation setup 10:34am,Mon
Cool or Cool to Heat.	to Cool or	Cool to Heat.	Auto
			Outdoor temp. for (Heat to Cool) Outdoor temp. for (Cool to Heat)
		for (Heat to Cool) /	Outdoor temp. for (Cool to Heat)
	Outdoor temp.	for (Cool to Heat)	_Select [←]Confirm
	> Outdoor temp. for (Heat to Cool)		<u></u>
	7 Outdoor temp. for (fleat to Coor)		Operation setup 10:34am, Mon
		Set outdoor	Auto: Outdoor temp.(Heat to Cool)
	4500	temperature for	Range: (11°C~25°C)
	15°C	switching from Heat to Cool.	Steps: ±1°C 15 °C
	nom ricat to cool.		\$Select [←] Confirm
	> Outdoor temp. for ((Cool to Heat)	
			Operation setup 10:34am, Mon
		Set outdoor	Auto: Outdoor temp.(Cool to Heat)
	10°C	temperature for	Range: (5°C~14°C)
		switching from Cool to Heat.	Steps: ±1°C 10 °C
			\$Select [←] Confirm
6.4 > Tank			
Setting functions for the tank.	Floor anaroti	an time (may) /	Operation setup 10:34am,Mon
		on time (max) / p time (max) /	Tank
 Available only if connected to 		neat temp. /	Floor operation time (max) Tank heat up time (max)
the tank.			Tank re-heat temp.
	Sterilization		-Select []Confirm
	The display will show	3 functions at a time.	
	> Floor operation time (max)		
			Operation setup 10:34am,Mon
		Maximum time for	Tank:Floor ope. time (max)
	8:00	floor operation	Range: (0:30~10:00)
		(in hours and minutes)	Steps: ±0:30 8:00
		,	\$Select [←] Confirm
	1		A F1


^{*1} The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.
*2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).


Menu	Default Setting	Setting Options / Di	isplay	
	> Tank heat up time (max)		
	1:00	Maximum time for heating the tank (in hours and minutes)	Operation setup Tank:Heat up time (I Range: (0:05~4:00) Steps: ±0:05	1:00
	. =		\$Select [₄](Confirm
	> Tank re-heat temp.	T.		
	-8°C	Set temperature to perform reboil of tank water.	Operation setup Tank:Re-heat temp. Range: (-12°C~-2°C) Steps: ±1°C \$\times Select [-4](10:34am,Mon
	> Sterilization		Applier F-14	
	Monday	Sterilization may be set for 1 or more days of the week. Sun / Mon / Tue / Wed / Thu / Fri / Sat	Operation setup Sterilization: Day Sun Mon Tue Wed -	10:34am,Mon Thu Fri Sat — — — [↔] Confirm
	> Sterilization: Time			
	12:00	Time of the selected day(s) of the week to sterilize the tank 0:00 ~ 23:59		10:34am,Mon
	> Sterilization: Boilin	a temp.		
	65°C	Set boiling temperatures for sterilize the tank.	Operation setup Sterilization: Boiling Range: (55°C~65°C) Steps: ±1°C	10:34am,Mon temp.
			-Select [] €	Confirm
	> Sterilization: Ope. t	ime (max)		
	0:10	Set sterilizing time (in hours and minutes)	Operation setup Sterilization: Ope. ti Range: (0:05~1:00) Steps: ±0:05	10:34am, Mon me (max)
			\$Select [↩](Confirm
7 Installer setup > Service setu	ıp			


7.1 | Select | Pump maximum speed | Setting the flow rate, max. duty and operation the pump. | Setting the flow rate, max. duty and operation the pump. | Service setup | 10:34am, Mon | Flow rate | Max. Duty | Operation | Service setup | 10:34am, Mon | Flow rate | Max. Duty | Operation | Once | Air Purge | Once | On

Menu	ı	Default Setting	Setting Options / D	Display	
70	> Pump down				
To	o set the pump down peration.	Pump down operation	n DN	Pl Pump down in progr	ress!
7.3	> Dry concrete				
To etc	o dry the concrete (floor, walls, c.) during construction. o not use this menu for any her purposes and in period	·	rature of dry concrete.	Service setup Dry concrete ON Edit	
	her than during construction			→Select [←]	Confirm
outer than during constituction		Stages: 1 Temperature: 25°C	Heating temperature for drying the concrete. Select the desired stages: 1 ~ 10, range: 1 ~ 99	Service setup Dry concrete: 1/10 Range: (25°C~55°C) Steps: ±1°C *Select [+-]	10:34am, Mon
		> ON			
		Confirm the setting temperatures of dry concrete for each stage.		Service setup Dry concrete: Status Stage Water set temp. Actual water temp. [①] OFF	10:34am, Mon 5 : 1/10 : 25°C :25°C/25°C
7	> Service contact				40.04
	o set up to 2 contact names nd numbers for the User.	-	me and contact number. / Contact 2	Service setup Service contact: Contact Contact Select Contact	
		> Contact 1 / Contact	2	4201001 [4-]	COMMINI
		Contact nam	ne or number.	Service contact Contact 1 Name : Bryan A	10:34am,Mon
		Name / phone icon		_	5678 Edit
		·	and number alphabet a ~ z.	ABCDEFGHIJKLI STUVWXYZ abco jklmnopqrstu	defghi BS
			mber: 1 ~ 9	7 8 9	5) 9 - <u>B</u> S

5.1.6 **Main Components**








FOR WH-MXC09J3E8

FOR WH-MXC12J9E8 & WH-MXC16J9E8





- 1 PCB
- (2-1) 3 phase RCCB (Main Power)
- 2-2 Single or 3 phase RCCB (Backup Heater)
- (3) Heat Exchanger
- (4) Water Pressure gauge
- (5) Water pump
- 6 Cabinet top plate
- 7 Expansion vessel (Not Visible)
- 8 Flow sensor


- 9 Heater assembly
- Overload protector (4 pieces)
- (1) Pressure relief valve
- (12) Air purge valve
- (13) Water Filter Set

- (16) Cabinet front plate
- (17) Cover

(10)

- 14) Plug (2 pieces)
- (15) Bushing (6 pieces)

It is advisable to avoid more than 2 blockage directions. For better ventilation & multiple-outdoor installation, please consult authorized dealer/specialist.




Connector name

- (a) Water inlet
- (b) Water outlet


6. Dimensions

6.1 Mono Bloc Unit




7. Refrigeration and Water Cycle Diagram


---- Refrigerant Cycle (Cooling)



7.1 Standard System (Optional PCB not connected)




7.2 Advance System (Optional PCB connected)




8. Block Diagram

8.1 WH-MXC09J3E8




8.2 WH-MXC12J9E8




9. Wiring Connection Diagram

9.1 Water System

9.1.1 WH-MXC09J3E8




9.1.2 WH-MXC12J9E8



9.2 Refrigerant System


9.2.1 WH-MXC09J3E8 WH-MXC12J9E8




10. Electronic Circuit Diagram

10.1 Water System

10.1.1 WH-MXC09J3E8




10.1.2 WH-MXC12J9E8



10.2 Refrigerant System


10.2.1 WH-MXC09J3E8 WH-MXC12J9E8




11. Printed Circuit Board

11.1 Water System

11.1.1 Main Printed Circuit Board




11.1.2 Optional Printed Circuit Board




11.2 Refrigerant System

11.2.1 Main Printed Circuit Board



11.2.2 Noise Filter Printed Circuit Board



12.Installation Instruction

12.1 Mono Bloc Unit

Attached Accessories

No.	Accessories part	Qty.
1	Drain elbow	1
2	Rubber cap	8
3	Remote controller	1

Optional Accessory

No.	Accessories part	Qty.
4	Optional PCB (CZ-NS4P)	1
5	Base Pan Heater (CZ-NE3P)	1
6	Network Adaptor (CZ-TAW1)	1
7	Network Adaptor Cable (CZ-TAW1-CBL)	1

Field Supply Accessories (Optional)

-					
No.	Part		Model	Specification	Maker
i 2-way valve kit		Electromotoric Actuator	SFA21/18	AC230V	Siemens
		2-port Valve	VVI46/25	-	Siemens
ii	3-way valve kit	Electromotoric Actuator	SFA21/18	AC230V	Siemens
	3-way valve Kit	3-port Valve	VXI46/25	-	Siemens
		Wired	PAW-A2W-RTWIRED	AC230V	
iii	Room thermostat	Wireless	PAW-A2W-RTWIRELESS	AC230V	-
iv	Mixing valve	-	167032	AC230V	Caleffi
v	Pump	-	Yonos 25/6	AC230V	Wilo
vi	Buffer tank sensor	-	PAW-A2W-TSBU	-	-
vii	Outdoor sensor	-	PAW-A2W-TSOD	-	-
viii	Zone water sensor	-	PAW-A2W-TSHC	-	-
ix	Zone room sensor	-	PAW-A2W-TSRT	-	-
х	Solar sensor	-	PAW-A2W-TSSO	-	-


- It is recommended to purchase the field supply accessories listed in above table.
- · Handling of Mono bloc unit
 - Mono bloc unit is a large and heavy apparatus.
 The handling of the unit only to be done by lifting tools with slings. These slings can be fitted into sleeves at the unit's base frame.



12.1.1 Select the Best Location

- Install the Mono bloc unit in outdoor locations only.
- Avoid installations in areas where the ambient temperature may drop below -20°C.
- The Mono bloc unit must be installed on a flat, solid surface.
- A place removed from any heat source or steam which may effect the operation of the Mono bloc unit
- A place where air circulation is good.
- A place where drainage can be easily done.
- A place where Mono bloc unit's operation noise will not cause discomfort to the user.
- A place which is accessible for maintenance.
- Ensure to keep minimum distance of spaces as illustrated, from wall, ceiling, or other obstacles.
- A place where flammable gas leaking might not occur.
- A place where the Mono bloc unit's piping and wiring lengths come within reasonable ranges.


- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- Avoid installing the Mono bloc unit at a location where suction side may be exposed directly to wind.
- If Mono bloc unit installed near sea, region with high content of sulphur or oily location (e.g. machinery oil, etc.), it lifespan maybe shorten.
- When installing the product in a place where it will be affected by typhoon or strong wind such as wind blowing between buildings, including the rooftop of a building and a place where there is no building in surroundings, fix the product with an overturn prevention wire, etc. (Overturn prevention fitting model number: K-KYZP15C)



12.1.2 Mono Bloc Unit Installation

Mono bloc unit will become heavy when filled with water. Please install the unit on a strong concrete floor and consider the weight of the unit and water.


- Fix Mono bloc unit on the concrete floor with M12 anchor bolt at 4 locations.
- Pull-out strength of these anchor bolts must be above 15000N.



 $\underline{\textbf{Illustration of grip type and embedded type anchor bolt}}$

12.1.2.1 Disposal of Mono Bloc Unit Drain Water

- When a Drain elbow 1 is used, please ensure to follow below:
 - The unit should be placed on a stand which is taller than 50mm.
 - o Cover the 8 holes (ø20mm) with Rubber cap ☑ (refer to illustration below)
 - Use a tray (field supply) when necessary to dispose the Mono bloc unit drain water.




• If the unit is used in an area where temperature falls below 0°C for 2 or 3 consecutive days, it is recommended not to use the Drain elbow 1 and Rubber cap 2, for the drain water freezes and the fan will not rotate.

12.1.3 Piping Installation

MARNING

This section is for authorized and licensed electrician / water system installer only. Work behind the Cabinet Front Plate (6) secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.

Typical Piping Installation




Please engage a licensed water circuit installer to install this water circuit.

- This water circuit must comply with relevant European and national regulations (including EN61770), and local building regulation codes.
- Ensure the components installed in the water circuit could withstand water pressure during operation.
- Do not apply excessive force to piping that may damage the pipes.
- Use Rp 1½" nut for both water inlet and water outlet connection and clean all piping with tap water before connecting to the Mono bloc unit.
- Cover the pipe end to prevent dirt and dust when inserting it through a wall. If an existing tank is to be connected to this Mono bloc unit, ensure the pipes are clean before water pipe installation is carried out.
- Choose proper sealer which can withstand the pressures and temperatures of the system.
- Make sure to use two spanners to tighten the connection. Tighten the nuts with torque wrench: 117.6 N•m.
- If non-brass metallic piping is used for installation, make sure to insulate the piping to prevent galvanic corrosion.
- Do not use pipes that are crushed or deformed. If these inferior pipes are used, it may cause unit malfunction.
- Make sure to insulate the water circuit piping (insulator thickness: 20mm or more) to prevent condensation
 during cooling operation and reduction of heating capacity, as well as avoid freezing of the outdoor water circuit
 piping during winter season.
- After installation, check the water leakage condition in connection area during test run.
- In case of a power supply failure or pump operating failure, drain the system (as suggested in the figure below).




When water is idle inside the system, freezing up is very likely to happen which could damage the system.



Drainage piping installation

- Use a drain hose with inner diameter of 15 mm.
- The hose must be installed in a continuously downward direction and left open to the frost-free atmosphere.
- If drain hose is long, use a metal support fixture along the way to eliminate the wavy pattern of drain tube.
- Water will drip from this hose, therefore the outlet of this hose must be installed in an area where the outlet cannot become blocked.
- Do not insert this hose into sewage or drain pipe that may generate ammonia gas, sulfuric gas, etc.

 If necessary, use a hose clamp to tighten the hose at drain hose connector to prevent it from leaking.




12.1.4 Connect the Cable to Mono Bloc Unit

/Î\ WARNING

This section is for authorised and licensed electrician only. Work behind the cabinet front plate (6) secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.

12.1.4.1 Remove The Cabinet Front Plate (16)

- 1. Remove the 4 mounting screws as shown in the illustration.
- 2. Slide the cabinet front plate (6) downward to release the pawls. Then, pull it toward front to remove it.



12.1.4.2 Fixing of Power Supply Cord

(REFER TO WIRING DIAGRAM AT UNIT FOR DETAIL)

- 1. An isolating device must be connected to the power supply cable.
 - o Isolating device (Disconnecting means) should have minimum 3.0 mm contact gap.
 - Connect the approved polychloroprene sheathed power supply 1 cord and power supply 2 cord and type designation 60245 IEC 57 or heavier cord to the terminal board, and to the other end of the cord to isolating device (Disconnecting means). See below table for cable size requirement.

For model WH-MXC09J3E8

Power Supply Cord	Cable Size	Isolating Devices	Recommended RCD
1	5 x minimum 1.5 mm ²	20A	30mA, 4P, type A
2	3 x minimum 1.5 mm ²	15/16A	30mA, 2P, type AC

For model WH-MXC12J9E8


Power Supply Cord	Cable Size	Isolating Devices	Recommended RCD
1	5 x minimum 1.5 mm ²	20A	30mA, 4P, type A
2	5 x minimum 1.5 mm ²	20A	30mA, 4P, type AC

For model WH-MXC16J9E8

Power Supply Cord	Cable Size	Isolating Devices	Recommended RCD
1	5 x minimum 2.5 mm ²	20A	30mA, 4P, type A
2	5 x minimum 1.5 mm ²	20A	30mA, 4P, type AC

- 2. To avoid the cable and cord being damaged by sharp edges, the cable and cord must be passed through the designated holes before being connected to the terminal block.
- 3. Secure the cable onto the control board with the holder (clamper).

For model WH-MXC09J3E8



12.1.4.3 Connecting Requirement


For model WH-MXC09J3E8

- The equipment's Power Supply 1 complies with IEC/EN 61000-3-2.
- The equipment's Power Supply 1 complies with IEC/EN 61000-3-3 and can be connected to current supply network.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-2.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-11 and shall be connected to suitable supply network, with the following maximum permissible system impedance Z_{max} = 0.426 ohm(Ω) at the interface. Please liaise with supply authority to ensure that the Power Supply 2 is connected only to a supply of that impedance or less.


For model WH-MXC12J9E8, WH-MXC16J9E8


- For model WH-MXC12J9E8, the equipment's Power Supply 1 complies with IEC/EN61000-3-2.
 For model WH-MXC16J9E8, the equipment's Power Supply 1 complies with IEC/EN61000-3-12 provided that the short-circuit power Ssc is greater than or equals to 550kVA at the interface point between the user's supply and the public system.
 - It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary that the equipment is connected only to supply with a short-circuit power Ssc greater than or equals to 550kVA.
- The equipment's Power Supply 1 complies with IEC/EN 61000-3-3 and can be connected to current supply network.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-2.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-3 and can be connected to current supply network.

12.1.4.4 Wire Stripping and Connecting Requirement




Terminal screw	Tightening torque cN•m {kgf•cm}
M4	157~196 {16~20}
M5	196~245 {20~25}






12.1.4.5 Connecting with External Device (Optional)


- All connections shall follow to the local national wiring standard.
- It is strongly recommended to use manufacturer-recommended parts and accessories for installation.
- For connection to main PCB (1)
 - 1 Two-way valve shall be spring and electronic type, refer to "Field Supply Accessories" table for details. Valve cable shall be (3 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
 - * note: Two-way Valve shall be CE marking compliance component.
 - Maximum load for the valve is 9.8VA.
 - Three-way valve shall be spring and electronic type. Valve cable shall be (3 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
 - * note: Shall be CE marking compliance component.
 - It shall be directed to heating mode when it is OFF.
 - Maximum load for the valve is 9.8VA.
 - 3 Room thermostat cable must be (4 or 3 x min 0.5 mm²), of type designation 60245 IEC 57 or heavier cord, or similarly double insulation sheathed cable.
 - 4 Maximum output power of booster heater shall be \leq 3 kW. Booster heater cable must be (3 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
 - 5 Extra pump cable shall be (2 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
 - 6 Boiler contact cable / defrost signal cable shall be (2 x min 0.5 mm²), of type designation 60245 IEC 57 or heavier.
 - External control shall be connected to 1-pole switch with min 3.0 mm contact gap. Its cable must be (2 x min 0.5 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
 - * note: Switch used shall be CE compliance component.
 - Maximum operating current shall be less than 3A_{rms}.
 - Tank sensor shall be resistance type, please refer to graph below for the characteristic and details of sensor. Its cable shall be (2 x min 0.3 mm²), double insulation layer (with insulation strength of min 30V) of PVC-sheathed or rubber-sheathed cable.



- 9 Room sensor zone 1 cable shall be (2 x min 0.3 mm²) double insulation layer of PVC-sheathed or rubber-sheathed.
- 10 Outdoor air sensor cable shall be (2 x min 0.3 mm²) double insulation layer of PVC-sheathed or rubber-sheathed.
- 11 Tank OLP cable must be (2 x min 0.5 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.



How to guide optional cables and power supply cords to Bushing (15)




How to guide optional cables and power supply cords (view without internal wiring)


For connection to optional PCB 4

- By connecting optional PCB, 2 Zone temperature control can be achieved. Please connect mixing valves, water pumps and thermistors in zone 1 and zone 2 to each terminals in optional PCB. Temperature of each zone can be controlled independently by remote controller.
- 2 Pump zone 1 and zone 2 cable shall be (2 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
- 3 Solar pump cable shall be (2 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
- 4 Pool pump cable shall be (2 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
- Room thermostat zone 1 and zone 2 cable shall be (4 x min 0.5 mm²), of type designation 60245 IEC 57 or heavier.
- 6 Mixing valve zone 1 and zone 2 cable shall be (3 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
- 7 Room sensor zone 1 and zone 2 cable shall be (2 x min 0.3 mm²), double insulation layer (with insulation strength of minimum 30V) of PVC-sheathed or rubber-sheathed cable.
- 8 Buffer tank sensor, pool water sensor and solar sensor cable shall be (2 x min 0.3 mm²), double insulation layer (with insulation strength of minimum 30V) of PVC-sheathed or rubber-sheathed cable.

- 9 Water sensor zone 1 and zone 2 cable shall be (2 x min 0.3 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 10 Demand signal cable shall be (2 x min 0.3 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 11 SG signal cable shall be (3 x min 0.3 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 12 Heat/Cool switch cable shall be (2 x min 0.3 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 13 External compressor switch cable shall be (2 x min 0.3 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.



How to guide optional cables to bushing (5)



How to guide optional cables (view without internal wiring)


Terminal screw on PCB	Maximum tightening torque cN•m {kgf•cm}
M3	50 {5.1}
M4	120 {12.24}

12.1.5 Installation of Remote Controller

12.1.5.1 Installation Location

- Install at the height of 1 to 1.5 m from the floor (Location where average room temperature can be detected).
- Install vertically against the wall.
- Avoid the following locations for installation.
 - 1 By the window, etc. exposed to direct sunlight or direct air.
 - 2 In the shadow or backside of objects deviated from the room airflow.
 - 3 Location where condensation occurs (The Remote Controller is not moisture proof or drip proof.)
 - 4 Location near heat source.
 - 5 Uneven surface.
- Keep distance of 1 m or more from the TV, radio and PC. (Cause of fuzzy image or noise)

12.1.5.2 Remote Controller 3 Wiring




- Remote Controller cable shall be (2 x min 0.3 mm²), of double insulation PVC-sheathed or rubber sheathed cable. Total cable length shall be 50 m or less.
- Be careful not to connect cables to other terminals (e.g. power source wiring terminal). Malfunction may occur.
- Do not bundle together with the power source wiring or store in the same metal tube. Operation error may occur.


12.1.5.3 Mounting The Remote Controller

For exposed type

Preparation: Make 2 holes for screws using a driver.



Preparation: Make 2 holes for screws using a driver.




MARNING

This section is for authorized and licensed electrician only. Work behind the Cabinet Front Plate (6) secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.


12.1.6 Installation of Network Adaptor and Base Pan Heater

12.1.6.1 Network Adaptor 6 and 7 Installation (Optional)


- 1. Open the Cabinet front plate (6), then connect the Network Adaptor Cable ☑ to the CN-CNT connector on the printed circuit board.
 - Pull the cable out of the Mono bloc unit so that there is no pinching.
 - If an optional PCB has been install in the Mono bloc unit, connect the CN-CNT connector to Optional PCB 4.




 Insert a flat head screwdriver into the slot on the top of the adaptor and remove the cover.
 Connect the other end of the CN-CNT cable connector to the connector inside the adaptor.



3. On the wall near the Mono bloc unit, attach the adaptor by screwing screws through the holes in the back cover.




4. Pull the CN-CNT cable through the hole in the bottom of the adaptor and re-attach the front cover to the back cover.



5. Use the included cord clamp to fix the CN-CNT cable to the wall.

Pull the cable around as shown in the diagram so that external forces cannot act on the connector in the adaptor. Use the included cable tie to fix the cables together.




12.1.6.2 Base Pan Heater 5 (Optional)


• It is strongly recommended to install a Base Pan Heater 5 (optional) if the Mono bloc unit is installed in cold climate area. Refer the Base Pan Heater 5 (optional) installation instruction for details of installation.

12.1.7 **Charging the Water**

- Make sure all the piping installations are properly done before carry out below steps.
 - Open Cabinet front plate (16) to access to the Pressure Relief Valve (11) and Air Purge Valve
 - Turn the plug on the Air Purge Valve (12) outlet anticlockwise by one complete turn from fully closed position.



Set the Pressure Relief Valve (11) level "DOWN".



- Start filling water (with pressure more than 0.1 MPa (1 bar)) to the Mono bloc unit via water inlet. Stop filling water if the free water flow through Pressure Relief Valve (11) drain
- 5 Turn ON the power supply and make sure Water Pump (5) is running.
- Check and make sure no water leaking at the tube connecting points.
- 7 Reinstall the Cabinet front plate (16) by tightening the 2 mounting screws.

12.1.8 Reconfirmation

♠ WARNING

Be sure to switch off all power supply before performing each of the below checkings. Before obtaining access to terminals, all supply circuits must be disconnected.

12.1.8.1 Check Water Pressure *(0.1 MPa = 1 bar)

Water pressure should not lower than 0.05 MPa (with inspects the Water Pressure Gauge (4)). If necessary add tap water into the water circuit.

Check Pressure Relief Valve (11) 12.1.8.2



- Check for correct operation of Pressure Relief Valve (11) by turning on the lever to become
- If you do not hear a clacking sound (due to water drainage), contact your local authorized dealer.
- Push down the lever after finish checking.
- In case the water keeps drained out from the unit. switch off the system, and then contact your local authorized dealer.

Expansion Vessel (7) Pre 12.1.8.3 Pressure Checking

[Upper limit water volume of the system] The Mono bloc unit has a build-in Expansion Vessel with 10 L air capacity and initial pressure of 1 bar.

Without antifreeze agent condition Total amount of water in the system should be below

If the total amount of water is more than 200 L, please add expansion vessel (field supply).

With antifreeze agent condition In the case of using antifreeze agent, expansion rate ε is different depending on its maker.

Please refer to the antifreeze agent maker for the expansion rate ε before calculate the upper limit water volume of the system.

The expansion vessel capacity required for the system can be calculated from the formula below.

E x Vo

$$V = \cfrac{1}{1 - \cfrac{98 + P_1}{98 + P_2}}$$

$$V : \text{Required gas volume expansion vessel volume L>}$$

$$Vo : \text{System total water volume }$$

$$\varepsilon : \text{Expansion rate } 5 \rightarrow 60^{\circ}\text{C} \qquad = (\text{depends on antifreeze agent used})$$

$$P_1 : \text{Expansion tank filling pressure} \qquad = (100) \text{ kPa}$$

$$P_2 : \text{System maximum pressure} \qquad = 300 \text{ kPa}$$

$$- () \text{ Please confirm at actual place}$$

$$- \text{The gas volume of the sealed type expansion vessel is presented by .}$$

$$\text{It's advised to add } 10\% \text{ margin for required gas volume of calculation.}$$

[Adjustment of the initial pressure of the expansion vessel when there is a difference in installation height] If the height difference between the Mono bloc unit and the highest point of the system water circuit (H) is more than 7m, please adjust the initial pressure of the expansion vessel (Pg) according to the following formula.

12.1.8.4 Check RCCB (2)

Ensure the RCCB ② set to "ON" condition before check RCCB ②.

Turn on the power supply to the Mono bloc unit. This testing could only be done when power is supplied to the Mono bloc unit.

↑ WARNING

Be careful not to touch parts other than RCCB test button when the power is supplied to Mono bloc unit. Else, electrical shock may happen.

- Push the "TEST" button on the RCCB ②. The lever would turn down and indicate "0", if it functions normal.
- Contact authorized dealer if the RCCB ② malfunction.
- Turn off the power supply to the Mono bloc unit.
- If RCCB ② functions normal, set the lever to "ON" again after testing finish.

This product contains fluorinated greenhouse gasses.

Refrigerant type: R32 (GWP=675)

For WH-MXC09J3E8 and WH-MXC12J9E8 Amount: 1.6kg (1.080 ton CO₂ equivalent)

For WH-MXC16J9E8

Amount: 1.8 kg (1.215 ton CO₂ equivalent)

12.1.9 Test Run

- 1. Before test run, make sure below items have been checked:-
 - Pipework are properly done.
 - Electric cable connecting work are properly done.
 - Mono bloc unit is filled up with water and trapped air is released.
- 2. Antifreeze agent must be added into water circuit to prevent freezing of water when outdoor ambient temperatures is low. Recommended antifreeze: Propylene glycol: 40% (equivalent to -20°C)
- 3. Set ON to the Mono bloc unit and RCCB ②. Then, for remote control operation please refers to (Mono bloc) Air-to-Water Heatpump's operation instruction.

Note:

- During winter, turn on the power supply and standby the unit for at least 15 minutes before test
 - Allow sufficient time to warm up refrigerant and prevent wrong error code judgement.
- 4. For normal operation, Water Pressure Gauge 4 reading should be in between 0.05 MPa and 0.3 MPa
- 5. After test run, please clean the Magnetic Water Filter Set (3). Reinstall it after finish cleaning.

12.1.9.1 Check Water Flow of Water

Confirm the maximum water flow during main pump operation not less than 15 l/min.

*Water flow can be check through service setup (Pump Max Speed)

[Heating operation at low water temperature with lower water flow may trigger "H75" during defrost process.]

12.1.9.2 Reset Overload Protector (10)

Overload Protector (10) serves the safety purpose to prevent the water over heating. When the Overload Protector (10) trip at high water temperature, take below steps to reset it.

- Take out the cover.
- 2. Use a test pen to push the centre button gently in order to reset the Overload Protector (10).
- 3. Fix the cover to the original fixing condition.



Use test pen to push this button for reset Overload Protector 10.

12.1.10 Maintenance


• In order to ensure optimal performance of the unit, seasonal inspections on the unit, functional check of RCCB, field wiring and piping have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer.

12.1.10.1 Maintenance for Magnetic Water Filter Set (3)

- 1. Remove the Cover (7) by loosening the mounting screws to access to the Magnetic Water Filter Set (13).
- 2. Turn OFF power supply.
- 3. Set the two valves for the Magnetic Water Filter Set (13) to "CLOSE".
- 4. Take off the clip, then gently pull out the mesh. Beware of small amount water drain out from it.
- 5. Clean the mesh with warm water to remove all the stain. Use soft brush if necessary.
- 6. Reinstall the mesh to the Magnetic Water Filter Set (3) and set back the clip on it.
- 7. Set the two valves for the Magnetic Water Filter Set (13) to "OPEN".
- 8. Turn ON power supply.
- 9. After cleaning, reinstall the Cover (7) by tightening the mounting screws properly.

MARNING

Do not add or replace other than R32 type. It may cause product damage, burst, injury and etc. Use compatible R32 tools for refrigerant piping work and refrigerant charging during installation or servicing.




12.2 Variation of System

This section introduces variation of various systems using Air-To-Water Heatpump and actual setting method.

12.2.1 Introduce Application Related to Temperature Setting.


12.2.1.1 Temperature Setting Variation for Heating

1. Remote Controller




Connect floor heating or radiator directly to the Mono bloc. This is the basic form of the most simple system.

2. Room Thermostat




Connect floor heating or radiator directly to the Mono bloc. Install the remote controller in the room where floor heating is installed. This is an application that uses remote controller as Room Thermostat.

3. External Room Thermostat



Connect floor heating or radiator directly to Mono bloc. Install separate external Room Thermostat (field supply) in the room where floor heating is installed. This is an application that uses external Room Thermostat.

4. Room Thermistor



Setting of remote controller

Installer setting
System setup
Optional PCB connectivity - No
Zone & Sensor:

Room thermistor

Connect floor heating or radiator directly to Mono bloc.

Install separate external room thermistor (specified by Panasonic) in the room where floor heating is installed. This is an application that uses external room thermistor.

There are 2 kinds of circulation water temperature setting method.

Direct: set direct circulation water temperature (fixed value)

Compensation curve: set circulation water temperature depends on outdoor ambient temperature

In case of Room thermo or Room thermistor, compensation curve can be set.

In this case, shift compensation curve according to the thermo ON/OFF situation.


(Example) If room temperature increasing speed is;

very slow → shift up the compensation curve

very fast → shift down the compensation curve

12.2.1.2 Examples of Installations

Floor heating 1 + Floor heating 2



Setting of remote controller

Installer setting System setup

Optional PCB connectivity - Yes

Zone and Sensor - 2 Zone system Zone 1:Sensor Room thermostat

Internal

Zone 2:Sensor Room

Room thermostat (External)

Connect floor heating to 2 circuits through buffer tank as shown in the figure.

Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits.

Install the remote controller in one of the circuit and use it as Room Thermostat.

Install external Room Thermostat (field supply) in another circuit.


Both circuits can set circulation water temperature independently.

Install buffer tank thermistor on buffer tank.

It requires connection setting of buffer tank and ΔT temperature setting at heating operation separately.

This system requires optional PCB (CZ-NS4P).

Floor heating + Radiator



Connect floor heating or radiator to 2 circuits through buffer tank as shown in figure.

Install pumps and thermistors (specified by Panasonic) on both circuits.

Install mixing valve in the circuit with lower temperature among the 2 circuits.

(Generally, if install floor heating and radiator circuit at 2 zones, install mixing valve in floor heating circuit.)

For temperature setting, select circulation water temperature for both circuits.

Both circuits can set circulation water temperature independently.


Install buffer tank thermistor on buffer tank.

It requires connection setting of buffer tank and ΔT temperature setting at heating operation separately.

This system requires the optional PCB (CZ-NS4P).

Mind that if there is no mixing valve at the secondary side, the circulation water temperature may get higher than setting temperature.

Floor heating + Swimming pool



Connect floor heating and swimming pool to 2 circuits through buffer tank as shown in figure.

Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits.

Then, install additional pool heat exchanger, pool pump and pool sensor on pool circuit.

Install the remote controller in room where floor heating is installed. Circulation water temperature of floor heating and swimming pool can be set independently.


Install buffer tank sensor on buffer tank.

It requires connection setting of buffer tank and ΔT temperature setting at heating operation separately. This system requires the optional PCB (CZ-NS4P).

*Must connect swimming pool to "Zone 2".

If it is connected to swimming pool, operation of pool will stop when "Cooling" is operated.

Swimming pool only



This is an application that connects to the swimming pool only.

Connects pool heat exchanger directly to Mono bloc without using buffer tank.

Install pool pump and pool sensor (specified by Panasonic) at secondary side of the pool heat exchanger.


Install the remote controller in room where floor heating is installed.


Temperature of swimming pool can be set independently.

This system requires the optional PCB (CZ-NS4P).

In this application, cooling mode cannot be selected. (not display on remote controller)

Simple 2 zone (Floor heating + Radiator)





This is an example of simple 2 zone control without using buffer tank.

Built-in pump from Mono bloc served as a pump in zone 1.

Install mixing valve, pump and thermistor (specified by Panasonic) on zone 2 circuit.

Please be sure to assign high temperature side to zone 1 as temperature of zone 1 cannot be adjusted.

Zone 1 thermistor is required to display temperature of zone 1 on remote controller.

Circulation water temperature of both circuits can be set independently.

(However, temperature of high temperature side and low temperature side cannot be reversed)

This system requires the optional PCB (CZ-NS4P).

(NOTE)


- Thermistor 1 does not affect operation directly. But error happens if it is not installed.
- Please adjust flow rate of zone 1 and zone 2 to be in balance. If it is not adjusted correctly, it may affects the
 performance.

(If zone 2 pump flow rate is too high, there is possibility that no hot water flowing to zone 1.)

Total flow rate can be confirmed by "Actuator Check" from maintenance menu.


12.2.2 Introduce Applications of System that Uses Optional Equipment.

DHW (Domestic Hot Water) Tank connection



This is an application that connects the DHW tank to the Mono bloc through 3-way valve. DHW tank's temperature is detected by tank thermistor (specified by Panasonic).

Tank + Solar connection




This is an application that connects the DHW tank to the Mono bloc through 3-way valve before connect the solar water heater to heat up the tank. DHW tank's temperature is detected by tank thermistor (specified by Panasonic). Solar panel's temperature is detected by solar thermistor (specified by Panasonic).

DHW tank shall use tank with built-in solar heat exchange coil independently.


Heat accumulation operates automatically by comparing the temperature of tank thermistor and solar thermistor. During winter season, solar pump for circuit protection will be activated continuously. If does not want to activate the solar pump operation, please use glycol and set the anti-freezing operation start temperature to -20°C. This system requires optional PCB (CZ-NS4P).

Buffer tank connection



This is an application that connects the buffer tank to the Mono bloc. Buffer tank's temperature is detected by buffer tank thermistor (specified by Panasonic). This system requires optional PCB (CZ-NS4P).

Buffer tank + Solar



This is an application that connects the buffer tank to the Mono bloc before connecting to the solar water heater to heat up the tank.

Buffer tank's temperature is detected by buffer tank thermistor (specified by Panasonic).

Solar panel's temperature is detected by solar thermistor (specified by Panasonic).


Buffer tank shall use tank with built-in solar heat exchange coil independently.

During winter season, solar pump for circuit protection will be activated continuously. If does not want to activate the solar pump operation, please use glycol and set the anti-freezing operation start temperature to -20°C.

Heat accumulation operates automatically by comparing the temperature of tank thermistor and solar thermistor.

This system requires optional PCB (CZ-NS4P).

Boiler connection



This is an application that connects the boiler to the Mono bloc, to compensate for insufficient capacity by operate boiler when outdoor temperature drops & heat pump capacity is insufficient.

Boiler is connected parallel with heat pump against heating circuit.

There are 3 modes selectable by remote controller for boiler connection.

Besides that, an application that connects to the DHW tank's circuit to heat up tank's hot water is also possible.

(Operation setting of boiler shall be responsible by installer.)

This system requires optional PCB (CZ-NS4P).

Depending on the settings of the boiler, it is recommended to install buffer tank as temperature of circulating water may get higher. (It must connect to buffer tank especially when selecting Advanced Parallel setting.)

WARNING Panasonic is NOT responsible for incorrect or unsafe situation of the boiler system.

Make sure the boiler and its integration in the system complies with applicable legislation.

Make sure the return water temperature from the heating circuit to the Mono bloc does NOT exceed 55°C.

Boiler is turned off by safety control when the water temperature of the heating circuit exceed 85°C.


12.3 How to Fix External Device

12.3.1 Connecting Cables Length

When connecting cables between Mono bloc and external devices, the length of the said cables must not exceed the maximum length as shown in the table.

External device	Maximum cables length (m)
Two-way valve	50
Three-way valve	50
Mixing valve	50
Room thermostat	50
Booster heater	50
Extra pump	50
Solar pump	50
Pool pump	50
Pump	50
Boiler contact / Defrost signal	50
External control	50
Tank sensor	30
Room sensor	30
Outdoor air sensor	30
Tank OLP	30
Buffer tank sensor	30
Pool water sensor	30
Solar sensor	30
Water sensor	30
Demand signal	50
SG signal	50
Heat/Cool switch	50
External compressor switch	50

12.3.1.1 Connection of the Main PCB



■ Signal inputs

Optional Thermostat	L N =AC230V, Heat, Cool=Thermostat heat, Cool terminal # It does not function when using the optional PCB
OLP for booster heater	Dry contact Vcc-Bit1, Vcc-Bit2 open/short (System setup necessary) It is connected to the safety device (OLP) of DHW tank.
External control	Dry contact Open=not operate, Short=operate (System setup necessary) Able to turn ON/OFF the operation by external switch
Remote controller	Connected (Please use 2 cores wire for relocation and extension. Total cable length shall be 50m or less.)


■ Outputs

3-way valve	AC230V N=Neutral Open, Close=direction (For circuit switching when connected to DHW tank)
2-way valve	AC230V N=Neutral Open, Close (Prevent water circuit pass through during cooling mode)
Extra pump	AC230V (Used when Mono bloc pump capacity is insufficient)
Booster heater	AC230V (Used when using booster heater in DHW tank)
Boiler contact / Defrost signal	Dry contact (System setup necessary)

■ Thermistor inputs

Zone 1 room sensor	PAW-A2W-TSRT	
Outdoor air sensor	AW-A2W-TSOD (Total cable length shall be 30m or less)	
Tank sensor	Please use Panasonic specified part	

12.3.1.2 Connection of Optional PCB (CZ-NS4P)



■ Signal inputs

Optional Thermostat	L N =AC230V, Heat, Cool=Thermostat heat, Cool terminal
SG signal	Dry contact Vcc-Bit1, Vcc-Bit2 open/short (System setup necessary) Switching SW (Please connect to the 2 contacts controller)
Heat/Cool SW	Dry contact Open=Heat, Short=Cool (System setup necessary)
External comp.SW	Dry contact Open=Comp.OFF, Short=Comp.ON (System setup necessary)
Demand signal	DC 0~10V (System setup necessary) Please connect to the DC 0~10V controller.

■ Outputs

Mixing valve	AC230V N=Neutral Open, Close=mixture direction Operating time: 30s~120s
Pool pump	AC230V
Solar pump	AC230V
Zone pump	AC230V


■ Thermistor inputs

Zone room sensor	PAW-A2W-TSRT
Buffer tank sensor	PAW-A2W-TSBU
Pool water sensor	PAW-A2W-TSHC
Zone water sensor	PAW-A2W-TSHC
Solar sensor	PAW-A2W-TSSO

12.3.1.3 Recommended External Device Specification


- This section explains about the external devices (optional) recommended by Panasonic. Please always ensure to use the correct external device during system installation.
- · For optional sensor.
 - Buffer tank sensor: PAW-A2W-TSBU
 Use for measurement of the buffer tank
 temperature.


Insert the sensor into the sensor pocket and paste it on the buffer tank surface.



2 Zone water sensor: PAW-A2W-TSHC Use to detect the water temperature of the control zone.


Mount it on the water piping by using the stainless steel metal strap and contact paste (both are included).






3 Outdoor sensor: PAW-A2W-TSOD If the installation location of the outdoor unit is exposed to direct sunlight, the outdoor air temperature sensor will be unable to measure the actual outdoor ambient temperature correctly.

In this case, optional outdoor temperature sensor can be fixed at a suitable location to more accurately measure ambient temperature.




4 Room sensor: PAW-A2W-TSRT Install the room temperature sensor to the room which requires room temperature control.



Solar sensor: PAW-A2W-TSSO
 Use for measurement of the solar panel temperature.

 Insert the sensor into the sensor pocket and

Insert the sensor into the sensor pocket and paste it on the solar panel surface.



6 Please refer to the table below for sensor characteristic of the sensors mentioned above.

Temperature (°C)	Resistance (kΩ)
30	5.326
25	6.523
20	8.044
15	9.980
10	12.443
5	15.604
0	19.70
-5	25.05
-10	32.10
-15	41.45
-20	53.92
-25	70.53
-30	93.05
-35	124.24
-40	167.82
150	0.147
140	0.186
130	0.236
120	0.302
110	0.390
100	0.511
90	0.686
80	0.932
70	1.279
65	1.504
60	1.777
55	2.106
50	2.508
45	3.003
40	3.615
35	4.375

For optional pump.
 Power supply: AC230V/50Hz, <500W
 Recommended part: Yonos 25/6: made by Wilo



• For optional mixing valve.

Power supply: AC230V/50Hz (input open/output

close)


Operating time: 30s~120s

Recommended part: 167032: made by Caleffi




12.4 System Installation

12.4.1 Remote Controller Outline



Name **Function** Main screen Display information A: B: Menu Open/Close main menu Triangle (Move) Select or change item C: D: Operate Start/Stop operation E: Back Back to previous item F: Quick Menu Open/Close Quick menu OK Confirm G:




First time of power ON (Start of installation)


 $[\, \boldsymbol{\leftarrow}] \, \mathsf{Confirm}$


Set time display & confirm

Select



12.4.2 Installer Setup





12.4.3 System Setup


1. Optional PCB connectivity

Initial setting: No

If function below is necessary, please purchase and install optional PCB. Please select Yes after installing optional PCB.

- 2-zone control
- Pool
- · Buffer tank
- Solar

- External error signal output
- Demand control
- SG ready
- · Stop heat source unit by external SW



2. Zone & Sensor

Initial setting: Room and Water temp.

If no Optional PCB connectivity

Select sensor of room temperature control from the following 3 items


- ① Water temperature (Circulation water temperature)
- ② Room thermostat (Internal or External)
- 3 Room thermistor

When there is Optional PCB connectivity

- 1 Select either 1 zone control or 2 zone control.
 - If it is 1 zone, select either room or pool, select sensor

If it is 2 zone, after select sensor of zone 1, select either room or pool for zone 2, select sensor

(NOTE) In 2 zone system, pool function can be set at zone 2 only.



3. Heater capacity

Initial setting: Depend on model

If there is built-in Heater, set the selectable heater capacity.

(NOTE) There are models which cannot select heater capacity.

System setup 12:00am,Mon

Optional PCB connectivity

Zone & Sensor

Heater capacity

Anti freezing

Select [---] Confirm


4. Anti freezing

Initial setting: Yes

Operate anti-freezing of water circulation circuit.

If select Yes, when the water temperature is reaching its freezing temperature, the circulation pump will start up. If the water temperature does not reach the pump stop temperature, back-up heater will be activated.

(NOTE) If set No, when the water temperature is reaching its freezing temperature or below 0°C, the water circulation circuit may freeze and cause malfunction.



5. Tank connection

Initial setting: No

Select whether it is connected to hot water tank or not.

If set Yes, it becomes setting that uses hot water function.


Hot water temperature of tank can be set from main screen.

6. DHW Capacity

Initial setting: Variable

Variable DHW capacity setting normally run with efficient boiling which is energy saving heating. But while hot water usage high and tank water temperature low, variable DHW mode will run with fast heat up which heat up the tank with high heating capacity.

If standard DHW capacity setting is selected, heat pump run with heating rated capacity at tank heat up operation.



7. Buffer Tank connection

Initial setting: No


Select whether it is connected to buffer tank for heating or not.

If buffer tank is used, please set Yes.

Connect buffer tank thermistor and set, ΔT (ΔT use to increase primary side temp against secondary side target temp).

(NOTE) Does not display if there is no Optional PCB.

If the buffer tank capacity is not so large, please set larger value for ΔT .



[🔟] Confirm

12:00am,Mon

8. Tank heater

Initial setting: Internal

Select to use either built-in heater or external heater as heater for hot water tank. If heater is installed on tank, please select External.


(NOTE) Does not display if there is no tank for hot water supply.

Please set "Tank heater" to "ON" in the "Function setup" from remote controller when using heater to boil the tank.

A setting which is using booster heater installed on DHW tank Internal External to boil the tank.

The permissible heater capacity is 3kW and below.

The operation to boil the tank with heater is as below.



A setting which is using backup heater of Mono bloc to boil

Buffer tank connection

System setup


Tank connection

DHW Capacity

Tank heater

Select

The operation to boil the tank with heater is as below.




9. Base pan heater

Initial setting: No

Select whether Base pan heater is installed or not. If set Yes, select to use either heater A or B.

A: Turn on Heater when heating with defrost operation only

B: Turn on Heater at heating




10. Alternative outdoor sensor

Initial setting: No

Set Yes if outdoor sensor is installed.

Controlled by optional outdoor sensor without reading the outdoor sensor of heat pump unit.



11. Bivalent connection

Initial setting: No


Set if heat pump linked with boiler operation.

Connect the start signal of the boiler in boiler contact terminal (main PCB).

Set Bivalent connection to YES.

After that, please begin setting according to remote controller instruction.

Boiler icon will be displayed on remote controller top screen.



After Bivalent connection Set YES, there is two option of control pattern to be select, (SG Ready / Auto)

- 1) SG ready (Only available to set when Optional PCB set to YES)
 - SG Ready input from Optional PCB terminal control ON/OFF of boiler and heat pump as below condition

SG signal		Operation pattern
Vcc-bit1	Vcc-bit2	
Open	Open	Heat pump OFF, Boiler OFF
Short	Open	Heat pump ON, Boiler OFF
Open	Short	Heat pump OFF, Boiler ON
Short	Short	Heat pump ON, Boiler ON

- This bivalent SG ready input is sharing same terminal as [16. SG ready] connection. Only one of these two setting can be set at the same time. When one is set, another setting will reset to not set.

 2) Auto (If Optional PCB no Set, bivalent control pattern will set to this auto as default value)

There are 3 different modes in the boiler operation. Movement of each modes are shown below.


- ① Alternative (switch to boiler operation when drops below setting temperature)
- 2 Parallel (allow boiler operation when drops below setting temperature)
- 3 Advanced Parallel (able to slightly delay boiler operation time of parallel operation)

When the boiler operation is "ON", "boiler contact" is "ON", " (underscore) will be displayed below the boiler icon.


Please set target temperature of boiler to be the same as heat pump temperature.

When boiler temperature is higher than heat pump temperature, zone temperature cannot be achieved if mixing valve is not installed.

This product only allows one signal to control the boiler operation. Operation setting of boiler shall be responsible by installer.




In Advanced Parallel mode, setting for both heating and tank can be made simultaneously. During operation of "Heating/Tank" mode, when each time the mode is switched, the boiler output will be reset to OFF. Please have good understanding on the boiler control characteristic in order to select the optimal setting for the system.



12. External SW

Initial setting: No

Able to turn ON/OFF the operation by external switch.



13. Solar connection

Initial setting: No

Set when solar water heater is installed.

Setting include items below.

- 1 Set either buffer tank or DHW tank for connection with solar water heater.
- ② Set temperature difference between solar panel thermistor and buffer tank or DHW tank thermistor to operate the solar pump.
- 3 Set temperature difference between solar panel thermistor and buffer tank or DHW tank thermistor to stop the solar pump.
- 4 Anti-freezing operation start temperature (please change setting based on usage of glycol.)
- Solar pump stop operation when it exceeds high limit temperature (when tank temperature exceed designated temperature (70~90°C))

14. External Error signal


Initial setting: No

Set when external error display unit is installed. Turn on Dry Contact SW when error happened.

(NOTE) Does not display when there is no Optional PCB.

When error occurs, error signal will be ON.

After turn off "close" from the display, error signal will still remain ON.



[🗗] Confirm

12:00am,Mon

15. Demand control

Initial setting: No

Analog input

Set when there is demand control.

Adjust terminal voltage within 1 ~ 10 V to change the operating current limit.

(NOTE) Does not display when there is no Optional PCB.

		Syste	em s	setup		12	:00am,Mon
		Exte	erna	ISW			
		Sola	ar co	nnecti	on		
		Exte	erna	l Error	signal		
		Den	nanc	contro	ol		
		\$	Sele	ect		[←] Confirm	
innut	Rate					_	

System setup

External SW

Select

Alternative outdoor sensor

Bivalent connection

Analog input [v]			ate %]
0.0 0.1 ~ 0.6	4	not a	ctivate
0.7 0.8		10	not activate
0.9 ~ 1.1		1	
1.2 1.3		15	10
1.4 ~ 1.6	П	1	5
1.7 1.8		20	15
1.9 ~ 2.1	П	2	0
2.2		25	20
2.4 ~ 2.6	25		5
2.7 2.8		30	25
2.9 ~ 3.1		3	0
3.2 3.3		35	30
3.4 ~ 3.6		3	5
3.7		40	35

Analog Input [v]			11e 6]
3.9 ~ 4.1	7	4	0
4.2	ĺ	45	40
4.3		4	
4.4 ~ 4.6		4	5
4.7		50	45
4.8			
4.9 ~ 5.1	L	5	0
5.2		55	50
5.3		55	5
5.4 ~ 5.6		5	5
5.7		60	55
5.8		00	55
5.9 ~ 6.1		6	0
6.2		65	60
6.3		00	60
6.4 ~ 6.6		6	5
6.7		70	G.F.
6.8		70	65
6.9 ~ 7.1		7	0
7.2		75	70
7.3		13	70

Rate

Analog input [v]			ate 6]
7.4 ~ 7.6	1	7	5
7.7	Í	80	75
7.8		80	75
7.9 ~ 8.1		8	0
8.2		85	80
8.3		00	00
8.4 ~ 8.6		8	5
8.7		90	85
8.8		90	65
8.9 ~ 9.1		9	0
9.2		95	90
9.3		95	90
9.4 ~ 9.6		9	5
9.7		100	95
9.8		100	95
9.9 ~		10	00

- *A minimum operating current is applied on each model for protection purpose.
 *0.2 voltage hysteresis is provided.
- The value of voltage after 2nd decimal point are cut off.

16. SG ready

Initial setting: No

Switch operation of heat pump by open-short of 2 terminals. Setting belows are possible

SG signal		Working pattern
Vcc-bit1	Vcc-bit2	
Open	Open	Normal
Short	Open	Heat pump and Heater OFF
Open	Short	Capacity 1
Short	Short	Capacity 2


Capacity setting 1

- DHW capacity
- Heating capacity
- Cooling capacity

Capacity setting 2

- DHW capacity
- Heating capacity _
- Cooling capacity

(When SG ready set to YES, Bivalent control pattern will set to Auto.)



Set by SG ready setting of remote controller

17. External Compressor SW

Initial setting: No

Set when external compressor SW is connected.

SW is connected to external devices to control power consumption, Open Signal will stop compressor's operation. (Heating operation etc. are not cancelled).

(NOTE) Does not display if there is no Optional PCB.

If follow Swiss standard power connection, need to turn on DIP SW (SW2 pin3) of main unit PCB. Short/Open signal used to ON/OFF tank heater (for sterilization purpose)

12:00am,Mon System setup External Error signal Demand control SG ready External compressor SW [←] Confirm Select

18. Circulation Liquid

Initial setting: Water

Set circulation of heating water.

There are 2 types of settings, water and glycol.

(NOTE) Please set glycol when using anti-freeze liquid. It may cause error if setting is wrong.

System setup 12:00am,Mon Demand control SG ready External compressor SW Circulation liquid Confirm Select

System setup

Circulation liquid Heat-Cool SW Select

External compressor SW

SG ready

12:00am,Mon

19. Heat-Cool SW

Initial setting: Disable

Able to switch (fix) heating & cooling by external switch.

(Open): Fix at Heating (Heating +DHW) (Short): Fix at Cooling (Cooling +DHW) (NOTE) This setting is disabled for model without Cooling. (NOTE) Does not display if there is no Optional PCB.

Timer function cannot be used. Cannot use Auto mode.

20. Force Heater

Initial setting: Manual

Under manual mode, user can turn on force heater through quick menu.

If selection is 'auto', force heater mode will turn automatically if pop up error happen during operation.

Force heater will operate follow the latest mode selection, mode selection is disable under force heater operation.

Heater source will ON during force heater mode.

12:00am,Mon System setup External compressor SW Circulation liquid Heat-Cool SW Force Heater Select [←] Confirm

[←] Confirm

21. Force Defrost

Initial setting: Manual

Under manual code, user can turn on force defrost through quick menu.

If selection is 'auto', outdoor unit will run defrost operation once if heat pump have long hour of heating without any defrost operation before at low ambient condition.

(Even auto is selected, user still can turn on force defrost through quick menu)

System setup 12:00am,Mon Circulation liquid Heat-Cool SW Force heater Force defrost [←] Confirm Select

22. Defrost signal

Initial setting: No

Defrost signal sharing same terminal as bivalent contact in main board. When defrost signal set to YES, bivalent connection reset to NO. Only one function can be set between defrost signal and bivalent.

When defrost signal set to YES, during defrost operation is running at outdoor unit defrost signal contact turn ON. Defrost signal contact turn OFF after defrost operation end.

(Purpose of this contact output is to stop indoor fan coil or water pump during defrost operation).


12:00am,Mon System setup Heat-Cool SW Force heater Force defrost Defrost signal [🞝] Confirm Select

23. Pump flowrate

Initial setting: ΔT

If pump flowrate setting is ΔT , unit adjust pump duty to get different of water inlet and outlet base on setting on * ΔT for heating ON and * ΔT for cooling ON in operation setup menu during room side operation.

If pump flowrate setting is set to Max. duty, unit will set the pump duty to the set duty at *Pump maximum speed in service setup menu during room side operation.



12.4.4 **Operation Setup**

Heat

24. Water temp. for heating ON

Initial setting: compensation curve

Set target water temperature to operate heating operation.

Compensation curve: Target water temperature change in conjunction with outdoor ambient temperature change.


Direct: Set direct circulation water temperature.

Regardless of the above setting, the water temperature will be limited as follows.

Outdoor temperature	Maximum water temperature limit
-20°C	55°C
-15 ~ 0°C	60°C
5 ~ 20°C	65°C
25 ~ 35°C	60°C

However, only when ΔT is set to 15°C, the water temperature setting of 61°C or higher will take effect.


In 2 zone system, zone 1 and zone 2 water temperature can be set separately.



25. Outdoor temp. for heating OFF

Initial setting: 24°C

Set outdoor temp to stop heating. Setting range is 5°C ~ 35°C




26. ΔT for heating ON

Initial setting: 5°C

Set temp difference between out temp & return temp of circulating water of Heating operation. When temp gap is enlarged, it is energy saving but less comfort. When the gap gets smaller, energy saving effect gets worse but it is more comfortable.

Setting range is 1°C ~ 15°C



27. Heater ON/OFF

a. Outdoor temp. for heater ON

Initial setting: 0°C

Set outdoor temp when back-up heater starts to operate.

Setting range is -20°C ~ 15°C

User shall set whether to use or not to use heater.

b. Heater ON delay time

Initial setting: 30 minutes

Set delay time from compressor ON for heater to turn ON if not achieve water set temperature

Setting range is 10 minutes ~ 60 minutes

c. Heater ON: ΔT of target Temp

Initial setting: -4°C

Set water temperature for heater to turn on at heat mode.


Setting range is -10°C ~ -2°C

d. Heater OFF: ΔT of target Temp

Initial setting: -2°C

Set water temperature for heater to turn off at heat mode.

Setting range is -8°C ~ 0°C



Cool


28. Water temp. for cooling ON

Initial setting: Compensation curve

Set target water temperature to operate cooling operation.
Compensation curve: Target water temperature change in conjunction with outdoor ambient temperature change.

Direct: Set direct circulation water temperature.


In 2 zone system, zone 1 and zone 2 water temperature can be set separately.




29. ΔT for cooling ON

Initial setting: 5°C


Set temp difference between out temp & return temp of circulating water of Cooling operation. When temp gap is enlarged, it is energy saving but less comfort. When the gap gets smaller, energy saving effect gets worse but it is more comfortable. Setting range is 1°C ~ 15°C




Auto



Tank



12.4.5 Service Setup



12.5 Service and Maintenance

If forget Password and cannot operate remote controller


Press → + → → ▶ for 5 sec.

Password unlock screen appears, press Confirm and it shall reset.


Password will become 0000. Please reset it again.

(NOTE) Only display when it is locked by password.

Maintenance menu



Custom menu



13. Operation and Control

13.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operating mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operating mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at outdoor unit is operating following the frequency instructed by the microcomputer at indoor unit that judging the condition according to internal water setting temperature and water outlet temperature.

13.1.1 Internal Water Setting Temperature

Once the operation starts, control panel setting temperature will be taken as base value for temperature shifting processes. These shifting processes are depending on the Air-to-Water Heat pump settings and the operation environment. The final shifted value will be used as internal water setting temperature and it is updated continuously whenever the electrical power is supplied to the unit.

13.1.2 Heating Operation

13.1.2.1 Thermostat Control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > 2°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) <-3°C.

13.1.2.2 Thermostat Control (Outdoor Ambient Temperature)

Stops provide heating to room side during high outdoor ambient condition. Control content:

- Heating operation and water pump will turn OFF when outdoor ambient temperature > outdoor thermo off temperature + 3°C.
 - (Outdoor thermo off set temperature is set by control panel. Thermo off set temperature is between 5°C ~ 35°C)
- Heating operation will resume when Outdoor ambient temperature < Outdoor thermo OFF set temperature + 1°C.

13.1.2.3 Heat Mode Operation

Operation of heat pump provide heating capacity to room side by hot water through heating panel, floor heating or fan coil unit.

- 1 3 ways valve control:
 - o 3 ways valve switch and fix to room side.
- 2 Heat pump operates follow normal heating operation.
- 3 Back up heater operate follow normal operation.
- 4 2 ways valve control:
 - 2 ways valve opens.

13.1.3 Cooling Operation

13.1.3.1 Thermostat control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature < -1.5°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) >3°C.

13.1.3.2 Cool Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch and fix to room side.
- 2 Heat pump operates follow normal cooling operation.
- 3 Room heater DOES NOT operate during cool mode.
- 4 2 ways valve control:
 - o 2 ways valve is closed.

13.1.4 Target Water Temperature Setting

13.1.4.1 Target Water Temperature Control of Standard System (Optional PCB not connected)

There are 2 types of temperature control selection which are Compensation and Direct.

• Temperature control type selection by installer:

Compensation: WLo, WHi, ODLo, ODHi can be set at installer menu.

2 Direct : Direct Water Temperature Set

Remote control setting by user:

1 Compensation: Shift value ±5°C from the compensation curve

2 Direct : Direct water temperature set change

- Target water temperature is calculated as below condition.
 - Target water temperature = A (Base temperature) + B (shift temperature)

A (Base Temperature)	Compensation	Direct
A (base remperature)	Value from the curve + User shift value set	Direct value from user setting

o B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below				
Sensor selection					
Water temperature	B = 0				
External Room thermostat	B = 0				
Internal Room Thermostat & Room Thermistor	Cool Mode: B = 0; when Zone OFF or Zone Room Thermo OFF B = 1* (room set temp (R/C) - actual room temp) Max/Min Regulation of B: (Max = 5; Min = -5) Heat Mode: B = 0; when Zone OFF or Zone Room Thermo OFF B = follow Heating PI control contents				

Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
Max	55 (Below Ambient -20°C) *1 60 (Ambient -15 ~ 0°C or Above Ambient 25°C) *1 65 (Ambient 5 ~ 20°C) *1*2	20°C
Min	20°C	5°C

^{*1} Between outdoor ambient -15°C and -20°C, the water outlet temperature gradually decreases from 60°C to 55°C.

^{*}This setting is only able to set when the room sensor select as Water Temperature.

^{*}Instead of water temperature, user will set target room temperature when room sensor select as Room Thermistor OR Internal Room Thermostat.


^{*1} Between outdoor ambient 5°C and 0°C, the water outlet temperature gradually decreases from 65°C to 60°C.

^{*1} Between outdoor ambient 20°C and 25°C, the water outlet temperature gradually decreases from 65°C to 60°C.

^{*2} Only when ΔT is set to 15°C, the set temperature above 60°C will take effect.

Compensation Type: (Operation under Heat Mode and Cool Mode)


The set temperature defines the parameters for the ambient (Outdoor temperature) dependent operation of the unit. The water temperature is determined automatically depending on the outdoor temperature. Default setting is the colder outdoor temperature will result in warmer water and vice versa. The user has the possibility to shift up and shift down the target water by remote control setting.



- Outdoor ambient is updated every 30 minutes when operation ON.
- Setting water outlet temperature always follow W_(LO) or W_(HI) whenever is higher if outdoor ambient sensor or indoor comminication error happen.

However, when powerful mode is requested by remote control during heating mode, the higher value of WLo or WHi will be used for A calculation.

- * There are 2 compensation curves (for heating and cooling). During heating mode, the heating curve is used and during cooling mode, the cooling curve is use.
- Compensation curve set shift value:



13.1.5 Target Water Temperature at Extension System (Optional PCB is connected)

Target water temperature is calculated as below.

- Heat Mode:
 - When buffer tank selection is "YES:"
 Target water temperature = Target buffer tank temperature + [2°C]
 - When buffer tank selection is "NO"
 - If both zone 1 and zone 2 is active
 Target Water Temperature = Higher zone target water temperature of Zone 1 and Zone 2.
 - If only one zone is active
 Target Water Temperature = Zone target water temperature of active zone.
- Cool mode:
 - When buffer tank selection is "YES"
 - If both zone 1 and zone 2 is active
 Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2 + [-3°C]
 - If only one zone is active
 Target Water Temperature = Zone Target Water Temperature of active zone + [-3°C]
 - When buffer tank selection is "NO"
 - If both zone 1 and zone 2 active
 - Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2
 - o If only one zone is active
 - Target Water Temperature = Zone Target Water Temperature of active zone

13.1.6 Target Zone Water Temperature Control

Purpose:- To control zone mixing and zone pump according to the zone sensor temperature

13.1.6.1 Target Zone 1 water temperature setting control

- Start condition
 - Heating zone 1 is ON by remote control or Timer or Auto Mode OR
 - Cooling zone 1 is ON by remote control or Timer or Auto Mode.
- Cancel condition
 - Heating zone 1 is OFF by remote control or Timer or Auto mode AND
 - Cooling zone 1 is OFF by remote control or Timer or Auto mode.
- Target Zone 1 water temperature is calculated as below condition.
 - o Target Zone 1 water temperature = A (Base temperature) + B (shift temperature)

A (Page Temperature)	Compensation	Direct
A (Base Temperature)	Value from the curve + User shift value set	Direct value from user setting

^{*} During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.

o B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below	
Sensor selection		
Water temperature	B = 0	
External Room thermostat	B = 0	
Internal Room Thermostat & Room Thermistor Cool Mode: B = 0 ; when Zone OFF or Zone Room Therma OFF B = 1* (room set temp (R/C) - actual room temp) Max/Min Regulation of B: (Max = 5; Min = -5) Heat Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = follow Heating Room Temperature PI control logic		
Pool Function Selected	B = Delta value setting from remocon	

^{*} B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool "B" value)

- ** Pool function also can be select at Zone 1 when optional PCB is connected and Zone 1 system is select.
- Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
Max	55 (Below Ambient -20°C) *1 60 (Ambient -15 ~ 0°C or Above Ambient 25°C) *1 65 (Ambient 5 ~ 20°C) *1*2	20°C
Min	20°C	5°C

^{*1} Between outdoor ambient -15°C and -20°C, the water outlet temperature gradually decreases from 60°C to 55°C.

- Target Zone 1 Water Temperature (Heat mode) during SG ready control
 - If buffer tank selection is "NO" then following shift is carried out.
 - While digital input is "10" or "11" then,
 - Final Target Zone 1 water temperature
 - = Target Zone 1 water temperature* (SG ready % setting (remote control menu))%
 - If buffer tank selection is "YES"
 - No shift of Target Zone 1 Water Temperature. Target Buffer Tank Temperature will change accordingly.
 - * Refer to "Buffer tank temperature control"
- Target Zone 1 Water Temperature (Cool mode) during SG ready control
 - Final Target Zone 1 water temperature = Target Zone 1 water temperature + SG Cool Setting

13.1.6.2 Target Zone 2 water temperature setting control

- Start condition
 - Heating zone 2 is ON by remote control or Timer or Auto Mode OR
 - o Cooling zone 2 is ON by remote control or Timer or Auto Mode.
- Cancel condition
 - Heating zone 2 is OFF by remote control or Timer or Auto mode AND
 - \circ $\,$ Cooling zone 2 is OFF by remote control or Timer or Auto mode.
- Target Zone 2 water temperature is calculated as below condition.
 - Target Zone 2 water temperature = A (Base temperature) + B (shift temperature)

A (Base Temperature)	Compensation	Direct
A (base reinperature)	Value from the curve + User shift value set	Direct value from user setting

^{*} During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.

^{*1} Between outdoor ambient 5°C and 0°C, the water outlet temperature gradually decreases from 65°C to 60°C.

^{*1} Between outdoor ambient 20°C and 25°C, the water outlet temperature gradually decreases from 65°C to 60°C.

^{*2} Only when ΔT is set to 15°C, the set temperature above 60°C will take effect.

o B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below	
Sensor selection		
Water temperature B = 0		
External Room thermostat	B = 0	
Internal Room Thermostat & Room Thermistor	Cool Mode: B = 0; when Zone OFF or Zone Room Thermo OFF B = 1* (room set temp (R/C) - actual room temp) Max/Min Regulation of B: (Max = 5; Min = -5)	
	Heat Mode: B = 0; when Zone OFF or Zone Room Thermo OFF B = follow Heating Room Temperature PI control logic	
Pool Function Selected	B = Delta value setting from remocon	

- B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool "B" value)
- ** Pool function also can be select at Zone 2 when optional PCB is connected and Zone 2 system is select.
- Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
Max	55 (Below Ambient -20°C) *1 60 (Ambient -15 ~ 0°C or Above Ambient 25°C) *1 65 (Ambient 5 ~ 20°C) *1*2	20°C
Min	20°C	5°C


- *1 Between outdoor ambient -15°C and -20°C, the water outlet temperature gradually decreases from 60°C to 55°C.
- *1 Between outdoor ambient 5°C and 0°C, the water outlet temperature gradually decreases from 65°C to 60°C.
- *1 Between outdoor ambient 20°C and 25°C, the water outlet temperature gradually decreases from 65°C to 60°C.
- *2 Only when ΔT is set to 15°C, the set temperature above 60°C will take effect.
- Target Zone 2 Water Temperature (Heat mode) during SG ready control
 - If buffer tank selection is "NO" then following shift is carried out.
 - While digital input is "10" or "11" then,
 - Final Target Zone 2 water temperature
 - = Target Zone 1 water temperature* (SG ready % setting (remote control menu))%
 - If buffer tank selection is "YES"
 - No shift of Target Zone 2 Water Temperature. Target Buffer Tank Temperature will change accordingly.
 - * Refer to "Buffer tank temperature control"
- Target Zone 2 Water Temperature (Cool mode) during SG ready control
 - Final Target Zone 2 water temperature = Target Zone 2 water temperature + SG Cool Setting

13.1.6.3 Zone Temperature Control Contents

- During Standard System (Optional PCB not connected)
 - Only 1 zone temperature control is available
 - This zone room temperature is control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temperature)
 - Target Zone Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor. Target Water Temperature will set same as Target Zone Water Temperature
 - o Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).
- * There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.
- During Extension System (Optional PCB connected)

- Buffer Tank connection select "NO" &
 - One zone system is select
 - This zone room temperature control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temp.)
 - Target Zone Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor.
 - Target Water Temperature will set same as Target Zone Water Temperature
 - Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).
- * There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.
 - 2 zone system select
 - Each zone room temperature is control by each sensor which select from either one of the 4 room sensor
 - Target Zone 1 & 2 Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor.
 - * Zone Mixing Valve & Zone pump will operate to achieve Target Zone Water Temperature which refer to zone sensor.
 - * Zone Sensor will detect if zone sensor is open or short.
 - Target Water Temperature will set same as the active & higher zone water temperature setting. (When cooling mode, lower zone water temp setting)
 - Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat).
- Buffer Tank Connection select "YES" &
 - 1 zone system or 2 zone system select
 - Each zone control by each sensor which select from either one of the 4 room sensor
 - Target Zone 1 & 2 Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor. Each zone have their own Target Zone Water Temperature.
 - * Zone Mixing Valve & Zone pump will operate to achieve each Target Zone Water Temperature which refer to zone sensor
 - * Zone Sensor will detect if zone sensor is open or short.
 - Target Buffer Tank Temperature will be set as active & higher zone water temperature setting + Buffer Delta T. (Heating) Target Buffer Tank Temperature will be set as active & lower zone water temperature setting (Cooling).
 - Target Water Temperature will set as Target Buffer Tank Temperature + [2°C] (Heating) Target Water Temperature will set as Lower or Active Target Zone Water Temp. + [-3°C] (Cooling)
 - Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM thermo OFF
 - Heat mode: ROOM thermo OFF (Buffer Tank Temperature > Target Buffer Tank + [0°C]
 - Cool mode: ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat)

13.1.7 Auto Mode Operation




Control details:

- To enable the unit to operate either heat or cool mode automatically, heat to cool set temperature and cool to heat set temperature can be set by control panel.
- Automatic operation is judged based on control panel setting temperature and outdoor ambient temperature.
- * Minimum setting of heat to cool set temperature is 1°C higher than cool to heat set temperature.

Judgement control:

- If outdoor ambient temperature < Heat to Cool Set Temperature, unit will operate in Heat Mode or else the unit will operate in Cool Mode.
- If current operation is Cool mode, outdoor ambient temperature > Cool to Heat Temperature, unit will maintain Cool mode operation or else the unit will operate Heat mode.
- If current operation is Heat mode, outdoor ambient temperature > Heat to Cool Temperature, unit will maintain Heat mode operation or else the unit will operate Cool mode.
- o Every 60 minutes the outdoor ambient temperature is judged.
- When Auto + Tank mode is selected, operation mode switching is judged by both outdoor ambient temperature and indoor air temperature.

13.1.8 Auto Cooling Mode Operation Limit



- Auto Mode Cooling Only operation will start once the outdoor ambient temperature reaches 10°C and compressor will continue to run until the outdoor ambient temperature drops to 8°C.
- Due to this limitation,
 If Heat to Cool temperature is set lower than 10°C, the compressor will not operates until the outdoor ambient temperature reaches 10°C or higher.

13.1.9 Tank Mode Operation

- 3 ways valve direction
 - 3 ways valve switch to tank side during Tank Thermo ON condition. Switch 3 ways valve to room side when tank achieve Tank Thermo OFF temperature.
- Tank Thermo ON/OFF Characteristic
 - o Tank Thermo OFF

Case 1: Internal Tank Heater is select and Tank Heater ON

- o Tank temperature > Tank Set Temperature continuously for 15 seconds.
- Water outlet >75°C

Case 2: Tank Heater OFF OR External Heater is select

- When heat pump OFF due to water thermos & Tank temperature > Tank water set temperature for continuously 20 seconds. OR
- Tank temperature > Tank set temperature + 1°C for continuously 20 seconds.

Tank Thermo ON

Case 1: Internal Tank Heater is select and Tank Heater ON

o Tank temperature < Tank set temperature + R/C (Tank re-heat temperature)

Case 2: Tank Heater select OFF OR External Heater is select

- Tank temperature < Tank water set temperature + R/C (Tank re-heat temperature)
- * When tank thermo ON, water pump will ON for 3 minutes then only heat pump turn ON.
- * Tank water set temperature = tank set temperature or tank limit temperature whichever lower.

Outdoor ambient temperature	Tank limit temperature
OD < -17°C	48°C
-17°C <= OD < 36°C	52°C
36°C <= OD	50°C

- 2 ways valve close
- Heat pump Thermostat Characteristic
 - Heat pump Water Outlet set temperature is set to below table:

Outdoor ambient temperature	Heat pump water outlet set temperature
OD < -17°C	54°C
-17°C <= OD < -3°C	56°C
-3°C <= OD	59°C

Characteristic of heat pump thermos ON/OFF under tank mode condition:

Water Outlet Thermo Condition

- Heat pump thermos OFF temperature:
 - 1 Heat pump thermo OFF temperature = Target Water outlet temperature + (2°C)
 - 2 Water outlet temperature > heat pump thermo OFF temperature for continuously 90 seconds, heat pump OFF but water pump continue ON.
- Heat pump thermo ON temperature:
 - 1 Heat pump thermo ON temperature = water inlet during thermo OFF time + [-3°C]
 - 2 When water outlet temperature < heat pump thermo ON temperature, heat pump ON.

Water inlet thermo protection condition

- Heat pump thermo OFF temperature:
 - 1 Water inlet temperature > [60°C] for continuously 30 seconds, heat pump OFF, water pump continue ON.
- Heat pump thermo ON temperature:
 - 1 Heat pump thermos ON temp = water inlet temperature < [60°C].

Thermo ON/OFF for Heat Pump in Tank Operation:

When tank temperature achieve heat pump OFF condition, refer below condition:

Condition 1: When Internal Tank Heater is select and Tank Heater ON

 Heat pump will turn OFF, water pump continue ON and room heater will continue ON if tank temperature below tank heater thermo ON condition. 3 ways valve will only switch to room side after tank temperature reach tank heater thermo OFF condition.

Condition 2: When Tank Heater select OFF OR when External Tank Heater is select and Tank heater ON

• If tank temperature achieve tank thermo OFF, heat pump turn OFF, water pump turn OFF, room heater OFF and 3 ways valve switch to room side.

When tank temperature achieve heat pump ON condition, water pump ON, heat pump ON and room heater turn OFF.

Heat pump OFF condition at Tank Mode

- Tank temperature > tank water set temperature continuously for 20 seconds after heat pump thermos OFF due to water thermo. (Heat pump turn OFF but water pump continue ON and room heater turn ON to achieve tank set temperature) OR
- Tank temperature > tank set temperature + [1°C] for continuously 20 seconds. (Heat pump OFF, water pump OFF, room heater OFF and 3 ways valve switch to room side)

Heat pump ON condition at Tank Mode

Tank temperature < tank water set temperature + R/C setting (Tank re-heat temp)
 (Water pump turn ON OR continue ON, heat pump ON and 3 ways valve switch to tank side or maintain at tank side)

Internal heater control

 Internal heater only operates to tank side if the Internal Tank Heater is select, Tank heater ON and backup heater is enable.

Internal heater turn ON condition:

- Tank temperature < tank set temperature AND
- Heat pump thermos OFF AND
- 20 minutes from previous heater off AND
- Internal tank heater selects USE from control panel.

Internal heater turn OFF condition:

- Tank temperature > tank set temperature for continuously 15 seconds OR
- Heat pump thermo ON OR
- Mode change or operation is off by control panel.

External Heater control

External heater only operate to tank side if tank heater ON & External Heater select.

13.1.10 Heat + Tank Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch to room side during room heat-up interval and switch to tank side during tank heat-up interval. Both modes will switch alternately. Tank mode is the initial running mode of Heat + Tank mode.
- 2 Heat pump operation control:
 - During room heat-up interval
 - Follow normal heating operation.
 - Switching to tank side depends to below cases:

Case 1:

[Previous switch from tank interval to room interval due to thermo OFF]

 Switch to tank heat-up interval when Tank temp < Tank thermos ON temp (Room heat-up interval ends)

Case 2:

[If heating operation at room side is less than 30 minutes and switch to tank side 3 times consecutively]

 Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank thermo ON temperature. Case 3:

[Previous switch from tank interval to room interval due to tank interval timer is complete]

 Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** tank temperature < Tank thermo ON temperature.

- During Tank heat-up interval
 - Tank interval is the first mode running when heat + tank mode is select.
 - Switch to room interval only when tank achieve tank thermo OFF OR tank heat-up interval timer is complete.
 - Heat pump operates according to normal tank mode operation.
- 3 Room heater control:
 - During heating heat-up interval
 - Follow normal room heater control operation.
- 4 Tank heater control:
 - During heating heat-up interval
 - If External tank heater is select.
 - External heater ON/OFF according to external tank heater operation control.
 - If internal tank heater is select.
 - Internal tank heater will not function under heating heat-up interval.
 - During tank heat-up interval
 - If External tank heater is select.
 - Once heating heat-up interval switched to tank heat-up interval, tank heater is turn OFF and tank heater delay timer will start counting.
 - Tank heater will turn ON after tank heater delay timer is fulfill and tank temperature is lower than tank set temperature.
 - Tank heater delay timer is clear when switching to heating heat-up interval.
 - If internal tank heater is select.
 - Internal tank heater will turn ON after heat punp thermo off to boil tank temperature to tank set temperature.
 - o 2 ways valve control is open
 - Indoor water pump control:
 - Indoor water pump always turn ON if room heat pump thermo ON OR Tank thermo ON.

13.1.11 Cool + Tank Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch to room side during room cooling interval and switch to tank side during tank heat-up interval. Both mode will switch alternately. Tank mode is the initial mode of cool + tank mode.
- 2 Heat pump operation control:
 - During room heat-up interval
 - Follow normal cooling operation.

Switching to tank side depends to below cases:

Case 1:

[Previous switch from tank interval to room interval due to thermo OFF]

 Switch to tank heat-up interval when Tank temperature < Tank Thermo ON temperature (Room interval will ends)

Case 2:

[If cooling operation at room side is less than 30 minutes and switch to tank side for 3 times consecutively]

 Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank thermo ON temperature. Case 3:

[Previous switch from tank interval to room interval is due to tank interval timer is complete]

 Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** tank temperature < Tank thermo ON temperature.

*Tank Thermo ON temperature:

Internal Tank Heater select USE	<tank (tank="" +="" c="" r="" re-heat="" set="" setting="" temperature="" temperature)<="" th=""></tank>
Others	<tank (tank="" +="" c="" r="" re-heat="" set="" setting="" td="" temperature="" temperature)<="" water=""></tank>

- o During tank heat-up interval
 - Tank interval is the first mode running when the cool + tank mode is select.
 - Switch to room interval only when tank achieve tank thermo OFF OR tank heat-up interval timer is complete.
 - Heat pump operates according to normal tank mode operation.

3 Room heater control:


- During room cooling interval
 - Room heater is OFF and not operates.

4 Tank heater control:

- During room cooling interval
 - If External tank heater is select.
 - External heater ON/OFF according to external tank heater operation control.
 - If internal tank heater is select and tank heater ON
 - Internal tank heater will not function under room cooling interval.
- o During tank heat-up interval
 - If External tank heater is select.
 - Once room cooling interval switch to tank heat-up interval, tank heater will turn OFF and tank heater delay timer will start counting.
 - Tank heater turns ON after tank heater delay timer is fulfill and tank temperature is lower than tank set temperature.
 - Tank heater delay timer is clear when switch to room cooling interval.
 - If internal tank heater is select and tank heater ON.
 - Internal tank heater will turn ON after heat pump thermos off to boil tank temperature to tank set temperature.
- 5 2 ways vale is close.
- 6 Indoor water pump control:
 - o Indoor water pump always turn ON if room heat pump thermo ON OR Tank thermo ON.

13.1.12 Outdoor Fan Motor Operation


Outdoor fan motor is adjusted according to operation condition. It starts when compressor starts operation and it stops 30 seconds after compressor stops operation.



13.2 Water Pump

13.2.1 Water Pump Control

- Once the indoor unit is ON, the water pump will be ON immediately and no error judgment for 70 seconds.
 However, during this 70 seconds operation, if there is any abnormality cause at outdoor or malfunction, the compressor should be OFF immediately and restart delay after 3 minutes.
- The system will start checking on the water flow level after operation start for 70 seconds. If water flow level is detected low continuously 60 seconds, the water pump and the compressor will be OFF permanently and OFF/ON control panel LED will blink (H62 error occurs).
- When error happens, the power has to be reset to clear the error.
- If there is no error indication, the water pump shall be continuously running.
- The water pump will remain ON when compressor OFF due to thermostat OFF setting is reached.
- Water pump will OFF when room thermo **OR** tank thermo **OR** buffer tank thermo OFF.
- Water pump will delay 15 seconds to turn OFF when request to OFF except during anti-freeze deice activate or air purge mode.



Maximum pump speed setting on remote control


- When Pump flowrate setting is ΔT
 Standard pump speed is automatically controlled to get the designed water temperature different between water inlet and outlet (ΔT). The maximum pump speed setting limitation can be adjusted by the installer according to water circuit pressure drop condition.
- When Pump flowrate setting is Max. Duty
 Indoor water pump speed will operate at the maximum pump speed setting at room side operation. The maximum pump speed setting can be adjusted by the installer according to water circuit pressure drop condition.

However, the following sequences do not follow maximum pump duty setting by remote control.

- Pump down mode
- Air purge mode
- Normal deice

1) P-Q graph for different pump HEX duty


P-Q (WH-MXC09J3E8, WH-MXC12J9E8)



13.2.2 Zone Water Pump Control

Purpose:

 Water pump install at each zone to circulate the water inside each zone during buffer tank connection selected "YES" or 2 zone systems.



Content:

- AC type water pump install for this zone water pump control. When optional PCB connected, 230V output will
 drive this zone pump.
- There are three pump can be connected through Optional PCB. (Zone 1 Pump, Zone 2 Pump, & Pool Pump)
 - * Zone 1 pump [P1] use to circulate zone 1 water circuit & Zone 1 mixing valve [M1] adjust to control the Zone 1 target water temperature.
 - * Zone 2 pump [P2] use to circulate zone 2 water circuit & Zone 2 mixing valve [M2] adjust to control the Zone 2 target water temperature.
 - * When Pool Function select as Zone 2 circuit, [P2] use to circulate water to heat exchanger which use to transfer heat to pool water.
 - * Pool pump [P3] circulates the pool water through the heat exchanger to get warm water.
- Zone 1 and Zone 2 water pump start condition:
 - Zone room request ON
 - (eg. Zone 1 thermo ON, only zone 1 pump will turn ON)
- Zone 1 and Zone 2 water pump stop condition:
 - Zone room request OFF
- Pool water pump start condition:
 - Pool Zone request ON AND
 - Pool function is selected
- Pool water pump stop condition
 - Pool zone: Zone room request OFF OR
 - o Pool function is cancel
 - * Zone 1 & Zone 2 water pump need to turn OFF when antifreeze deice pump stop control activate and turn ON back after the antifreeze deice pump stop control end under setting of "NO" buffer tank connection.

Zone Pump Prohibit ON control:

Start condition:

Zone 1 water temperature ≥ 75°C continuously for 5 minutes *stop zone water pump operates if the zone water fulfilled.

Cancel condition:

After 30 minutes from start condition fulfilled.

*zone water pump operates according to normal condition.

Zone Pump Control during Anti-Freeze

Zone pump control during Zone Anti-Freeze Control:

- When Zone Anti-Freeze Flag=1, Zone Pump Turn ON.
- When Zone Anti-Freeze Flag=0, Zone Pump Turn OFF.

Zone pump control during Indoor Anti-Freeze Control:


• Zone pump only ON/OFF if the Extension PCB connected and Buffer Tank select "NO" condition

When Indoor Anti-Freeze flag=1, Zone Pump Turn ON When Indoor Anti-Freeze flag=0, Zone Pump Turn OFF

* Pool Water Pump will not affected by both Indoor anti-freeze control or zone anti-freeze control.

13.2.3 Water Pump Speed Feedback Error


- Basically pump speed feedback is control by micon.
- When pump speed is below low limit or over high limit for a few seconds, micon detect pump error and system is stopped.
- Error detection conditions:
 - Detect abnormal water pump speed for continuous 10 secs.
 - Current pump speed < 700 rpm or
 - Current pump speed > 6000 rpm for 10 seconds.
- Control contents:
 - When error occurs, water pump, heating and heater is stopped for 30 seconds then restart again (Retry control).
 - When micon detect error again, system is stopped and error code [H20] is displayed at control panel.



13.3 Indoor Unit Safety

13.3.1 Indoor Unit Safety Control

- 1 When water pump is ON, the system will start checking flow switch status (ON/OFF).
- 2 If the flow switch ON for 10 seconds, the system will check on the water inlet temperature for 10 seconds. If the water inlet temperature not exceeds 80°C, the water pump shall be continuously running with normal mode.
 - If the water inlet temperature exceeds 80°C for continuously 10 seconds, the water pump will be OFF immediately.
- 3 After water pump OFF for more than 10 minutes, it will be ON back and the indoor unit safety control checking is restarted.



13.4 Auto Restart Control

1 When the power supply is cut off during the operation of Air-to-Water Heatpump, the compressor will reoperate after power supply resumes.

13.5 Indication Panel

LED	Operation
Color	Green
Light ON	Operation ON
Light OFF	Operation OFF

Note:

• If Operation LED is blinking, there is an abnormality operation occurs.

13.6 Indoor Back-Up Heater Control

13.6.1 Indoor Electric Heater Control

- Normal Heating Mode
 - Heater On condition:
 - a. Heater switch is ON
 - b. After Heatpump thermo ON for Remote Control Set Delay Time mins
 - c. After water pump operate [1] minute
 - d. Outdoor air temperature < Outdoor set temperature for heater
 - e. When water outlet temperature < Water set temperature + Remote Control Heater ON Setting
 - f. [20] minutes since previous Backup heater Off
 - When heatpump cannot operate due to error happens during normal operation, heater will go into force mode automatic
 - * Heater need to operate during deice operation
 - o Heater Stop Condition:
 - a. When outdoor set temperature > outdoor set temperature + [+2°C] for continuous 15 secs OR
 - b. When water out temp> water set temperature + Remote Control Heater OFF Setting for continuous 15 secs OR
 - c. Heater switch is Off OR
 - d. Heatpump thermo-off or OFF condition

2 Force Heater Mode

- Heater On condition:
 - a. After water pump operate [2] minutes
 - b. When water outlet temperature < water set temperature + Remote Control Heater ON Setting
 - c. [20] minutes since previous Backup heater Off
- o Heater Stop condition
 - a. Force mode off **OR**
 - When water outlet temperature > water set temperature + Remote Control Heater OFF Setting for continuous 15 secs
- * Do not operate heater at the following situation
- 1 Water outlet temperature sensor, and water inlet sensor abnormal
- 2 Flow switch abnormal
- 3 Circulation pump stop condition

13.6.2 Room Heater Operation during Deice

Purpose:

To protect the indoor Heat Exchanger from ice forming and prevent heat exchanger plate breakage.

Control content:

- This Heater protection control will activate only if the backup heater is enable at custom setup by remote controller. Once fulfil the start condition, room heater will turn ON together (base on max heater capacity selection) and stop together if stop condition is fulfilled.
 - * If the heater is request to turn ON OLP feedback will be detected.

Starting conditions:

- During normal deice operation 4~9
- Water outlet temperature < 7°C
- Water Flow rate < 20L/min
- Water outlet temperature < 10°C or Outdoor air temperature < -30°C or Water inlet temperature < 10°C

Heater operates when 1 ~2 fulfilled **OR** When 1 and 3 ~ 4 is fulfilled.


However, this control does not relate to Heater ON/OFF button on remote control.

Stop condition:

- · When normal deice end or
- Water outlet temperature > 45°C

However, room heater keeps ON if indoor electric heater control activate.

< Deice operation time chart >



^{*} Backup heater must Turn OFF if the water pump turn OFF.

13.7 Tank Heater Control

13.7.1 Tank Heater Remote Control Setting

1 Tank heater selection:

External: - Booster Heater use to heat up tank when select external Internal: - Backup Heater use to heat up tank when select internal

2 Tank Heater ON/OFF selection by user.


The remote control Tank set Temperature range will change according to the External and Internal Tank Heater use.

Tank Heater Selection	Range
External	40 ~ 75°C
Internal	40 ~ 65°C

^{*} When select External Tank Heater, Heater Delay ON Timer need to set. (range 20 min ~ 3 hrs)

13.7.2 External Heater Control at Tank Side


Heating operation condition:



- Tank heater Turn On condition:
 - 1 External Heater selected for Tank heater by remote controller.
 - 2 Tank Heater select ON by user.
 - 3 Tank mode operation ON (Tank mode, Heat + Tank, or Cool + Tank).
 - 4 After TANK HEATER DELAY TIMER fulfill during heat pump startup time in tank mode, or during switching from heating heat-up interval to tank heat + up interval in heat + tank mode.
 - 5 Tank temperature < tank set temperature +[Remote controller Set Tank Re-heat Temp] + [-1°C].
 - 6 20 minutes since previous heater off.
 - * TANK HEATER DELAY TIMER is clear when tank heat-up interval end.
- Tank heater Turn Off condition:
 - 1 Tank temperature > tank set temperature + [0°C] for continuous 15 seconds.
 - 2 When BOOSTER HEATER DELAY TIMER start count after switch from heating heat-up interval to tank heat-up interval.
 - 3 Tank Heater select OFF by user.
 - 4 Tank Mode Operation OFF.

13.7.3 Internal Heater Control at Tank Mode

- Internal heater turn On condition:
 - 1 Internal Heater select for Tank heater by remote controller
 - 2 Tank Heater select ON by user.
 - 3 Backup Heater Enable
 - 4 Tank Temperature < Tank Set Temperature
 - 5 Heat Pump Thermo OFF
 - 6 20 minutes from previous heater off.
- Internal heater turn OFF condition:
 - 1 Tank Temperature > Tank Set Temperature + [0°C] for continuous 15 seconds. **OR**
 - 2 Heat Pump Thermo ON OR
 - 3 Mode Change or Operation OFF by remote controller OR
 - 4 Water outlet temperature > 75°C
 - * Backup Heater Turn ON/OFF all together according to the selected heater capacity.



13.8 Base Pan Heater Control (Optional)

- To enable the base pan heater function, control panel initial setting has to be manually adjusted by activating Base Pan Heater menu.
- There are 2 optional start condition can be selected, Type A or Type B.
- Control details:
 - 1 Type A: (Default Auto Mode)

Start conditions:

When outdoor air temperature ≤ 3°C during heating and deice operation is ON.

Control contents:

Base pan heater is ON during deice operation and continues ON for 10 minutes after deice operation ends.

Cancel condition:

- o When outdoor temperature > 6°C after deice end or
- o When operation is not at heating mode or
- Base pan heater ON timer count is completed.

2 Type B: (ON Mode)

Start conditions:

When outdoor air temperature is $\leq 5^{\circ}$ C and operates in heating mode, base pan heater is ON.

Cancel conditions:

- When outdoor air temperature is > 7°C or
- o When operation is not at heating mode.

13.9 Heater Turn ON/OFF priority Control

Purpose:

 To allow only one heater between room and tank heater to turn ON at the same time due to both heater power supplies is sharing the same ELCB. Prohibit two heater sources to turn ON at the same time to avoid overcurrent.

Start condition:

Tank heater function select YES by remote controller

Control contents:

- When there is only one heater source (Room Heater or Tank Heater) request to turn ON, operate same as normal room heater and tank heater operation.
- When both backup heater and booster heater request to turn ON at same time, will turn ON only ONE heater source. Under normal condition, tank heater has priority to turn ON except below condition.
 - 1 Backup Heater Priority to Turn ON when
 - o Request Backup heater turn ON at Hex Protection control during deice.
 - Request Backup Heater turn ON at Hex Protection Control during low water temperature.
 - Request Backup Heater turn ON at Anti-frost control.
 - Heat pump error and Force Mode operate.
- When switching from booster heater to backup heater OR backup heater to booster heater, need to delay
 5 seconds in between Turn OFF one heater source and Turn ON another heater source.

13.10 Force Heater Mode

Purpose of Force Heater Mode

 As a backup heat source when heat pump error. Force heater Mode control backup heater to heat up the room circuit, and turn ON back up heater or booster heater to boil up tank water base on the tank heater selection (internal or external)

Force Heater Control start condition:

- Force heater request ON by user OR auto turn ON by remote controller during error AND
 (Force Heater mode can be operate regardless of mode selection, remocon will send the latest mode
 selection and force bit to indoor. Indoor will judge to turn ON heater to room side if it is heat mode selected,
 and turn ON heater to heat up tank water base on tank heater selection)
- During Error Happen (exclude the error list below)

Error List not allow Force Heater Operation

H12	H12 Capacity Mismatch H76 Indoor-Remote Controller Communication		Indoor-Remote Controller Communication Error	
H20	H20 Abnormal Water Pump		Abnormal Voltage Connection	
H62	Abnormal Water Flow	F37 Abnormal Water Inlet sensor		
H70	Abnormal Back-up Heater OLP	F45 Abnormal Water Outlet sensor		
H74	PCB Communication Error			
[When tank m	node operate with external heater selected & tank heater	select ON]		
H72	H72 Abnormal tank sensor		Abnormal tank heater OLP	

Force Heater Control Stop Condition:

- Force Heater request OFF OR
- Operation OFF request OR
- Mode change request OR
- Power reset OR
- Error of above list happens during force heater operation.

Control contents:

After fulfil start condition, indoor will operate the force heater operation according to below mode condition
 Heat mode Only
 Turn ON backup heater to achieve room heat pump target water temperature.
 Heat + Tank mode
 Turn ON backup heater to heat up room OR Turn ON Heater to Boil up tank water.

Cool mode Only : Water pump and backup heater will OFF in force heater mode

Cool + Tank mode

Cool + Tank

* For heat mode condition, backup heater will only turn ON if the backup heater is enable regardless of Room Heater Selection

* For tank mode condition, If internal heater selected backup heater will turn ON to boil up tank water. If external heater selected, booster heater will turn ON to boil up tank water regardless of tank heater selection

Room Side: (Heat Mode)

- When force heater mode start condition fulfilled, turn ON water pump and turn ON backup heater follow below control.
- 2) Operate the 3 ways valve at room side only and turn ON 2 ways valve as heat mode operation.
- 3) Turn ON the zone pump and mixing valve if system select 2 zone system or Buffer tank connect YES, control according to normal zone pump and mixing valve control.
- 4) When Force heater mode stop condition fulfilled, turn OFF heater as below condition and turn OFF water pump after pump delay time.

Backup Heater On Condition:

- a) When Force Heater Control start condition fulfill AND
- b) After water pump operate 2 minute AND
- c) When water outlet temperature < water set temperature + Remote Control Heater ON Setting AND
- d) 20 minutes since previous Backup heater Off AND
- e) Backup Heater Enable

Backup Heater Stop condition

- a) Force mode off OR
- b) Operation off **OR**
- c) When water outlet temperature > water set temperature + Remote Control Heater OFF Setting for continuous 15 secs **OR**
 - * ON/OFF follow normal heater sequence.

Tank side (Tank mode)

- 1) When tank mode select and force heater bit received, turn ON backup heater (INTERNAL) or Booster Heater (External) depend on the tank heater selection.
- 2) If tank heater selection is INTERNAL, follow normal thermo judgement to switch 3 ways valve to tank side and room side.
- 3) If tank heater selection is EXTERNAL, only turn ON booster heater according to tank thermo.

Tank Heater selection is INTERNAL:

Backup Heater ON Condition:

- a) After water pump operate 2 mins AND
- b) When tank temperature < Tank set temperature [Remocon Set Tank Re-heat Temp] AND
- c) 20 minutes since previous backup heater OFF AND
- d) Backup heater enable

Backup Heater OFF Condition:

- a) Force mode OFF OR
- b) When tank temperature > Tank set temperature for continuous 15 secs OR
- c) Tank Operation OFF

Tank Heater selection is EXTERNAL:

Backup Heater ON Condition:

- a) Force Heater mode ON AND
- b) Tank temperature < tank set temperature + [Remocon Set Tank Re-heat Temp] 1°C, AND
- c) 20 minutes since previous heater off.

Backup Heater OFF Condition:

- a) Tank temperature > tank set temperature for continuous 15 sec
- b) Force mode OFF
- c) Tank Mode Operation OFF
 - (During tank interval or tank mode condition, water pump and 3 ways valve will OFF)

13.11 Powerful Operation

Powerful mode is use to increase the capacity of heat pump to achieve higher target temperature. Powerful mode is applicable when heat mode is operating.

Remote control setting:

On quick menu of remote control, there is 4 options of powerful mode can be select.

OFF
30 minutes
60 minutes
90 minutes
Cancel powerful mode
Set powerful for 30 minutes
Set powerful for 60 minutes
Set powerful for 90 minutes

Control contents:

During the time set by remote control, powerful will activate according to 2 shift up controls. However, this function is applicable only for heating. Remote control will transmit the signal to indoor unit once this function is select then transmit OFF signal to indoor when the timer is complete. Indoor will transmit signal to outdoor for frequency control.

Indoor setting temperature shift

- If system is standard system (Optional PCB is not connected)
 - Target water temperature will shift up to Wlo or Whi whichever higher.
- If system is extension system (Optional PCB is connected)
 - o Target water Zone 1 and Zone 2 temperature will shift up to Wlo or Whi whichever higher.

Start condition

Powerful function is select by remote control.

End Condition

- o OFF/ON button is pressed.
- Powerful function is OFF by remote control.

13.12 Quiet Operation

Quiet mode is use to reduce the noise of outdoor unit by reducing the frequency or fan speed.

Quiet leve

There are 3 level (Level 1, Level 2, Level 3) to set by quick menu function on remote control.

Control content

Once the quiet function is select, the remote control will transmit the signal to indoor and outdoor unit.

Start condition

- Quiet mode is set on remote control.
- Quiet mode is request ON by weekly timer.

Stop condition

If any of below condition is achieve.

- OFF/ON button is pressed.
- Quiet mode is OFF by remote control.
- Quiet mode is request OFF by weekly timer.

^{*} If "Direct Type" temperature control is select, this powerful shift up setting is not effective.

13.13 Sterilization Mode

Purpose:

o To sterilize water tank by setting the required boiling temperature.

· Remote control setting

- o Days for sterilization function to start can be select.
- o Time of selected day to start sterilization function.
- o Boiling temperature (External heater is 55°C ~ 75°C, Internal heater is 55°C ~ 65°C)
- o Maximum operation time is 5 minutes to 1 hour.

Start condition

- Tank connection set to "YES" by remote control
- Sterilization function selects "YES".
- Sterilization signal received from remote controller by timer.
- Tank mode request ON.

• Stop condition

- When boiling timer is completed. Boiling timer (Remote control set maximum operation time) start counting once tank achieve boiling set temperature **OR**
- o After 8 hours of operation since sterilization start.
- Tank mode request OFF.


Control content:

- During sterilization function activation time, target tank set temperature will internally change to boiling set temperature.
- During sterilization activates, heat pump and heater (external or internal) will operate as normal tank mode to achieve the boiling set temperature.
- Sterilization operation will end when stop condition is fulfill.
- After sterilization is complete, tank set temperature will resume to normal operation.

13.14 Outdoor Ambient Thermo OFF Control

Purpose

Stop provides heating to room side during high outdoor ambient condition.



Control content

- Heating outdoor ambient thermos OFF control only applicable when heat pump operate in heat mode. (This
 control will not activate when running in tank side)
- Heat pump and water pump will turn OFF when outdoor ambient is higher than outdoor thermo OFF set temperature.
- Heat pump thermos ON when outdoor ambient < outdoor thermos OFF set temperature + 1°C.

^{*} Tank temperature may not achieve boiling set temperature if tank heater is select OFF **OR** external compressor switch.

13.15 Alternative Outdoor Ambient Sensor Control

Purpose of the Alternative Outdoor Ambient Sensor:

• It is some possibility that the air to water heat pump unit will install at a location where the original ambient sensor is expose to direct sunlight. Therefore, another optional ambient sensor can be connect to indoor PCB and locate at new and better reading location to improve the heat pump performance.

Control Detail:

- Remocon can select either the extra outdoor ambient sensor is connected or not. (YES/NO)
- The alternative outdoor ambient sensor will connect to indoor unit main PCB terminal.
 - when alternative sensor select NO
 - Original Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
 - Data communication direction: OUTDOOR send outdoor temperature reading to INDOOR.
 - Error judge: OUTDOOR will judge the original outdoor sensor error (F36 display if error detect). No
 judge error on alternative outdoor sensor
 - when alternative sensor select YES
 - Alternative Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
 - Data communication direction: INDOOR send outdoor temperature reading to OUTDOOR.
 - Error judge: INDOOR will judge the Extra outdoor sensor error only after operation ON request received from remocon.
 - (F36 display if error detect). No judge error on original outdoor sensor.

13.16 Force DHW mode

Purpose:

When user want to use hot water now, user can press this force DWH mode under the quick menu to operate tank only mode to boil up the tank temperature.

Remocon setting:

Force DHW function can be activate under quick menu.

Control Content:

- When press the Force DHW function during operation OFF condition:
 - When receive this Force DHW bit from remocon, indoor will run tank only mode regardless of the mode selection.
 - After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to operation OFF with previous mode selection.
- When press the Force DHW function during operation ON condition:
 - When receive this Force DHW bit from remocon, indoor will memories the running mode and run tank only mode regardless of the mode selection.
 - After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to previous memories running mode.
 - * when operation OFF or mode change request from remocon during force DHW mode operation, End force DHW mode and follow the new request operation.
 - * Once receive force DHW mode from remocon, indoor direct start tank mode and consider tank thermo ON. Thermo OFF only when achieve tank thermo OFF depend on the Tank System Setting.

13.17 SMART DHW mode

Panasonic All In One model provide the option to choose STANDARD DHW Mode or SMART DHW Mode for Tank Heat Up according to requirement. SMART DHW mode comparatively consume lower tank heat up power but longer re-heat time than STANDARD DHW Mode.

SMART DHW control

- During SMART DHW start time 20:00 (Default Setting) to SMART DHW stop time 05:00 (Default setting) Heat pump re-heat the tank water only when tank temperature drop below 20°C (Default setting)
- Time between 05:00 to 20:00

 Heat pump reheat the tank water when tank temperature as below condition

Condition 1: Tank Heater ON

Reheat when tank temperature below tank set temperature + R/C (Tank re-heat Temperature) - 3°C

Condition 2: Tank Heater OFF

Reheat when tank temperature below Tank set temperature or tank limit temperature (Whichever lower) + R/C (Tank re-heat Temperature) -3°C

* SMART DHW start time, stop time and SMART ON Temperature can change in CUSTOM menu.

STANDARD DHW Mode

Heat pump always reheat the tank water when tank temperature as below condition

Condition 1: Tank Heater ON

Reheat when tank temperature below tank set temperature + R/C (Tank re-heat temperature)

Condition 2: Tank Heater OFF

Reheat when tank temperature below Tank set temperature or tank limit temperature (Whichever lower) + R/C (Tank re-heat temperature)

Outdoor ambient temperature	Tank limit temperature
OD < -17°C	48°C
-17°C <= OD < 36°C	52°C
36°C <= OD	50°C

13.18 DHW Capacity Setting

DHW Capacity is heat pump heating capacity output control during tank boiling operation. There are two DHW capacity setting (VARIABLE & STANDARD) which can be set in remote control.

VARIABLE DHW Capacity:

• Heat pump operate with efficient (Low) Capacity to boil tank temperature during re-heat process. And heat pump regulated to operate with high capacity to boil tank temperature when tank temperature drop below 25°C.

STANDARD DHW Capacity:

Heat pump operate according to outdoor rated heating capacity during tank boiling process.

13.19 Anti Freeze Control

- Anti freeze protection control menu can be set YES or NO by control panel.
- In heatpump system, there are 3 types of anti freeze control:
 - 1. Expansion tank anti-freeze control
 - Expansion tank anti freeze heater ON condition:
 - Outdoor ambient temp. < 3°C
 - Expansion tank anti freeze heater OFF condition:
 - Outdoor ambient temp. > 4°C
 - 2. Water pump circulation anti freeze control
 - Water pump turns ON when <u>ALL</u> below conditions are fulfilled:
 - o Heatpump OFF (stand by) OR error occurs.
 - Water flowing flag is ON.
 - Water flow switch is not abnormal.
 - Outdoor ambient temp. < 3°C OR outdoor ambient temp. sensor is abnormal.
 - Water inlet/outlet temp. < 6°C.
 - After 5 minutes from previous water pump OFF.
 - Water pump turn OFF when ANY of below conditions is fulfilled:
 - Outdoor ambient temperature ≥ 4°C.
 - During -5°C < outdoor ambient temp. < 4°C
 - After water pump ON for 4 minutes, and water inlet temp. ≥ 8°C.
 - Else, shift to back up heater anti freeze control.
 - During outdoor ambient temp. < -5°C
 - After water pump ON for 4 minutes, and water inlet/outlet ≥ 20°C.
 - Else, shift to back up heater anti freeze control.
 - However, if flow switch is abnormal (H62), then water pump circulation anti freeze control will not activate.
 - 3. Back up heater anti freeze control:
 - Back up heater turn ON when <u>ALL</u> below conditions is fulfilled:
 - Water inlet/outlet temp. < 6°C.
 - Water pump circulation anti freeze control activated and water pump ON for 4 minutes.
 - Back up heater turns OFF when ANY of below conditions is fulfilled:
 - Water inlet/outlet temp. > 28°C.
 - Water pump circulation anti freeze control deactivated/water pump OFF.
 - However, if back up heater is abnormal (H70) then back up heater anti freeze control will not activate.

13.19.1 Zone Anti-Freeze Control

If buffer tank selection is "NO" and Anti- Freeze function select "NO" from remote control, this control cannot
activate.

Start condition:

- After [5] min from previous Zone pump off. AND
- Outdoor air temp < [3] °C OR Outdoor sensor is abnormal. AND
- Zone water temperature < [6] °C **OR** Zone Sensor Short or Open

Cancel condition:

- After water Zone pump ON [4] min AND
- Outdoor air temp ≥ [4]°C OR
- During -5 °C ≤ Outdoor air temp < [4] °C
 Zone water temperature sensor > [8] °C OR
- During Outdoor air temp < [-5] °C
 - Zone water temperature sensor > [20] °C
 - *However, Zone water temperature sensor is Open or Short, Condition 3 and 4 is ignored.


13.20 Solar Operation (Optional)

13.20.1 Solar Operation:

Solar function:

 This function allow user to control the solar pump to operate depend on the solar sensor reading compare to the tank installed. Solar pump will circulate the hot water energy store at solar panel to heat up the DHW Tank or Buffer Tank.

Solar Connection Diagram:



- Solar function can only enable when the Optional PCB is connected.
- Few part as below need to install to control the solar operation:
 - Solar Panel
 - Solar Pump
 - Solar Panel Sensor
 - o Tank Sensor (Buffer tank sensor OR DHW Tank sensor depend on the connection direction)
 - * During Solar Connection to the system, installer need to alert on the high water temperature may flow to the zone circuit or DHW piping circuit. Therefore pipe which withstand higher water temperature need to be installed.
- Solar remote control setting
 - 1 Solar Setting can only be set when the optional PCB connection is select "YES"
 - 2 By remote controller, Setting as below list can be set for solar function operation (Installer Menu)
 - Solar Function ("YES" or "NO)
 - o Tank Connection Direction ("DHW TANK" or "BUFFER TANK")
 - Delta T turns ON: Difference temperature setting between solar panel sensor and Tank to turn on solar pump. (Range :5 ~ 15°C)
 - Delta T turns OFF: Difference temperature setting between solar panel thermistor and Tank to turn off solar pump. (Range :2 ~ 10°C)
 - Outdoor temp for Anti-Freeze : Outdoor temp to start Anti-Freeze control for solar circuit. (Range : -20 ~ 10°C)
 - Tank Temperature HI Limit Set (Range : 70 ~ 90°C)

13.20.2 Solar Operation Control

 Solar function can only be activate if the solar function selection "YES" from remote control. To achieve hot water from solar panel, indoor need to control the solar pump and circulate hot water from solar panel.

Under normal case:

- Solar pump start condition:
 - Solar panel temperature > Delta T turn on setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) AND
 - Tank temperature (DHW or Buffer) < Solar HI Limit Temp (R/C) AND
 - Operation ON with heat mode (apply to solar connect to "Buffer Tank" case)
 - * Condition c) ignore if the solar system is connect to DHW tank (control active under operation OFF time for Tank connection case)
- Solar pump stop condition:
 - Solar panel temperature < Delta T turn OFF setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) OR
 - Tank hot water temp >= Solar HI Limit Temp (R/C) + [2]°C

Under solar Anti-freeze protection control:

- Solar pump start condition:
 - Outdoor temp < Outdoor temp setting for Anti-Freeze (R/C)
- Solar pump stop condition:
 - Outdoor temp > Outdoor temp setting for Anti-Freeze + [2]°C

- Solar operation during error:
 - During Tank sensor (DHW or Buffer depend on selection) abnormal, Solar operation will not able to function.
 - o During Solar Panel sensor detect OPEN (not include SHORT), Solar operation will not able to function too.

13.21 Boiler Bivalent Control

- Boiler is an additional or alternative heat source to heat up the room when necessary.
- Purpose of this control is to turn ON and turn OFF the Boiler output signal when boiler heating capacity needed in the system.
- Boiler is possible to connect to DHW Tank and Buffer Tank depends on the installer.
- Boiler operation parameter need to be set on Boiler itself, indoor do not control the boiler operation direction and operation.
- There is two option of control pattern can be set by remote controller: AUTO OR SG ready Mode

AUTO Control Mode:

 There are Alternative mode, Parallel mode, & Advance Parallel mode available to select by installer to fit to the total system.

Bivalent control selection by remote controller

Remote control setting value:

1 Outdoor Ambient Set = (Range: -15°C ~ 15°C)

Alternative Mode

- o Only one heat source operates at one time, either heat pump or boiler depends on condition.
- External pump will turn ON when the external pump selection is ON when boiler is ON even heat pump is OFF.

Control detail:

During Operation ON at Heat mode or Tank mode or Heat + Tank Mode

- Boiler signal turn ON and heat pump and water pump turn OFF when:
 - Outdoor ambient < Outdoor Ambient Set AND
 - Boiler prohibit flag = 0

^{**}However, During Cool mode this function cannot activate if Tank selection is "Buffer Tank".

^{**}Solar pump can operate even if Heat pump is under error stop.

- ** However indoor water pump can operate when Anti-freeze control condition fulfilled.
 - Boiler signal turn OFF and heat pump and water pump turn ON when:
 - Outdoor ambient > Outdoor Ambient Set + [2°C] OR
 - Boiler prohibit flag = 1

Parallel Mode

o Parallel mode allows heat pump and boiler ON at the same time. Boiler operates as an additional heating capacity when low heat pump capacity at low ambient condition.

Control detail:

During operation ON at Heat mode or Tank mode or Heat + Tank mode

- o Boiler signal turns ON when:
 - Outdoor ambient < Outdoor Ambient Set AND
 - Boiler prohibit flag = 0
- Boiler signal turns OFF when:
 - Outdoor ambient > Outdoor Ambient Set + [2°C] OR
 - Boiler prohibit flag = 1

Advance Parallel Mode

 Advance parallel mode allow heat pump to operate and turn ON boiler only when ambient and temperature condition is fulfilled.

Remote control setting value:

- 1 Outdoor Ambient Set = (Range : -15°C ~ 15°C)
- 2 Selection of boiler connection direction. (Heat only, DHW only, Heat & DHW)
- 3 Setting data under Heat Direction
 - o Start Temperature | START TEMP |
 - Start Delay Timer | START_TIMER |
 - Stop Temperature | STOP_TEMP |
 - Stop Delay Timer | STOP_TIMER |
- 4 Setting data under DHW Direction
 - Delay Timer | DELAY_TIMER |

Control detail:

During operation ON at Heat Mode

- Boiler signal turns ON when
 - Outdoor ambient < Outdoor Ambient Set AND
 - Buffer tank temperature < Target Buffer Tank Temperature + [START TEMP] for [START TIMER] AND
 - Heat pump operate at room side AND
 - Connection of Boiler to Heating Select "YES" From installer menu AND
 - Buffer Tank connection select "YES" AND
 - Boiler prohibit flag = 0
- Boiler signal turns OFF when
 - Outdoor ambient > Outdoor Ambient Set + [-2°C] OR
 - Buffer Tank temperature > Target Buffer Tank temperature + [STOP TEMP] for [STOP TIMER] OR
 - Heat pump not at room side. OR1
 - Boiler prohibit flag = 1

During operation ON at Tank Mode

- Boiler signal turns ON when
 - Outdoor ambient < Outdoor Ambient Set AND
 - Heat pump operate at tank side for continuous | DELAY TIMER | AND
 - Connection of Boiler to DWH Tank select "YES" from installer menu. AND
 - Boiler prohibit flag = 0
- Boiler signal turns OFF when
 - Outdoor ambient > Outdoor Ambient Set + [2°C] OR
 - Heat pump not operates at tank side. OR
 - Boiler prohibit flag = 1

SG ready Control Mode:

- Using same SG ready from Sub Board input to control boiler ON/OFF output.
- * When this SG ready is select for bivalent control, default SG ready function will change to control bivalent output.
- Remote controller can set the External Pump ON/OFF like bivalent alternative mode.

Control Content

Indoor will follow the SG ready bit input to control ON/OFF heat pump and boiler 00 : Heat pump OFF, Boiler OFF 10 : Heat pump OFF, Boiler ON 11 : Heat pump ON, Boiler ON

Boiler prohibit flag control

Purpose:

o For product safety. Boiler signal is OFF when water temperature is too high.

Start condition:

- o Water outlet ≥ 85°C continues for 5 minutes.
- Water inlet ≥ 85°C continues for 5 minutes.
- Zone1 water temp ≥ 85°C continues for 5 minutes.
- o Zone2 Water temp ≥ 85°C continues for 5 minutes.

Contents:

After start condition fulfilled, set boiler prohibit flag = 1

Cancel condition:

After 30 minutes from start condition fulfilled.

Contents:

Set boiler prohibit flag = 0

13.22 External Room Thermostat Control (Optional)

Purpose:


Better room temperature control to fulfill different temperature request by external room thermostat. Recommended external room thermostat:

Maker	Characteristic
Siemen (REV200)	Touch panel
Siemen (RAA20)	Analog

Connection of external room thermostat:

Wire Connection and thermo characteristic of Siemen REV200:


Setting	Setting L/L1 (H)		L/L2 (C)	Cool Thermo
Set Temp < Actual Temp Open Circuit		OFF	Short Circuit	ON
Set Temp > Actual Temp	Short Circuit	ON	Open Circuit	OFF



^{*} External pump will turn ON when the external pump selection is ON when boiler is ON even heat pump is OFF.

Wire Connection and thermo characteristic of Siemen RAA20:

Setting L/Y1 (H)		Heat Thermo	L/Y2 (C)	Cool Thermo
Set Temp < Actual Temp Open Circuit		OFF	Short Circuit	ON
Set Temp > Actual Temp Short Circuit		ON	Open Circuit	OFF



Control Content:

- External room thermostat control activate only when remote thermostat connection select YES by Indoor control
 panel.
- When indoor running heat mode, refer thermo On/Off from heating line feedback. And when indoor running cool mode, refer thermo On/Off from cooling line feedback.
- Heat pump Off immediately when receive thermo off feedback.


13.23 Three Ways Valve Control

Purpose:

- 3 ways valve is used to change flow direction of hot water from heat pump between heating side and tank side.

Control contents:

- 1 3 ways valve switch Off:
 - During 3 ways valve switch Off time, the hot water will provide heat capacity to heating side.
- 2 3 ways valve switch On:
 - During 3 ways valve switch On time, the hot water will provide heat capacity to tank side.
- 3 Stop condition:
 - During stop mode, 3 ways valve will be in switch off position.



- * During pump down and force mode, fix 3 ways valve in close condition.
- * Recommended Parts : SFA 21/18 (Siemens)


13.24 Two Ways Valve Control

Functionality of 2 ways valve:

• Use to allow hot water to floor heating panel or block cold water to floor heating panel.

Control contents:


- 1 When indoor running in heat mode, OPEN the 2 ways valve.
- 2 When indoor running in cool mode, CLOSE the 2 ways valve.
- 3 Stop condition:
 - a. During stop mode, fix 2 ways valve in close condition.



- * During pump down mode, fix 2 ways valve in close condition.
- * During force mode, open 2 ways valve.
- * Recommended Parts : SFA 21/18 (Siemens)


13.25 External OFF/ON Control

• Communication circuit between indoor unit and external controller is as per below.



- Maximum length of communication cable is 50 meter.
- Control content:

External Control Switch	Control Panel OFF/ON	Control Panel Power LED	System Status
ON ON		ON	ON
ON OFF		OFF	OFF
OFF ON		ON	OFF
OFF OFF		OFF	OFF



When External SW connection select "YES" from remocon installer menu:

- Heating or Cooling system will operate normally if the External Switch signal is ON.
- Once the External Switch turn OFF, System Turn OFF (Heat pump, water pump, heater etc...)
- Remocon LED remain ON or OFF according to the current operation request.
- Pop up menu at remocon main screen as above screen to inform customer system stop by External Switch.
- It is possible to press cancel and return to main screen to do change of operation setting while waiting the
 External Switch turn ON back.
- Remocon LED will always follow the latest changes from remocon.
- If no action on remocon for continuous 5 minutes, the pop up screen will show again on the screen.
- But once the External Switch Turn ON back, pop up screen will disappear and system can operate normally according to the latest operation setting and request.

13.26 External Compressor Switch (Optional PCB)

External compressor switch port can have two purpose of control as below:

- Heat source ON/OFF function (Dip switch Pin 3 on PCB "OFF")
- Heater ON/OFF function (Dip switch Pin 3 on PCB "ON")
- Heat source ON/OFF function

Purpose:

 Heat pump ON/OFF function is use to turn OFF the high power consumption device (Heat pump, & Heater) when there is energy or electric current limitation. Other optional function still can be operate under heat pump and heater OFF condition.

Control Detail:

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & Dip Switch on PCB "OFF"
 This heat pump ON/OFF function will activate
- The ON/OFF signal of this External Compressor Switch is same as External Switch.
- When the External Compressor Switch is ON:
 - Heat pump system operate normally
- When the External Compressor Switch is OFF:
 - o Heat pump, Indoor water pump & Heater (Booster heater & Backup Heater) need to turn OFF
 - Solar, Boiler and zone control can be operate follow normal control condition.
 - * pump delay OFF also included in this control

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

Heater ON/OFF function

Purpose:

Heater ON/OFF function is use to turn OFF the heater (backup heater & booster heater) when there is energy or
electric current limitation. Heat pump and other optional function still can operate.

Control detail

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & Dip Switch on PCB "ON"
 This heater ON/OFF function will activate
- When the External Compressor Switch is ON:
 - o Heat pump and heater operate normally
- When the External Compressor Switch is OFF:
 - o Backup heater and booster heater cannot operate even heater request is ON.
 - Heat pump and option function (Solar, Boiler and zone control) can be operate follow normal control condition.

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

13.27 Heat/Cool Switch (Optional PCB)

Purpose:

• User can switch the running mode from heat to cool or cool to heat through external installed Heat/Cool switch. This kind of heat / cool switch may built in inside the field supply room remocon as well.

Control contents:


- Heat/Cool Switch can only be set when Cool Function is "enable" at custom menu setting, & Extension PCB select "YES" & Zone 1 not set "Pool" condition.
- This heat/cool switch control will be activate only when installer set the Heat/Cool Switch "USE" through remocon.
- Once the Heat/Cool Switch Set "USE", remocon will check indoor send Signal to judge the option of mode select.
 - When Heat/Cool Switch Contact Open : Remocon only can select Heat Mode, or Heat + Tank Mode, or Tank Mode
 - When Heat/Cool Switch Contact Close: Remocon only can select Cool Mode, or Cool + Tank Mode, or Tank Mode
- Operation ON/OFF will depend on remocon request.
- When Heat Mode is running with Contact Open, user change this setting to contact close, indoor will this signal to remocon judge and change mode to cool and send back to indoor. And it is same as from cool mode change to heat mode.
 - * This switch have higher priority, remocon follow indoor send signal when control activated.
 - * There is no effect to the operation when the mode running is only Tank Mode.

(Weekly Timer are ignored and cannot be set during Heat / Cool Switch is "Enable" Condition.)

13.28 SG Ready Control (Optional PCB)

Purpose:

• To set ON/OFF of heat pump and target temperature by digital input of third party device if necessary in field.



Remote control setting

For this function, following items need to be set on R/C (installer menu) –

- SG control = YES or NO
- Capacity up setting 1
 - Heating capacity [50 ~ 150 %]
 - DHW capacity [50 ~ 150 %]
- Capacity up setting 2
 - Heating capacity [50 ~ 150 %]
 - o DHW capacity [50 ~ 150 %]

Control contents:

If SG control on remote control = "Yes", then following control only activate by digital input.

• While Digital input is " 00 " (Normal operation)

- Normal operation. Once detect '00' system will operate back to normal condition.
 (All the target set temperature for heating side and DHW side will return back to previous set temperature when digital signal change from "10' or"11" back to "00".)
- While digital input is detected "01" (HP stop)
 - Heat pump & room heater & tank heater cannot operate.
 (Solar control and Boiler back up and 2 Zone control can activate.)
- While digital input is detected " 10 " (Capacity 1)
 - Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting.
 - Target water temperature of cooling is changed according to the adjustment value set by Remote control setting.
 - However, which setting temperature is change depend on system setting.
- While digital input is detected " 11 " (Capacity 2)
 - Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting.
 - Target water temperature of cooling is changed according to the adjustment value set by Remote control setting
 - However, which setting temperature is change depend on system setting.
- While digital input is detected " 10 " (Capacity 1)
 - Setting temperature for heating and Tank is changed.
 However, which setting temperature is change depend on system setting.

If Buffer selection is "YES"

Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature * Remote Control setting (" capacity 1) %

- Max Min regulation is follow Target Buffer tank temperature control specification
- ** No change of Target zone water temperature, only set higher buffer tank temperature.

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 1) % * (Max regulation depend on the tank max setting limit)

If Buffer selection is "NO"

Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature * Remote Control Setting (*Capacity 1) %

(Zone 1 and Zone 2 will change according to its own target zone water temperature.)

(Max regulation depend on the temperature control type select)

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 1) % * (Max regulation depends on the tank max setting limit)

Setting temperature for cooling is changed.

New Target Water Temperature = Target Water Temperature + Remote Control setting for cool (*Capacity 1) * (Min/Max regulation of cooling water set apply)

While digital input is detected "11" (Capacity 2)

Setting temperature for heating and Tank is changed.
 However, which setting temperature is change depend on system setting.

If Buffer selection is "YES"

Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature * Remote Control setting (" capacity 2) %

- * Max Min regulation is follow Target Buffer tank temperature control specification
- ** No change of Target zone water temperature, only set higher buffer tank temperature.

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 2) % * (Max regulation depends on the tank max setting limit)

If Buffer selection is "NO"

Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature * Remote Control Setting (*Capacity 2) %

(Zone 1 and Zone 2 will change according to it's own target zone water temperature.)

(Max regulation depend on the temperature control type select)

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 2) % * (Max regulation depends on the tank max setting limit)

Setting temperature for cooling is changed.

New Target Water Temperature = Target Water Temperature + Remote Control setting for cool (*Capacity 2)

* (Min/Max regulation of cooling water set apply)

13.29 Demand Control (Optional PCB)

Remote control setting:

• When Optional PCB connection select 'YES", Demand Control function can select "YES" or "NO".

Purpose:

- After the demand control select YES, below control will activated.
 - 0-10V Demand control

0-10V Demand control

Demand control is use to reduce the current usage of heat pump unit by third party device.

Control start condition:

- Select "YES" at Demand control at installer menu.
- 0-10V input for this electrical current control is detected.

Control content:

- If start condition is fulfilled, indoor will receive the voltage signal from optional PCB. Indoor will send the rate value to outdoor unit.
- Outdoor will change the current limit according to the percentage receive from indoor unit.

13.30 Holiday Mode

Purpose:

Promotes energy saving by allowing the user to stop the system during holiday and enables the system to resume at the preset temperature after holiday.

- Control details:
 - Indoor operate the unit according running mode request. Target temperature will follow holiday setting temperature.
 - If heat mode request is receive, Target Water Out Temperature will change according to holiday shift temperature set.
 - [If heat is set OFF at holiday, unit, water pump and zone control will OFF]
 - If tank mode request is receive, Target Tank Set Temperature will change according to the holiday tank shift temperature set.
 - [If tank is set OFF at holiday, heat pump and tank heater will OFF]
 - After days of holiday have been set, heat pump will stop and only resume operation at the end of holiday countdown.
- Start condition:
 - o Holiday timer set and the holiday timer start
 - * The day holiday mode was set is counted as day 1.
- Stop condition:
 - o OFF/ON button is pressed.
 - Holiday timer is reached.

13.31 Dry Concrete

Purpose:

Provide heat to floor heating panel and dry the wet concrete during installation.

- Setting condition:
 - o Dry concrete parameter can be set through remote control under system setup.
 - o Parameters are possible to set up to 99 days with different target set temperature
- Control details:
 - o Dry concrete mode will be activates when select ON from service setup.
 - o Once start dry concrete function, remote control will send step 1 setting temperature to indoor unit.
 - * This temperature is set at zone temperature. If system is 2 zones, both zone target temperature is set as same temperature.
 - Heat pump will start heat mode operation to room side with received target water outlet temperature.
 - * Heat pump will operate according to Heat pump Target Water Temperature.
 - o After complete day 1 setup operation, day 2 data will be send to indoor at 12.00am on the second day.
 - Each preset data will be send every day until dry concrete mode is complete, unit will turns OFF and exit dry concrete function.
 - o 3 ways valve and booster heater will turn OFF and 2 ways valve will turns ON.
- Cancel condition:
 - Dry concrete mode is complete and OFF signal is received.
 - o OFF signal is received by pressing OFF/ON button.

13.32 Flow Sensor

- The water flow sensor serves as an overload protector that shuts down the unit when the water level is detected to below.
- Abnormal flow detection:

Condtioin	Abnormal flow	Normal flow
Normal case	Flow rate < 5 l/min or >= 69 l/min	>= 5 l/min
During Deice Operation OR COOL Mode	Flow rate < 11 l/min or >= 69 l/min	>= 11 l/min
During status 2~6 on Anti-freeze deice	Flow rate >= 5 l/min	< 5 l/min

14. Protection Control

14.1 Protection Control for All Operations

14.1.1 Time Delay Safety Control

1 The compressor will not start for three minutes after stop of operation.

14.1.2 30 Seconds Forced Operation

- 1 Once the compressor starts operation, it will not stop its operation for 30 seconds.
- 2 However, it can be stopped using control panel at indoor unit.

14.1.3 Total Running Current Control

- 1 When the outdoor running current exceeds X value, the compressor frequency will decrease.
- 2 If the outdoor running current does not exceed X value, the compressor frequency will return to normal operating frequency.
- 3 If the outdoor running current continue to increase till exceed Y value, compressor will stop, and if this occurs 3 times within 20 minutes, system will stop operation and OFF/ON control panel LED will blink (F16 error occurs).


	WH-MXC	09J3E8	WH-MXC	12J9E8
Operation Mode	X (A)	Y (A)	X (A)	Y (A)
Heating	9.4	12.8	10.8	12.8
Cooling	7.2	12.8	7.2	12.8

A. DC Peak Current Control

- 1 When the current to IPM exceeds set value, compressor will stop. Compressor will restart after three minutes.
- 2 If the set value exceeds again for more than 30 seconds after the compressor restarts, operation will restart after two minutes.
- If the set value exceeds again for within 30 seconds after the compressor restarts, operation will restart after one minute. If this condition repeats continuously for seven times, system will stop operation and OFF/ON control panel LED will blink (F23 error occurs).

14.1.4 Compressor Overheating Prevention Control


• The compressor operating frequency is regulated in accordance to compressor tank temperature as shown in below figures. When the compressor tank temperature exceeds 107°C, compressor will stop, and if this occurs 4 times within 30 minutes, system will stop operation and OFF/ON control panel LED will blink (F20 error occurs).



14.1.5 High Pressure Sensor Control

- Purpose:
 - To protect the system operation.
- Detection period:
 - After compressor on for 1 minute.
- Detection conditions:
 - When abnormal high voltage detection, 5 V or when open circuit detection 0V for 5 seconds continuously.
- After detection:
 - When abnormality is detected 4 times within 120 minutes, unit stop operation.
 - OFF/ON control panel LED will blink (H64 error occurs).

14.1.6 Outside Temperature Current Control



14.1.7 Crank Case Heater Control

- Purpose:
 - For compressor protection during low outdoor ambient operation (during heating low temperature operation).
- Control content:
 - a. Trigger heater START condition
 - When the outdoor air temperature is below than 4/5°C, and discharge temperature is 9/11°C or below.
 - b. Resetting heater STOP condition
 - 1. When the outdoor air temperature exceeds entry condition (6/7°C)
 - 2. When the discharge temperature exceeds entry condition (13/16°C)

		WH-MXC09J3E8	WH-MXC12J9E8	
Start condition	Outdoor air temperature	4°C	4°C	
Start condition	Discharge temperature	9°C	9°C	
Cton condition	Outdoor air temperature	6°C	6°C	
Stop condition	Discharge temperature	13°C	13°C	

14.2 Protection Control for Heating Operation

14.2.1 Outdoor Air Temperature Control


The maximum current value is regulated when the outdoor air temperature rises above 14°C in order to avoid compressor overloading.

14.2.2 Deice Operation

When outdoor pipe temperature and outdoor air temperature is low, deice operation start where outdoor fan motor stop.


Normally, deice start if pipe sensor temperature fulfil deice condition. If remote controller set to AUTO force defrost setting, unit will start force deice after heat pump operate for 3 hours without deice at below outdoor temperature 5°C.

Deice judging condition



• Deice mode selection condition

 There are 2 deice modes, according to water inlet temperature and outdoor ambient temperature the deice mode is decided.




Judgement details:

- 1 When water inlet temperature is more than 60°C, unit will operate deice mode 1.
- When water inlet temperature is less than 27°C, unit will operate deice mode 2.
- When water inlet temperature is less than 60°C and outdoor ambient temperature is less than -10°C, unit will operate deice mode 2.
- 4 When water outlet temperature sensor 2 detect temperature is less than 22°C, unit will operate deice mode 2.

Deice operation time diagram

a. Deice mode 1 control:



b. Deice mode 2 control:

	Normal Deice	←				mode 2 minutes				Heating operation
Sequence	4~6	1	2	3	4	5	6	7	8	
Compressor										Free
Four way valve	OFF	ON								ON
OD fan	OFF		OFF							Free
Main Expansion valve Bypass										Free Free
Expansion valve Gas Bypass SV	0 OFF		ON							OFF
Pump	ON		OFF							ON

14.2.3 Force Defrost Operation


Force defrost can be set through remote control with two selection (Manual OR Auto).

- If Manual defrost set, heat pump only run force defrost at heat mode when force defrost request from quick menu remote control.
- If Auto defrost set, heat pump automatically run force defrost operation after 3 hours heating accumulation time without defrost when ambient below 5°C.

14.3 Protection Control for Cooling Operation

14.3.1 Outdoor Air Temperature Control

- The Compressor operating frequency is regulated in accordance to the outdoor air temperature as shown in the diagram below.
- This control will begin 1 minute after the compressor starts.
- Compressor frequency will adjust base on outdoor air temperature.



14.3.2 Freeze Prevention Control 1

- 1 When indoor heat exchanger temperature is lower than 0°C continuously for 10 seconds, compressor will stop operating.
- 2 Compressor will resume its operation three minutes after the indoor heat exchanger is higher than 1°C.
- 3 Indoor heat exchanger freeze prevention (H99) will memory in error history.

15. Servicing Mode

15.1 Expansion Vessel 7 Pre Pressure Checking

[Upper limit water volume of the system] The Mono bloc unit has a build-in Expansion Vessel with 10 L air capacity and initial pressure of 1 bar.

Without antifreeze agent condition

Total amount of water in the system should be below

If the total amount of water is more than 200 L, please add expansion vessel (field supply).

• With antifreeze agent condition

In the case of using antifreeze agent, expansion rate $\boldsymbol{\epsilon}$ is different depending on its maker.

Please refer to the antifreeze agent maker for the expansion rate ϵ before calculate the upper limit water volume of the system.

The expansion vessel capacity required for the system can be calculated from the formula below.

$$V = \frac{\epsilon \times Vo}{1 - \frac{98 + P_1}{98 + P_2}}$$

$$V : \text{Required gas volume } < \text{expansion vessel volume L} > \text{Vo} : \text{System total water volume } < \text{L} > \text{E} : \text{Expansion rate } 5 ^{\circ} 60^{\circ}\text{C} = (\text{depends on antifreeze agent used})$$

$$P_1 : \text{Expansion rath filling pressure} = (100) \text{ kPa}$$

$$P_2 : \text{System maximum pressure} = 300 \text{ kPa}$$

$$) \text{ Please confirm at actual place}$$

The gas volume of the sealed type expansion vessel is presented by <V>
 It's advised to add 10% margin for required gas volume of calculation.

[Adjustment of the initial pressure of the expansion vessel when there is a difference in installation height] If the height difference between the Mono bloc unit and the highest point of the system water circuit (H) is more than 7m, please adjust the initial pressure of the expansion vessel (Pg) according to the following formula.

Pg= (H*10+30) kPa

15.2 Maintenance

 In order to ensure optimal performance of the unit, seasonal inspections on the unit, functional check of RCCB, field wiring and piping have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer.

15.2.1 Maintenance for Magnetic Water Filter Set (13)

- 1. Remove the Cover ① by loosening the mounting screws to access to the Magnetic Water Filter Set ①.
- 2. Turn OFF power supply.
- 3. Set the two valves for the Magnetic Water Filter Set (13) to "CLOSE".
- Take off the clip, then gently pull out the mesh. Beware of small amount water drain out from it.
- Clean the mesh with warm water to remove all the stain. Use soft brush if necessary.
- 6. Reinstall the mesh to the Magnetic Water Filter Set (3) and set back the clip on it.
- 7. Set the two valves for the Magnetic Water Filter Set (13) to "OPEN".
- 8. Turn ON power supply.
- After cleaning, reinstall the Cover (7) by tightening the mounting screws properly.




MARNING


Do not add or replace other than R32 type. It may cause product damage, burst, injury and etc. Use compatible R32 tools for refrigerant piping work and refrigerant charging during installation or servicing.

15.3 Pump Down Procedures

Refer below steps for proper pump down procedure.



15.4 How To Adjust Pump Speed




Press ▲ or ▼ SW to select & confirm operation

NOTE:


- 1. Whenever at [Screen 5], if press (SW to OFF, pump operation should be turned OFF.
- 2. Whenever at [Screen 6], if press (SW to OFF, pump operation should be turned OFF.

15.5 How To Unlock Cool Mode

Operation must be OFF




15.6 EEPROM Factory Default Data Setup Procedure




- EEPROM default data setup is only possible during initialization process.
- Press (▲, ▼, ◀, ▶)simultaneously for 5secs continuously, initialization process will stop & EEPROM default data setup process will start.


During EEPROM default data setup process, display should be as shown below.




- Once EEPROM default data setup process is complete, initialization process will re-start from beginning.



15.7 Dry Concrete Setup






16. Maintenance Guide

In order to ensure safety and optimal performance of the unit, seasonal inspections on the unit, functional check of RCCB/ELCB, field wiring and piping have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer. Contact dealer for scheduled inspection.


1 Air purge valve

Make sure all the piping installations are properly done before carry out below steps.

- Open Cabinet front plate to access to the Pressure Relief Valve and Air Purge Valve.
- Turn the plug on the Air Purge Valve outlet anticlockwise by one complete turn from fully closed position.



Set the Pressure Relief Valve level "DOWN".



- Start filling water (with pressure more than 0.1 MPa (1 bar)) to the Mono bloc unit via water inlet. Stop
 filling water if the free water flow through Pressure Relief Valve drain hose.
- o Turn ON the power supply and make sure Water Pump is running.
- o Check and make sure no water leaking at the tube connecting points.
- o Reinstall the Cabinet front plate by tightening the 2 mounting screws.
- 2 Water pressure *(0.1 MPa = 1 bar)

Water pressure should not lower than 0.05 MPa (with inspects the Water Pressure Gauge). If necessary add tap water into the water circuit.

- 3 Pressure relief valve
 - o Check for correct operation of Pressure Relief Valve by turning on the lever to become horizontal.
 - o If you do not hear a clacking sound (due to water drainage), contact your local authorized dealer.
 - Push down the lever after finish checking.
 - o In case the water keeps drained out from the unit, switch off the system, and then contact your local authorized dealer.

4 Expansion vessel

[Upper limit water volume of the system]

The Mono bloc unit has a build-in Expansion Vessel with 10 L air capacity and initial pressure of 1 bar.

Without antifreeze agent condition

Total amount of water in the system should be below 200 L.

If the total amount of water is more than 200 L, please add expansion vessel (field supply).

With antifreeze agent condition

In the case of using antifreeze agent, expansion rate ε is different depending on its maker.

Please refer to the antifreeze agent maker for the expansion rate ε before calculate the upper limit water volume of the system.

The expansion vessel capacity required for the system can be calculated from the formula below.

$$V = \frac{\varepsilon \times Vo}{1 - \frac{98 + P_1}{98 + P_2}}$$

V : Required gas volume <expansion vessel volume L>

Vo : System total water volume <L>

 ε : Expansion rate 5 \rightarrow 60 °C = (depends on antifreeze agent used)

P₁: Expansion tank filling pressure = (100) kPa P₂: System maximum pressure = 300 kPa

- () Please confirm at actual place

- The gas volume of the sealed type expansion vessel is presented by <V>.

O It's advised to add 10% margin for required gas volume of calculation.

[Adjustment of the initial pressure of the expansion vessel when there is a difference in installation height]

If the height difference between the Mono bloc unit and the highest point of the system water circuit (H) is more than 7m, please adjust the initial pressure of the expansion vessel (Pg) according to the following formula.

5 RCCB

Ensure the RCCB set to "ON" condition before check RCCB.

Turn on the power supply to the Mono bloc unit.

This testing could only be done when power is supplied to the Mono bloc unit.

/ WARNING

Be careful not to touch parts other than RCCB test button when the power is supplied to Mono bloc unit. Else, electrical shock may happen.

- Push the "TEST" button on the RCCB. The lever would turn down and indicate "0", if it functions normal.
- Contact authorized dealer if the RCCB malfunction.
- Turn off the power supply to the Mono bloc Unit.
- o If RCCB functions normal, set the lever to "ON" again after testing finish.

6 Test run

Before test run, make sure below items have been checked:-

- a. Pipework are properly done.
- b. Electric cable connecting work are properly done.
- c. Mono bloc unit is filled up with water and trapped air is released.

Antifreeze agent must be added into water circuit to prevent freezing of water when outdoor ambient temperatures is low. Recommended antifreeze:

Propylene glycol: 40% (equivalent to -20°C)

 Set ON to the Mono bloc unit and RCCB 2. Then, for remote control operation please refers to (Mono bloc) Air-to-Water Heatpump's operation instruction.

Note:

During winter, turn on the power supply and standby the unit for at least 15 minutes before test run.
 Allow sufficient time to warm up refrigerant and prevent wrong error code judgement.

For normal operation, Water Pressure Gauge reading should be in between 0.05 MPa and 0.3 MPa. After test run, please clean the Magnetic Water Filter Set. Reinstall it after finish cleaning.

7 Water flow of water circuit

Confirm the maximum water flow during main pump operation not less than 15 l/min.


*Water flow can be check through service setup (Pump Max Speed)

[Heating operation at low water temperature with lower water flow may trigger "H75" during defrost process.]

8 Reset overload protector

Overload Protector a serves the safety purpose to prevent the water over heating. When the Overload Protector a trip at high water temperature, take below steps to reset it.


- a. Take out the cover.
- b. Use a test pen to push the centre button gently in order to reset the Overload Protector.
- c. Fix the cover to the original fixing condition.




Use test pen to push this button for reset Overload protector.

16.1 Maintenance Menu


16.1.1 Service and Maintenance



16.1.2 Maintenance Menu



16.1.3 Custom Menu



16.1.4 Specifications

16.1.4.1 Specifications of Fresh Water was Heat Transfer Medium in Brazed Heat Exchanger

Parameter	Quality Limits for Tap Water on the Secondary Side
Temperature	Below 60°C
pН	7 to 9
Alkalinity	60mg/I <hco<sub>3 <300mg/I</hco<sub>
Conductivity	< 500µS/cm
Hardness	[Ca ⁺ , Mg ⁺] / [HCO ₃ ⁻] > 5
Chloride	< 200mg/l at 60°C
Sulphate	[SO ₄ ²⁻] > 100mg/I and [HCO ₃ ⁻] / [SO ₄ ²⁻] > 1
Nitrate	NO ₃ < 100mg/I
Chlorine	< 0.5mg/l

16.1.4.2 External Filter

Solids in the water must be filtered.

Minimum filter mesh size required for the field supply external filter in the water inlet is 20 mesh.

17. Troubleshooting Guide

17.1 Refrigeration Cycle System

In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle.


Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a fan

The normal pressure of the refrigeration cycle depends on various conditions, the standard values for them are shown in the table on the right.

Normal Pressure (Standard)

	Gas pressure MPa (kg/cm²G)
Heating Mode	2.3 ~ 2.9 (23 ~ 29)
Cooling Mode	0.9 ~ 1.2 (9 ~ 12)

- ★ Condition: Outdoor temperature 7°C at heating mode and 35°C at cooling mode.
 - Compressor operates at rated frequency.



17.2 Relationship between the Condition of the Air-to-Water Heatpump Indoor and Outdoor Units and Pressure and Electric Current

	Heating Mode			Cooling Mode		
Condition of the Air-to-Water Heatpump indoor and outdoor units	Low Pressure	High Pressure	Electric current during operation	Low Pressure	High Pressure	Electric current during operation
Water leakage or insufficient water flow rate in the system	-	*	1	1	1	1
Excessive amount of refrigerant	-	-	*	1	*	*
Inefficient compression	-	1	1	1	1	1
Insufficient refrigerant (gas leakage)	*	*	1	1	*	*
Outdoor heat exchange deficiency	1	1	1	1	-	-
Clogged expansion valve or Strainer	*	-	1	-	*	*

Carry out the measurements of pressure, electric current, and temperature fifteen minutes after an operation is started.

17.3 Breakdown Self Diagnosis Function


17.3.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- When abnormality occur during operation, the system will stop operation, and OFF/ON control panel LED will blink and error code will display on the control panel.
- Even error code is reset by turning OFF power supply or by selecting ERROR RESET, if the system abnormality
 is still unrepaired, system will again stop operation, and OFF/ON control panel LED will again blinks and error
 code will be display.
- The error code will store in IC memory.

To check the error code

- When an abnormality occurs, system will stop operation and OFF/ON control panel LED will blink.
- Error code of the abnormality will be display on the control panel.
- To determine the abnormality description, the error code table needs to be referred.

eg:



Press


to select Close / Reset then press

To display past/last error code

- Turn ON power supply.
- Refer below procedure to retrieve the error code history.

• To permanently delete error code from IC memory

- Turn ON power supply.
- Refer below procedure to clear error history.



Error history

[4] Clear history

1. --2. --3. --4. -- 9 41am, Mon

17.4 Error Codes Table

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify
H00	No abnormality detected	_	_
H12	Indoor/Outdoor capacity unmatched	90s after power supply	Indoor/outdoor connection wire Indoor/outdoor PCB Specification and combination table in catalogue
H15	Outdoor compressor temperature sensor abnormality	Continue for 5 sec.	Compressor temperature sensor (defective or disconnected)
H20	Water pump abnormality	Continue for 10 sec.	Indoor PCBWater pump (malfunction)
H23	Indoor refrigerant liquid temperature sensor abnormality	Continue for 5 sec.	Refrigerant liquid temperature sensor (defective or disconnected)
H27	Service valve error	Continue for 5 minutes	High pressure sensor (defective or disconnected)
H28	Abnormal solar sensor	Continue for 5 sec.	Solar temperature sensor (defective or disconnected)
H31	Abnormal swimming pool sensor	Continue for 5 sec.	 Pool temperature sensor (defective or disconnected)
H36	Abnormal buffer tank sensor	Continue for 5 sec.	Buffer tank sensor (defective or disconnected)
H38	Brand code not match	When indoor and outdoor brand code not same	_
H42	Compressor low pressure abnormality	60 times occurence within 480 minutes.	 Outdoor pipe temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB Compressor
H43	Abnormal Zone 1 sensor	Continue for 5 sec.	Water temperature Zone 1 sensor
H44	Abnormal Zone 2 sensor	Continue for 5 sec.	Water temperature Zone 2 sensor
H62	Water flow abnormality	Continue for 1 min.	Water flow sensor
H63	Abnormal low pressure sensor	4 times in 20 minutes	Low pressure sensor (defective or disconnect)
H64	Refrigerant high pressure abnormality	5V : Continue for 5 sec. 0V : 4 times occurrence within 120 minutes	Outdoor high pressure sensor (defective or disconnected)
H65	Abnormal deice water circulation	water flow > 5 l/min continuously for 20 seconds during anti freeze deice	Water pump
H67	Abnormal External Thermistor 1	Continue for 5 sec.	Room temperature Zone 1 sensor
H68	Abnormal External Thermistor 2	Continue for 5 sec.	Room temperature Zone 2 sensor
H70	Back-up heater OLP abnormality	Continue for 60 sec.	Back-up heater OLP (Disconnection or activated)
H72	Tank sensor abnormal	Continue for 5 sec.	Tank sensor
H74	PCB communication error	Communication or transfer error	Indoor main PCB and Sub PCB
H75	Low water temperature control	Room heater disable and deice request to operate under low water temperature	Heater operation must enable to increase water temperature
H76	Indoor - control panel communication abnormality	_	 Indoor - control panel (defective or disconnected)
H90	Indoor/outdoor abnormal communication	> 1 min after starting operation	Internal/external cable connectionsIndoor/Outdoor PCB
H91	Tank heater OLP abnormality	Continue for 60 sec.	Tank heater OLP (Disconnection or activated)
H95	Indoor/Outdoor wrong connection		Indoor/Outdoor supply voltage

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify
Н98	Outdoor high pressure overload protection	-	Outdoor high pressure sensor Water pump or water leakage Clogged expansion valve or strainer Excess refrigerant Outdoor PCB
F95	Cooling high pressure overload protection	4 times occurrence within 20 minutes	 Outdoor high pressure sensor Fan motor Clogged expansion valve or strainer Excess refrigerant Outdoor PCB
H99	Indoor heat exchanger freeze prevention	10 sec	Indoor heat exchanger Refrigerant shortage
F12	Pressure switch activate	4 times occurrence within 30 minutes	Pressure switch
F14	Outdoor compressor abnormal revolution	4 times occurrence within 20 minutes	Outdoor compressor
F15	Outdoor fan motor lock abnormality	2 times occurrence within 20 minutes	Outdoor PCB Outdoor fan motor
F16	Total running current protection	3 times occurrence within 20 minutes	Excess refrigerant Outdoor PCB
F20	Outdoor compressor overheating protection	4 times occurrence within 20 minutes	Compressor tank temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB Compressor
F22	IPM (power transistor) overheating protection	4 times occurrence within 30 minutes	Improper heat exchange IPM (Power transistor)
F23	Outdoor Direct Current (DC) peak detection	7 times occurrence continuously	Outdoor PCB Compressor
F24	Refrigeration cycle abnormality	2 times occurrence within 30 minutes	Insufficient refrigerant Outdoor PCB Compressor low compression
F25	Cooling/Heating cycle changeover abnormality	4 times occurrence within 30 minutes	4-way valve V-coil
F27	Pressure switch abnormality	Continue for 1 min.	Pressure switch
F30	Water outlet sensor 2 abnormality	Continue for 5 sec.	Water outlet sensor 2 (defective or disconnected)
F32	Abnormal Internal Thermostat	Continue for 5 sec.	Control panel PCB thermostat
F36	Outdoor air temperature sensor abnormality	Continue for 5 sec.	Outdoor air temperature sensor (defective or disconnected)
F37	Indoor water inlet temperature sensor abnormality	Continue for 5 sec.	Water inlet temperature sensor (defective or disconnected)
F40	Outdoor discharge pipe temperature sensor abnormality	Continue for 5 sec.	Outdoor discharge pipe temperature sensor (defective or disconnected)
F41	PFC control	4 times occurrence within 10 minutes	Voltage at PFC
F42	Outdoor heat exchanger temperature sensor abnormality	Continue for 5 sec.	Outdoor heat exchanger temperature sensor (defective or disconnected)
F43	Outdoor defrost sensor abnormality	Continue for 5 sec.	Outdoor defrost sensor (defective or disconnected)
F45	Indoor water outlet temperature sensor abnormality	Continue for 5 sec.	Water outlet temperature sensor (defective or disconnected)
F46	Outdoor Current Transformer open circuit	_	Insufficient refrigerant Outdoor PCB Compressor low
F48	Outdoor EVA outlet temperature sensor abnormality	Continue for 5 sec.	Outdoor EVA outlet temperature sensor (defective or disconnected)
F49	Outdoor bypass outlet temperature sensor abnormality	Continue for 5 sec.	Outdoor bypass outlet temperature sensor (defective or disconnected)

17.5 Self-diagnosis Method

17.5.1 Connection Capability Rank Abnormality (H12)

Malfunction Decision Conditions:

During startup operation of cooling and heating, the capability rank of indoor checked by the outdoor is used to determine connection capability rank abnormality.


Malfunction Caused:

- 1 Wrong model interconnected.
- 2 Wrong indoor unit or outdoor unit PCB (main) used.
- 3 Faulty indoor unit or outdoor unit PCB (main).

Abnormality Judgment:

Continue for 90 seconds.

Troubleshooting:



17.5.2 Compressor Tank Temperature Sensor Abnormality (H15)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the compressor tank temperature sensor are used to determine sensor error.


Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Short circuit: Continue for 5 seconds. Open circuit: Continue for 120 seconds.

Troubleshooting:



17.5.3 Water Pump Abnormality (H20)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the rotation speed detected by the IPM of water pump motor during water pump operation is used to determine abnormal water pump (feedback of rotation > 6,000rpm or < 700rpm).

Malfunction Caused:


- 1 Operation stop due to short circuit inside the water pump motor winding.
- 2 Operation stop due to breaking of wire inside the water pump motor.
- 3 Operation stop due to breaking of water pump lead wires.
- 4 Operation stop due to water pump motor IPM malfunction.
- 5 Operation error due to faulty indoor unit PCB.

Abnormality Judgment:

Continue for 10 seconds.

Troubleshooting:





17.5.4 Indoor Refrigerant Liquid Temperature Sensor Abnormality (H23)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor refrigerant liquid temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





17.5.5 Service Valve Error (H27)

Malfunction Decision Conditions:

During cooling operation, when:-

- [a] Indoor refrigerant pipe temperature at compressor startup present indoor refrigerant pipe temperature < 2°C
- [b] Present high pressure high pressure at compressor startup < 5kg/cm²
- **Judgment only for first time cooling operation and not during pump down operation.

Malfunction Caused:


- 1 3 way valves closed.
- 2 Faulty high pressure sensor.
- 3 Faulty indoor refrigerant pipe temperature sensor
- 4 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 minutes.

Troubleshooting:






17.5.6 Abnormal Solar Sensor (H28)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty solar sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:




17.5.7 Abnormal Swimming Pool Sensor (H31)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty swimming pool sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:




17.5.8 Abnormal Buffer Tank Sensor (H36)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.


Abnormality Judgment:



17.5.9 Brand Code Not Matching (H38)

Malfunction Caused:

1 Indoor and outdoor brand code not match.



17.5.10 Compressor Low Pressure Protection (H42)

Malfunction Decision Conditions:


During operation of heating and after 5 minutes compressor ON, when outdoor pipe temperature below -37°C or above 26°C is detected by the outdoor pipe temperature sensor.

Malfunction Caused:

- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 2 way valve partially closed.
- 4 Faulty outdoor unit fan motor.
- 5 Refrigerant shortage (refrigerant leakage).
- 6 Clogged expansion valve or strainer.
- 7 Faulty outdoor pipe temperature sensor.
- 8 Faulty outdoor unit main PCB (main).

Troubleshooting:






17.5.11 Abnormal Zone 1 Sensor (H43)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:




17.5.12 Abnormal Zone 2 Sensor (H44)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:



17.5.13 Water Flow Switch Abnormality (H62)

Malfunction Decision Conditions:

During operation of cooling and heating, the water flow detected by the indoor water flow switch is used to determine water flow error.

Malfunction Caused:


- 1 Faulty water pump.
- 2 Water leak in system.
- 3 Faulty connector connection.
- 4 Faulty water flow switch.
- 5 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 10 seconds (but no judgment for 70 seconds after compressor startup/restart).

Troubleshooting:





17.5.14 Outdoor High Pressure Abnormality (H64)

Malfunction Decision Conditions:

During operation of cooling and heating, when the outdoor high pressure sensor output signal is 0 Vdc or 5 Vdc.

Malfunction Caused:


- Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 20 minutes.

Troubleshooting:





17.5.15 Deice Circulation Error (H65)

Malfunction Decision Conditions:

During startup and operation of deice (mode 2), the water flow (> 5l/min) detected by the water flow switch is used to determine deice circulation error.

Malfunction Caused:


- 1 Water flow in air-to-water heatpump indoor unit circuitry.
- 2 Faulty indoor unit water flow switch.
- 3 Faulty indoor unit water pump.
- 4 Faulty indoor unit PCB.

Abnormality Judgment:

Continue for 10 seconds.

Troubleshooting:






17.5.16 Abnormal External Thermistor 1 (H67)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty room temperature zone 1 sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:




17.5.17 Abnormal External Thermistor 2 (H68)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty room temperature zone 2 sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:



17.5.18 Indoor Backup Heater OLP Abnormality (H70)

Malfunction Decision Conditions:

During operation of indoor backup heater, when no power supplies to indoor backup heater or OLP open circuit.

Malfunction Caused:


- 1 Faulty power supply connector connection.
- 2 Faulty connector connection.
- 3 Faulty indoor backup heater overload protector (OLP).
- 4 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 60 seconds.

Troubleshooting:





17.5.19 Tank Temperature Sensor Abnormality (H72)

Malfunction Decision Conditions:

When tank connection is set to ON, the temperatures detected by the tank temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





17.5.20 PCB Communication Error (H74)

Malfunction Decision Conditions:


When External PCB connection is select "YES" and no communication with External PCB micon for 10 seconds and above.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty Indoor PCB.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

After 1 minute operation started.



17.5.21 Indoor-Control Panel Communication Abnormality (H76)

Malfunction Decision Conditions:


During standby and operation of cooling and heating, indoor-control panel error occur.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty control panel.
- 3 Faulty indoor unit PCB (main).

Troubleshooting:





17.5.22 Indoor/Outdoor Abnormal Communication (H90)

Malfunction Decision Conditions:

During operation of cooling and heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

Malfunction Caused:


- 1 Faulty outdoor unit PCB (main).
- 2 Faulty indoor unit PCB (main).
- 3 Indoor-outdoor signal transmission error due to wrong wiring.
- 4 Indoor-outdoor signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.
- 5 Indoor-outdoor signal transmission error due to disturbed power supply waveform.

Abnormality Judgment:

Continue for 1 minute after operation.

Troubleshooting:





17.5.23 Tank Booster Heater OLP Abnormality (H91)

Malfunction Decision Conditions:

During operation of tank booster heater, and tank booster heater OLP open circuit.

Malfunction Caused:


- Faulty connector connection.
- 2 Faulty tank booster heater overload protector (OLP).
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 60 seconds.

Troubleshooting:





17.5.24 Unspecified Voltage between Indoor and Outdoor (H95)

Malfunction Decision Conditions:


The supply power is detected for its requirement by the indoor/outdoor transmission.

Malfunction Caused:

- 1 Insufficient power supply.
- 2 Faulty outdoor unit PCB (noise filter/main).

Troubleshooting:





17.5.25 Outdoor High Pressure Protection (H98 / F95)

Malfunction Decision Conditions:


During operation of cooling / heating, when pressure 4.2 MPa and above is detected by outdoor high pressure sensor.

Malfunction Caused:


- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 Dust accumulation in the outdoor unit heat exchanger.
- 5 Air short circuit at outdoor.
- 6 Faulty outdoor unit fan motor.
- 7 2/3 way closed.
- 8 Clogged expansion valve or strainer.
- 9 Excessive refrigerant.
- 10 Faulty outdoor high pressure sensor.
- 11 Faulty outdoor unit PCB (main).

Troubleshooting:









17.5.26 Indoor Freeze-up Protection (H99)

Malfunction Decision Conditions:


During anti-freezing control in cooling operation, when the indoor refrigerant liquid temperature < 0°C.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 2 way valve partially closed.
- 5 Clogged expansion valve or strainer.
- 6 Refrigerant shortage (refrigerant leakage).
- 7 Faulty indoor refrigerant liquid temperature sensor.
- 8 Faulty indoor unit PCB (main).

Troubleshooting:





17.5.27 Outdoor High Pressure Switch Activate (F12)

Malfunction Decision Conditions:

During operation of cooling and heating, when pressure 4.3 MPa and above is detected by outdoor high pressure switch.

Malfunction Caused:


- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 Faulty water pump.
- 4 Insufficient water flow rate in system.
- 5 Water leak in system.
- 6 2/3 way valve closed.
- 7 Clogged expansion valve or strainer.
- 8 Excessive refrigerant.
- 9 Faulty outdoor high pressure sensor and switch.
- 10 Faulty outdoor unit PCB.

Abnormality Judgment:

Continue 4 times in 30 minutes.

Troubleshooting:





17.5.28 Compressor Rotation Failure (F14)

Malfunction Decision Conditions:

A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction Caused:


- 1 Compressor terminal disconnect.
- 2 Faulty outdoor unit PCB (main).
- 3 Faulty compressor.

Abnormality Judgment:

Continue 4 times in 20 minutes.

Troubleshooting:





17.5.29 Outdoor Fan Motor (DC Motor) Mechanism Locked (F15)

Malfunction Decision Conditions:

The rotation speed detected by the Hall IC of the fan motor during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550 rpm or < 20 rpm).

Malfunction Caused:


- 1 Operation stop due to short circuit inside the fan motor winding.
- 2 Operation stop due to breaking of wire inside the fan motor.
- 3 Operation stop due to breaking of fan motor lead wires.
- 4 Operation stop due to fan motor Hall IC malfunction.
- 5 Operation error due to faulty outdoor unit PCB.

Abnormality Judgment:

Continue 2 times in 20 minutes.

Troubleshooting:





17.5.30 Input Over Current Detection (F16)

Malfunction Decision Conditions:

During operation of cooling and heating, when outdoor current exceeding the following table is detected by the current transformer (CT) in the outdoor unit PCB.

	WH-MXC09J3E8	WH-MXC12J9E8	WH-MXC16J9E8	
Current	12.8A	12.8A	17.4A	

Malfunction Caused:


- 1 Excessive refrigerant.
- 2 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 3 times in 20 minutes.

Troubleshooting:





17.5.31 Compressor Overheating (F20)

Malfunction Decision Conditions:

During operation of cooling and heating, when temperature above 117°C is detected by the outdoor discharge pipe temperature sensor.

Malfunction Caused:


- 1 Faulty outdoor discharge pipe temperature sensor.
- 2 2/3 way valve closed.
- 3 Refrigerant shortage (refrigerant leakage).
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).
- 6 Faulty compressor.

Abnormality Judgment:

Continue 4 times in 20 minutes.

Troubleshooting:





17.5.32 **IPM Overheating (F22)**

Malfunction Decision Conditions:

During operation of cooling and heating, when temperature 95°C is detected by the outdoor IPM temperature sensor.

Malfunction Caused:


- 1 Faulty outdoor unit fan motor.
- 2 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 30 minutes.

Troubleshooting:





17.5.33 Output Over Current Detection (F23)

Malfunction Decision Conditions:

During operation of cooling and heating, when outdoor DC current exceeding the following table is detected by the IPM DC Peak sensing circuitry in the outdoor unit PCB (main).


	WH-MXC09J3E8	WH-MXC12J9E8	WH-MXC16J9E8	
DC current	32A	32A	41.2A	


Malfunction Caused:

- 1 Faulty outdoor unit PCB (main).
- 2 Faulty compressor.

Abnormality Judgment:

Continue for 7 times.





17.5.34 Refrigeration Cycle Abnormality (F24)

Malfunction Decision Conditions:


- 1 During operation running (heating / cooling) for more than 5 minutes expect deice, pumpdown and test mode.
- 2 During heating / cooling, water outlet and water inlet difference is less than 3°C (Heating) / 2°C (Cooling).
- 3 During heating / cooling, high pressure < 1.90MPa (275 Psi) for more than 10 minutes or < 1.6MPa (232 Psi) for more than 10 minutes.
- 4 During heating / cooling, discharge temperature saturation temperature of high pressure ≥ 65°C (Heating) / 70°C (Cooling).
- 5 During heating / cooling, high pressure < 0.5MPa (72 Psi) for more than 4 minutes".

Malfunction Caused:

- 1 Refrigerant shortage (refrigerant leakage).
- 2 Faulty indoor water inlet, indoor water outlet, compressor discharge temp sensor or high pressure sensor.
- 3 2/3 way valve closed.
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).
- 6 Poor compression of compressor.

Abnormality Judgment:

Continue 2 times in 30 minutes.



17.5.35 Four Way Valve Abnormality (F25)

Malfunction Decision Conditions:

- 1 During heating operation, when the indoor pipe temperature of thermostat ON indoor unit < 0°C.
- 2 During cooling operation, when the indoor pipe temperature of thermostat ON indoor unit > 45°C.

Malfunction Caused:


- 1 Faulty sensor.
- 2 Faulty connector connection.
- 3 Faulty outdoor unit PCB (noise filter/main).
- 4 Faulty four way valve.

Abnormality Judgment:

Continue 4 times in 30 minutes.

Troubleshooting:





17.5.36 Outdoor High Pressure Switch Abnormal (F27)

Malfunction Decision Conditions:

During compressor stop, and outdoor high pressure switch is remain opened.

Malfunction Caused:


- Faulty connector connection.
- 2 Faulty switch.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 1 minute.

Troubleshooting:





17.5.37 Indoor Water Outlet Temperature Sensor 2 Abnormality (F30)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water outlet temperature sensor 2 are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB.

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





17.5.38 Outdoor Air Temperature Sensor Abnormality (F36)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





17.5.39 Indoor Water Inlet Temperature Sensor Abnormality (F37)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water inlet temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





17.5.40 Outdoor Discharge Pipe Temperature Sensor Abnormality (F40)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Short circuit: Continue for 5 seconds. Open circuit: Continue for 120 seconds.

Troubleshooting:





17.5.41 Power Factor Correction (PFC) Abnormality (F41)

Malfunction Decision Conditions:

During operation of cooling and heating, when the PFC protection circuitry in the outdoor unit PCB (main) senses abnormal high DC voltage level.

Malfunction Caused:


- 1 Power supply surge.
- 2 Compressor windings not uniform.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 10 minutes.

Troubleshooting:





17.5.42 Outdoor Pipe Temperature Sensor Abnormality (F42)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





17.5.43 Outdoor Defrost Temperature Sensor Abnormality (F43)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor defrost temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





17.5.44 Indoor Water Outlet Temperature Sensor Abnormality (F45)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water outlet temperature sensor are used to determine sensor errors.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





17.5.45 Outdoor Current Transformer Open Circuit (F46)

Malfunction Decision Conditions:


A current transformer (CT) open circuit is detected by checking the compressor running frequency (≥ rated frequency) and CT detected input current (< 1.6 A) for continuously 20 seconds.

Malfunction Caused:

- 1 CT defective.
- 2 Faulty outdoor unit PCB (main).
- 3 Compressor defective (low compression).

Troubleshooting:





18. Disassembly and Assembly Instructions


♠ WARNING

High Voltage are generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.

♠ WARNING

Be sure to switch off all the power supply before performing each of the below action.

18.1 To Remove The Cabinet Front Plate




- 1. Remove 4 mounting screws.
- Slide the cabinet front plate downward to release the pawls. Then, pull it toward front to remove it.


18.2 To Remove The Cabinet Top Plate

1. Remove the 13 mounting screws


2. Lift the cabinet top plate upward to remove it.



18.3 To Remove The Cabinet Rear Plate




18.4 To Remove Pressure Gauge




For WH-MXC12J9E8


18.5 To Remove Water System Electronic Controller Board




For WH-MXC12J9E8




18.6 To Remove Air Purge Valve




18.7 To Remove Flow Sensor




18.8 To Remove Water Pump




Mhen reinstall the water pipe, use grease or water at the joining.



18.9 To Remove Heater



18.10 To Remove Filter



the Water Filter.

3. Remove the retaining ring, then remove the

19. Technical Data

19.1 Operation Characteristics


19.1.1 WH-MXC09J3E8


Heating Characteristics at Different Outdoor Air Temperature

Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT)

Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C







Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C







Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 19°C Indoor water outlet temperature : 14°C







Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 23°C Indoor water outlet temperature : 18°C






19.1.2 WH-MXC12J9E8


Heating Characteristics at Different Outdoor Air Temperature

Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT)

Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C







Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C







Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 19°C Indoor water outlet temperature : 14°C







Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 23°C Indoor water outlet temperature : 18°C





19.2 Heating Capacity Table

19.2.1 WH-MXC09J3E8

Water Out		25°C			35°C			
Outdoor Air	Capacity(W)	Input Power(W)	Current(A)	Capacity(W)	Input Power(W)	Current(A)		
-20	9000	3440	5.1	9000	3950	5.9		
-15	9000	2980	4.5	9000	3410	5.1		
-7	10500	2720	4.1	9000	2920	4.4		
2	10800	2140	3.2	9000	2360	3.5		
7	9000	1380	2.1	9000	1770	2.6		
25	9000	770	1.2	9000	1000	1.5		

Water Out	at 45°C				55°C			60°C		
Outdoor Air	Capacity(W)	Input Power(W)	Current(A)	Capacity(W)	Input Power(W)	Current(A)	Capacity(W)	Input Power(W)	Current(A)	
-20	9000	4650	6.9	7900	5580	8.3	-	-	-	
-15	9000	4040	6.0	9000	4830	7.2	8700	5370	8.0	
-7	9000	3540	5.3	9000	4240	6.3	9000	4620	6.9	
2	9000	2910	4.3	9000	3550	5.3	9000	4050	6.1	
7	9000	2370	3.5	9000	2920	4.4	9000	3290	4.9	
25	10000	1670	2.5	10000	2280	3.4	11000	2860	4.3	

Note:

^{*} Between outdoor ambient -15°C and -20°C, the water outlet temperature gradually decreases from 60°C to 55°C.

^{*} Only when ΔT is set to 15°C, the set temperature above 60°C will take effect.

19.2.2 WH-MXC12J9E8

Water Out		25°C		35°C			
Outdoor Air	Capacity(W)	Input Power(W)	Current(A)	Capacity(W)	Input Power(W)	Current(A)	
-20	12000	5020	7.5	12000	5800	8.7	
-15	12000	4140	6.2	12000	4830	7.2	
-7	13500	4300	6.4	12000	4250	6.3	
2	14500	3230	4.8	12000	3400	5.1	
7	12000	2000	3.0	12000	2500	3.7	
25	12000	1200	1.8	12000	1490	2.2	

Water Out	45°C			55°C			60°C		
Outdoor Air	Capacity(W)	Input Power(W)	Current(A)	Capacity(W)	Input Power(W)	Current(A)	Capacity(W)	Input Power(W)	Current(A)
-20	10500	5750	8.6	9200	5800	8.7	-	-	-
-15	12000	5670	8.5	11100	6350	9.5	8700	6200	9.3
-7	12000	5020	7.5	12000	6000	9.0	11000	6300	9.4
2	12000	4200	6.3	12000	4950	7.4	12000	5770	8.6
7	12000	3240	4.8	12000	3940	5.9	12000	4520	6.8
25	12000	2100	3.1	12000	2750	4.1	12000	3110	4.6

^{*} Between outdoor ambient -15°C and -20°C, the water outlet temperature gradually decreases from 60°C to 55°C. * Only when ΔT is set to 15°C, the set temperature above 60°C will take effect.

19.3 Cooling Capacity Table

19.3.1 WH-MXC09J3E8


	Water Out 7°C			V	Water Out 14°C			Water Out 18°C		
OD	Capacity(W)	Input Power(W)	Current(A)	Capacity(W)	Input Power(W)	Current(A)	Capacity(W)	Input Power(W)	Current(A)	
16	9000	1660	2.5	11000	1540	2.3	11400	1350	2.0	
25	9000	2060	3.1	12600	2450	3.7	10500	1600	2.4	
35	9000	2910	4.3	10900	3070	4.6	9000	2020	3.0	
43	7200	3360	5.0	8700	3330	5.0	7300	2530	3.8	

19.3.2 WH-MXC12J9E8

	Water Out 7°C			V	Water Out 14°C			Water Out 18°C		
OD	Capacity(W)	Input Power(W)	Current(A)	Capacity(W)	Input Power(W)	Current(A)	Capacity(W)	Input Power(W)	Current(A)	
16	11400	2150	3.2	13600	2140	3.2	15000	2150	3.2	
25	12000	2930	4.4	15700	3680	5.5	14000	2660	4.0	
35	12000	4230	6.3	13600	4440	6.6	12000	3170	4.7	
43	10300	5000	7.5	11800	5090	7.6	10400	3870	5.8	

20. Exploded View and Replacement Parts List

20.1 Water System




Note:

The above exploded view is for the purpose of parts disassembly and replacement.


The non-numbered parts are not kept as standard service parts.

20.2 Refrigerant System




Note:

The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.



Note:

The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.



Note: The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.

<Water System>

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	WH-MXC09J3E8	WH-MXC12J9E8	REMARK
	1	BASE PAN ASS'Y	1	ACXD52K02760	←	
\triangle	2	HOT WATER COIL - COMPLETE	1	ACXB90C01450	←	
\triangle	3	FLOW SWITCH	1	ACXB62-00930	←	
\triangle	4	PUMP	1	ACXB53-00390	←	
\triangle	5	HEATER ASS'Y	1	ACXA34K00380	ACXA34K00390	
	6	SOUND PROOF MATERIAL	1	CWG302594	←	
	7	THERMOSTAT	4	CWA151074	←	
\triangle	8	ELECTRONIC CONTROLLER (MAIN)	1	ACXA73C7869R	ACXA73C7870R	
\triangle	9	TERMINAL BOARD ASS'Y (A,B)	1	CWA28K1340	←	
	10	SOUND PROOF MATERIAL	1	CWG302599	←	
\triangle	11	TERMINAL BOARD ASS'Y (1,2,3,4,5,6)	1	CWA28K1341	←	
\triangle	12	TERMINAL BOARD ASS'Y (7,8,9,10,11,12)	1	CWA28K1340	←	
\triangle	13	TERMINAL BOARD ASS'Y (13,14,15,16,17,18)	1	CWA28K1343	←	
\triangle	14	TERMINAL BOARD ASS'Y (A) / (A,B)	1	CWA28K1260	CWA28K1238	
\triangle	15	REACTOR	1	G0C103Z00003	←	
	16	AIR PURGE VALVE	1	ACXB62-00130	←	
	17	PRESSURE GAUGE	1	CWB070003	←	
	18	PRESSURE RELIEF VALVE	1	ACXB62-00740	←	
\triangle	19	CIRCUIT BREAKER	1	CWA181005	-	
	20	FILTER COMPLETE	1	ACXB51C00100	←	
\triangle	21	SENSOR - COMPLETE (WATER IN, OUT, REF TEMP)	1	ACXA50C16670	←	
\triangle	22	SENSOR - COMPLETE (HEX WATER OUTLET)	1	ACXA50C13140	←	
\triangle	23	REMOTE CONTROL COMPLETE	1	ACXA75C15751	←	
	24	RECEIVER	1	CWB141039	←	
	25	HOLDER COUPLING	1	ACXH35-01510A	←	
	26	CABINET SIDE PLATE	1	ACXE04-12210A	←	
	27	HANDLE	4	ACXE16-00100	←	
	28	CABINET FRONT PLATE	1	ACXE06-03550A	←	
	29	CONNECTING BAR	1	CWE261313A	←	
	30	CONNECTING BAR	1	CWE261214A	←	
	31	PANASONIC BADGE	1	CWE373439	←	
	33	OPERATING INSTRUCTION	1	ACXF55-30920	←	
	34	OPERATING INSTRUCTION	1	ACXF55-30930	←	
	35	OPERATING INSTRUCTION	1	ACXF55-30940	←	
	36	OPERATING INSTRUCTION	1	ACXF55-30950	←	
	37	OPERATING INSTRUCTION	1	ACXF55-30960	←	
	38	OPERATING INSTRUCTION	1	ACXF55-30970	←	
	39	OPERATING INSTRUCTION	1	ACXF55-30980	←	
	40	INSTALLATION INSTRUCTION	1	ACXF60-43800	←	
	41	INSTALLATION INSTRUCTION	1	ACXF60-41781	←	

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	WH-MXC09J3E8	WH-MXC12J9E8	REMARK
	42	SOUND PROOF MATERIAL	1	ACXG30-07663	←	
	43	BAG	1	CWG861452	←	
	44	SHOCK ABSORBER	2	CWG713660	←	
	45	SHOCK ABSORBER	2	CWG713661	←	
	46	SHOCK ABSORBER	2	CWG713662	←	
	47	BASE BOARD - COMPLETE	1	ACXG62C02080	←	
	48	C.C. CASE	1	ACXG50-57120	←	
\triangle	49	CIRCUIT BREAKER	1/2	CWA181008	←	
	50	TERMINAL COVER	1	CWH171051	←	
	51	GASKET FOR TERMINAL COVER	1	CWB811177	←	
	52	MODEL LABEL	2	ACXF85-73280	ACXF85-73290	

Note:

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock.

<Refrigerant System>

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	WH-MXC09J3E8	WH-MXC12J9E8	REMARK
	1	BASE PAN ASS'Y	1	CWD52K1276	←	
\triangle	2	COMPRESSOR	1	9JD420XBA22	←	
	3	BUSHING - COMPRESSOR MOUNT	3	CWH50055	←	
	4	NUT - COMPRESSOR MOUNT	3	CWH561049	←	
\triangle	5	CRANKCASE HEATER	1	ACXA34-00110	←	
	6	CONDENSER COMPLETE	1	ACXB32C25160	←	
	7	HIGH PRESSURE SENSOR	1	ACXA50-05990	←	
	8	DISCHARGE MUFFLER	1	ACXB12-01450	←	
	9	HIGH PRESSURE SWITCH	1	ACXA10-00650	←	
	10	3-WAYS VALVE (GAS)	1	CWB011699	←	
	11	4-WAYS VALVE	1	CWB001046	←	
	12	3-WAYS VALVE (LIQUID)	1	CWB011700	←	
	13	STRAINER	3	CWB111032	←	
	14	GASKET FOR TERMINAL COVER	3	CWB811017	←	
	20	SOUND PROOF MATERIAL	1	ACXG30-12020	←	
	21	SOUND PROOF MATERIAL	1	ACXG30-12030	←	
	22	SOUND PROOF BOARD	1	CWH151243	←	
\triangle	23	V-COIL COMPLETE (4 WAY VALVE)	1	CWA43C2169J	←	
\triangle	24	V-COIL COMPLETE (MAIN EXPANSION VALVE)	1	ACXA43C06900	←	
\triangle	25	SENSOR - COMP. (OUTDOOR AIR, PIPE TEMP)	1	ACXA50C16850	←	
\triangle	26	SENSOR - COMP. (DISCHARGE TEMP)	1	CWA50C2576	←	
	28	CABINET REAR PLATE - COMPLETE	1	ACXE02-02020A	←	
	29	CONTROL BOARD CASING ASSY	1	CWH10K1228	←	
Ţ	30	SENSOR - COMP. (DEFROST TEMP)	1	CWA50C2577	←	
	31	TERMINAL BOARD ASS'Y (1,2,3,4,5)	1	CWA28K1240	←	
	32	TERMINAL BOARD ASS'Y (L,N)	1	CWA28K1335	←	
	34	TERMINAL COVER	1	CWH171039A	←	
	35	NUT - TERMINAL COVER	1	CWH7080300J	←	
\triangle	38	ELECTRONIC CO. (NOISE FILTER)	1	ACXA73-36070	←	
\triangle	44	ELECTRONIC CONTROLLER (MAIN)	1	ACXA73C7872R	ACXA73C7873R	
\triangle	46	REACTOR	3	G0C392J00039	←	
-	50	FAN MOTOR BRACKET ASSY	1	ACXD54K02340	←	
	51	SCREW - FAN MOTOR BRACKET	2	CWH551040J	←	
\triangle	52	FAN MOTOR (UPPER)	1	L6CBYYYL0362	←	
\triangle	53	FAN MOTOR (LOWER)	1	L6CBYYYL0363	←	
	54	SCREW - FAN MOTOR MOUNT	8	CWH551323	←	
	55	PROPELLER FAN ASSY	2	CWH00K1006	←	
	56	NUT	2	CWH561092	←	
	57	CABINET FRONT PLATE	1	CWE061098A	←	
	58	DISCHARGE GRILLE	2	CWE201154	←	

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	WH-MXC09J3E8	WH-MXC12J9E8	REMARK
	59	CABINET SIDE PLATE ASSY	1	CWE04K1023A	←	
	60	WIRE NET	1	CWD041069	←	
	61	CABINET TOP PLATE	1	ACXE03C00880	←	
	62	ACCESSORY CO. (RUBBER CAP)	1	CWH82C1839	←	
	66	CABINET FRONT PLATE	1	CWE061274A	←	
	68	TUBE ASSY (CAP.TUBE)	1	ACXT07K09171	←	
	70	EXPANSION VALVE (1)	1	CWB051091	←	
	71	EXPANSION VALVE (2)	1	CWB051029	←	
	72	2-WAYS VALVE (LIQUID)	1	CWB021637	←	
\triangle	73	V-COIL COMPLETE (2-WAY VALVE)	1	CWA43C2607	←	
\triangle	74	V-COIL COMPLETE (BYPASS EXPANSION VALVE)	1	CWA43C2335	←	
	75	ACCESSORY CO. (DRAIN ELBOW)	1	CWG87C900	←	
\triangle	76	HEATER	1	CWA341071	←	
	78	HIGH PRESSURE SENSOR	1	CWA50C3165	←	
	80	SOUND PROOF MATERIAL	1	CWG302598	←	
\triangle	82	ELECTRO MAGNETIC SWITCH	1	K6C2AGA00002	←	
\triangle	83	ELECTRO MAGNETIC SWITCH	1	K6C4E8A00001	←	
\triangle	85	PTC THERMISTORS	1	D4DDG1010001	←	
\triangle	87	LEADWIRE COMPRESSOR	1	ACXA60C84610	←	
\triangle	88	SENSOR - COMPLETE (CN-TANK)	1	CWA50C2629	←	
	89	FLEXIBLE PIPE (L-TUBE)	1	CWH5850080	←	
	90	PACKING - L.TUBE	1	CWB81012	←	
\triangle	91	ELECTRONIC CONTROLLER - SUB	1	ACXA73-36370	←	

Note:

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.