



PART No. 9378561007

AIR CONDITIONER OPTIONAL PARTS Optional filter

INSTALLATION MANUAL

To access the online manual, scan the 2-dimensional barcode.

ONLINE MANUALS



www.fujitsu-general.com/global/support/

1. SAFETY PRECAUTIONS

To prevent personal injury or property damage, read this section carefully before you use this product, and be sure to comply with the following safety precautions.

Incorrect operation due to failure to follow the instructions may cause harm or damage, the seriousness of which is classified as follows:



WARNING

This mark warns of death or serious injury.



CAUTION

This mark warns of injury or damage to property.



This mark denotes an action that is PROHIBITED.



This mark denotes an action that is COMPULSORY.



WARNING



- For installation this optional parts, read this manual and the operation manual of the indoor unit thoroughly.
- Before installation, be sure that all sources of power have been shut off.



- Do not turn on the power until all installation works is complete.



CAUTION




- If this optional parts installation involves high-place work, consult the authorized service personnel.



- Do not stand on slippery, uneven or unstable surfaces when installation work.
- Do not touch the aluminum fins of heat exchanger built-in the indoor unit to avoid personal injury when installation work.


2. ACCESSORIES

Name and shape	Q'ty
Filter holder with optional filter  *The shape depends on the model.	2

3. INSTALLING THE FILTERS

- For details of the procedure, refer to the operation manual of the indoor unit.
- If you are concerned about dirt on your hands, wear cleaning gloves when installing or replacing.


1. Open the intake grille and remove the air filters.




If the air filter is dirty, clean it by referring to the operation manual of the indoor unit.

3.1. Installation procedure type A

2. Attach the filter holder with optional filter to the air filter of the indoor unit.



Fit the snap fittings on the filter holder to the air filter.




The number of the snap fitting differs depending on the model.


4 snap fittings



6 snap fittings




8 snap fittings




3. Reinstall the air filters.
4. Close the intake grille.

3.2. Installation procedure type B

2. Remove the optional filter from the filter holder.



3. Attach the optional filters to the holders on the indoor unit.



4. Reinstall the air filters.
5. Close the intake grille.

4. CLEANING AND CARE

Cleaning the filter: Every 3 months

- Hand-wash in cold to lukewarm water or with a neutral detergent. Do not scrub with force, as that may cause the entire filter to tear or become entangled and degrade the filter's effectiveness. Do not use the filter if damaged.
- Do not use organic solvents such as benzene, alcohol or gasoline, or cleaning tools like steel brushes.
- After washing the filter, dry it before use. Do not dry at high temperatures or with a microwave oven.

Replacing the filter: Every 3 years

Store the filter in a place where there are no high temperatures or high humidity, and use this filter as soon as possible after opening.